


Model 60 8" Jointer

MAINTENANCE INSTRUCTIONS AND PARTS LIST



Better By DesignTM

POWERMATIC[®] 

McMINNVILLE, TENNESSEE 37110 ☐ AC 615-473-5551

TABLE OF CONTENTS

FOREWORD.....	3
WARRANTY.....	4
SAFETY:	
General Rules.....	5
Specific Rules.....	6
Decal Instruction.....	7
SPECIFICATIONS: Model 60-8" Jointer.....	8
RECEIVING THE JOINTER.....	9
INSTALLATION OF JOINTER.....	9
JOINTER ADJUSTMENTS:	
Leveling Tables (Gib Adjustment).....	10
Spring Cut.....	11
Table Removal.....	11
Squaring Fence.....	11
Fence Tilt Adjustment.....	12
Guard Removal.....	13
Installing New Knives.....	13
Jointing the Knives.....	14
Depth of Cut.....	15
Cutterhead Removal.....	16
Bearing Replacement.....	16
Notes.....	17
PARTS LIST.....	18
PARTS: Exploded View.....	19
ELECTRICAL: Parts List.....	20
ELECTRICAL: Schematic.....	21
PREVENTIVE MAINTENANCE CHECK LIST.....	22

FOREWORD

This manual has been prepared for the owner and those responsible for the maintenance of a POWERMATIC Model 60-8" Jointer.

Its purpose, aside from machine operation, is to promote safety through the use of accepted correct operating and maintenance procedures. Read the safety, operating, and maintenance instructions thoroughly before operating or servicing the machine.

In order to obtain maximum life and efficiency from your Powermatic jointer and to aid in operating and maintaining the jointer with safety, read the manuals thoroughly and follow all instructions carefully.

The specifications put forth in this manual were in effect at the time of publications. However, owing to Powermatic's policy of continuous improvement, changes to these specifications may be made at any time without obligation on the part of POWERMATIC HOUDAILLE.

The information and recommendations contained in this publication come from sources believed to be reliable and to represent the best current practice. Powermatic does not intend this manual to be a complete course of instruction on how to use this machine with safety and does not guarantee or represent that the information is absolutely correct or sufficient. In addition, it cannot be assumed that all acceptable safety measures are listed or that other additional measures are not needed under particular or exceptional circumstances or conditions.

WARRANTY

POWERMATIC WARRANTY

Powermatic-Houdaille, Inc. a Subsidiary of Houdaille Industries, Inc., McMinnville, Tennessee 37110 ("Powermatic") warrants to its authorized distributors of Powermatic products and the original purchasers for such distributors, all products manufactured by Powermatic to be free of defects in material and workmanship for a period of twelve (12) months from the date of delivery from its authorized distributors or 2000 hours of use, whichever occurs first. During said warranty period Powermatic will, at its option, repair or replace any product (or component part thereof proving defective during said period. This warranty applies only to products which are used in accordance with all instructions as to operation, maintenance and safety set forth in the catalogs, manuals, and/or instruction sets furnished by Powermatic. This warranty becomes effective only if the accompanying card is fully and properly completed and returned to Powermatic within ten (10) days from date of delivery to the original purchaser.

This warranty does not apply to items that would normally be consumed or require replacement due to normal wear (blades, lubricants, etc.); to electrical motors and components which are warranted by their manufacturer; or the costs of removal, shipment for service and reinstallation. Claims relating to electrical components must be taken to the component manufacturer's local authorized repair station for service.

This warranty is null and void if the product has been subjected to (1) misuse, abuse or improper service or storage; (2) accident, neglect, damage or other circumstances beyond Powermatic's control; (3) modifications, disassembly tampering, alterations or repairs outside of Powermatic's factory not authorized by Powermatic; or to any product not bearing its original serial number plate. This warranty does not apply to normal wear and tear, corrosion, abrasion, or repairs required due to natural causes or acts of God.

To obtain the fastest possible warranty service you must first notify in writing the authorized Powermatic distributor from whom you purchased the product specifying (1) the product by catalog number and serial number, (2) the date the product was delivered to you, (3) a description of the problem for which you seek warranty service, and (4) evidence of proof of purchase. Should circumstances prohibit you contacting the distributor then contact the Powermatic factory directly. If your claim is covered by this warranty, your Powermatic distributor will provide you with instructions as to how and where service will be provided. On simple warranty replacement or repairs, installations instructions will be provided to allow correction by customer personnel. Powermatic assumes no responsibility for products which are returned without its prior written authorization. Powermatic's obligation under this warranty shall be exclusively limited to repairing or replacing (at Powermatic's option) products which are determined by Powermatic to be defective upon delivery, F.O.B. (return freight paid by customer) Powermatic's factory, and on inspection by Powermatic. In no event shall Powermatic's liability under this warranty exceed the purchase price paid for the product.

THIS IS POWERMATIC'S SOLE WRITTEN WARRANTY. ANY AND ALL OTHER WARRANTIES WHICH MAY BE IMPLIED BY LAW, INCLUDING ANY WARRANTIES FOR MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. POWERMATIC SHALL NOT BE LIABLE FOR ANY LOSS, DAMAGE, OR EXPENSES DIRECTLY OR INDIRECTLY RELATED TO THE USE OF ITS PRODUCTS OR FROM ANY OTHER CAUSE OR FOR CONSEQUENTIAL DAMAGES (INCLUDING WITHOUT LIMITATION, LOSS OF TIME, INCONVENIENCE, AND LOSS OF PRODUCTION). THE WARRANTY CONTAINED HEREIN MAY NOT BE MODIFIED AND NO OTHER WARRANTY, EXPRESS OR IMPLIED, SHALL BE MADE BY OR ON BEHALF OF POWERMATIC.

SAFETY: General Rules

READ THE MANUAL

Always read the owner's manual carefully before attempting to use the machine. Know the limitations and hazards associated with its use.

INSTALLATION

All power machines must be secured to a solid foundation. Check your machine to see it is firmly secured with anchor bolts to prevent movement or tip over.

PROTECTION

Take every precaution to protect yourself, others around you, and the machine itself, from improper use. Safety is a combination of using common sense, knowing how to use the machine, and being alert at all times when using the machine.

EYES

Always wear approved safety goggles, glasses, or a face shield when operating this machine. There are no exceptions to this rule.

DRESS CODE

Do not wear loose clothing, neckties, jewelry, or gloves that can get caught in moving parts. Confine long hair. Keep sleeves above the elbow.

PLACEMENT

Place machine so that potential kickback area is not in line with aisles, doorways, wash stations, or other work areas.

ELECTRICAL GROUNDING

Your machine must be electrically grounded. If a cord and plug are used, make certain the grounding lug connects to a suitable ground. Follow the grounding procedure indicated by the National Electric Code. Keep power tools in dry areas free from moisture.

GUARDS

Be sure machine guards are in place and in good working order. Use them at all times on operations where they can be used. If a guard must be removed for any operation, make sure it is replaced immediately following completion of that operation.

POWER OFF

Make sure the machine is either unplugged or electrically disconnected and locked out when performing maintenance or service work.

HOUSEKEEPING

Before turning on machine remove all extra equipment such as keys, wrenches, scrap, stock, and cleaning rags from the machine. Keep the area around machine clean and free of scrap material and sawdust to minimize the danger of slipping.

POWER ON


On machines equipped with a manual starter make sure the starter is in "OFF" position before connecting power to machine.

SAFETY: Specific Rules

READ THE MANUAL Read, understand, and follow the safety instructions found in this manual. Know the limitations and hazards in using the 60-8 inch jointer. One safety rule decal and two caution decals (P.7) are placed on each machine as reminders of good safety practice.

NEVER surface stock less than 12 inches long, or 3 inches wide, or 3 inches thick without a hold down push block.

3 INCH RULE When working a piece of wood on the jointer, follow the 3 inch radius rule. The hands must never be closer than 3 inches to the cutter head (Fig.1).




KICKBACK Use extra care in the location of the jointer in the shop. Position the jointer so that a kicked back stock will strike a wall and not endanger other persons in the area.

AVOID TIP-IN Never apply pressure to stock directly over the cutterhead. This may result in the stock tipping into the cutterhead along with the operator's fingers. Follow the 3 inch rule. Position hands away from extreme ends of stock, and push through with a smooth, even motion.

AVOID KICKBACK "Pull-out" and the danger of kicked back stock can occur when the workpiece has knots, holes, or foreign materials such as nails. It can also occur when the stock is fed against the grain on the jointer. The grain must run in the same direction you are cutting. Before attempting to joint, or plane, each workpiece must be carefully examined for stock condition and grain orientation.

NOTE: At certain times it may be necessary to plane against the grain when working with a swirly grain wood or burls. With this type work the operator must use a lesser depth of cut and a slow rate of feed (Operating Manual p.13).

HAND SAFETY It is good practice to move the hands in an alternate motion from back to front as the work continues through the cut. Never pass the hands directly over the cutter knife. As one hand approaches the knives remove it from the stock in an arc motion and place it back on the stock in a position beyond the cutterknife (Fig.2). **NOTE:** At all times hold the stock firmly.



SAFETY: Decal Instruction

CAUTION

SET THE KNIVES NO MORE THAN
.015 ABOVE CUTTERHEAD TO
MINIMIZE THE DANGER OF
KICKBACK AND POTENTIAL INJURY.


3330315

CAUTION

KEEP HANDS CLEAR
OF CUTTERHEAD

3330305

FIGURE 3



SAFETY RULES

CAREFULLY READ INSTRUCTION MANUAL BEFORE OPERATING MACHINE.

DO NOT OPERATE WITHOUT ALL GUARDS AND COVERS IN POSITION.

BE SURE MACHINE IS ELECTRICALLY GROUNDED.

REMOVE OR FASTEN LOOSE ARTICLES OF CLOTHING SUCH AS NECKTIES, ETC. CONFINE HAIR.

REMOVE JEWELRY SUCH AS FINGER RINGS, WATCHES, BRACELETS, ETC.

USE SAFETY FACE SHIELD, GOGGLES, OR GLASSES TO PROTECT EYES AND OTHER PERSONAL SAFETY EQUIPMENT AS REQUIRED.

STOP MACHINE BEFORE MAKING ADJUSTMENTS OR CLEANING CHIPS FROM WORK AREA.

KEEP THE FLOOR AROUND THE MACHINE CLEAN AND FREE FROM SCRAPS, SAWDUST, OIL OR GREASE TO MINIMIZE THE DANGER OF SLIPPING.

3330283

SPECIFICATIONS: Model 60-8" Jointer

FIGURE 4




Table	9" x 65" (228.6 x 1651 mm)
Head cutting arc	3" (76.2 mm)
Knives (3) H.S. steel	1/8" x 3/4" x 8" (3.2 x 19 x 203.2)
Speed of head (maximum)	5,000 rpm
Knife-cuts-per-minute	15,000
Maximum depth of cut	1/2" (12.7 mm)
Maximum rabbeting cut	1/2" x 8" (12.7 x 203.2 mm)
Fence size overall	4" x 36" (101.6 x 914 mm)
Height, less stand	14" (355.6 mm)
Height, with stand	40" (1016 mm)
Motor recommended	3/4 to 2 HP (.56 to 1.49 kw)
Weight, domestic crated, with stand & motor	332 lbs. (152 kg)
Weight, domestic crated, less stand	400 lbs. (183 kg)
Weight, domestic crated, with stand	440 lbs. (200 kg)

WARNING: DO NOT EQUIP OR USE THIS JOINTER WITH A MOTOR LARGER THAN 2 HORSEPOWER AT 3600 R.P.M. OR OPERATE THE CUTTERHEAD IN EXCESS OF 5000 R.P.M. USE OF A LARGER HORSEPOWER MOTOR OR HIGHER CUTTERHEAD SPEED VOIDS THE WARRANTY AND POWER-MATIC HOLDS ITSELF HARMLESS FOR ANY INJURY WHICH MAY RESULT.

RECEIVING THE JOINTER

Remove the jointer assembly and base from their respective shipping cartons and inspect for damage. Any damage should be reported to your distributor and shipping agent immediately.

Before proceeding further, read your maintenance manual thoroughly to familiarize yourself with proper assembly, set-up, maintenance and safety procedures.

INSTALLATION OF JOINTER

Mount base to the floor with high quality anchor bolts. Bolts are attached through the mounting holes on each end of the base.

After base has been secured to a solid foundation, align the holes in the bottom of the jointer with the holes in the top of the base and secure with the three mounting bolts provided.

Attach the drive belt and adjust as shown (Fig.5,6). Using thumb and index finger, compress belt at center until it becomes taut. At this point the distance between the in-sides of the belt should be one inch. Using the adjusting slot on the motor support, raise or lower motor support base to obtain proper tension and retighten base.

FIGURE 5





FIGURE 6




DANGER: If the machine does not come wired to run, the electricals and motor wiring must be done by a qualified

electrician. The machine must be properly grounded to help avoid electrical shock and possible death.

JOINTER ADJUSTMENTS

Check all mounting screws and set screws to see that they are locked.

FIGURE 7



LEVELING TABLES (Gib Adjustment)

Periodically check the parallelism of the infeed and outfeed tables by placing a steel straight edge or carefully jointed wood, across the full length of both tables. Non parallelism caused by loose gibs may be corrected by the following procedure:

- 1 Loosen gibs-A and table lock handle-B (Fig.7).
- 2 Remove lower gib screw-A and check screw hole to make sure that countersink, or punch mark, in the gib is aligned with the screw hole. If countersink is not visible, or it does not line up with screw hole, use a screwdriver to lightly tap the gib back up into alignment.
- 3 Replace the lower gib screw but do not tighten.
- 4 Tighten the table lock handle-B carefully. The table will begin to move toward the straightedge.

5 When aligned, reset the gib screws-A until tight. If table does not align with straightedge use the adjusting arm-E until the table is flush with the straightedge.

6 Tighten the gib screws-A then back off approximately 1/4 turn or until the table moves freely, and reset lock nuts-D on the gib screws.

If table will not line up remove gib screws and table locking handle and remove gib. Check gib to see that set screws do not go all the way through the gib or dimple the opposite side. If either of these conditions exist replace with a new gib.

Also, check to be sure the ways are clean and free of pitch and sawdust. Lubricate gib and way with Fiske Lubriplate.

Replace gib making certain countersink, or punch mark, line up with locking screw holes. Replace gib screws.

Repeat steps 3 thru 6.

Spring Cutting

To spring cut, the outfeed table is lowered below the level of the cutterhead blade (Fig.8). Loosen both gib screws A on the outfeed table. Amount of end-drop is controlled with the table lock handle B. Tighten handle to reduce amount of drop. A 1/32 inch drop usually creates the ideal concave for spring joints. Return the outfeed table to be in line with the cutterhead knives on completion of the cut.





Table Removal

- 1 Unplug machine or disconnect the power from machine and lock it out.
- 2 Remove the entire fence assembly except for the support bracket.
- 3 Remove the cutterhead guard (p.13).
- 4 Lower the infeed and outfeed tables and remove cutterhead (p.16).
- 5 Remove the snap rings on both ends of the table adjustment rod A (Fig.9) and push out

- 6 Loosen the gib set screws and table lock screw (Fig.8).


CAUTION: After gib screws are loosened table could suddenly slide down.

- 7 Remove infeed or outfeed table by sliding upward.




Squaring Fence

Before operating the jointer it is important to check that the fence is correctly aligned to the table. Loosen the lock nut A (Fig.10) and return the fence to the 90° position. There will be some play in the fence when



it is unlocked. All play must be removed by tilting the fence toward or away from the table while locking the lock nut. Always remove the backlash by tilting the fence in the same direction while tightening. If the fence does not come to 90° do the following procedure.


1. Place a square on the outfeed table near cutterhead.
2. Loosen lock nut-A (Fig.11) and insert an adjusting tool in tilt rod-B .
3. Turn rod clockwise to move top of fence to the right and counterclockwise to move fence to the left.
4. When fence is square with outfeed table reset lock nut-A



Should the fence fail to return to 90° and play is evident in the fence, remove the fence lock plunger mechanism by loosening the jam nut and inspect plunger assembly conical retainer.

If tilt rod shows signs of wear or scarring, grind the conical portion of plunger (Fig.12) until it will fully engage in the annular groove in the tilt rod. Replace plunger assembly and tighten jam nut.


FIGURE 12



Fence Tilt Adjustment

The fence may be tilted forward or backward by unlocking the fence lock screw-A and pulling out the fence lock plunger-B (Fig.13).

FIGURE 13



TILT FORWARD


To tilt the fence forward in the cradle-cut position loosen the fence lock screw-A . Pull up on the fence lock plunger-B and tilt the fence forward. Check the setting with a combination square. The two jam nuts-C on the end of the tilt rod are factory pre-set to stop the forward tilt at 45°. The front nut is used for adjusting and the rear nut to lock the setting. When all adjustments have been made retighten the fence lock screw-A.

TILT BACKWARD

To tilt the fence backward loosen the fence lock screw-A. Raise or lower the tilt stop screw-D. When the desired degree cut is reached retighten the fence lock screw-A.

Guard Removal

In order to remove the guard, loosen lock nut A on rabbeting ledge and loosen lock screw B (Fig.14). Guard assembly will lift vertically




out to provide for rabbeting operations. When replacing guard it will be necessary to set guard spring tension by turning knob clockwise on top of guard to the desired tension and locking in position with the set screw. Tighten hex lock nut to prevent the set screw from backing out. Test guard with fence in back position. Make sure it operates freely and does not drag on rabbet ledge or infeed table. If dragging occurs replace the guard assembly.

Installing New Knives

Unplug or disconnect jointer from power source and lock out power. When installing new knives remove only one knife at a time. Clean the knife slot and install the new knife. Adjust and lock new knife in cutterhead assembly before proceeding to next knife.


To remove the old knives, loosen gib locking bolts A and remove gib, knife, and jack screws (Fig.15). Using an allen wrench, turn jack screws B down one turn. Clean the jack screws, gib, knife slot, and knife thoroughly and replace jack screws.



Sandwich knife and gib together and drop into knife slot. Be certain that the back of the knife is resting on the seat of the jack screw plug. Next, to position the knife for rabbeting cuts, a 1/32 inch shop scale should be placed flat on the end of the cutterhead or the rabbet slot - whichever extends the farthest.


Slide the knife out until it is flush with the end of the shop scale. Set the knife locking gib 1/32 inch in from the end of the knife (Fig.16).

WARNING--Set the knives no more than .015 inches above the body of the cutterhead to minimize the hazard of kickback and severe personal injury.



Snug the two outside gib locking screws. If you have a Model 150 knife setting gauge, place it on the outfeed table to the rear of the cutterhead with the movable platen over the cutterhead (Fig.17).

Insert an allen wrench into the jack screw, and rock the cutterhead back and forth. Watch the pointer on the 150 gauge. The pointer will begin moving downward toward "0".



When the pointer reaches "0", it is parallel with the outfeed table. Move the gauge to the front of the cutterhead and repeat the above procedure.

This adjusting process puts the knife into the knife slot with the tip parallel and flush with the outfeed table.


Once the correct knife height has been established, secure the gib locking screws beginning with the center screw to prevent buckling or uneven knives.

If a Model 150 gauge is not available use a standard shop scale. Stand the scale on its edge on the outfeed table. The scale should extend over the cutterhead. Using the above method, raise knife until it just touches the scale at the cutterhead arc apex.

Jointing The Knives


After extended use it will be necessary to sharpen the knives on the cutterhead assembly. Before sharpening, disconnect the machine from its power source and remove the cutterguard (See "GUARD REMOVAL" p.13).

DANGER: Be sure to wear approved eye protection. Next, place a 6 inch shop scale across the infeed and outfeed tables (Fig.18).



Set tables to the exact height of the high knife at the apex of the knife arc.

Clamp a block of wood across the infeed table so that the end of a sharpening stone may be placed against the wood block during the jointing operation. This will help to prevent kickback of the stone (Fig.19). Lower outfeed table .003 inches.



Turn machine on.

CAUTION: Keep hands clear of turning cutterhead. Place a hard 10" Arkansas oilstone over cutterhead with ends resting on infeed and outfeed tables. Slide the oil stone back and forth across the tables until knives are jointed lightly. Turn the machine off and visually inspect each knife. If only the high knife has been touched, lower the outfeed table and continue the sharpening process until every knife has been touched by the stone. After sharpening knives, place shop scales on the outfeed table.


Raise the outfeed table to the original setting parallel with the knife at the apex of the arc. Weekly sharpening will

keep knives in the proper cutting condition.

If knives are excessively worn or nicked they must be reground to a new bevel. If this is the case, follow the procedure indicated in this section "INSTALLING NEW KNIVES", page 13.

Depth Of Cut

Depth of cut is determined by the height of the infeed table relative to the cutterhead. Raise or lower the infeed table by raising the table adjustment arm located underneath the infeed table (Fig.20). Depth of cut is indicated by the depth gauge located on the side of the jointer ways. To check the accuracy of the gauge, flush the table with the cutterhead using a straight edge, and see if it reads zero depth. If it does not, readjust pointer.



Cutterhead Removal

The following procedure is to be followed for cutterhead removal (Fig.21).

- 1 Unplug or disconnect jointer from its power source and lock it out.
- 2 Remove fence assembly and drive belt.
- 3 Loosen bearing housing retaining bolts - A , front and rear.
- 4 Lower infeed table.
- 5 Loosen the two (2) hex head screws attaching fence support, and turn stand support 90° on edge as shown.
- 6 Slide cutterhead out from rear of machine.

AFTER REASSEMBLY, INFEEED TABLE WILL HAVE TO BE RELEVELLED (SEE "LEVELING TABLES", page 10).

Bearing Replacement

Before attempting any maintenance unplug or disconnect jointer from power source and lock it out.

See "Cutterhead Removal" and remove the cutterhead assembly. Remove bearing housings (Fig.22) Remove bearings with an arbor press or wheel puller.

Use fine emery cloth to remove any fine rust. Clean the cutterhead shaft and coat with oil. Press new bearing onto shaft, replace bearing housings, and re-install cutterhead assembly.

FIGURE 22





FIGURE 21




PARTS LIST: Model 60-8" Jointer

ITEM NO.	PART NO.	DESCRIPTION	QTY
1	3797185	TABLE, FRONT	1
2	6715119	SCREW, SOC. SET DOG PT. 5/16"-18X3/8"	2
3	3244013	GIB	2
4	6430010	KNOB, 1-15/16 DIA. X 5/8-18 THD.	2
5	3025100	ARM, TABLE ADJUSTMENT	2
6	6715072	SCREW, HEX HD. CAP 5/16-18X2	2
7	6515007	NUT, JAM 5/16 - 18	2
8	3055241	BLOCK, TABLE ADJUSTMENT	2
9	3670306	ROD, TABLE ADJUSTMENT	2
10	6670008	RING, RETAINING 5100 - 62	4
11	3670307	ROD, TABLE ADJUSTMENT	2
12	3042198	BASE	2
13	3797191	TABLE, REAR	1
14	3064554	BRACKET, RABBIT	1
15	6714137	SCREW, 1/4" - 20X1" SOC. SET CONE PT.	1
16	6514001	NUT, 1/4" - 20 HEX	4
17	6716031	SCREW, 3/8" - 16 X 1" HEX HD.	4
18	6861300	WASHER, SPRING LOCK 3/8"	2
19	2695032	SCREW, LOCK ASSEMBLY (ITEMS 27-31)	2
20	3406016	KNOB	2
21	3268002	HANDLE	2
22	3448003	LOCK	2
23	6515001	NUT, 5/16" - 18 HEX.	1
24	6715153	SCREW, 5/16" - 18 X 2 CONE PT.	1
25	2109022	CUTTERHEAD ASSY. (ITEMS 32-38)	2
26	3298001	HOUSING BEARING	2
27	6060005	BEARING, 203PP	2
28	3112029	CUTTERHEAD, 8" JOINTER	2
29	3388004	KEY, 3/16" X 3/16" X 1-3/4"	1
30	6807027	SHEAVE, AK 25 5/8" BORE BROWNING	1
31	2438001	LIFTER ASSY., CUTTERHEAD KNIFE (ITEMS 39-40)	1
32	3438201	LIFTER, KNIFE CUTTERHEAD	6
33	6714129	SCREW, SOC. SET 1/4-20 X 3/4" LG.	1
34	2244009	SHIM ASSY. (ITEMS 41-42)	1
35	3244201	GIB, KNIFE, 8" JOINTER	3
36	3690065	SCREW, ADJ. SHIM	15
37	6427002	KNIFE CUTTERHEAD (SET OF 3)	1
38	2250179	GUARD ASSY. (ITEMS 48-60)	1
39	3711009	SHAFT, PIVOT	1
40	6813022	SPRING, EXT. J-8-1, 1/2" O.D. X 3 3/4" LG.	1
41	6114013	CHAIN, SASH 8 X 2 3/8" LG.	1
42	3096220	COLLAR, GUARD SPRING	1
43	6622005	PIN, COTTER KEY 1/8" X 1-1/4" X 1/4"	1
44	6095024	BUSHING, BRONZE, 5/8" X 3/4" O.D. X 1 1/4"	1
45	3406017	KNOB	1
46	6760078	10/32 X 3/8 SOC SET SCR.	1
47	3250047	GUARD, CUTTERHEAD	2
48	3055120	BLOCK MOUNTING	1
49	2195007	FENCE ASSY. ITEMS 63-106	1
50	2440005	LOCK ASSY. PLUNGER (ITEMS 63-66)	1
51	3406208	KNOB, ROUND 1" DIA. NYLON 1/4" - 20	1
52	3601204	PLUNGER, FENCE STOP	1
53	3529012	OPERATING NUT, FENCE STOP PLUNGER	1
54	6813002	SPRING, COMPRESSION JS-3 3/8" O.D. X 1 1/4" LG.	1
55	3670109	ROD, DEGREE TILTING	1
56	6567006	NUT, HEX 7/16 - 20	1
57	3064038	BRACKET, TABLE STOP	1
58	6715064	SCREW, SHOULDER 5/16 - 18 X 1 3/4	1
59	6715223	SCREW, SOC. HD. 5/16 - 18 X 1 3/4	1
60	3773314	STUD, PIVOT	2
61	3092046	CLAMP, FENCE TILTING	2
62	3728003	SLEEVE, FENCE TILTING	1
63	6570003	NUT, HEX	1
64	2695038	SCREW LOCK ASSY, FENCE (ITEMS 77-79)	1
65	3406016	KNOB, HANDLE	1
66	3695206	SCREW, LOCK	2
67	3268002	HANDLE	2
68	3042197	BASE FENCE SLIDE	1
69	3195121	FENCE, TABLE	1
70	3282009	HINGE, FENCE MTG.	1
71	3695206	SCREW LOCK	1
72	6715088	SCREW, SQ. HD. 5/16" - 18 X 1"	1
73	6515007	NUT, HEX JAM 5/16" - 18	1
74	6716117	SCREW, 3/8" - 16 X 1 1/2" SLOTTED SET	4
75	6516009	NUT, HEX JAM 3/8" - 16	2
76	6714114	SCREW, 1/4" - 20 ROUND HD. X 3/8" LG.	2
77	6861101	WASHER, 1/4" PLAIN FLAT	2
78	3064233	BRACKET, FENCE LOCK	2
79	6861501	WASHER, 1/2" PLAIN FLAT	1
80	2386003	KEY ASSY. FENCE SLIDING (ITEMS 94 - 95)	3
81	3388031	KEY 3/8" X 10 5/16"	1
82	6626056	PIN, SPRING 1/8" X 7/8"	1
83	2526001	NUT ASSY. FENCE SLIDING (ITEMS 96 - 97)	1
84	3528004	LOCKNUT, FENCE SLIDE	1
85	6626038	PIN, SPRING 1/4" X 1" LG.	1
86	3250006	GUARD, BELT	1
87	6861200	WASHER, SPRING LOCK 5/16"	3
88	6715045	SCREW, HEX HD. 5/16" - 18 X 2 1/2"	1
89	6716039	SCREW, HEX. HD. 3/8" - 16 X 1 1/4"	1
90	6861300	WASHER, SPRING LOCK 3/8"	5
91	6861301	WASHER, FLAT 3/8"	5
92	3604004	POINTER	1
93	6706035	SCREW, ROUND HD. 6-32 X 1/4"	1
94	3776020	SUPPORT FENCE	1
95	6715047	SCREW, HEX HD. 5/16" - 18 X 5" LG.	1
96	6861201	WASHER, FLAT 5/16"	2
97	3684220	SCALE, TABLE HEIGHT ADJ.	2
98	3312228	PLATE, SERIAL PMI	1
99	6747000	SCREW, DRIVE	1
100	6716035	SCREW, 3/8" - 16 X 1 3/4" HEX HD	2
101	6077161	BELT, A55	3
102	6807034	SHEAVE, MOTOR	1
103	2759047	ASSEMBLY, JOINTER STAND	1
104	2136043	ASSEMBLY, DOOR	1
105	3330283	PLATE, SAFETY RULES	1
106	3330305	PLATE, INSTRUCTION CAUTION	1
107	3330315	PLATE, CAUTION (NOT SHOWN)	1
108	6102001	CABLE	1
109	6284104	FITTING, CABLE	2

PARTS: Exploded View

Parts List



ELECTRICAL: Parts List

MANUAL

REF.	QTY.	POWERMATIC NO.	MFG. DESCRIPTION
S1	1	(30) 6821135 (10) 6821134	SWITCH. SWITCH.

MAGNETIC


REF.	QTY.	POWERMATIC NO.	MFG. DESCRIPTION
M1	1	(30) 6816111 (10) 6816105	STARTER, MAGNETIC. STARTER, MAGNETIC.
(PB 1) (PB 2)		6821014	SWITCH. MOMENTARY PB

MAGNETIC WITH LOW VOLTAGE CONTROL


REF.	QTY.	POWERMATIC NO.	MFG. DESCRIPTION
(PB 1) (PB 2)	1	6821014	SWITCH. MOMENTARY PB.
T1	1	6831068	TRANSFORMER 115/230-24V. 50 VA
		6831069	TRANSFORMER 230-460-24V. 75 VA
		6831070	TRANSFORMER 230/460-115V. 50VA
1M (WITH XMF)	1	6816195	STARTER, MAG. W/XMR. 10. 24V.
		6816138	STARTER, MAG. W/XMR. 10. 115V
		6816207	STARTER, MAG. W/XMR. 30. 24V
		6816212	STARTER, MAG. W/XMR. 30. 115V.
MTR.	1	6470801	MOTOR, ELECT. 3/4 HP, 10 3600 RPM. 115/230V. 56 FR
		6470809	MOTOR, ELECT. 3/4 HP. 30. 3600 RPM. 200V. 56 FR
		6470810	MOTOR, ELECT. 3/4 HP. 30. 3600 RPM. 230/460V. 56 FR
		6471100	MOTOR, ELECT. 3/4 HP. 10. 3600 RPM. 115/230V. 56 FR
		6471118	MOTOR, ELECT. 1 HP, 30. 3600 RPM. 200V. 56 FR
		6471119	MOTOR, ELECT. 1 HP, 10. 3600 RPM. 230/460V. 56 FR
		6471400	MOTOR, ELECT. 1½ HP. 30. 3600 RPM. 115/230V. 56 FR
		6471412	MOTOR, ELECT. 1½ HP. 30. 3600 RPM. 200V. 56 FR
		6471413	MOTOR, ELECT. 1½ HP. 30. 3600 RPM. 230/460V. 56 FR
		6471706	MOTOR, ELECT. 2 HP, 30, 3600 RPM, 230/460V, 56 FR

ELECTRICAL: Schematic


MANUAL





MAGNETIC



MAGNETIC W/LOW VOLTAGE CONTROL



NOTE: FOR SINGLE PHASE UNITS, OMIT LINE L3



PREVENTIVE MAINTENANCE CHECK LIST

OPERATOR _____ DATE: _____
MODEL NO. _____ S/N _____ ASSET NO. _____

SATISFACTORY; ACCEPTABLE, BUT NEEDS ATTENTION;
UNSATISFACTORY--RED TAG

1. ALL KNIVES SET TO BE NO MORE THAN .015 TO .025
FROM CUTTERHEAD BODY.....S A U
2. KNIVES LOCKED SECURELY IN CUTTERHEAD.....S U
3. KNIVES SHARP AND FREE OF NICKS AND GROOVES.....S U
4. GUARD IN PLACE AND WORKING PROPERLY.....S U
5. OUT-FEED TABLE IN LINE WITH TOP OF ARC OF CUTTERHEAD. ALL
BLADES ARC WITHIN .002.....S A U
6. ALL SAFETY DECALS IN PLACE.....S U
7. WORKING AREA AROUND MACHINE MARKED OFF.....S U
8. ANTI-SKID STRIPS OR FLOOR AREA WHERE OPERATOR
NORMALLY STANDS.....S U
9. VARIOUS TYPES OF PUSH BLOCKS READILY AVAILABLE TO OPERATORS..S A U
10. KICKBACK PATH NOT AIMED AT OTHER WORK AREAS, AISLES, OR
DOORWAYS.....S U
11. FENCE CLAMPS TIGHTLY TO BASE AND TO FENCE BRACKET.....S A U
12. NO MISSING PARTS OR LOOSE SCREWS.....S A U
13. MACHINE IS BOLTED TO FLOOR.....S A U
14. GIBS ARE ADJUSTED TO LIGHT DRAG ON ADJUSTMENTS FOR BOTH
INFEED AND OUTFEED TABLES.....S A U
15. LOCKS ON INFEED AND OUTFEED TABLES ARE IN POSITION AND
OPERATE PROPERLY.....S A U
16. TABLE FREE OF PITCH, RESIN OR ANY FOREIGN MATERIAL.....S A U
17. OTHER PROBLEMS.....S A U

FORWARD A COPY OF THIS
FILLED OUT FORM TO
YOUR SUPERVISOR FOR
IMMEDIATE ACTION

POWERMATIC[®] -  HOUDAILLE[®], INC.
McMinnville, Tennessee 37110 (615) 473-5551