INDUSTRIAL EQUIPMENT MANUFACTURING LTD.

109-19433 96th Avenue Surrey BC Canada V4N 4C4 Tel 604-513-9930 Fax 604-513-9905

OPERATING, INSTALLATION & MAINTENANCE MANUAL

APRON FEEDERS & DRIBBLE CONVEYORS

IEM ADMIN JOB V977

CUSTOMER INFORMATION

Name	MEGATECH ENGINEERING
Project	
Purchase Order	110557
_	
Reference	Apron Feeder





109 -19433 96th Avenue Surrey, BC V4N 4C4 Canada Tel: 604-513-9930 Fax: 604-513-9905 Web: www.iem.ca

TABLE OF CONTENTS

A. GENERAL

- Contact Personnel
- General Description
- Safety Precautions
- Warranty

B. OPERATING INSTRUCTIONS

C. INSTALLATION

- Storage
- Lifting Points & Weights (shipping list)
- Bolt Lists
- Apron Feeder Leveling & Alignment
- Head & Tailshaft Bearings
- Take-Up Adjustment
- Field Assembled/Installed Items
 - Apron Feeder
 - Drive Assemblies
 - 5 Gal. HPU
 - Lincoln Lube System
 - Zero Speed Switch
 - Guard Panels

D. MAINTENANCE OF COMPONENTS

Conveyor Components

- 1. D8N Chain
- 2. Rollers
- 3. Apron Pans
- 4. D8N Sprockets

Drives

- SEW Eurodrive Right bevel Planetary & Bevel Combination Reducer PHF082MC3RLSF06
- 6. 93.2 kW Baldor Electric Motor (Supplied by Others)
- 7. R+W Servomax Torque Limiter ES2/1500BF

Bearings/Pulley

- 8. FAG
- 9. Ringball

Miscellaneous & Switches

- 10. Hydraulic Assist Take-ups
 - o Brand Hand Operated Hydraulic Pump
 - Hy-Spec MAL Cylinders
 - Hy-Spec High Pressure Ball Valves
 - Hy-Spec Fluid Level Indicators
 - Stauff Filter Unit
 - Stauff Pressure Gauges
 - o Stauff Ball Valve
- 11. Rotech 4B Zero Speed Switch (Supplied by Megatech)
- 12. Crouse Hinds' Pullcord Switch
- 13. Lincoln Auto Lube System
- 14. Texaco Starplex Grease

E. ARRANGEMENT DRAWINGS

V977-01-01	GA D8N Apron Fdr SHT 1 OF 2
V977-01-02	GA D8N Apron Fdr SHT 2 OF 2
V977-11	Hydr Assist 5 Gal pump unit
V977-502	Pullcord Switch assy
V977-505	Hydr Assist Poweer Unit
V977-507	Hydr Assist diagram
V977-513	Lube system diagram
V977-520	Shop Bolt List
V977-521	Field Bolt List
V977-522	Shipping list

GENERAL

CONTACT PERSONNEL

Otto Zhang Ph. No: 604-513-9930 x302 Project Engineer Fax No: 604-513-9905

E-Mail: ozhang@iem.ca

John Williamson, P.Eng. Direct No: 604-513-5202 Chief Engineer Fax No: 604-513-9905

> E-Mail: jwilliamson@iem.ca

John Hards Direct No: 604-513-5200 President Fax No: 604-513-9905

E-Mail: jhards@iem.ca

GENERAL DESCRIPTION

The Apron Feeders comprise of:

- 1) D8N Series, 215.9mm Pitch for 2134mm Wide Inclined Apron Feeder
- 2) Cast manganese apron pans bolted to the chain using hi-strength track bolts.
- 3) Two segmental sprockets, 21 teeth, three segments bolted to steel hubs mounted on head shaft.
- Two segmental traction wheels bolted to steel hubs mounted on tail shaft.
- 5) Heavy duty support rollers to support chain on the working part of the feeder (Same indication sizes as chain. eg: D8).
- 6) Return rollers to support pans/chain. Pan ends run on the outside surface of rollers on return. (Part number S638B).
- 7) Drive system comprising of Electric motor and SEW Eurodrive Right Angle Planetary Reducer
- 8) Apron Feeder operates in one direction only as shown on GA drawings.

SAFETY PRECAUTIONS

Do not operate Apron Feeder with guardrails removed, except as may be required for maintenance.

During maintenance, Apron Feeder is to be fenced off and electrical supply and control are to be locked out in accordance with plant safety procedures.

Apron Feeder may require operation during maintenance for inspection and/or for momentary advancement when replacing pans or chains.

When the feeder is to be run it must be verified that no one is in contact or near the feeder posing any danger prior to starting it.

During the actual work on the feeder, the feeder must be locked out at all times.

It is recommended that a minimum of two workers be in attendance at all times during maintenance.

Plant safety procedures should be reviewed for additional precautions and procedures.

B. OPERATING INSTRUCTIONS

The Apron Feeder is controlled from a remote location using plant PLC.

On initial startup, it is recommended to have the feeder running at 20% speed prior to initial load of ore being handled.

As ore is loaded, speed unit up during a five minute period to the maximum speed.

It is recommended that a bed of ore be maintained on the pans to soften the direct impact of ore on the apron pans. This will tend to extend the life of the pans.

The feeder has a "Zero Speed" switch equipped to monitor the speed of the tail shaft. The PLC will need to be programmed to allow for little rotation during slow startups of the feeder. During normal operation the PLC should be programmed to trip the drive if the head or tail shaft falls speed falls too low

In the event of a jamming / stall condition, the Apron Feeder drive must be shut down automatically. Feeder must be checked and problem resolved before operating again.

DO NOT REVERSE THE DRIVE DIRECTION. The Apron Feeder is designed to operate in one direction only.

C. INSTALLATION INSTRUCTIONS

STORAGE

If the equipment and materials will not be needed for installation upon arrival at the site, we recommend the following minimum storage instructions:

- Leave small equipment in its shipping packaging and store instrumentation and field bolts in a protected area.
- If equipment is to be exposed to rain/sun for a long period of time, the following procedures are required:
 - Rotate shafts once a month, where possible. A few turns is enough to spread lubricant in bearings. If chains and pans are already installed and drive is not connected, a come-along can be used to move chain thereby rotating shafts.
 - Re-lubricate pillow blocks and labyrinth seals prior to operation. See FAG bearing lubrication instructions.

LIFTING POINTS & WEIGHTS

The Apron Feeder is supplied with four (4) lifting lugs. Load is fairly evenly distributed on the four lugs when the drive is not already mounted.

Drive to be mounted when Apron Feeder has been positioned and fastened in place.

For lifting the drive assembly use lifting points according to SEW Installation and Maintenance Manual.

It is recommended that spreader bars be used when lifting feeder.

The weight of the feeder/drive is listed on arrangement drawings and shipping lists.

APRON FEEDER LEVELING & ALIGNMENT

Leveling

Apron Feeder will need to be leveled at time of installation.

Extreme ends of main beams are reference points for leveling (4 points). These are used to level unit in shop during fabrication and assembly.

Positioning

Apron feeder needs to be positioned accurately with centerline of feeder as reference point.

Skirtboard centerline should coincide with feeder/apron pans centerline.

Head shaft centerline is reference point to be used to position the feeder longitudinally.

Squaring Shafts

Although shafts were squared and aligned at time of shop assembly, there is a possibility that transport and/or installation of feeder may have caused some movement.

Refer to Industrial Equipment Manufacturing Ltd. Fabricating & Machine Shop Procedures for Apron Feeder Alignment EP-055-00 Oct. 31, 2003.

Clearance

Ensure adequate operating clearance:

- between apron pan sides and outside of skirtboard (minimum 1" per side)
- underside of skirtboard and top of apron pans
- slot through end of skirtboards to clear apron pan lifting lug/pan sides

Grouting

If grouting is used, mount and fasten Apron Feeder to supports ensuring level is maintained and finish grout.

HEAD & TAILSHAFT BEARINGS

Apron Feeder Shipped Assembled

Although the head and tailshaft bearings have been aligned and adjusted during shop assembly, the integrity of alignment should be checked to ensure no movement has taken place during transport or installation.

Apron Feeder Shipped Disassembled

Shaft assemblies are supplied with sprockets/idler wheels mounted on head and tailshafts.


Pillow blocks are mounted on shafts. If bearings have taconite seals, seal assemblies have been backed off to ensure they are not damaged by pillow block movement beyond allowable angles during transit and re-installation.

Shaft assemblies are fit onto Apron Feeder and aligned prior to disassembly for shipment.

Refer to "Apron Feeder Leveling & Alignment" for installation and alignment procedure for shaft assemblies.

TAKE - UP ADJUSTMENT / HYDRAULIC ASSIST

Return chain catenary should be checked regularly. Apron pans will accept limited 'back bending'. It is important that chain tension be adjusted as wear occurs to ensure back bending of pans is minimized on the return (maximum 7 degrees)



If the optional integral hydraulic assist system has not been ordered, a portable jack, such as Enerpac, could be used to assist in making chain take-up adjustment.

Note: Make sure both sides are adjusted equally so taconite seals will not be damaged. (Advance each side max 1/8" at a time)

FIELD ASSEMBLED / INSTALLED ITEMS

Feeder & Dribble Conveyor

The Apron Feeders and Dribble conveyors have been shipped individually and will need to be installed in the field. The Apron feeder is mounted on top of the dribble conveyor in eight places. The Dribble conveyor feet are mounted to the floor through the same support beams that are securing the Apron Feeder above. Reference the appropriate arrangement drawing for the field bolt arrangements.

Drive Assembly

The drive assembly has been pre-assembled and shipped separate from the feeder to prevent damage during transportation and installation. The drive shaft and the hollow shaft of the reducer needs to be thoroughly cleaned as per instructions in the SEW Operation and Maintenance manual. The location of the drive on the drive shaft needs to be positioned according to the dimensions given on the general arrangement drawings.

Hydraulic Power Unit

This is also shipped loose to keep safe during transportation. The fluid capacity of the system depends on the size of the Feeder. Please reference dwg: V977-11 and the General Arr't to assemble the Hydraulic Power Assist to the feeder.

Lincoln Lube System

The Lincoln Lubrication system has been shipped separate from the feeder to prevent damage during transportation. The Hydraulic lines and fitting have however been secured to the frame and connected to the head/tail shaft bearings. This also includes the Lincoln injectors. As for the Lincoln Electric Pump, it will need to be mounted to the frame as indicated by the General Arrangement drawings and then connected to the system according to the Lincoln Installation Manual included.

Zero Speed Switch

The Zero Speed Switch has not been supplied by IEM. Please contact Megatech or Rotech for any technical questions regarding installation and operation.

Guard Panels

The guard panels for all the feeders and the dribble conveyors have been shipped separate for ease of shipment. The guards are installed by simply dropping them into the pipe slots fabricated to the frames. The arrangement drawings for each feeder and dribble conveyor show the location of these panels.

(See "MAINTENANCE" section for manuals referred to above)

D. MAINTENANCE OF COMPONENTS

PROCEDURE TO REPLACE APRON PANS AND/OR CHAINS

SAFETY

Do not operate Apron Feeder with guardrails removed, except as may be required for maintenance.

During maintenance, Apron Feeder is to be fenced off and electrical supply and control are to be locked out in accordance with plant safety procedures.

Apron Feeder may require operation during maintenance for inspection and/or momentary advancement when replacing pans or chains.

When the feeder is to be run it must be verified that no one is in contact or near the feeder posing any danger prior to starting it.

During the actual work on the feeder, the feeder must be locked out at all times.

It is recommended that a minimum of two workers be in attendance at all times during maintenance.

Plant safety procedures should be reviewed for additional precautions and procedures.

VERIFY WEAR ON COMPONENTS

Sprockets

Check the amount of wear on the sprocket face. If the wear is more than 1/8" deep, the sprocket should be reversed. If both sides of the teeth are worn, the sprockets should be replaced.

Chains

Check the pitch length of the chains by measuring the length over 10 pitches and divide it by 10. If the pitch is more than 2% longer than the new chain pitch, the chains should be replaced. Also verify the integrity of the chain barrels, seals etc. If unusual damage or wear shows on some or all links consult supplier to remedy problem.

Pans

Verify the base thickness of the pans and compare with the original thickness. If more than $\frac{1}{4}$ " of material has worn off the face of the pans, replace the pans. If some or all pans have local damage or excessive wear, consult supplier to remedy problem and or replace pans.

Carry and Return Rollers

Verify that rollers are turning during operation. If roller does not turn under load it should replaced. If roller has excessive wear (more than 1/8" deep) on the running face it should be replaced

REPLACING PANS ONLY

- 1. If one or more damaged pans are to be replaced, run the feeder to bring those pans to the back of the feeder just on top of the tail traction wheel where it will be easiest to work.
- 2. If one or more pans are missing completely, do not run this gap through the return, where it will hang up on the return rollers. Either replace the pan on the top run or in the head chute or carefully guide the gap over each return roller.
- 3. Remove the damaged pans and replace them with new pans.
- 4. Verify that the pan fits properly on the chains and does not interfere with the adjacent pans.
- 5. Do not re-use the old bolts, always use new high strength "track" bolts with square nuts and hardened steel flat washers. (see separate page "Mounting Apron Pan To Chain").
- 6. Please note that the pan on the master link may have a different bolt pattern from the rest.
- 7. Make sure there is a hardened flat washer under all the bolt heads and that the bolts are torqued correctly to prevent bolts coming loose later on.
- 8. Make sure all guards are back in place before operating feeder again.

REPLACING CHAINS AND PANS

- 1. If the pans and chains are to be replaced, run the feeder until one of the split master links sits just forward of the tail traction wheel.
- 2. Loosen the take ups on the tail shaft forward approx 2"-3" so the chains are slack.
- Take the pan off the split master link, which also will separate the chains. Remove the adjacent 5 or 6 pans on the tail traction wheel and fold the chains back from the traction wheel.
- 4. Lay the new chains behind the feeder in the correct orientation, connect them to the forward chains and mount a new pan on the master links (which for some chains has a different bolt pattern than the rest) and should be marked as "master link pan". Only use the bolts that come with the master link as they are special and different from the rest.
- 5. Mount 2 or 3 more new pans on the new chains and snug the bolts, but do not tighten them until all the pans are on.
- 6. Now, advance the feeder a little while at the same time pulling the return chains and pans back out of the feeder with a come-along or winch.
- 7. Remove some more pans from the old chain and put more pans on the new chains and keep repeating this procedure until all the pans and chains are replaced and the new chains can be connected in full circle.

- 8. Make sure that the pans are sitting correctly on the return rollers and that there is not one pan missing which will cause a hang up on the return.
- 9. Now run the feeder until the chain has gone around at least one more time. If everything looks okay, the pan bolts can be tightened to specified torque.
- 10. Make sure there is a hardened flat washer under all the bolt heads and that the bolts are torqued correctly to prevent bolts coming loose later on.
- 11. Make sure all guards are back in place before operating feeder again.

CONVEYOR COMPONENTS

CHAIN

Chain is TREK sealed and lubricated track chain (SALT) for the Apron Feeders.

Disassembly / Assembly of Master Links

Each chain is supplied with split master links for ease of chain connection and disassembly.

Fasteners supplied with chain only are to be used – do not substitute with standard fasteners.

If chain is to be broken outside of split master link:

Removal (if master pin press is not available)

Drive chain pin out with minimum 20 lb sledge hammer.
 Do not drive directly on pin. Use a drive pin with diameter smaller than pin O.D. Pin can be removed from either side of chain.

Install (if master pin press not available)

- 1. Clean pin boss in link.
- 2. Install seal washers and trust rings in link counter bore. Make sure pin boss and bushing bore are in a direct line.
- 3. Drive pin with 20 lb sledge hammer. Do not drive directly on pin. Use same drift pin as used in dismantling chain.

Note: Do not heat chain links to make pin installation / removal easier. This will reduce chain strength.



Since 1957 Trek has been a trusted leader in the marketplace, offering Quality and Reliable Undercarriage parts at a Competitive Price. Our line of Excavator and Tractor parts are manufactured with strict quality control measures to assure 100% interchangeable with those of the original equipment manufacturer. Trek offers a written warranty unmatched by any other undercarriage distribution network in the after market. Knowledgeable sales and product support staff are available throughout the United States and Canada. Call one of our 10 Trek locations or log on to our web site www.trekdirect.com for your parts requirements.

CHAINS

Trek Chain is manufactured from the finest quality steel, using the latest world technology to ensure long life and resistance to wear. Track links are forged from high quality boron steel, having greater mass in key areas for reinforcement.

Track pins and bushings receive special heat treatment to provide exceptional strength and shock resistance, combined with a focused hardness, which ensures a longer wear life.

Trek design Seals prolong pin and bushing life by sealing lubricants in and by preventing joint contamination.

DETROIT, MICHIGAN

Phone: (800) 444-8735 • (313) 579-1100 Fax: (313) 579-2980

PENNSAUKEN, NEW JERSEY

Phone: (800) 945-1890 • (856) 662-0008 Fax: (856) 662-0380

BLOOMINGTON, MINNESOTA

Phone: (800) 753-8032 • (952) 884-5600 Fax: (952) 884-0628

NORCROSS, (ATLANTA) GEORGIA

Phone: (800) 766-8949 • (770) 923-7600 Fax: (770) 923-2821

DESOTO, (DALLAS) TEXAS

Phone: (800) 933-4415 • (972) 224-1589 Fax: (972) 224-4259

PORTLAND, OREGON

Phone: (800) 374-8551 • (503) 288-7575 Fax: (503) 288-3204

RIVERSIDE, CALIFORNIA

Phone: (800) 685-0668 • (909) 787-7755 Fax: (909) 787-7757

EDMONTON, ALBERTA

Phone: **(800) 661-8809** • (780) 436-2570 Fax: (780) 436-2573

DELTA, (VANCOUVER) BRITISH COLUMBIA

Phone: (800) 663-0022 • (604) 946-5525 Fax: (604) 940-0559

POINTE-CLAIRE, (MONTREAL) QUEBEC

Phone: (800) 361-7154 • (514) 426-7144 Fax: (514) 426-7289








#109 - 19433 96th Ave, Surrey, BC, Canada V4N 4C4 Phone (604) 513-9930 Fax (604) 513-9905

D8N SALT Track Chain 215.9mm (8.5") Pitch



December 2003

ROLLERS

Rollers used are "lubricated for life" and have lifetime seals. Rollers are normally replaced when worn or seized.

However, if the need arises to re-lubricate, this can be done.

To replace lubrication in rollers:

Carrying Roller

- 1. Remove carry roller from feeder.
- 2. Remove plug in middle of carrying roller and drain out old oil as much as possible.
- 3. Turn roller so that plug is on top of roller.
- 4. Pump/pour 30W oil into roller until new oil overflows freely.
- 5. Use new gasket with plug and tighten.
- 6. Put roller back on feeder and align with chain before tightening down.

Return Roller

- 1. Remove roller from feeder
- 2. Roller has plug in end of cap; remove plug.
- 3. Drain out old oil as much as possible.
- 4. Stand Roller on end (shaft down) and insert nozzle.
- 5. Pump/pour 30W oil through nozzle until new oil flows freely.
- 6. Use Teflon tape or pipe sealant on plug and tighten.
- 7. Re-install return roller in feeder.



Since 1957 Trek has been a trusted leader in the marketplace, offering Quality and Reliable Undercarriage parts at a Competitive Price. Our line of Excavator and Tractor parts are manufactured with strict quality control measures to assure 100% interchangeable with those of the original equipment manufacturer. Trek offers a written warranty unmatched by any other undercarriage distribution network in the after market. Knowledgeable sales and product support staff are available throughout the United States and Canada. Call one of our 10 Trek locations or log on to our web site www.trekdirect.com for your parts requirements.

ROLLERS

Trek provides the finest top quality Upper and Lower Rollers, which are guaranteed to be interchangeable for the replacement market. Trek demands the best materials be used in the manufacturing of their rollers, to provide extended wear life. Trek is working to complete the full line of "R" Series High Drive Symmetrical Seal Rollers. This design retro fits older models and is the trouble free extended wear Roller for today's bigger and faster Tractors.

Trek continues to earn customer satisfaction and trust by our constant effort to provide an exceptional trouble free product.

DETROIT, MICHIGAN

Phone: **(800) 444-8735 •** (313) 579-1100 Fax: (313) 579-2980

PENNSAUKEN, NEW JERSEY

Phone: **(800) 945-1890 •** (856) 662-0008 Fax: (856) 662-0380

BLOOMINGTON, MINNESOTA

Phone: **(800) 753-8032** • (952) 884-5600

Fax: (952) 884-0628

NORCROSS, (ATLANTA) GEORGIA

Phone: (800) 766-8949 • (770) 923-7600

Fax: (770) 923-2821

DESOTO, (DALLAS) TEXAS Phone: **(800) 933-4415** • (972) 224-1589

Fax: (972) 224-4259

PORTLAND, OREGON

Phone: (800) 374-8551 • (503) 288-7575

Fax: (503) 288-3204

RIVERSIDE, CALIFORNIA

Phone: (800) 685-0668 • (909) 787-7755

Fax: (909) 787-7757

EDMONTON, ALBERTA

Phone: (800) 661-8809 • (780) 436-2570

Fax: (780) 436-2573

DELTA, (VANCOUVER) BRITISH COLUMBIA

Phone: **(800) 663-0022** • (604) 946-5525

Fax: (604) 940-0559

POINTE-CLAIRE, (MONTREAL) QUEBEC

Phone: (800) 361-7154 • (514) 426-7144

Fax: (514) 426-7289








#109 - 19433 96th Ave, Surrey, BC, Canada V4N 4C4 Phone (604) 513-9930 Fax (604) 513-9905

D8N CARRY ROLLER PART #01070586



CHAIN CARRY ROLLERS

REMOVAL/INSTALLATION

IEM apron feeders allow for removal/installation of chain carry rollers without need for:

- dismantling apron pans
- dismantling chain
- dismantling skirtboards
- emptying charge area





Remove Roller

- 1) Remove bolts on inside support "B".
- 2) Loosen lower bolts on outside support "A".
- 3) Remove spacer from inside support "B"
- 4) Undo lower bolts on outside spacer "A" allowing roller to rest on top of inside support "B".
- 5) Remove lower bolts of outside support "A".
- 6) Remove roller with attached support "A".

Install Roller

- 1) Position roller end on top of inside support "B".
- 2) Position outside support "A" under roller end.
- 3) Install bolts (loosely) in top and bottom flanges of outside support "A".
- 4) Raise roller upwards to allow spacer to be inserted on top of support "B".
- 5) Install bolts loosely in top of inside support "B".
- 6) Do final positioning of roller to give equal clearance, both sides, between outside of chain link and inside of roller end flanges.
- 7) Tighten bolts as required.








REPLACING RETURN ROLLER ASSEMBLIES

IEM Return Rollers are designed and mounted for ease of replacement.

Steps are as follows:

1) The apron pan on the return side must be lifted clear of the return roller outside hardened sleeve and held in the clear position until the roller has been replaced. This allows the roller to be easily removed and replaced by taking the pan and chain weight off the roller. Typically, a chain hoist can be used to do this...see below.



- 2) Loosen the four bolts anchoring the door assembly to the main frame and pull the door open. The return roller is now accessible for removal.
- 3) Loosen the three holding bolts on outside of the tapered bushing holding the roller shaft. Remove the bolts and re-install them into the threaded holes on the bushing. Tighten the bolts which now push the bushing out of the tapered bushing.
 <u>CAUTION</u>: Place some blocking under the roller while the roller shaft is being pushed out to support the roller from falling. When the roller has been pushed out from the bushing, the new roller can be installed by reversing the process.
- 4) Once the new roller has been installed into the bushing assembly, check the clearance between the inside wall of the door and roller body before tightening the bushing.
- 5) Close the door and re-install the four door bolts.
- 6) Lower the pan back on to the roller and remove the chain hoist.










 $\#109 - 19433\ 96^{th}\ Ave,\ Surrey,\ BC,\ Canada\ V4N\ 4C4\ Phone\ (604)\ 513-9930\ Fax\ (604)\ 513-9905$

#S638 Return Roller





#109 - 19433 96th Ave, Surrey, BC, Canada V4N 4C4 Phone (604) 513-9930 Fax (604) 513-9905

REPLACING CHAIN RETURN ROLLER



1. Remove locking bolts.



2. Pull door out (may require a strong pull).



3. Replace roller:

Loosen two bolts and slide roller out from clamp. Install new roller making sure that positioning dowels are inserted into mating holes in clamp.



4. Close door until end of roller touches side of apron pans. Install pry bar through hole and raise apron pans above top of roller. Close door and release pry bar and tighten bolts.

APRON PANS

Each cast manganese apron pan has been test fit to a jig to ensure proper fit prior to installing them on the chain.

Pans are supplied with top lifting lugs to assist in positioning or removing pans using a winch, come-along, etc.

If pans are replaced, always check clearances before applying full toque to bolts. Check front & rear overlap clearances of mating pans and side clearance.

Always use hardened flat washer under bolt head.





TYPICAL CAST MANGANESE APRON PAN


ISO 9001 Certified for Quality Assurance

109 -19433 96th Avenue Surrey, BC V4N 4C4 Canada Tel: 604-513-9930 Fax: 604-513-9905

Web: www.iem.ca







January/2008


Close tolerance at articulation point minimizes leakage of fine ore between pans

#109 - 19433 96th Ave, Surrey, BC, Canada V4N 4C4 Phone (604) 513-9930 Fax (604) 513-9905

CAST MANGANESE APRON PANS

Cast manganese apron pans are test fit to jig prior to installation on feeder (or prior to shipping as spares).

When installing new pans, place pan in position, install track bolts but do not torque down until proper fit and clearances have been confirmed.




#109 - 19433 96th Ave, Surrey, BC, Canada V4N 4C4 Phone (604) 513-9930 Fax (604) 513-9905

MOUNTING APRON PAN TO CHAIN

Use High Tensile strength track bolts and square nuts from chain manufacturer. SAE flat hardened washers can be purchased from local fastener suppliers.

The square track nut is held in place by the recess in the chain link. The hardened flat washer is used under the head of the track bolt. This assists in the torquing of the bolt by providing a flat, smooth surface for the bolt head to turn when torquing bolt in place. Track bolts are to be torqued to the dry torque values shown below for the different size of chain.

Prior to installing the pan onto the chain, any excessive paint on the top of the chain link should be removed.



Track Bolt Dry Torque Settings

Chain Size	Track Bolt	Torque Setting
CS450	1/2"	50 lb.ft plus 1/3 turn
D4E-EWL	5/8"	130 lb.ft plus 1/3 turn
D6D	3/4"	250 lb.ft plus 1/3 turn
D7G	3/4"	250 lb.ft plus 1/3 turn
D8N	7/8"	375 lb.ft plus 1/3 turn

SPROCKETS

Sprockets are segmented (3 segments each with 7 teeth bolt-on type).

Segments are jig drilled. When worn, sprockets can be reversed.

Ensure sprocket split locations are in the same location on both sprockets / hubs.

#109 - 19433 96th Ave, Surrey, BC, Canada V4N 4C4 Phone (604) 513-9930 Fax (604) 513-9905

SEGMENTAL SPROCKETS

D7-21 Tooth (10 1/2 Effective Teeth)




Sprocket segments are jig-drilled so they can be mounted in any position on the hub.


When sprockets are worn on one side, all segments can be reversed to present the new tooth face to the chain.

It is recommended that splits between segments be positioned in the same location on both sprockets
















Industrial Gear Units P.MC.. Series

Edition 12/2006 11572604 / EN Operating Instructions





Contents



1		ant Notes	
		Explanation of symbols	
		Operating notes	
2	-	Notes	
		ntroduction	
		General informationSymbols on the gear unit	
		Fransportation	
		Corrosion and surface protection	
3	Gear U	nit Design	17
		Combination of P planetary gear unit with MC primary gear unit	
	3.2	Structure of the planetary gear unit	18
		Design of the MC.P series primary gear unit	
		Design of the MC.R series primary gear unit	
		Jnit designation / nameplates	
		Shaft position	
		Direction of rotation	
4		ation / Assembly	
•		Required tools / resources	
		nstallation tolerances	
		Prerequisites for assembly	
		Preliminary work	
		Notes on installing the gear unit	
		Flange mountingnstalling torque arms for hollow shaft gear units	
		Assembly / disassembly of hollow shaft gear units and shrink discs	
		Mounting a motor with motor adapter	
5	Mechai	nical Installation Options	45
	5.1 li	mportant installation instructions	45
	5.1 lı 5.2 lı	mportant installation instructionsnstalling couplings	45 48
	5.1 li 5.2 li 5.3 E	mportant installation instructions nstalling couplings Backstop FXM	45 48 55
	5.1 li 5.2 li 5.3 E 5.4 S	mportant installation instructions nstalling couplings	45 48 55
	5.1 li 5.2 li 5.3 E 5.4 S 5.5 C	mportant installation instructions	45 48 55 58 61
	5.1 III 5.2 III 5.3 E 5.4 S 5.5 C 5.6 T	mportant installation instructions nstalling couplings	45 55 58 61 67
	5.1 III 5.2 III 5.3 E 5.4 S 5.5 C 5.6 T 5.7 F 5.8 F	mportant installation instructions nstalling couplings Backstop FXM Shaft end pump SHP Dil heater Temperature sensor PT100 Fan	45 48 55 58 61 67 68
	5.1 III 5.2 III 5.3 E 5.4 S 5.5 C 5.6 T 5.7 F 5.8 F 5.9 V	mportant installation instructions nstalling couplings Backstop FXM Shaft end pump SHP Dil heater Temperature sensor PT100 Fan Flow switch	45 55 58 61 67 68 69
	5.1 III 5.2 III 5.3 E 5.4 S 5.5 C 5.6 T 5.7 F 5.8 F 5.9 V 5.10 C	mportant installation instructions nstalling couplings Backstop FXM Shaft end pump SHP Dil heater Femperature sensor PT100 Fan Flow switch Visual flow indicator Dil expansion tank and oil riser pipe	45 48 55 61 67 68 69 72
	5.1 III 5.2 III 5.3 E 5.4 S 5.5 C 5.6 T 5.7 F 5.8 F 5.9 V 5.10 C 5.11 C	mportant installation instructions nstalling couplings Backstop FXM Shaft end pump SHP Dil heater Femperature sensor PT100 Fan Flow switch Visual flow indicator Dil expansion tank and oil riser pipe Connecting the oil/water cooling system	45 55 58 61 67 68 69 73 73
	5.1 III 5.2 III 5.3 E 5.4 S 5.5 C 5.6 T 5.7 F 5.8 F 5.9 V 5.10 C 5.11 C 5.12 C	mportant installation instructions nstalling couplings Backstop FXM Bhaft end pump SHP Dil heater Femperature sensor PT100 Fan Flow switch Visual flow indicator Dil expansion tank and oil riser pipe Connecting the oil/water cooling system Connecting the oil/air cooling system	45 48 55 58 61 67 68 69 72 73 73
	5.1 II 5.2 II 5.3 E 5.4 S 5.5 C 5.6 T 5.7 F 5.8 F 5.9 V 5.10 C 5.11 C 5.12 C	mportant installation instructions nstalling couplings Backstop FXM Bhaft end pump SHP Dil heater Temperature sensor PT100 Fan Flow switch Visual flow indicator Dil expansion tank and oil riser pipe Connecting the oil/water cooling system Connecting the motor pump	45 48 55 61 67 68 72 73 73 73
6	5.1 III 5.2 III 5.3 E 5.4 S 5.5 C 5.6 T 5.7 F 5.8 F 5.9 V 5.10 C 5.11 C 5.12 C 5.13 C	mportant installation instructions nstalling couplings Backstop FXM Shaft end pump SHP Dil heater Femperature sensor PT100 Fan Flow switch Visual flow indicator Dil expansion tank and oil riser pipe Connecting the oil/water cooling system Connecting the motor pump Dil connecting the motor pump	45 48 55 58 61 67 68 72 73 73 73
	5.1 III 5.2 III 5.3 E 5.4 S 5.5 C 5.6 T 5.7 F 5.8 F 5.9 V 5.10 C 5.11 C 5.12 C 5.13 C Startup 6.1 S	mportant installation instructions nstalling couplings Backstop FXM Bhaft end pump SHP Dil heater Temperature sensor PT100 Fan Flow switch Visual flow indicator Dil expansion tank and oil riser pipe Connecting the oil/water cooling system Connecting the motor pump	45 48 55 58 61 67 68 72 73 73 73 74
	5.1 III 5.2 III 5.3 E 5.4 S 5.5 C 5.6 T 5.7 F 5.8 F 5.9 V 5.10 C 5.11 C 5.12 C 5.13 C Startup 6.1 S 6.2 S 6.3 S	mportant installation instructions nstalling couplings Backstop FXM Shaft end pump SHP Dil heater Temperature sensor PT100 Fan Flow switch Visual flow indicator Dil expansion tank and oil riser pipe Connecting the oil/water cooling system Connecting the oil/air cooling system Connecting the motor pump Startup of gear units Startup of gear units with long-term protection Starting up gear units with backstop	45 48 55 58 61 67 68 72 73 73 74 75 76
	5.1 III 5.2 III 5.3 E 5.4 S 5.5 C 5.6 T 5.7 F 5.8 F 5.9 V 5.10 C 5.11 C 5.12 C 5.13 C Startup 6.1 S 6.2 S 6.3 S	mportant installation instructions nstalling couplings Backstop FXM Shaft end pump SHP Dil heater Temperature sensor PT100 Fan Flow switch Visual flow indicator Dil expansion tank and oil riser pipe Connecting the oil/water cooling system Connecting the motor pump Startup of gear units Startup of gear units with long-term protection	45 48 55 58 61 67 68 72 73 73 74 75 76
	5.1 III 5.2 III 5.3 E 5.4 S 5.5 C 5.6 T 5.7 F 5.8 F 5.9 V 5.10 C 5.11 C 5.12 C 5.13 C Startup 6.1 S 6.2 S 6.3 S 6.4 S	mportant installation instructions nstalling couplings Backstop FXM Shaft end pump SHP Dil heater Temperature sensor PT100 Fan Flow switch Visual flow indicator Dil expansion tank and oil riser pipe Connecting the oil/water cooling system Connecting the motor pump Distartup of gear units Startup of gear units with long-term protection Starting up gear units with backstop Shutting down gear units tion and Maintenance	45 48 55 58 61 67 68 72 73 73 73 74 75 76 76
6	5.1 III 5.2 III 5.3 E 5.4 S 5.5 C 5.6 T 5.7 F 5.8 F 5.9 V 5.10 C 5.11 C 5.12 C 5.13 C Startup 6.1 S 6.2 S 6.3 S 6.4 S Inspec	mportant installation instructions Installing couplings Backstop FXM Bhaft end pump SHP Dil heater Temperature sensor PT100 Fan Flow switch Visual flow indicator Dil expansion tank and oil riser pipe Connecting the oil/water cooling system Connecting the oil/air cooling system Connecting the motor pump Distartup of gear units Startup of gear units with long-term protection Startup of gear units with backstop Shutting down gear units Shutting down gear units Story and Maintenance Inspection and Maintenance intervals	45 48 55 58 61 67 73 73 73 74 75 76 76
6	5.1 III 5.2 III 5.3 E 5.4 S 5.5 C 5.6 T 5.7 F 5.8 F 5.9 V 5.10 C 5.11 C 5.12 C 5.13 C Startup 6.1 S 6.2 S 6.3 S 6.4 S Inspect	mportant installation instructions nstalling couplings Backstop FXM Shaft end pump SHP Dil heater Temperature sensor PT100 Fan Flow switch Visual flow indicator Dil expansion tank and oil riser pipe Connecting the oil/water cooling system Connecting the oil/air cooling system Connecting the motor pump Dil Startup of gear units Startup of gear units with long-term protection Starting up gear units with backstop Shutting down gear units tion and Maintenance nspection and Maintenance intervals Lubricant change intervals	45 48 55 58 61 67 73 73 73 74 75 76 76 78 79
6	5.1 III 5.2 III 5.3 E 5.3 E 5.4 S 5.5 C 5.6 T 5.7 F 5.8 F 5.9 V 5.10 C 5.11 C 5.12 C 5.13 C Startup 6.1 S 6.2 S 6.3 S 6.4 S Inspect 7.1 II 7.2 L 7.3 C	mportant installation instructions nstalling couplings Backstop FXM Shaft end pump SHP Dil heater Femperature sensor PT100 Fan Flow switch Visual flow indicator Dil expansion tank and oil riser pipe Connecting the oil/water cooling system Connecting the oil/air cooling system Connecting the motor pump Distartup of gear units Startup of gear units with long-term protection Starting up gear units with backstop Shutting down gear units tion and Maintenance nspection and Maintenance intervals Lubricant change intervals Checking the oil level	45 48 55 58 61 67 73 73 73 74 75 76 76 78 79 80
6	5.1 li 5.2 li 5.3 E 5.4 S 5.5 C 5.6 T 5.7 F 5.8 F 5.9 V 5.10 C 5.11 C 5.12 C 5.13 C Startup 6.1 S 6.2 S 6.3 S 6.4 S Inspect 7.1 li 7.2 L 7.3 7.4 C	mportant installation instructions	45 48 55 58 61 67 73 73 73 74 75 76 76 78 79 80 80
6	5.1 III 5.2 III 5.3 E 5.3 E 5.4 S 5.5 C 5.6 T 5.7 F 5.8 F 5.9 V 5.10 C 5.11 C 5.12 C 5.13 C Startup 6.1 S 6.2 S 6.4 S Inspec 7.1 II 7.2 L 7.3 C 7.4 C 7.5 C	mportant installation instructions nstalling couplings Backstop FXM Shaft end pump SHP Dil heater Femperature sensor PT100 Fan Flow switch Visual flow indicator Dil expansion tank and oil riser pipe Connecting the oil/water cooling system Connecting the oil/air cooling system Connecting the motor pump Distartup of gear units Startup of gear units with long-term protection Starting up gear units with backstop Shutting down gear units tion and Maintenance nspection and Maintenance intervals Lubricant change intervals Checking the oil level	45 48 55 58 61 67 73 73 73 74 75 76 76 78 79 80 81
6	5.1 III 5.2 III 5.3 E 5.3 E 5.4 S 5.5 C 5.6 T 5.7 F 5.8 F 5.9 V 5.10 C 5.11 C 5.12 C 5.13 C Startup 6.1 S 6.2 S 6.3 S 6.4 S Inspect 7.1 II 7.2 L 7.3 C 7.6 C 7.6 C	mportant installation instructions	45 48 55 58 61 67 73 73 74 75 76 76 78 79 80 81 82
6	5.1 III 5.2 III 5.3 E 5.3 E 5.4 S 5.5 C 5.6 T 5.7 F 5.8 F 5.9 V 5.10 C 5.11 C 5.12 C 5.13 C Startup 6.1 S 6.2 S 6.4 S Inspect 7.1 II 7.2 L 7.3 C 7.4 C 7.5 C Malfun	mportant installation instructions. Installing couplings. Backstop FXM. Shaft end pump SHP. Dil heater Femperature sensor PT100. Fan. Flow switch Visual flow indicator Dil expansion tank and oil riser pipe Connecting the oil/water cooling system. Connecting the motor pump. Distartup of gear units. Startup of gear units with long-term protection. Starting up gear units with backstop. Shutting down gear units tion and Maintenance Inspection and Maintenance intervals. Lubricant change intervals. Checking the oil level. Checking the oil Checking the oil Checking and cleaning the breather plug.	45 48 55 58 61 67 73 73 74 75 76 76 76 78 79 80 81 82 83





9	Lubi	ricants	85
		Guidelines for lubricant selection	
	9.2	Lubricant table	86
	9.3	Lubricant fill quantities	88
		Sealing grease	88





1 Important Notes

Introduction

A requirement of fault-free operation and fulfillment of any rights to claim under limited warranty is that you adhere to the information in the operating instructions. Read the operating instructions before you start working with the unit.

Make sure that the operating instructions are available to persons responsible for the plant and its operation, as well as to person who work independently on the unit.

Also observe other technical documents, contracts for delivery or other agreements.

General information

P.MC.. industrial gear units are a combination of

- 1. P.. planetary gear units output stage
- 2. MC.R.. or MC.P.. primary gear unit
- 3. Motor, coupling, adapter and backstop, if required.

Designated use

The designated use refers to the procedure specified in the operating instructions.

The P.MC.. industrial gear units are units run by motors for industrial and commercial systems. Gear unit utilizations other than those specified and areas of application other than industrial and commercial systems can only be used after consultation with SEW-EURODRIVE.

In compliance with the EG Machinery Directive 98/37/EG, the P.MC.. industrial gear units are components for installation in machinery and systems. In the scope of the EG directive, you must not take the machinery into operation in the designated fashion until you have established that the end product complies with the Machinery Directive 98/37/EG.

Qualified personnel

P.MC.. series industrial gear units represent a potential hazard for persons and material. Consequently, assembly, installation, startup and service work may only be performed by trained personnel who are aware of the potential hazards.

The personnel must be appropriately qualified for the task in hand and must be familiar with the

- Assembly
- Installation
- Startup
- Operation
- Inspection
- Maintenance

of the product.

The personnel must read the operating instructions, in particular the safety notes section, carefully and ensure that they understand and comply with them.





Exclusion of liability

You must comply with the information contained in these operating instructions to ensure safe operation of the P.MC.. series gear units and to achieve the specified product characteristics and performance requirements.

SEW-EURODRIVE GmbH & CoKG assumes no liability for injury to persons or damage to equipment or property resulting from non-observance of these operating instructions. In such cases, any liability for defects is excluded.

Product names and trademarks

The brands and product names contained within these operating instructions are trademarks or registered trademarks of the titleholders.

Disposal

(Please follow the latest instructions):



- Housing parts, gears, shafts and roller bearings of the gear units must be disposed
 of as steel scrap. This also applies to gray-cast iron parts if there is no special
 collection.
- · Collect waste oil and dispose of it according to the regulations in force.



1.1 Explanation of symbols

Important instructions concerning the safety and industrial safety are marked by the following symbols.



Electrical hazard

Possible consequences: Severe or fatal injuries.



Hazard

Possible consequences: Severe or fatal injuries.



Hazardous situation

Possible consequences: Slight or minor injuries.



Harmful situation

Possible consequences: Damage to the drive and the environment.



Tips and useful information.

1.2 Operating notes



- The industrial gear units of the P.MC.. series are delivered without oil fill.
- The nameplate of the gear unit contains the most important technical data!
- The two gear units have a common oil compartment!
- The mounting position may only be changed after consultation with SEW-EURODRIVE. The warranty will become void without prior consultation. When changing to a vertical mounting position of the MC.. gear unit (M2, M4), oil compensator or oil riser pipe are required. Adjust the lubricant fill volume and position of the breather valve accordingly.
- Follow the instructions in Sec. "Mechanical installation" / "Installing the gear unit"!





2 Safety Notes

2.1 Introduction



- The following safety notes are concerned with the use of industrial gear units of the P.MC.. series.
- Please also consider the supplementary safety notes in the individual sections of these operating instructions.

2.2 General information



Burns hazard!

Touching the gear unit when it has not been cooled will result in burns. The gear unit can have a surface temperature of more than 100 °C.

Never touch the gear unit during operation or in the cool down phase once the unit has been switched off.



Never install damaged products or take them into operation.

Submit a complaint to the shipping company immediately in the event of damage.

During or after operation, industrial gear units and motors have:

- · Live parts
- · Moving parts
- Hot surfaces (may be the case)

Only qualified personnel may carry out the following work:

- · Installation / assembly
- Connection
- Startup
- Maintenance
- Servicing

The following information and documents must be observed during these processes:

- Relevant operating instructions and wiring diagrams
- · Warning and safety signs on the gear unit
- · System-specific regulations and requirements
- · National/regional regulations governing safety and the prevention of accidents



Serious injuries and property damage may result from:

- Improper use
- · Incorrect installation or operation
- Unauthorized removal of necessary protection covers or housing



Startup / operation



- Check that the direction of rotation is correct in decoupled status. Listen out for unusual grinding noises as the shaft rotates.
- Secure the keys for test mode without output elements.
- Do not deactivate monitoring and protection equipment even in test mode.
- Switch off the main motor if in doubt whenever changes occur in relation to normal operation (e.g. increased temperatures, noise, oscillation). Determine the cause of the fault and consult SEW-EURODRIVE.
- · Work carefully and keep safety in mind.
- Work on the gear unit only when the machine is not in use. Prevent the drive unit from being unintentionally switched on, for example by locking the keyswitch or removing the fuses from the power supply. Attach an information sign near the on-switch to warn that the gear unit is being worked on.
- Observe the notes attached to the gear unit such as the nameplate and direction arrow. They must be free of paint and dirt. Replace missing signs.
- When installing the gear unit in devices or systems, the manufacturers of the device or system are obliged to include the regulations, notes, and descriptions from these operating instructions in their own operating instructions.
- Purchase spare parts from SEW-EURODRIVE.

Inspection / maintenance

Refer to the instructions in Sec. "Inspection and Maintenance."

Operational environment



- · The gear unit is not suited for operation in potentially explosive atmospheres!
- Observe the information of the order-specific ambient temperature and ambient conditions. Modifications require prior approval by SEW-EURODRIVE.





2.3 Symbols on the gear unit

The symbols on the gear unit must be observed. They have the following meaning:

Symbol	Meaning
	Breather valve
	Oil filling plug
	Oil drain plug
	Lubrication point
MIN	Oil sight glass
	Direction of rotation
DELIVERED WITHOUT OIL	Delivery status
	Hot surfaces
GEAR UNIT IS VPI ANTI-RUST TREATED. COVER AND PLUG OF GEAR UNIT MUST NOT TO BE OPEND AND GEAR UNIT MUST NOT ROTATED BEFORE START-UP. BEFORE START-UP. THE PROTECTIVE PLUG MUST BE REMOVED AND REPLACED BY ENCLOSED AIR VALVE.	Extended storage



2.4 Transportation

General notes




- Inspect the shipment for any damage in transit as soon as you receive the delivery. Inform the shipping company immediately. It may be necessary to preclude startup.
- · Do not stay under the gear unit during transportation.
- · Secure the danger zone.
- During transport, use only hoists and load-bearing equipment with sufficient load-bearing capacity.
- The weight of the gear unit is indicated on the nameplate or the dimension sheet. Observe the loads and regulations specified on the nameplate.
- The gear unit must be transported in a manner that prevents injuries and damage to the gear unit. For example, impacts against exposed shaft ends can damage the gear unit.
- Do not use the eyebolts on motors, auxiliary gear units or primary gear units for transport of the mounted drive unit (see next page).
- Use suitable, sufficiently rated handling equipment if necessary. Before startup, remove securing devices used for transport.

Transporting the gear unit without motor



The gear unit may only be transported using lifting belts and ropes or chains. Take the load distribution of the gear unit into account. The main load has to be carried by the transport eye [1] and the lift belt [2] at the P.. gear unit. The lift chain [3] at the lifting eyebolts of the MC gear unit is only for balancing during transport.




61082AXX

Safety Notes Transportation

Transporting the gear unit with motor adapter



The gear unit may only be transported using lifting belts and ropes or chains. Take the load distribution of the gear unit and motor into account. The main load has to be carried by the transport eye [1] and the lifting belt [2] at the P.. gear unit. The lifting belt [3] at the motor adapter and the lifting chain [4] at the lifting eyebolts of the MC gear unit are only for balancing during transport.







2.5 Corrosion and surface protection



The information in this section apply only to P.MC.. series industrial gear units assembled in Europe. Other paint systems might be used in other regions. Please consult the SEW-EURODRIVE assembly plant for P.MC.. industrial gear units at your location.

Introduction

The corrosion and surface protection of gear units comprises the following three basic features:

- 1. Painting system
 - Standard painting system K7 E160/2
 - High-resistant painting system K7 E260/3 as option
- 2. Gear unit corrosion protection with
 - · interior protection and
 - exterior protection
- 3. Gear unit packing
 - Standard packing (pallet)
 - Wooden box
 - · Seaworthy packaging

Standard painting system K7 E160/2

Painting is performed according to TEKNOS EPOXY SYSTEM K7 based on the high-solid epoxy paint TEKNOPLAST HS 150.

Two layer system K7 E 160/2	Thickness
Epoxy primer	60 μm
Teknoplast HS 150	100 μm
Total thickness	160 μm

Color shade: RAL 7031, blue gray

Protective covers

Powder coating, epoxy-based coat paint (EP) is used for guards and shields.

Layer thickness: 65 µm

Color shade: TM 1310 PK, warning in yellow color

High-resistant painting system K7 E 260/3

Painting is performed according to TEKNOS EPOXY SYSTEM K7 based on the high-solid epoxy paint TEKNOPLAST HS 150.

Three-layer system, E 260/3	Thickness
Epoxy primer	60 μm
Teknoplast HS 150	2x100 μm
Total thickness	260 μ m

Optional color shade

Other color shades are available on request.



Safety Notes Corrosion and surface protection

Usage of painting system

Environmental pollution	No	Low	medium	High	Very high
Typical environ- mental conditions		Unheated build- ings where con- densation can build up. Atmospheres with low pollution. Mostly rural areas.	Production halls with high humidity levels and low air contamination. City and industrial atmospheres, moderate contamination with sulphur dioxide. Coastal areas with low salt load.	Industrial areas and coastal areas with moderate salt load. Chemical plants	Buildings or areas with almost per- manent condensa- tion and high levels of contami- nation. Industrial areas with very high lev- els of moisture and aggressive atmospheres.
Mounting	Indoors	Indoors	Indoors or outdoors	Indoors or outdoors	Indoors or outdoors
Relative humidity	< 90 %	Up to 95 %	Up to 100 %	Up to 100 %	Up to 100 %
Recommended painting system	Standard painting system K7 E160/2	Standard painting system K7 E160/2	Standard painting system K7 E160/2	High resistant paint- ing system K7 E260/3	Consult SEW-EURODRIVE

Storage and transport conditions

Industrial gear units of the P.MC.. series are delivered without oil fill. Different protection systems are required depending on storage period and ambient conditions:

Storage	Storage conditions Gear unit corrosion protection				Transport conditions Gear unit packing	
period: Up to months	OUTDOORS, roofed	INDOORS, heated (0°C+20°C)	Storage OUT- DOORS close to the sea, roofed	Storage close to the sea INDOORS	Land transport	Sea transport
6	Standard protection	Standard protection	Consult SEW-EURODRIVE	Long-term protection	Standard packaging	Seaworthy packaging
12	Consult SEW-EURODRIVE	Standard protection	Consult SEW-EURODRIVE	Long-term protection	Standard packaging	Seaworthy packaging
24	Long-term protection	Consult SEW-EURODRIVE	Consult SEW-EURODRIVE	Long-term protection	Standard packaging	Seaworthy packaging
36	Consult SEW-EURODRIVE	Long-term protection	Consult SEW-EURODRIVE	Long-term protection	Standard packaging	Seaworthy packaging

Standard protection / interior

 Gear units undergo a test run with protection oil. The protection oil is drained by SEW-EURODRIVE before dispatch. The remaining layer of protection oil on the inner parts serves as basic protection.

Standard protection / exterior


- Oil seals and seal surfaces are protected by suitable bearing grease.
- Unpainted surfaces (including spare parts) are covered with a protective coating.
 Remove the coating using a solvent before mounting other equipment onto the surface.
- Small spare parts and loose pieces, such as screws, nuts, etc., are supplied in corrosion protection plastic bags (VCI corrosion protection bag).
- · Threaded holes and blind holes are covered by plastic plugs.
- The breather plug (position \rightarrow see order documents) is already installed at the factory.





Standard protection / packing

Standard packaging is used: The gear unit is delivered on a pallet without cover.




58048AXX

Long-term protection / interior

Internal gear unit protection in addition to the "standard protection":

A VPI solvent is sprayed through the oil filling hole.



- Take preventive measures to protect people from the solvent vapors. Make sure that open flames are avoided when the solvent is applied and when it evaporates.
- The output shaft must be rotated at least one turn in such a way that the position of the roller elements in the bearings of LSS and HSS changes. This procedure has to be repeated every 6 months until startup.
- Long-term protection of the gear unit interior with VPI solvent has to be repeated every 24 / 36 months until startup (according to the table "Storage and transport conditions").



Safety Notes Corrosion and surface protection

Long-term protection / exterior



- If the gear unit is stored longer than 6 months, it is recommended to regularly check the protective coating of unpainted areas as well as the paint coat. Areas with removed protection coating or paint have to be repainted, if necessary.
- · Oil seals and sealing surfaces are protected by suitable grease.
- Unpainted surfaces (including spare parts) are covered with a protective coating.
 Remove the coating using a solvent before mounting other equipment onto the surface.
- Small spare parts and loose pieces, such as screws, nuts, etc., are supplied in corrosion protection plastic bags (VCI corrosion protection bag).
- · Threaded holes and blind holes are covered by plastic plugs.
- The breather plug (position \rightarrow see order documents) is already installed at the factory.
- The breather plug is replaced by a screw plug. You find the position of the breather plug in the order documents. Prior to startup, the screw plug must be replaced again by the breather plug. The breather plug is attached to the gear unit separately.

Long-term protection / pack-aging

 Seaworthy packaging is used: The gear unit is packaged in a seaworthy plywood box and is delivered on a pallet.



57585AXX

Alternative packaging

Optionally, the gear unit can be supplied in a wooden box with standard gear unit protection.






3 **Gear Unit Design**

3.1 Combination of P.. planetary gear unit with MC.. primary gear unit

The following figure shows the design of P.MC.. gear units .

The gear unit comprises a P.. planetary gear unit and an MC.P../MC.R.. primary gear unit.



58063AXX

Р.. = Planetary gear unit

MC.P.. = Helical gear unit (primary gear unit)

MC.R.. = Bevel-helical gear unit (primary gear unit)


Gear Unit Design Structure of the planetary gear unit

3.2 Structure of the planetary gear unit



The following illustrations allow to easily assign components to the spare parts lists. Discrepancies are possible depending on the gear unit size and version.

P1..MC..



58049AXX


- [1] Planetary bearing
- [2] Circlip
- [3] Planet bolt
- [4] Planet wheel
- [5] Housing gear rim
- [6] Gear coupling
- [7] Bearing
- [8] Sun pinion
- [9] Retaining screw
- [10] Bearing

- [11] Bearing race
- [12] Flange cover
- [13] Sealing ring
- [14] Planet carrier output shaft





P2..MC..



58229AXX

[1] Planet carrier	[8] Planet carrier	[15] Circlip
[2] Bearing race	[9] Planet wheel	[16] Circlip
[3] Planetary gear axle	[10] Key (not in hollow shaft)	[17] Circlip
[4] Planet wheel	[11] Machine screw	[18] Cylindrical roller bearings
[5] Sun pinion	[12] Cylindrical roller bearings	[19] Cylindrical roller bearings
[6] Housing gear rim	[13] Self-aligning roller bearing	[20] Sun pinion
[7] Output flange	[14] Oil seal	[21] Intermediate shaft




Design of the MC.P.. series primary gear unit

3.3 Design of the MC.P.. series primary gear unit



The following illustrations allow to easily assign components to the spare parts lists. Discrepancies are possible depending on the gear unit size and version.



60331	AXX

[001] Gear unit housing	[195] Shim	[301] Pinion shaft	[411] Rolling element bearing
[010] Bearing cover	[199] End gear	[310] Bearing	[430] Key
[015] Bearing cover	[201] Pinion shaft	[331] Key	[434] Cover
[025] Bearing cover	[210] Bearing	[340] Spacer	[438] Socket
[040] Bearing cover	[231] Key	[342] Spacer	[443] Distance bushing
[070] Gearcase cover	[242] Spacer	[395] Shim	[480] Oil seal
[075] Cover plate	[243] Spacer	[399] Gearwheel	[495] Shim
[100] Output shaft	[295] Shim	[401] Input shaft	[725] Lifting eyebolt
[110] Bearing	[299] Gearwheel	[410] Bearing	






3.4 Design of the MC.R.. series primary gear unit



The following illustrations allow to easily assign components to the spare parts lists. Discrepancies are possible depending on the gear unit size and version.




[001] Gearcase	[199] End gear	[310] Bearing	[411] Bearing
[010] Bearing cover	[201] Pinion shaft	[331] Key	[422] Bearing bushing
[015] Bearing cover	[210] Bearing	[340] Spacer	[423] Bearing bushing
[025] Bearing cover	[231] Key	[341] Spacer	[430] Key
[040] Cover	[242] Spacer	[342] Spacer	[436] Sleeve
[070] Gearcase cover	[243] Spacer	[395] Shim	[470] Clamping nut
[080] Bearing cover	[295] Shim	[399] Bevel	[480] Oil seal
[100] Output shaft	[299] Gearwheel	[401] Bevel pinion shaft	[495] Shim
[110] Bearing	[301] Pinion shaft	[410] Bearing	[725] Lifting eyebolt
[195] Shim			

Gear Unit Design Unit designation / nameplates

3.5 Unit designation / nameplates


Sample unit designation







Example nameplate



61079AXX

Туре		Unit designation
Nr. 1		Serial number 1
Nr. 2		Serial number 2
P _{K1}	[KW]	Driving force gear unit
M _{K2}	[kNm]	Gear unit output torque
n ₁	[1/min]	Input speed (HSS)
n_2	[1/min]	Output speed (LSS)
norm.		Standard operating point
min.		Operating point at minimum speed
max		Operating point at maximum speed
i		Exact gear unit reduction ratio
F _S		Service factor
F _{R1}	[kN]	Actual overhung load acting on the input shaft
F _{R2}	[kN]	Actual overhung load acting on the output shaft
F _{A1}	[kN]	Actual axial load acting on the input shaft
F _{A2}	[kN]	Actual axial load acting on the output shaft
Mass	[kg]	Weight of the gear unit
Qty of greasing points:		Number of points that require regreasing
Fan		Number of installed fans
Lubricant		Oil grade and viscosity class / oil capacity
Year		Year of construction
IM		Mounting position: Housing orientation and mounting surface variants
TU		Permitted ambient temperature




3.6 Mounting positions


Mounting position designations


SEW-EURODRIVE differentiates between mounting positions M1, M2 and M4 for planetary gearmotors. The following figure shows the spatial orientation of the gear unit. The mounting positions apply to planetary gear units with solid shafts and hollow shafts.




Refer to your oder documents if the position of the primary gear unit differs.










57886AXX


3.7 Shaft position

The following figure shows the shaft position (0, 1, 2, 3, 4).




3.8 Direction of rotation

Shaft positions and corresponding directions of rotation of P.MC2P.. The following figures show shaft positions and corresponding directions of rotation for P.MC2P.. series industrial gear units.




Gear Unit Design Direction of rotation

Shaft positions and corresponding directions of rotation of P.MC3P.. The following figures show shaft positions and corresponding directions of rotation for P.MC3P.. series industrial gear units.




Shaft positions and corresponding directions of rotation of P.MC.R.. without backstop The following figures show shaft positions and corresponding directions of rotation for two and three stage P.MC.R.. series industrial gear units without backstop.








Shaft positions and corresponding directions of rotation of P.MC2RS.. / P.MC2RH.. keyway with backstop The following figures show shaft positions and directions of rotation for two-stage gear units with backstop of the types P.MC.RS..und P.MC.RH.. with keyway.





Only one direction of rotation is possible, which has to be specified in the order. The permitted direction of rotation is indicated on the housing.

Shaft positions and corresponding direction of rotation for P.MC3R.. with backstop on driven machine end The following figures show the shaft positions and corresponding directions of rotation for 3-stage gear units with backstop P.MC.3R..






Only one direction of rotation is possible, which has to be specified in the order. The permitted direction of rotation is indicated on the housing.



Shaft positions and corresponding directions of rotation of P.MC3R.. Backstop opposite driven machine

The following figures show the shaft positions and corresponding directions of rotation for gear units with backstop P.MC3R.





Only one direction of rotation is possible, which has to be specified in the order. The permitted direction of rotation is indicated on the housing.

Gear Unit Design Direction of rotation

Splash lubrication

With splash lubrication, the oil level is low. With this lubrication method, oil is splashed onto the bearings and gearing components.

Oil bath lubrication

With oil bath lubrication, the oil level is so high that the bearings and gearing components are completely immersed in the lubricant.

Oil expansion tanks are **always used with bath lubrication**. Oil expansion tanks allow the lubricant to expand when the gear unit heats up during operation.

Symbols used

The following table shows the symbols used in the following figures that appear in the order documents. Refer to the order documents for the mounting positions of the gear units.

Symbol	Meaning
	Breather plug
	Air outlet screw
	Inspection opening
	Oil filling plug
	Oil drain plug
	Oil dipstick
	Oil sight glass





4 Installation / Assembly

4.1 Required tools / resources

Not included in the scope of delivery:

- · Set of wrenches
- Torque wrench (for shrink disks)
- Motor mount on motor adapter
- · Mounting device
- · Compensation elements (shims, spacing rings)
- · Fasteners for input and output elements
- Mount the components according to the gear unit illustrations shown in Sec. "Gear unit foundation".

4.2 Installation tolerances

	Shaft end	Flange	
Primary gear unit MC	Diameter tolerance > 50 mm -> ISO m6 Center hole in accordance with DIN 332, shape D d, d1 > 85130 mm -> M24 > 130180 mm -> M30 > 180 mm -> -	Centering shoulder tolerance -> ISO m8	
P planetary gear units	Shaft end ISO m6	Centering shoulder ISO f8	

4.3 Prerequisites for assembly

Check that the following conditions have been met:

- The entries on the nameplate of the gearmotor match the voltage supply system.
- The drive has not been damaged during transportation or storage.
- Ambient temperature according to the nameplate.
- The drive must not be assembled in the following ambient conditions:
 - Potentially explosive area
 - Oils
 - Acids
 - Gases
 - Vapors
 - Radiation





4.4 Preliminary work

Cleaning the shaft



Ensure sufficient ventilation when using solvents. There is a risk of explosion. No open flames.



Risk of material damage.

Do not let the solvent come into contact with the sealing lips of the oil seals.

- You must clean the output shafts and flange surfaces thoroughly to ensure they are free of anti-corrosion agents, contamination or similar. Use a commercially available solvent.
- Protect all oil seals against direct contact with abrasive substances (such as sand, dust, shavings).

Extended storage

Please note: The service life of the bearing lubricant in the bearing is reduced if the unit is stored for ≥ 1 year.

P.MC.. gear units designed for "extended storage" usually have a higher oil level (CLP PG). Adjust the oil level before startup (see Sec. "Inspection / Maintenance").

Oil check



Fill the P.MC.. gear unit with the oil grade and quantity specified on the nameplate (see Sec. 'Startup' and 'Inspection and Maintenance'):

- Fill to volume suitable for the mounting position (see nameplate)
- · Check oil level through oil sight glass or with oil dipstick
- ightarrow see Sec. "Inspection and Maintenance" and "Design and Operating Notes".





4.5 Notes on installing the gear unit



- You must strictly adhere to the safety instructions in the previous sections.
- The nameplate indicates the most important technical data. Additional data relevant for operation is available in drawings, order confirmation or any orderspecific documentation.
- The gear unit must be installed with great care by qualified personnel. Damage caused by improper handling leads to exclusion of liability.
- Install/mount the gear unit only in the specified mounting position on a level, vibration-damping, and torsionally rigid support structure. Do not tighten housing legs and mounting flanges against each other.
- Work on the gear unit only when the machine is not in use. Prevent the drive unit from being unintentionally switched on (for example by locking the keyswitch or removing the fuses from the power supply). Attach an information sign near the on-switch to warn that the gear unit is being worked on.
- The oil level and drain plugs as well as the breather valves must be easily accessible.
- Use plastic inserts (2 to 3 mm thick) if there is a risk of electrochemical corrosion between the gear unit and the driven machine (connection between different metals such as cast iron and high-grade steel). Also fit the plugs with plastic washers. Ground the housing additionally use the grounding screws on the motor.
- Before startup, check whether the oil fill corresponds to the specified mounting position (→ information on the nameplate).
- The mounting position may only be changed after consultation with SEW-EURODRIVE. Warranty will become void without prior consultation.
- Only authorized personnel may assemble gear head units with motors and adapters. Please contact SEW-EURODRIVE.
- Do not weld anywhere on the drive. Do not use the drive as a ground point for welding work. Welding may destroy gearing parts and bearings.
- Protect rotating drive parts, such as couplings, gears, or belt drives using suitable devices that protect from contact.
- Units installed outdoors must be protected from the sun. Suitable protective devices are required, such as covers or roofs. When using these, avoid heat accumulation. The operator must ensure that foreign objects do not impair the function of the gear unit (e.g. by falling objects, or coverings).
- Gear units are supplied with suitable coating for use in damp areas or in the open air. Any damage to the coating (e.g. on the breather valve) must be repaired.
- For the standard mounting positions, the breather valve on the gear unit is mounted at the factory and activated if the gear unit is supplied without oil fill.
 Check the functionality of the breather valve and that it is seated correctly.
- Only mount couplings using a mounting device.




Installation / Assembly Flange mounting

4.6 Flange mounting



During gear unit mounting on the torque arm and/or machine frame, note the following.

- Only use screws of strength class 8.8 in accordance with the table below.
- Tighten the screws with the specified tightening torque.
- In addition, apply Loctite 640 to the screw contact surface [1].



Gear unit type P	Screws	Thread	Quan- tity	Strength classes	Tightening torque	Dimensions in [mm]						
	DIN				[Nm] \pm 20 %	ØS	Н	L	L1	ØA	ØB	ØC
P001MC	912/931	M20	20	8.8	310	22	36	70	34	410	370	330 f8
P011.MC	912/931	M20	20	8.8	310	22	38	70	32	450	410	370 f8
P021MC	912/931	M20	24	8.8	310	22	44	80	36	500	460	410 f8
P031MC	912/931	M24	20	8.8	540	26	46	80	34	560	510	460 f8
P041MC	912/931	M30	20	8.8	1100	33	60	110	50	620	560	480 f8
P051MC	912/931	M30	24	8.8	1100	33	60	110	50	650	590	530 f8
P061MC	912/931	M36	24	8.8	1830	39	70	130	60	760	690	610 f8
P071MC	912/931	M36	24	8.8	1830	39	80	140	60	840	770	690 f8
P081MC	912/931	M42	24	8.8	3200	45	80	150	70	920	840	750 f8






4.7 Installing torque arms for hollow shaft gear units

Single-sided torque arm



Do not place torque arms under strain during installation.

The reactive force due to the gear unit torque is absorbed via the torque arm with lever arm A. The illustration shows an example for absorption in a welded construction with design dimensions. Two supporting plates are welded with the suggested dimensions on the machine design. Once the gear unit has been mounted, a connecting cover plate is welded onto the two supporting plates. The force of the gear unit torque acts on the support, divided by the length of the lever arm A. The reaction force also acts on the gear unit and machine shafts.



51056AXX





Installation / Assembly Installing torque arms for hollow shaft gear units

Dimensions

Gear unit				Dimen	sions i	n [mm]				Quantity	Weight
type	Α	В	С	D1	D2	D5	0	S	Т	X	[Kg]
P001	650	60	50	335	370	410	25	22	880	16	31
P011	700	70	60	375	410	450	30	22	955	20	36
P021	750	90	70	415	460	500	35	22	1035	24	58
P031	800	110	90	465	510	560	35	26	1125	20	70
P041	900	150	120	485	560	620	40	33	1270	20	117
P051	1000	160	130	535	590	650	40	33	1390	24	147
P061	1200	180	150	615	690	760	50	39	1655	24	183
P071	1500	230	200	695	770	840	60	39	2020	24	315
P081	1600	230	200	755	840	920	70	45	2160	24	360

Tightening torques



- Only use class 8.8 screws in accordance with the table below.
- Tighten the screws with the specified tightening torque.

Gear unit type	Screws	Thread	Quantity	Strength classes	Tightening torque
	DIN				[Nm] ± 20 %
P001	912/931	M20	20	8.8	310
P011	912/931	M20	20	8.8	310
P021	912/931	M20	24	8.8	310
P031	912/931	M24	20	8.8	540
P041	912/931	M30	20	8.8	1100
P051	912/931	M30	24	8.8	1100
P061	912/931	M36	24	8.8	1830
P071	912/931	M36	24	8.8	1830
P081	912/931	M42	24	8.8	3200



Installation / Assembly Installing torque arms for hollow shaft gear units




Double-sided torque arms



Do not place torque arms under strain during installation.

The reaction torque from the gear unit output torque is absorbed via the lever arms A. The resulting reactive force is absorbed in the foundation. No reaction forces act on the gear unit and machine bearings. The torque arm must be screwed onto a structure or foundation provided by the customer using the foot screws.





Installation / Assembly Installing torque arms for hollow shaft gear units

Dimensions

Gear unit		Dimensions in [mm]										
type	Α	В	С	D1	D2	D3	D4	D5	D6	E	F	Н
P061	500	500	190	610	690	770	90	810	200	370	110	640
P071	600	500	190	690	770	850	90	890	200	470	110	640
P081	700	520	200	750	840	930	100	970	220	555	120	710

Gear unit		Dimensions in [mm]						Quantity	Weight		
type	J	K	L	M	N	0	S	Т	V	Х	[Kg]
P061	1045	460	595	240	70	60	39	1140	560	24	780
P071	1085	460	695	240	70	60	39	1340	560	24	895
P081	1195	520	810	260	80	70	45	1560	600	24	1292

Tightening torques



- Only use class 8.8 screws in accordance with the table below.
- Tighten the screws with the specified tightening torque.

Gear unit type	DIN screws	Thread	Quantity	Strength class	Tightening torque [Nm] \pm 20 %
P061	912/931	M36	8	8.8	1830
P071	912/931	M36	8	8.8	1800
P081	912/931	M42	8	8.8	3200





4.8 Assembly / disassembly of hollow shaft gear units and shrink discs

Assembly instructions




- · Do not disassemble the shrink disc before the first installation.
- Never tighten the locking screws until the machine shaft has been installed.
- · Do not tighten the locking screws in diametrically opposite sequence.
- On the outside surface of the shrink disc, the bore of the hollow shaft and the
 machine shaft must be absolutely free from any grease. This is an important
 factor for the reliability of torque transmission. Contaminated solvents and
 cleaning rags are not suitable for degreasing.



The shrink discs are delivered preassembled and ready for installation.

Assembly



- [1] Outer ring
- [5] Inner ring
- [2] Locking screw
- [6] Free from grease
- [3] Machine shaft
- [7] Free from grease

[4] Hub

- [8] Correct position of the shrink disc
- 1. Before installing the shrink disc, clean and degrease the hub [4] and the machine shaft [3]. This is a very important factor for the reliability of torque transmission.
- 2. Ensure that the dimensions of the machine shafts correspond to SEW specifications.

Inst Asso

Installation / Assembly

Assembly / disassembly of hollow shaft gear units and shrink discs

- 3. Slide the loose shrink disc onto the hub [4].
- 4. Check the correct position of the shrink disc [8]. The shrink disc is positioned correctly when it is in contact with the shaft shoulder.
 - Never tighten the locking screws [2] until the machine shaft [3] has been installed.
- 5. Install the machine shaft [3] or slide the hub [4] to a stop on the machine shaft [3]. Perform the mounting sequence slowly to allow the compressed air to escape around the outside of the shaft.
- 6. Tighten the locking screws [2] manuall first. Tighten all locking screws by working round equally (not in diametrically opposite sequence) in 1/4 turn increments.
- Observe the tightening torque → see the table below. Tighten the locking screws
 [2] by continuing to work round in 1/4 turns until you reach the tightening torque.
 Additionally, you can visually check to see that the front lateral surfaces are aligned to the outer [1] and inner rings [5].



Verify the type details on your shrink disc and choose the tightening torque.

Shrink disc type	Gear unit type	Screws	Rated torque [Nm]	Tightening torque [Nm] \pm 20 %
3191	P001	M16	41000	250
	P011	M16	75500	290
	P021	M16	95500	290
	P031	M20	134000	570
3181	P041	M20	194000	570
3101	P051	M20	255000	570
	P061	M24	405000	980
	P071	M24	525000	980
	P081	M24	720000	980





Disassembly



Danger of injury if disassembly is not performed correctly.

- 1. Loosen the locking screws [2], working around in 1/4 turns for each screws.
 - If the rings [1] [5] do not loosen from each other, unscrew as many screws as there are forcing threads and screw these equally into the forcing threads until the tapered bushing is pushed out of the tapered ring.
 - Under no circumstances should more locking screws be unscrewed than there are forcing threads present, else there is a potential risk of injury.
- 2. Remove the machine shaft [3] or pull the hub [4] off the customer shaft (first, remove any corrosion, which may have formed between the hub and the shaft end).
- 3. Remove the shrink disc from the hub [4].

Cleaning and lubrication

Do not disassemble and regrease the removed shrink disc before installing it again. Only clean the shrink disc if it is contaminated.

Next, regrease only the inner sliding surfaces of the shrink disc.

Use a solid lubricant with a friction factor of μ = 0.04.

Lubricant	Sold as
Molykote 321 R (lube coat)	Spray
Molykote spray (powder spray)	Spray
Molykote G Rapid	Spray or paste
Aemasol MO 19R	Spray or paste
Molykombin UMFT 1	Spray
Unimoly P5	Powder


4.9 Mounting a motor with motor adapter

Motor adapters [1] are available for mounting IEC / NEMA motors to P.MC series industrial gear units.




For mounting the coupling [2], refer to the notes in Sec. "Mounting couplings".

The figures below show the basic structure of the motor adapter.



- [1] Motor adapter
- [2] Coupling



- [1] Motor adapter
- [2] Coupling



Installation / Assembly Mounting a motor with motor adapter





When selecting a motor, take into account the permitted motor weight, the gear unit design and the type of gear unit mounting according to the following tables.

The following applies to all tables:

G_M = Motor weight

G_G = Gear unit weight

	Series / industrial gear unit design					
Mounting type	MC.PL	MC.RL				
Foot-mounted	$G_{M} \leq G_{G}$	$G_{M} \leq G_{G}$				
Shaft-mounted	$G_{M} \le 0.5G_{G}$	$G_{M} \leq G_{G}$				
Flange-mounted	$G_{M} \leq 0.5G_{G}$	$G_{M} \leq G_{G}$				

	Series / industrial gear unit design					
Mounting type	MC.PV	MC.RV				
Foot-mounted	G _M ≤ 1.5G _G	$G_{M} \leq G_{G}$				
Shaft-mounted	$G_{M} \leq G_{G}$	$G_{M} \leq G_{G}$				
Flange-mounted	$G_{M} \leq G_{G}$	$G_{M} \leq 0.75G_{G}$				

	Series / industrial gear unit design					
Mounting type	MC.PE	MC.RE				
Foot-mounted	$G_{M} \leq G_{G}$	G _M ≤ 1.5G _G				
Shaft-mounted	$G_{M} \leq G_{G}$	$G_{M} \leq G_{G}$				
Flange-mounted	$G_{M} \leq G_{G}$	$G_{M} \leq G_{G}$				



These tables are only valid for stationary operation. If gear unit is moving during (e.g. travel drives) please contact SEW-EURODRIVE.




Installation / Assembly Mounting a motor with motor adapter

Permitted motors for connection



When mounting motors, observe the center of gravity of the motor and the weight of the motor.



[1] Center of gravity of the motor



These tables only apply to the following correlation of motor size / weight Fq and dimension "x".

Moto	Motor size		х
IEC	NEMA	[N]	[mm]
132S	213/215	579	189
132M	213/215	677	208
160M	254/286	1059	235
160L	254/286	1275	281
180M	254/286	1619	305
180L	254/286	1766	305
200L	324	2354	333
225S	365	2943	348
225M	365	3237	348
250M	405	4267	395
280S	444	5984	433
280M	445	6475	433
315S	505	8142	485
315M	505	8927	485
315L		11772	555

The maximum approved weight of the attached motor F_q has to be reduced in a linear manner if the center of gravity distance x is increased. $F_{q \ max}$ cannot be increased if the center of gravity distance is reduced.



Please contact SEW-EURODRIVE in the following cases.

- When retrofitting motor adapters with a cooling air fan (not for motors of sizes 132S and 132M).
- If a motor adapter is removed, re-alignment is necessary.





5 Mechanical Installation Options

5.1 Important installation instructions



- You must strictly adhere to the safety instructions in the individual sections.
- Disconnect the motor from the power supply before starting work on couplings and secure it against unintentional restart.
- Work on the gear unit only when the machine is not in use.
- Never drive couplings, pinions, etc. onto the shaft end by hitting them with a hammer (damage to bearings, housing and the shaft!).
- In the case of belt pulleys, make sure the belt is tensioned correctly in accordance with the manufacturer's instructions.
- Input and output elements such as couplings must be equipped with a touch guard!
- Power transmission elements should be balanced after installation and must not give rise to excessive radial or axial forces.
- Only use a mounting device for installing input and output elements. Use the center bore and the thread on the shaft end for positioning.




Mounting is easier if you first apply lubricant to the output element or heat it up briefly (to 80-100 °C).

Installation note for couplings

Adjust the following misalignments when mounting couplings:

- a) Axial misalignment (maximum and minimum clearance)
- b) Offset misalignment (concentric running fault)
- c) Angular misalignment





Mechanical Installation Options Important installation instructions







Note:

The following methods for measuring angular and axial misalignment are important for complying with the mounting tolerances specified in Sec. "Mounting of couplings"!

Measuring of angular misalignment with a feeler gauge The following figure shows the measurement for angular misalignment (α) using a feeler gauge. When using this method, an accurate result is only achieved when the deviation of the coupling faces is eliminated by turning both coupling halves by 180° and the average value is then calculated from the difference (a_1 – a_2).



Measuring of angular misalignment using a micrometer dial The following figure shows the measurement for angular misalignment using a micrometer dial. This measuring method provides the same result as described under "Measuring angular offset with a feeler gauge" if the **coupling halves are rotated together**, for instance with one coupling pin, so that the needle of the micrometer dial does not move noticeably on the measuring surface.




A prerequisite for this measuring method is that there is no axial play in the shaft bearings when the shafts rotate. If this condition is not fulfilled, the axial play between the faces of the coupling halves must be eliminated. As an alternative, you can use two micrometer dials positioned on the opposite sides of the coupling (to calculate the difference of the two micrometer dials when rotating the coupling).




Mechanical Installation Options Important installation instructions



Measuring of offset misalignment using straight-edge and micrometer dial The following figure shows the measurement for offset misalignment using a straightedge. Permissible values for eccentricity are usually so small that the best measurement results can be achieved with a micrometer dial. If you **rotate one coupling half** together with the micrometer dial and divide the deviation by two, the micrometer dial will indicate the deviation and as a result the misalignment (dimension "b"), which includes the offset misalignment of the other coupling half.




Measuring of offset misalignment using a micrometer dial The following figure shows the measurement for offset misalignment using a **more accurate measuring method**. The **coupling halves** are **rotated together** without the tip of the micrometer dial moving on the measuring surface. The offset misalignment is obtained by dividing the deviation indicated on the micrometer dial (dimension "b").



Mechanical Installation Options Installing couplings

5.2 Installing couplings

ROTEX coupling



- [1] Coupling hub
- [2] Ring gear


The low-maintenance, elastic ROTEX coupling is capable of compensating radial and angular misalignment. Careful and exact alignment of the shaft ensures long service life of the coupling.



Mechanical Installation Options Installing couplings



Mounting the coupling halves onto the shaft





The shaft distance must be strictly observed (dimension E) to ensure axial play of the coupling.


			N	ounting	dimensions		ı	ocking screw
Coupling size	E [mm]	s [mm]	d _H [mm]	d _W [mm]	L ₁ (Alu / GG / GGG) [mm]	L ₁ (steel) [mm]	G	Tightening torque [Nm]
14	13	1.5	10	7	-	-	M4	2.4
19	16	2	18	12	26	-	M5	4.8
24	18	2	27	20	30	-	M5	4.8
28	20	2.5	30	22	34	-	M6	8.3
38	24	3	38	28	40	60	M8	20
42	26	3	46	36	46	70	M8	20
48	28	3.5	51	40	50	76	M8	20
55	30	4	60	48	56	86	M10	40
65	35	4.5	68	55	63	91	M10	40
75	40	5	80	65	72	104	M10	40
90	45	5.5	100	80	83	121	M12	69
100	50	6	113	95	92	-	M12	69
110	55	6.5	127	100	103	-	M16	195
125	60	7	147	120	116	-	M16	195
140	65	7.5	165	135	127	-	M20	201
160	75	9	190	160	145	-	M20	201
180	85	10.5	220	185	163	-	M20	201

1

Mechanical Installation Options Installing couplings

Mounting dimensions of ROTEX coupling in motor adapter

Tighten the set screws (A) to avoid axial play of the coupling.





The mounting dimensions specified in the following table only apply to mounting a ROTEX coupling in a motor adapter. They apply to all gear unit versions and gear ratios.



The shaft distance must be strictly observed (dimension E) to ensure axial play of the coupling.

BOTEV counting		Mounting dimensions				
ROTEX coupling size	IEC motor size	E [mm]	L ₁ [mm]	L ₂ [mm]	L ₃ [mm]	
R28 / 38	132	20	0	-17	3	
R38 / 45	160	24	1	0	25	
R42 / 55	180/200	26	-1	0	25	
R48 / 60	225	28	0	-3	25	
R55 / 70	225	30	0	- 5	25	
R65 / 75	250/280	35	0	-10	25	
R75 / 90	315	40	0	-15	25	
R90 / 100	315	45	-20	0	25	




Mechanical Installation Options

Installing couplings



Nor-Mex coupling, types G and E

The low-maintenance Nor-Mex couplings types G and E are torsionally flexible couplings capable of compensating axial, angular, and radial misalignments. Torque is transmitted via an elastic element with high damping properties, which is also oil and heat resistant. The couplings can be used for either direction of rotation and can be mounted in any position. The design of the Nor-Mex coupling type G allows to replace the elastic element [5] without movement of the shafts.




51667AXX

- [1] Coupling hub
- [2] Elastic element

- [1] Socket head screw
- [2] Tooth lock washer
- [3] Claw ring
- [4] Flange hub
- [5] Elastic element
- [6] Coupling hub

Mechanical Installation Options Installing couplings

Mounting instructions, mounting dimensions for Nor-Mex G coupling After having mounted the coupling halves, ensure that the recommended play (dimension S_2 for type G, dimension S_1 for type E) and the overall length (dimension L_G for type G and dimension L_E for type E) corresponds with the dimensions given in the following tables. Accurate alignment of the coupling (\rightarrow Sec. 'Mounting tolerances') ensures long service life.




Nor-Mex G		Mounting dimensions					
Coupling size	l _E [mm]	l _G [mm]	L _G [mm]	Permitted deviation S ₂ [mm]	Weight [kg]		
82	40	40	92	12±1	1.85		
97	50	49	113	14±1	3.8		
112	60	58	133	15±1	5		
128	70	68	154	16±1	7.9		
148	80	78	176	18±1	12.3		
168	90	87	198	21±1.5	18.3		
194	100	97	221	24±1.5	26.7		
214	110	107	243	26±2	35.5		
240	120	117	267	30±2	45.6		
265	140	137	310	33±2.5	65.7		
295	150	147	334	37±2.5	83.9		
330	160	156	356	40±2.5	125.5		
370	180	176	399	43±2.5	177.2		
415	200	196	441	45±2.5	249.2		
480	220	220	485	45±2.5	352.9		
575	240	240	525	45±2.5	517.2		



Mechanical Installation Options Installing couplings



Mounting dimensions of the Nor-Mex E coupling




	Mounting dimensions					
Nor-Mex E Coupling size	l _E [mm]	LE [mm]	Permitted deviation S ₁ [mm]	Weight [kg]		
67	30	62.5	2.5± 0.5	0.93		
82	40	83	3± 1	1.76		
97	50	103	3± 1	3.46		
112	60	123.5	3.5± 1	5		
128	70	143.5	3.5± 1	7.9		
148	80	163.5	3.5± 1.5	12.3		
168	90	183.5	3.5± 1.5	18.4		
194	100	203.5	3.5± 1.5	26.3		
214	110	224	4± 2	35.7		
240	120	244	4± 2	46.7		
265	140	285.5	5.5± 2.5	66.3		
295	150	308	8± 2.5	84.8		
330	160	328	8± 2.5	121.3		
370	180	368	8± 2.5	169.5		
415	200	408	8± 2.5	237		
480	220	448	8± 2.5	320		
575	240	488	8± 2.5	457		

-

Mechanical Installation Options Installing couplings

Mounting dimensions of the Nor-Mex G coupling in the motor adapter Tighten the set screws (A) to avoid axial play of the coupling.





The mounting dimensions specified in the following table only apply to mounting a Nor-Mex coupling in a motor adapter.

NOR-MEX	(G Coupling size	97	97	112	128	148	168	194	214
	IEC motor size	132	160	160/180	200	225	250/280	280/315	315
Gear unit size Gear ratio i	Mounting dimensions		[mm]						
All	S ₂	14	14	15	16	18	21	24	26
All	L ₃	3	25	25	25	25	25	25	25
MC3R02	L ₂	-	5	5	5	10	2	1	0
i = 14 63	L ₁	-	6	5	4	-3	2	0	-1
MC3R05	L ₂	-	5	5	5	4	2	5	0
i = 14 63	L ₁	-	6	5	4	3	2	-4	-1
MC3R08	L ₂	-	5	5	5	4	2	1	5
i = 14 63	L ₁	-	6	5	4	3	2	1	-6
Other P.MC	L ₂	– 5	5	5	5	4	2	1	0
i = 7.1 112	L ₁	-6	6	5	4	3	2	0	-1



Mechanical Installation Options Backstop FXM




5.3 Backstop FXM

The purpose of a backstop is to prevent undesirable reverse rotation. During operation, the backstop permits rotation in one specified direction of rotation only.



- Do not start up the motor in the blocking direction. Note the correct power supply of the motor to achieve the required direction of rotation. Running the motor in blocking direction might destroy the backstop!
- Consult SEW-EURODRIVE if you want to change the blocking direction.

The maintenance-free FXM type backstop is a centrifugally operated backstop with sprags that lift off. Once the lift-off speed is reached, the sprags completely lift off from the contact surface of the outer ring. The backstop is lubricated with gear oil. An arrow on the gearcase indicates the permitted direction of rotation [1] (\rightarrow following figure).




Changing the direction of rotation

To change the direction of rotation, turn the inner ring with the sprags by 180°. Pull out the inner ring with the sprags using a pulling-off device (not included in the scope of delivery) and replace turned by 180° (see next page).

1

Mechanical Installation OptionsBackstop FXM

... Backstop mounted outside the gear unit



51640AXX

[1] Outer ring

[2] Retaining screws

[3] Circlip

[4] Inner ring with cage and sprags

- 1. Drain the gear unit oil (\rightarrow Sec. "Inspection and Maintenance").
- 2. Loosen the retaining screws [2] of the backstop.
- 3. Remove the outer ring [1]. To facilitate dismounting, slightly turn the outer ring [1] in freewheeling direction.
- 4. Remove circlip [3], and inner ring with cage and sprags [4].
- 5. Turn the inner ring [4] with the sprags by 180° and replace the parts in reverse order. When mounting the backstop, do not apply pressure to the cage with the sprags but to the inner ring [4] only. Use the threaded holes on the inner ring [4] for mounting.
- 6. Fix the inner ring [4] with the circlip [3] in axial direction. Mount the outer ring [1] using the retaining screws [2]. Observe the tightening torques specified in the following table:

Screw size	Tightening torque [Nm]
M5	6
M6	10
M8	25
M10	48
M12	84
M16	206
M20	402
M24	696
M30	1420


- 7. Alter the direction arrow on the gearcase.
- 8. Refill the gear oil (\rightarrow Sec. Lubricants). Check the oil level.
- 9. After mounting, check that the backstop runs smoothly.



Mechanical Installation Options Backstop FXM



... with backstop mounted inside the gear unit



[1] Outer ring

[5] Sleeve

[2] Circlip

[6] Bearing cover

[3] Inner ring with cage and sprags

[7] Shims

[4] Supporting ring

[8] Extractor

- 1. Drain the gear unit oil (\rightarrow Sec. "Inspection and Maintenance").
- 2. Remove bearing cover [6], shims [7] and sleeve [5]. It is important that shims [7] and sleeve [5] between bearing cover [6] and outer ring [1] are not mixed up because they must be assembled in the correct order.
- 3. Remove the circlip [2] from the input shaft.
- 4. Remove the inner ring with cage and sprags [3] using a suitable extractor [8]. Use the threaded holes on the inner ring [3] for mounting.
- 5. Turn the inner ring [3] with the sprags by 180° and replace the parts in reverse order. When mounting the backstop, do not apply pressure to the cage with the sprags but to the inner ring [3] only.
- 6. When mounting the backstop, turn it in freewheeling direction so that the sprags move into the outer ring.
- 7. Fix the inner ring [3] with the circlip [2] in axial direction.
- 8. Mount sleeve [5], shims [7] and bearing cover [6] in reverse order.
- 9. Alter the direction arrow on the gearcase.
- 10.Refill the gear oil (\rightarrow Sec. Lubricants). Check the oil level.
- 11. After mounting, check that the backstop runs smoothly.



Mechanical Installation Options Shaft end pump SHP

5.4 Shaft end pump SHP

Usage

The maintenance-free shaft end pump SHP.. can be used to lubricate gear unit parts of gear unit sizes MC04 to MC09 that are not submerged in the oil bath. The shaft end pump can be operated in both directions of rotation.



A minimum input speed is necessary for correct working of the shaft end pump. Therefore, always consult SEW-EURODRIVE in the event of variable input speeds (e.g. with inverter controlled drives) or when changing the input speed range of an already delivered gear unit with shaft end pump.

Pump position

The pump is mounted externally to the gear unit and is directly driven by the input shaft or intermediate shaft of the gear unit. A high reliability of the pump function is ensured in this way. The pump position depends on the following factors:

- · Number of gear unit stages
- Gear unit type (helical or bevel-helical)
- · Shaft position of the gear unit
- Output shaft type



Check for interference of the shaft end pump with other surrounding structures.



Mechanical Installation Options Shaft end pump SHP



	Shaft positions					
	23	13 ¹⁾	24 ¹⁾	14		
MC2PS • Solid shaft						
MC3PS • Solid shaft						

1) The maximum permitted external loads on the output shaft are lower.

		Shaft positions						
	03	04	03 ¹⁾	04 ¹⁾				
MC2R • Solid shaft								
MC3RS • Solid shaft								

1) The maximum permitted external loads on the output shaft are lower.

5

Mechanical Installation Options

Shaft end pump SHP

Pump suction




- It is essential that the gear unit is sufficiently lubricated from the very beginning!
- Do not change the diameter of the tube / pipe connection!
- Do not open the pressure line [PRE]!
- If the shaft end pump does not build up pressure within 10 seconds after the gear unit has been started, please contact SEW-EURODRIVE.

Shaft end pump mounted on top of the P.MC.V.. gear unit



Danger of dry-start with shaft end pump mounted on top of gear unit.



- [1] Separate suction oil filling plug
- [2] Flow switch or visual flow indicator (not visible in the drawing)

It is essential that the oil pump begins to pump oil as soon as the main motor begins to rotate. If the pump does not begin to pump oil immediately, open the separate oil filling plug [1] and pour in oil (1-4 liters). Once the oil begins to circulate (check with flow switch or visual flow indicator [2]), close the separate oil filling plug.

This procedure is particularly important if the gear unit has been standing for a long period of time and there is air in the suction pipe and oil pump.






5.5 Oil heater

Oil heating is required to ensure lubrication at startup when the ambient temperature is low (e.g. cold start of the gear unit).


Purpose and basic design

The oil heater consists of three basic parts:

- 1. Resistor element in the oil bath ("Oil heater") with terminal box
- 2. Temperature sensor
- 3. Thermostat



- [1] Oil heater
- [2] Temperature sensor
- [3] Thermostat




58059AXX

- [1] Oil heater
- [2] Temperature sensor
- [3] Thermostat



5

Mechanical Installation Options Oil heater



- [1] Oil heater
- [2] Temperature sensor
- [3] Thermostat

Activation / deactivation behaviour

- The oil heater is activated when the factory set temperature is reached. This temperature setpoint depends on the following factors:
 - Forth splash/bath lubrication: on the pourpoint of the used oil
 - For pressure lubricated units: on the temperature at which the oil viscosity reaches a maximum of 2000 cSt

	Trip point for splash/bath lubrication [°C]					
ISO VG	680	460	320	220	150	100
Mineral oil	-7	-10	-15	-20	-25	-28
Synthetic oil		-30	-35	-40	-40	-45

	Trip point for pressure lubrication [°C]					
ISO VG	680	460	320	220	150	100
Mineral oil	+25	+20	+15	+10	+5	
Synthetic oil		+15	+10	+5	0	-5

The oil heater is deactivated when the set temperature is exceeded by 8 to 10°C.

Thermostat and oil heater are usually installed on the gear unit and are ready for operation but without electrical connections. Therefore, do the following before startup:

- 1. Connect the resistor element ("Oil heater") to the power supply
- 2. Connect the thermostat to the power supply






Technical data

Gear unit size	Current consumption oil heater	Voltage supply
Gear unit Size	[W]	[V _{AC}]
04 - 06	600	See separate data sheet ¹⁾
07 - 09	1200	See separate data sileet


¹⁾ Only use voltage specified in separate data sheet.

Electrical connection resistor element


Wiring examples with 230/400 V supply voltage



1-phase		
Voltage	230 V	
Phase voltage	230 V	
Mains voltage	400 V	
Resistor element voltage	230 V	




3-phase / star connection		
Voltage	230/400 V	
Phase voltage	230 V	
Mains voltage	400 V	
Resistor element voltage	230 V	



3-phase / delta connection		
Voltage	400 V	
Mains voltage	400 V	
Resistor element voltage	400 V	

Basic structure of thermostat



53993AXX


- [1] Setting range know [2] Degree of protection IP66 (IP54 in units with external reset) [3] 2 x PG 13.5 for cable diameter 6 mm \rightarrow 14 mm [4] SPDT contact system. Exchangeable

- [5] Capillary tube length up to 10 m[6] Stainless steel bellows[7] Polyamid housing





Basic structure of thermostat



A contactor must be used in the following cases:

- · 3-phase voltage supply
- · 2 heating rods
- · current ratings exceed nominal values of thermostat.



5

Mechanical Installation Options


Oil heater

Adjusting the setpoint

The setpoint is usually set at the factory. Proceed as follows for adjustment:


The range is set by using the setting knob [1] while at the same time reading the main scale [2]. Use a tool if the thermostat is equipped with a cap. The differential is set using the differential disk [3].

The size of the differential obtained for the relevant thermostat can be established by comparing the set main scale value and the scale value on the differential disk with the help of a nomogram.



53994AXX

- [1] Setting range knob
- [2] Main scale
- [3] Differential setting disk



- [A] Setting range
- [B] Obtained differential
- [C] Differential setting







5.6 Temperature sensor PT100

The temperature sensor PT100 can be used to measure the temperature of the oil in the gear unit.

Dimensions



Electrical connection



50534AXX

Technical data

- Sensor tolerance \pm (0.3 + 0.005 \times t), (corresponds to DIN IEC 751 class B), t = oil temperature
- Plug connector DIN 43650 PG9 (IP65)
- The tightening torque for the retaining screw in the back of the plug connector for electrical connection is 25 Nm.




Fan


5.7 Fan



Make sure air intake vents are not blocked or covered!

A fan can be mounted if the projected thermal power of the gear unit is exceeded. A fan can be retrofitted if the ambient conditions change after having installed the gear unit. The direction of rotation of the gear unit does not influence the operation of the fan.





58061AXX

Gear unit	A ₁	B ₁	Y ₄	Y ₁	Air ir	ntake
type		[mm]				Angle
PMC3RL02	158	160	70	100	109	
PMC3RL03	178	165	82	112	131	
PMC3RL04	198	185	90	120	131	
PMC3RL05	213	195	95	125	156	30°
PMC3RL06	232	220	100	130	156	30
PMC3RL07	262	230	105	135	156	
PMC3RL08	297	255	105	135	198	
PMC3RL09	332	265	110	140	226	



Flow switch



5.8 Flow switch

Usage

The flow switch is an electrical switch used for controlling the correct functioning of a pressure lubrication system (\rightarrow shaft end pump; \rightarrow motor pump) by checking the oil flow.

In deliveries since March 1, 2005, the flow switch is a standard feature for all gear units supplied with

- · a motor pump
- a shaft end pump with a flow rate of 8.5 l/min or higher.

Shaft end pumps with a flow rate below 8.5 l/min are equipped only with a visual flow indicator (\rightarrow Visual flow indicator) as standard (as of 2006).

If the flow rate exceeds 8.5 l/min, the gear unit is delivered with a visual flow indicator and flow switch (as of 2006).

Selection

SEW-EURODRIVE selects the flow switch. As standard, a flow switch of the type DW-R-20 is used. All the following technical data refer to this type.

Function


The oil flow pushes against a circular plate attached to a pendulum. The pendulum, which is regulated by a spring, moves on its pivot. A magnet attached to the end of the pendulum operates a movable reed contact. The switch unit itself is separated from the oil.


The flow switch has two switching points:

- 1. Switching point HIGH (lower limit of flow rate) → contact closed ON
- 2. Switching point LOW (upper limit of flow rate) → contact closed OFF

Flow switch

Dimensions





55964AXX

	d (inner thread)	NW (rated width)	ı	sw	Z	Z	L	н	Z
			[mm]						
Material				A+B+C	A+B	С	D	D	D
Dimension	R ³ / ₄ "	20	11	30	50	50	19	109	66

Material abbreviations:

A = Brass

B = Nickel-plated brass


C = Stainless steel

D = Stainless steel / PVC




For determining the exact position of the flow switch, refer to the order-specific dimension drawing.

Electrical connection









[1] Switching point HIGH


[2] Switching point LOW

[3] Setting range

[4] Blue

[5] Brown

[6] Yellow/green



[1] Switching point HIGH[2] Switching point LOW[3] Brown

[3] Setting range [6] Yellow/green

Connection data: 230 V; 1,5 A; 80 W, 90 V_{A max}

Degree of protection: IP 65

Maximum temperature of medium: 110 °C

Maximum ambient temperature: 70 °C

Maximum working pressure: 25 bar

Length of connecting cable: 1.5 m

Switch: Switch can be used as normally closed or

normally open contact; SPDT switch available on request


Switch hysteresis: ca. 5 %

Type	Switching point range ON	Switching point range OFF	Maximum flow rate
		[l/min]	
DW-R-20	8.5 - 12.0	6.6 - 11.0	80



Mechanical Installation Options Visual flow indicator

5.9 Visual flow indicator



- [1] Direction of oil flow
- [2] Glass
- [3] Oil distribution block

Usage

The visual flow indicator is a simple method of checking the functioning of a pressure lubrication system by visually checking the oil flow. The visual flow indicator is a standard feature in all gear units with oil pump (as of 2006).

Gear units with oil pump and a flow rate above 8.5 l/min are equipped with an electrical flow switch and visual flow indicator (as of 2006).

Function

The oil flow can be seen behind the glass [2]. If no oil flows and/or if there are air bubbles in the oil, check the function of the pump and suction pipes with connections.



It is easier to see the oil flow when the glasses [2] are clean and bright light is used on the other side of the oil distribution block.





5.10 Oil expansion tank and oil riser pipe



An oil expansion tank or an oil riser pipe may be necessary for vertical output shaft positions. Please refer to the order documents for information.

5.11 Connecting the oil/water cooling system



Follow the instructions in the separate manufacturer's documentation when connecting the oil/water cooling system.

5.12 Connecting the oil/air cooling system



Follow the instructions in the separate manufacturer's documentation when connecting the oil/water cooling system.

5.13 Connecting the motor pump



Follow the instructions in the separate manufacturer's documentation when connecting the motor pump.



6 Startup

6.1 Startup of gear units



- It is essential to adhere to the safety notes in Sec. "Safety Notes."
- It is absolutely necessary to avoid open flames or sparking when working with the gear unit!
- Take preventive measures to protect people from the solvent vapors generated by the vapor phase inhibitor!
- Before startup, check for correct oil level! For lubricant fill quantities, refer to Sec. "Lubricants."
- For gear units with long-term protection: Replace the screw plug on the location indicated by the breather plug (Position \rightarrow Sec. "Mounting Positions").
- If doing maintenance or/and oil-filling activities on the gear unit check the surface temperature in advance. Danger of burns (hot oil inside inside gear unit!)!

Before startup

- Remove dust and dirt completely from gear unit surface.
- For gear units with long-term protection: Remove the gear unit from the seaworthy protection box.
- Remove the corrosion protection agent from the gear unit parts. Make sure gaskets, sealing surfaces and sealing lips are not damaged by mechanical abrasion, etc.
- Before filling the gear unit with the correct oil grade and volume, drain the remaining amount of protection oil. To do so, unscrew the oil drain plug and drain the remaining protection oil. Thread the oil drain plug back in place.



- Remove the oil filling plug (Position → Sec. "Mounting Positions"). Use a funnel to fill
 the oil (filter mesh max. 25 µm). Fill the gear unit with the correct oil grade and volume
 (→ Sec. "Nameplate"). The oil volume specified on the nameplate of the gear unit is
 a reference value. The mark on the dipstick is the decisive indicator of the
 correct oil level. Check for correct oil level (= below the "max" mark on the dipstick)
 using the oil dipstick. After having filled the oil, replace the oil filling plug.
- For gear units with steel oil expansion tank (\rightarrow 6.3 Startup of MC gear units with steel expansion tank).



- For gear units with oil sight glass (chapter 7.3): Visually check for correct oil level (= oil is visible in the oil sight glass).
- Make sure that rotating shafts as well as couplings are equipped with suitable protective covers.
- If the gear unit has a motor pump, check for proper functioning of the pressure lubricating system. Make sure that monitoring devices are connected properly.
- After an extended period of storage (max. two years), have the gear unit operate without load with the correct oil fill (→ Sec. "Nameplate"). This way, the correct functioning of the lubricating system and particularly the oil pump is ensured.
- If the gear unit is equipped with a fan on the input shaft, check for free air intake within the specified angle (→ Sec. "Fan").





Running-in period

SEW-EURODRIVE recommends running-in the gear unit as first startup phase. Increase load and revolutions in two to three steps up to maximum level. The running-in phase takes about 10 hours.

Check the following points during the running-in phase:

- Verify the power values specified on the nameplate because their frequency may be a decisive factor for the service life of the gear unit.
- Does the gear unit run smoothly?
- Are there vibrations or unusual running noise?
- Are there signs of oil leakages on the gear unit?



For further information and troubleshooting, refer to Sec. "Malfunctions."

6.2 Startup of gear units with long-term protection

Adhere to the following points for gear units with long-term protection:

Anti-corrosion agent:



Ensure sufficient ventilation when using solvents. There is a risk of explosion. No open flames.



Risk of material damage.

Do not let the solvent come into contact with the sealing lips of the oil seals.

Remove the corrosion protection agent from the gear unit parts. Make sure gaskets, sealing surfaces and sealing lips are not damaged by mechanical abrasion, etc.

Oil level


Since the gear units under "long-term protection" are delivered complete with oil, the correct oil volume and oil level should be checked before startup.

→ Correct the oil level to the appropriate fill level.

Breather plug:

Replace the screw plug by the enclosed breather filter.





6.3 Starting up gear units with backstop



Ensure that the direction of rotation of the motor is correct for gear units with backstop.

6.4 Shutting down gear units



Turn off the drive unit. Prevent the drive unit from unintentionally starting up. Put an information sign near the ON switch.

If the gear unit will not operated for an extended period of time, you must activate it regularly at intervals of approx. 2-3 weeks.

If the gear unit will not operated for a period **longer than nine months**, additional corrosion protection is required:

- Corrosion protection for the interior of gear units with splash or oil bath lubrication:
 - Fill the gear unit up to the breather plug with the oil grade specified on the nameplate.
 - Set the planetary gear unit in no-load running operation for a short period of time.

Exterior corrosion protection:

- · Clean the surfaces
- Grease the shaft around the sealing lip to separate the sealing lip of the oil seal and the corrosion protection
- Apply a wax-based protective coating to shaft ends and unpainted surfaces as corrosion protection.



Refer to the "Startup" section before restarting the gear unit.



Inspection and Maintenance

Shutting down gear units



7 Inspection and Maintenance



- · Strictly observe the safety notes in the individual sections.
- All maintenance work must be carried out carefully by qualified personnel.
- Work on the gear unit and additional equipment only when the machine is not in use. Prevent the drive unit from starting up unintentionally (for example by locking the keyswitch or removing the fuses from the power supply). Attach an information sign near the on-switch to warn that the gear unit is being worked on.
- Use only OEM spare parts according to the delivered spare parts lists.
- If you remove the gearcase cover, you must apply new sealing compound to the sealing surface. Else the sealing properties of the gear unit might be impaired. Contact SEW-EURODRIVE in this case.
- · During subsequent work, protect the gear unit from ingress of foreign objects.



Danger of burns

Touching the gear unit when it has not been cooled will result in burns.

Never touch the gear unit during operation or in the cool down phase once the unit has been switched off.



Inspection and Maintenance Inspection and Maintenance intervals

7.1 Inspection and Maintenance intervals

Maintenance interval	What to do?		
• Daily	Check the housing temperature: with mineral oil: max 90 °C with synthetic oil: max. 100 °C		
	Check gear unit noiseCheck gear unit for signs of leakage		
Every 3000 hours of operation, at least every 6 months:	 Check the oil and oil level. Check the oil: If the gear unit is operated outdoors or in humid conditions, check the water content of the oil. The water content must not exceed 0.05 % (500 ppm). Fill labyrinth seals with grease. Use about 30 g grease per grease nipple. Clean breather plug 		
Depending on the operating con- ditions, at the latest every 12 months	 Change the mineral oil (→ Sec. "Inspection and Maintenance") Check whether retaining screws are tightly secured Check contamination and condition of the oil/air cooling system Check the condition of the oil/water cooling system Clean oil filter, replace filter element if necessary 		
Depending on the operating con- ditions, at the latest every 3 years	Change the synthetic oil (→ Sec. "Inspection and Maintenance")		
Varying (depending on external factors)	 Repair or renew the surface/anticorrosion coating Clean the gearcase surface and fan Check the oil heater: Are all connection cables and terminals tightened securely and free from corrosion? Clean incrusted elements (e.g. heating element) and replace, if required (→ Sec. "Inspection and Maintenance") 		






7.2 Lubricant change intervals

Change the oil more frequently when using special versions subject to more severe/aggressive environmental conditions!



Mineral CLP lubricants and synthetic polyalphaolefin-based (PAO) lubricants are used for lubrication. The synthetic lubricant CLP HC (according to DIN 51502) shown in the following figure corresponds to the PAO oils.



- (1) Hours of operation
- (2) Sustained oil bath temperature
- Average value per oil type at 70 °C



Inspection and Maintenance

Checking the oil level

7.3 Checking the oil level



- Do not mix different synthetic lubricants and do not mix synthetic with mineral lubricants!
- The positions of the oil level plug, drain plug, and breather valve depends on the mounting position. Refer to the mounting position diagrams.
- · Mineral oil is used as standard lubricant.
- 1. Work on the gear unit only when the machine is not in use.
- 2. Secure the drive unit against unintentional power-up.



Wait until the gear unit has cooled off - Danger of burns!

- 3. For gear units with oil dipstick:
 - · Unscrew the oil dipstick and remove it.
 - Clean the oil dipstick and re-insert it into the gear unit (do **not** screw in tightly).
 - Remove dipstick again and check oil level. Correct, if necessary: the oil level is correct when it is between the oil level mark (= maximum oil level) and the end of the dipstick (= minimum oil level)
- 4. For gear units with oil sight glass:
 - Visually check for correct oil level (= middle of oil sight glass).

7.4 Checking the oil consistency

- 1. Work on the gear unit only when the machine is not in use.
- 2. Secure the drive unit against unintentional power-up.



Wait until the gear unit has cooled off - Danger of burns!

- 3. Remove a little oil from the oil drain plug.
- 4. Check the oil consistency:
 - For more detailed information on checking the oil for water content and viscosity, contact your lubricant manufacturer.
 - Contact SEW-EURODRIVE if the oil is heavily contaminated.



Inspection and Maintenance

Changing the oil



7.5 Changing the oil



- When changing the oil, always refill the gear unit with the grade of oil that was
 used before. Mixing oil of different grade or manufacturer is not permitted.
 Especially synthetic oils may not be mixed with mineral oils or other synthetic
 oils. If you switch from mineral oil to synthetic oil, or from synthetic oil on a
 certain basis to synthetic oil with a different basis, you will have to flush the
 gear unit thoroughly with the new oil.
- Refer to the lubrication table in section 9 to determine which oils from the various lubricant manufacturers can be used.
- Information such as the oil grade, oil viscosity and reqired oil volume is listed on the nameplate of the gear unit.
- The oil volume specified on the nameplate is an approximate quantity. The mark on the oil sight glass or dipstick is the decisive indicator of the correct oil level.
- · Only change the oil when the gear unit is at operating temperature.
- When changing the oil, flush the housing thoroughly with oil to remove oil sludge, oil residue, and abrasion. Use the same grade of oil that is used to operate the gear unit. Viscous oil must be heated up first. Fill with fresh oil only after all residues have been removed.
- The position of the oil level plug, oil drain plug and the breather valve depends on the mounting position. Refer to the diagrams of the mounting positions.

Procedure

- 1. Work on the gear unit only when the machine is not in use.
- 2. Secure the drive unit against unintentional power-up.



Wait until the gear unit has cooled off - Danger of burns!



The gear unit must still be warm otherwise the high viscosity of excessively cold oil will make it more difficult to drain the oil correctly.



When changing the oil, clean the gearcase thoroughly to remove oil residues and abrasion. Use the same oil grade as for the operation of the gear unit.



If your gear unit is equipped with an oil expansion tank, let the gear unit cool off until it reaches ambient temperature. The reason is that there might still be oil in the oil expansion tank which might leak through the oil filling hole!



Any dripping oil must be removed immediately with an oil binding agent.

3. Place a container underneath the oil drain plug.



Inspection and MaintenanceChecking and cleaning the breather plug

- 4. Remove the oil filling plug, breather plug and oil drain plugs. When using a steel oil expansion tank, also remove the air outlet screw on the air expansion tank. To drain all the oil, blow air through the breather into the oil expansion tank. As a result, the rubber membrane lowers and forces the remaining oil out. The lowering membrane compensates the pressure, which facilitates filling the new oil.
- 5. Drain all the oil.
- 6. Screw in the oil drain plug.
- Use a funnel to fill the oil (filter mesh max. 25 mm). Fill new oil of the same type as the old oil via the oil filling plug (if you want to change the oil type, contact our customer service first).
 - Fill the oil according to the volume specified on the nameplate ((→ Sec. "Nameplate"). The oil volume specified on the nameplate is an approximate value. The marks on the oil dipstick indicate the correct oil level.
 - Check whether the oil level is correct using the oil dipstick
- 8. Screw the oil level plug back in If your gear unit is equipped with a steel oil expansion tank, also screw in the air outlet screw.
- 9. Screw in the breather plug.
- 10. Clean the oil filter, replace the filter element if necessary (when using an external oil/air or oil/water cooling system).

7.6 Checking and cleaning the breather plug

The breather plug must be cleaned if there is a layer of dust and also before the expiration of a minimum period of three months.

To do so, remove the breather plug, clean it with benzine or a similar cleaning agent, and dry or blow the breather plug with compressed air. Prevent foreign objects from entering into the gear unit.





8 Malfunctions



- Strictly observe the safety notes in the individual sections.
- For eliminating malfunctions, the gear unit and additional equipment must be deactivated. Prevent the drive unit from starting up unintentionally (for example by locking the keyswitch or removing the fuses from the power supply). Attach an information sign near the ON switch to warn that the gear unit is being worked on.



Danger of burns

Touching the gear unit when it has not been cooled will result in burns.

Never touch the gear unit during operation or in the cool down phase once the unit has been switched off.



Malfunctions that occur during the warranty period that require repair to the gear unit may only be resolved by SEW-EURODRIVE.

After expiration of the warranty period, we recommend that our customers contact our customer service in the event of malfunctions whose cause is not clear.

8.1 Customer service

Please have the following information to hand if you require the assistance of our customer service:

- · Complete nameplate data
- · Type and extent of the problem
- Time the problem occurred and any accompanying circumstances
- Assumed cause





8.2 Gear unit malfunctions

Malfunction	Possible cause	Remedy
Unusual, regular running noise	A Meshing/grinding noise: Bearing damage B Knocking noise: Irregularity in the gearing	 A Check the oil (→ Sec. "Inspection and Maintenance), replace bearings B Contact customer service
Unusual, irregular run- ning noise	Foreign bodies in the oil	Check the oil (see Sec. "Inspection and Maintenance") Stop the drive, contact customer service
Unusual noise in the area of the gear unit mounting	Gear unit mounting has loosened	Tighten retaining screws and nuts to the specified torque Replace the damaged / defective retaining screws or nuts
Operating temperature too high	A Too much oil B Oil too old C The oil is heavily contaminated D Gear units with fan: air intake opening / gearcase contaminated E Shaft end pump defective F Malfunctions of oil/air or oil/water cooling system	 A Check the oil level, correct if necessary (→ Sec. "Inspection and Maintenance") B Check when the oil was changed last time; change oil if necessary (→ Sec. "Inspection and Maintenance") C Change the oil (→ Sec. "Inspection and Maintenance") D Check the air intake opening and clean if necessary, clean gearcase E Check shaft end pump; replace if necessary F Observe the separate operating instructions of the oil/water and oil/air cooling system.
Bearing point tempera- tures too high	A Oil not enough B Oil too old C Shaft end pump defective D Bearing damaged	 A Check the oil level, correct if necessary (→ Sec. "Inspection and Maintenance") B Check when the oil was changed last time; change oil if necessary (→ Sec. "Inspection and Maintenance") C Check shaft end pump; replace if necessary D Check bearing and replace if necessary, contact customer service
Oil leaking ¹⁾ • from cover plate • From the gear cover plate • from bearing cover • from mounting flange • from output/input end oil seal	A Gasket on cover plate / gearcase cover / bearing cover / mounting flange leaking B Sealing lip of the oil seal turned up C Oil seal damaged/worn	 A Tighten the bolts on the respective cover plate and observe the gear unit. If oil still leaks: Contact customer service B Vent the gear unit (→ Sec. "Mounting Positions") Observe the gear unit. If oil still leaks: Contact customer service C Contact customer service
Oil leaking from oil drain plug breather plug	A Too much oil B Drive operated in incorrect mounting position C Frequent cold starts (oil foams) and/or high oil level	A Correct the oil volume (see Sec. "Inspection and Maintenance) B Mount the breather plug correctly (see order documents) and correct the oil level (see nameplate)
Malfunctions of oil/air or oil/water cooling system		Observe the separate operating instructions for the oil/water and oil/air cooling system.
Operating temperature at backstop too high	Damaged / defective backstop	Check backstop; replace if necessaryContact customer service

¹⁾ It is normal for small amounts of oil/grease to emerge from the oil seal during the running-in phase - (24 hour running time, see also DIN 3761).





9 Lubricants

9.1 Guidelines for lubricant selection

General information

Unless a special arrangement is made, SEW-EURODRIVE delivers the P.MC.. gear units without an oil fill.



Before startup, ensure that the gear unit is filled with the correct oil grade and volume. You find the corresponding information on the gear unit nameplate and the lubricant table in the following section.



The most important factors for selecting the lubricant are the oil grade and viscosity specified on the nameplate. The specified viscosity / oil grade are chosen for the operating conditions agreed upon in the contract. Any deviation from these conditions requires consultation with SEW-EURODRIVE.



This lubricant recommendation does not represent a guarantee as to the quality of the lubricant delivered by each respective supplier. The lubricant manufacturers are responsible for the quality of their products.



Do not mix different synthetic lubricants and do not mix synthetic with mineral lubricants.

If you have selected synthetic oil because of the operating termperature or oil change intervals, SEW-EURODRIVE recommends that you use polyalphaolefin-based oil (PAO).




9.2 Lubricant table

General information

The lubricant table on the following page shows the permitted lubricants for SEW-EURODRIVE gear units. Please refer to the following legend for the lubricant table.

Legend for the lubricant table

Abbreviations used, meaning of shading, and notes:



Notes on the lubricant table



- The temperature ranges are to be considered as guide values. The decisive factor is the viscosity information on the nameplate.
- Contact SEW-EURODRIVE if you operate the unit under extreme conditions, such as cold, heat, or if the operating conditions differ from those based on the project planning.

LubricantsLubricant table



Lubricant table

01763198_3

									1	_
TOTAL		Carter SH 150			Carter SH 220		Carter SH 320		Carter SH 460	Renolin CLP680
(© Castrol			Alphamax 220 Tribol 1710/ 220	BM 220	Optigear Synthetic X 220	Alphamax 320 Tribol Optigear	Tribol Tribol Tribol Tribol 1710/320 Optigear Synthetic A320 Optigear Synthetic X 320	Alphamax 460 Tribol 1100 / 460 Optigear BM 460	Tribol 1510/ 460 Tribol 1710/ 460 Optigear Synthetic A460 Optigear Synthetic X 460	Tribol Optigear 1100 / 680 BM 680
Q8	Q8 Goya NT 150	Q8 ELGRECO 150	Q8 Goya NT 220		Q8 ELGRECO 220	Q8 Goya NT 320	Q8 ELGRECO 320	Q8 Goya NT 460	Q8 ELGRECO 460	Q8 Goya NT 680
FUCES	Renolin CLP150Plus	Renolin Unisyn CLP 150	Renolin CLP220Plus		Renolin Unisyn CLP 220	Renolin CLP320Plus	Renolin Unisyn CLP 320	Renolin CLP460Plus	Renolin Unisyn CLP 460	
**************************************			Meropa 220		Pinnacle EP 220	Meropa 320	Pinnacle EP 320	Meropa 460	Pinnacle EP 460	Meropa 680
dq	BP Energol GX-XF 150	Enersyn EP-XF 150 Enersyn SG-XP 150	BP Energol GX-XF 220		Enersyn EP -XF 220 Enersyn SG-XP 220	BP Energol GX-XF 320	Enersyn EP-XF 320 Enersyn SG-XP 320	BP Energol GX-XF 460	Enersyn EP-XF 460 Enersyn SG-XP 460	BP Energol GX-XF 680
	Degol BG Plus 150	Degol PAS 150 Degol GS 150	Degol BG Plus 220		Degol PAS 220 Degol GS220	Degol BG Plus 320	Degol PAS 320 Degol GS 320	Degol BG Plus 460	Degol PAS 460 Degol GS 460	Degol BG Plus 680
KOREGRA	KLÜBER GEM 1-150N	Klübersynth GEM4-150N	KLÜBER GEM 1-220N		Klübersynth GEM4-220N	KLÜBER GEM 1-320N	Klübersynth GEM4-320N	KLÜBER GEM 1-460N	Klübersynth GEM4-460N	KLÜBER GEM 1-680N
Shell			Omala Oil F220		Omala Oil HD 220	Omala Oil F320	Omala Oii HD 320	Omala Oil F460	Omala Oii HD 460	
Mobil®			Mobilgear XMP220		Mobilgear SHC XMP220	Mobilgear XMP320	Mobilgear SHC XMP320 Mobil SHC 632	Mobilgear XMP460	Mobilgear SHC XMP460 Mobil SHC 634	Mobilgear XMP680
ISO VG class	VG 150	VG 150	VG 220		VG 220	VG 320	VG 320	VG 460	VG 460	VG 680
(OSI) NIQ	CLP	CLP PAO	CLP		CLP PAO	CLP	CLP PAO	CLP	CLP PAO	CLP
			+25		+30	+40	+40	40	9+	
1) °C -40 0			-10		-35	0	-30	ιģ	-20	
				ان ا		MCR				

9.3 Lubricant fill quantities



The lubricant fill quantity is specified in your order document or on the nameplate.



The two gear units have a common oil chamber.



In case of a pivoted mounting position, refer to the oil fill quantity specified on the nameplate.

9.4 Sealing grease

The below mentioned greases can be used as

- · Sealing grease
- Bearing grease for the lower LSS bearings for gear units with Drywell sealing system

SEW-EURODRIVE recommends the grease types listed in below table for operating temperatures from – 30 $^{\circ}$ C to +100 $^{\circ}$ C.

Lubricating grease properties:

- · Contains EP additives
- · Hardness class NLGI2

Supplier	Oil	
Aral	Aralub HLP2	
ВР	Energrease LS-EPS	
Castrol	Spheerol EPL2	
Chevron	Dura-Lith EP2	
Elf	Epexa EP2	
Esso	Beacon EP2	
Exxon	Beacon EP2	
Gulf	Gulf crown Grease 2	
Klüber	Centoplex EP2	
Kuwait	Q8 Rembrandt EP2	
Mobil	Mobilux EP2	
Molub	Alloy BRB-572	
Optimol	Olista Longtime 2	
Shell	Alvania EP2	
Texaco	Multifak EP2	
Total	Multis EP2	
Tribol	Tribol 3030-2	





89

Adressenliste

Deutschland			
Hauptverwaltung Fertigungswerk Vertrieb	Bruchsal	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 D-76646 Bruchsal Postfachadresse Postfach 3023 • D-76642 Bruchsal	Tel. +49 7251 75-0 Fax +49 7251 75-1970 http://www.sew-eurodrive.de sew@sew-eurodrive.de
Service Competence Center	Mitte Getriebe / Motoren	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 1 D-76676 Graben-Neudorf	Tel. +49 7251 75-1710 Fax +49 7251 75-1711 sc-mitte-gm@sew-eurodrive.de
	Mitte Elektronik	SEW-EURODRIVE GmbH & Co KG Ernst-Blickle-Straße 42 D-76646 Bruchsal	Tel. +49 7251 75-1780 Fax +49 7251 75-1769 sc-mitte-e@sew-eurodrive.de
	Nord	SEW-EURODRIVE GmbH & Co KG Alte Ricklinger Straße 40-42 D-30823 Garbsen (bei Hannover)	Tel. +49 5137 8798-30 Fax +49 5137 8798-55 sc-nord@sew-eurodrive.de
	Ost	SEW-EURODRIVE GmbH & Co KG Dänkritzer Weg 1 D-08393 Meerane (bei Zwickau)	Tel. +49 3764 7606-0 Fax +49 3764 7606-30 sc-ost@sew-eurodrive.de
	Süd	SEW-EURODRIVE GmbH & Co KG Domagkstraße 5 D-85551 Kirchheim (bei München)	Tel. +49 89 909552-10 Fax +49 89 909552-50 sc-sued@sew-eurodrive.de
	West	SEW-EURODRIVE GmbH & Co KG Siemensstraße 1 D-40764 Langenfeld (bei Düsseldorf)	Tel. +49 2173 8507-30 Fax +49 2173 8507-55 sc-west@sew-eurodrive.de
	Drive Service	Hotline / 24-h-Rufbereitschaft	+49 180 5 SEWHELP +49 180 5 7394357
	Weitere Ansch	riften über Service-Stationen in Deutschland auf	Anfrage.

Frankreich					
Fertigungswerk Vertrieb Service	Haguenau	SEW-USOCOME 48-54, route de Soufflenheim B. P. 20185 F-67506 Haguenau Cedex	Tel. +33 3 88 73 67 00 Fax +33 3 88 73 66 00 http://www.usocome.com sew@usocome.com		
Fertigungswerk	Forbach	SEW-EUROCOME Zone Industrielle Technopole Forbach Sud – B. P. 30269 F-57604 Forbach Cedex	Tel. +33 3 87 29 38 00		
Montagewerke Vertrieb Service	Bordeaux	SEW-USOCOME Parc d'activités de Magellan 62, avenue de Magellan - B. P. 182 F-33607 Pessac Cedex	Tel. +33 5 57 26 39 00 Fax +33 5 57 26 39 09		
	Lyon	SEW-USOCOME Parc d'Affaires Roosevelt Rue Jacques Tati F-69120 Vaulx en Velin	Tel. +33 4 72 15 37 00 Fax +33 4 72 15 37 15		
	Paris	SEW-USOCOME Zone industrielle 2, rue Denis Papin F-77390 Verneuil l'Etang	Tel. +33 1 64 42 40 80 Fax +33 1 64 42 40 88		
	Weitere Anschriften über Service-Stationen in Frankreich auf Anfrage.				

Algerien				
Vertrieb	Alger	Réducom 16, rue des Frères Zaghnoun Bellevue El-Harrach 16200 Alger	Tel. +213 21 8222-84 Fax +213 21 8222-84	

Argentinien			
Montagewerk Vertrieb Service	Buenos Aires	SEW EURODRIVE ARGENTINA S.A. Centro Industrial Garin, Lote 35 Ruta Panamericana Km 37,5 1619 Garin	Tel. +54 3327 4572-84 Fax +54 3327 4572-21 sewar@sew-eurodrive.com.ar



Australien			
Montagewerke Vertrieb Service	Melbourne	SEW-EURODRIVE PTY. LTD. 27 Beverage Drive Tullamarine, Victoria 3043	Tel. +61 3 9933-1000 Fax +61 3 9933-1003 http://www.sew-eurodrive.com.au enquires@sew-eurodrive.com.au
	Sydney	SEW-EURODRIVE PTY. LTD. 9, Sleigh Place, Wetherill Park New South Wales, 2164	Tel. +61 2 9725-9900 Fax +61 2 9725-9905 enquires@sew-eurodrive.com.au
	Townsville	SEW-EURODRIVE PTY. LTD. 12 Leyland Street Garbutt, QLD 4814	Tel. +61 7 4779 4333 Fax +61 7 4779 5333 enquires@sew-eurodrive.com.au
Belgien			
Montagewerk Vertrieb Service	Brüssel	SEW Caron-Vector S.A. Avenue Eiffel 5 B-1300 Wavre	Tel. +32 10 231-311 Fax +32 10 231-336 http://www.sew-eurodrive.be info@caron-vector.be
Brasilien			
Fertigungswerk Vertrieb Service	Sao Paulo	SEW-EURODRIVE Brasil Ltda. Avenida Amâncio Gaiolli, 50 Caixa Postal: 201-07111-970 Guarulhos/SP - Cep.: 07251-250	Tel. +55 11 6489-9133 Fax +55 11 6480-3328 http://www.sew.com.br sew@sew.com.br
	Weitere Anschrift	en über Service-Stationen in Brasilien auf Anfrage	
Bulgarien			
Vertrieb	Sofia	BEVER-DRIVE GmbH Bogdanovetz Str.1 BG-1606 Sofia	Tel. +359 2 9151160 Fax +359 2 9151166 bever@fastbg.net
Chile			
Montagewerk Vertrieb Service	Santiago de Chile	SEW-EURODRIVE CHILE LTDA. Las Encinas 1295 Parque Industrial Valle Grande LAMPA RCH-Santiago de Chile Postfachadresse Casilla 23 Correo Quilicura - Santiago - Chile	Tel. +56 2 75770-00 Fax +56 2 75770-01 http://www.sew-eurodrive.cl ventas@sew-eurodrive.cl
China			
Fertigungswerk Montagewerk Vertrieb Service	Tianjin	SEW-EURODRIVE (Tianjin) Co., Ltd. No. 46, 7th Avenue, TEDA Tianjin 300457	Tel. +86 22 25322612 Fax +86 22 25322611 gm-tianjin@sew-eurodrive.cn http://www.sew-eurodrive.com.cn
Montagewerk Vertrieb Service	Suzhou	SEW-EURODRIVE (Suzhou) Co., Ltd. 333, Suhong Middle Road Suzhou Industrial Park Jiangsu Province, 215021 P. R. China	Tel. +86 512 62581781 Fax +86 512 62581783 suzhou@sew.com.cn
	Weitere Anschrift	en über Service-Stationen in China auf Anfrage.	
Dänemark			
Montagewerk Vertrieb Service	Kopenhagen	SEW-EURODRIVEA/S Geminivej 28-30 DK-2670 Greve	Tel. +45 43 9585-00 Fax +45 43 9585-09 http://www.sew-eurodrive.dk sew@sew-eurodrive.dk
Elfenbeinküste			
Vertrieb	Abidjan	SICA Ste industrielle et commerciale pour l'Afrique 165, Bld de Marseille B.P. 2323, Abidjan 08	Tel. +225 2579-44 Fax +225 2584-36





Estland				
			T	
Vertrieb	Tallin	ALAS-KUUL AS Reti tee 4	Tel. +372 6593230 Fax +372 6593231	
		EE-75301 Peetri küla, Rae vald, Harjumaa	veiko.soots@alas-kuul.ee	
		·		
Finnland				
Montagewerk	Lahti	SEW-EURODRIVE OY	Tel. +358 201 589-300	
Vertrieb Service		Vesimäentie 4 FIN-15860 Hollola 2	Fax +358 3 780-6211 sew@sew.fi	
Gervice		1 114-13000 1101101a 2	http://www.sew-eurodrive.fi	
			· · · · · · · · · · · · · · · · · · ·	
Gabun				
Vertrieb	Libreville	Electro-Services	Tel. +241 7340-11	
		B.P. 1889 Libreville	Fax +241 7340-12	
		Librariila		
Griechenland				
Vertrieb	Athen	Christ. Boznos & Son S.A.	Tel. +30 2 1042 251-34	
Service		12, Mavromichali Street	Fax +30 2 1042 251-59	
		P.O. Box 80136, GR-18545 Piraeus	http://www.boznos.gr info@boznos.gr	
			1110@3021103.91	
Großbritannien				
Montagewerk	Normanton	SEW-EURODRIVE Ltd.	Tel. +44 1924 893-855	
Vertrieb		Beckbridge Industrial Estate	Fax +44 1924 893-702	
Service		P.O. Box No.1 GB-Normanton. West- Yorkshire WF6 1QR	http://www.sew-eurodrive.co.uk info@sew-eurodrive.co.uk	
		GB-Normanion, West- Tokshile Wi o TQN	ino@sew-eurounve.co.uk	
Hong Kong				
Montagewerk	Hong Kong	SEW-EURODRIVE LTD.	Tel. +852 2 7960477 + 79604654	
Vertrieb		Unit No. 801-806, 8th Floor	Fax +852 2 7959129	
Service		Hong Leong Industrial Complex No. 4, Wang Kwong Road	sew@sewhk.com	
		Kowloon, Hong Kong		
Indien				
Montagewerk Vertrieb	Baroda	SEW-EURODRIVE India Pvt. Ltd.	Tel. +91 265 2831086 Fax +91 265 2831087	
Service		Plot No. 4, Gidc Por Ramangamdi • Baroda - 391 243	http://www.seweurodriveindia.com	
3011100		Gujarat	mdoffice@seweurodriveindia.com	
Technische Büros	Bangalore	SEW-EURODRIVE India Private Limited	Tel. +91 80 22266565	
	3	308, Prestige Centre Point	Fax +91 80 22266569	
		7, Edward Road	salesbang@seweurodriveinindia.com	
		Bangalore		
Irland				
Vertrieb	Dublin	Alperton Engineering Ltd.	Tel. +353 1 830-6277	
Service		48 Moyle Road	Fax +353 1 830-6458	
		Dublin Industrial Estate Glasnevin, Dublin 11	info@alperton.ie	
		Glasifeviii, Dubiiii 11		
Israel				
Vertrieb	Tel-Aviv	Liraz Handasa Ltd.	Tel. +972 3 5599511	
		Ahofer Str 34B / 228	Fax +972 3 5599512	
		58858 Holon	office@liraz-handasa.co.il	
Italien				
Montagewerk	Milano	SEW-EURODRIVE di R. Blickle & Co.s.a.s.	Tel. +39 02 96 9801	
Vertrieb	imano	Via Bernini,14	Fax +39 02 96 799781	
Service		I-20020 Solaro (Milano)	http://www.sew-eurodrive.it	
			sewit@sew-eurodrive.it	



Japan				
•	Tayyada aha	CEW ELIDODDIVE JADAN CO. LTD	T-1 +04 F20 272044	
Montagewerk Vertrieb Service	Toyoda-cho	SEW-EURODRIVE JAPAN CO., LTD 250-1, Shimoman-no, Iwata Shizuoka 438-0818	Tel. +81 538 373811 Fax +81 538 373814 http://www.sew-eurodrive.co.jp sewjapan@sew-eurodrive.co.jp	
Kamerun				
Vertrieb	Douala	Electro-Services Rue Drouot Akwa B.P. 2024 Douala	Tel. +237 4322-99 Fax +237 4277-03	
Kanada				
Montagewerke Vertrieb Service	Toronto	SEW-EURODRIVE CO. OF CANADA LTD. 210 Walker Drive Bramalea, Ontario L6T3W1	Tel. +1 905 791-1553 Fax +1 905 791-2999 http://www.sew-eurodrive.ca l.reynolds@sew-eurodrive.ca	
	Vancouver	SEW-EURODRIVE CO. OF CANADA LTD. 7188 Honeyman Street Delta. B.C. V4G 1 E2	Tel. +1 604 946-5535 Fax +1 604 946-2513 b.wake@sew-eurodrive.ca	
	Montreal	SEW-EURODRIVE CO. OF CANADA LTD. 2555 Rue Leger LaSalle, Quebec H8N 2V9	Tel. +1 514 367-1124 Fax +1 514 367-3677 a.peluso@sew-eurodrive.ca	
	Weitere Anschri	ften über Service-Stationen in Kanada auf Anfrage.		
Kolumbien				
Montagewerk Vertrieb Service	Bogotá	SEW-EURODRIVE COLOMBIA LTDA. Calle 22 No. 132-60 Bodega 6, Manzana B Santafé de Bogotá	Tel. +57 1 54750-50 Fax +57 1 54750-44 http://www.sew-eurodrive.com.co sewcol@sew-eurodrive.com.co	
Korea				
Montagewerk Vertrieb Service	Ansan-City	SEW-EURODRIVE KOREA CO., LTD. B 601-4, Banweol Industrial Estate Unit 1048-4, Shingil-Dong Ansan 425-120	Tel. +82 31 492-8051 Fax +82 31 492-8056 http://www.sew-korea.co.kr master@sew-korea.co.kr	
Kroatien				
Vertrieb Service	Zagreb	b KOMPEKS d. o. o. Tel. +385 1 4613-158 PIT Erdödy 4 II Fax +385 1 4613-158 HR 10 000 Zagreb kompeks@net.hr		
Lettland				
Vertrieb	Riga	SIA Alas-Kuul Katlakalna 11C LV-1073 Riga	Tel. +371 7139253 Fax +371 7139386 http://www.alas-kuul.com info@alas-kuul.com	
Libanon				
Vertrieb	Beirut	Gabriel Acar & Fils sarl B. P. 80484 Bourj Hammoud, Beirut	Tel. +961 1 4947-86 +961 1 4982-72 +961 3 2745-39 Fax +961 1 4949-71 gacar@beirut.com	
Litauen				
Vertrieb	Alytus	UAB Irseva Naujoji 19 LT-62175 Alytus	Tel. +370 315 79204 Fax +370 315 56175 info@irseva.lt http://www.sew-eurodrive.lt	
Luxemburg				
Montagewerk Vertrieb Service	Brüssel	CARON-VECTOR S.A. Avenue Eiffel 5 B-1300 Wavre	Tel. +32 10 231-311 Fax +32 10 231-336 http://www.sew-eurodrive.lu info@caron-vector.be	





Malaysia			
Montagewerk Vertrieb Service	ontagewerk Johore SEW-EURODRIVE SDN BHD Tel. +60 7 3549409 rtrieb No. 95, Jalan Seroja 39, Taman Johor Jaya Fax +60 7 3541404		
Marokko			
Vertrieb	Casablanca	Afit 5, rue Emir Abdelkader MA 20300 Casablanca	Tel. +212 22618372 Fax +212 22618351 richard.miekisiak@premium.net.ma
Mexiko			
Montagewerk Queretaro Vertrieb Service		SEW-EURODRIVE MEXIKO SA DE CV SEM-981118-M93 Tequisquiapan No. 102 Parque Industrial Queretaro C.P. 76220 Queretaro, Mexico	Tel. +52 442 1030-300 Fax +52 442 1030-301 http://www.sew-eurodrive.com.mx scmexico@seweurodrive.com.mx
Neuseeland			
Montagewerke Auckland Vertrieb Service		SEW-EURODRIVE NEW ZEALAND LTD. P.O. Box 58-428 82 Greenmount drive East Tamaki Auckland	Tel. +64 9 2745627 Fax +64 9 2740165 http://www.sew-eurodrive.co.nz sales@sew-eurodrive.co.nz
	Christchurch	SEW-EURODRIVE NEW ZEALAND LTD. 10 Settlers Crescent, Ferrymead Christchurch	Tel. +64 3 384-6251 Fax +64 3 384-6455 sales@sew-eurodrive.co.nz
Niederlande			
Montagewerk Vertrieb Service	Rotterdam	VECTOR Aandrijftechniek B.V. Industrieweg 175 NL-3044 AS Rotterdam Postbus 10085 NL-3004 AB Rotterdam	Tel. +31 10 4463-700 Fax +31 10 4155-552 http://www.vector.nu info@vector.nu
Norwegen			
Montagewerk Moss Vertrieb Service		SEW-EURODRIVE A/S Solgaard skog 71 N-1599 Moss	Tel. +47 69 241-020 Fax +47 69 241-040 http://www.sew-eurodrive.no sew@sew-eurodrive.no
Österreich			
Montagewerk Wien SEW-EU Vertrieb Richard-		SEW-EURODRIVE Ges.m.b.H. Richard-Strauss-Strasse 24 A-1230 Wien	Tel. +43 1 617 55 00-0 Fax +43 1 617 55 00-30 http://sew-eurodrive.at sew@sew-eurodrive.at
Peru			
Montagewerk Vertrieb Service	S.A.C. Fax +51 1 3493002 Los Calderos, 120-124 http://www.sew-eurodri		
Polen			
Montagewerk Vertrieb Service	ieb ul. Techniczna 5 Fax +48 42 67710-99		Fax +48 42 67710-99 http://www.sew-eurodrive.pl
Portugal			
Montagewerk Vertrieb Service	Coimbra	SEW-EURODRIVE, LDA. Apartado 15 P-3050-901 Mealhada	Tel. +351 231 20 9670 Fax +351 231 20 3685 http://www.sew-eurodrive.pt infosew@sew-eurodrive.pt



Rumänien					
Vertrieb Service	Bucuresti	Sialco Trading SRL Tel. +40 21 230-1328 str. Madrid nr.4 Fax +40 21 230-7170 011785 Bucuresti sialco@sialco.ro			
Russland					
Montagewerk Vertrieb Service	St. Petersburg	ZAO SEW-EURODRIVE Tel. +7 812 3332522 +7 812 535 P.O. Box 36 Fax +7 812 3332523 195220 St. Petersburg Russia http://www.sew-eurodrive.ru sew@sew-eurodrive.ru			
Schweden					
Montagewerk Vertrieb Service	Jönköping	SEW-EURODRIVE AB Gnejsvägen 6-8 S-55303 Jönköping Box 3100 S-55003 Jönköping	Tel. +46 36 3442-00 Fax +46 36 3442-80 http://www.sew-eurodrive.se info@sew-eurodrive.se		
Schweiz					
Montagewerk Vertrieb Service	Basel	Alfred Imhof A.G. Jurastrasse 10 CH-4142 Münchenstein bei Basel	Tel. +41 61 417 1717 Fax +41 61 417 1700 http://www.imhof-sew.ch info@imhof-sew.ch		
Senegal					
Vertrieb	Dakar	SENEMECA Mécanique Générale Km 8, Route de Rufisque B.P. 3251, Dakar	Tel. +221 849 47-70 Fax +221 849 47-71 senemeca@sentoo.sn		
Serbien und Monten	iegro				
Vertrieb	Beograd	DIPAR d.o.o. Ustanicka 128a PC Košum, IV floor SCG-11000 Beograd	Tel. +381 11 347 3244 / +381 11 288 0393 Fax +381 11 347 1337 dipar@yubc.net		
Singapur					
Montagewerk Vertrieb Service	Singapore	SEW-EURODRIVE PTE. LTD. No 9, Tuas Drive 2 Jurong Industrial Estate Singapore 638644	Tel. +65 68621701 Fax +65 68612827 http://www.sew-eurodrive.com.sg sewsingapore@sew-eurodrive.com		
Slowakei					
Vertrieb	Bratislava	SEW-Eurodrive SK s.r.o. Rybnicna 40 SK-83107 Bratislava	Tel. +421 2 49595201 Fax +421 2 49595200 http://www.sew.sk sew@sew-eurodrive.sk		
	Zilina	SEW-Eurodrive SK s.r.o. ul. Vojtecha Spanyola 33 SK-010 01 Zilina	Tel. +421 41 700 2513 Fax +421 41 700 2514 sew@sew-eurodrive.sk		
	Banská Bystrica	SEW-Eurodrive SK s.r.o. Rudlovská cesta 85 SK-97411 Banská Bystrica	Tel. +421 48 414 6564 Fax +421 48 414 6566 sew@sew-eurodrive.sk		
Slowenien					
Vertrieb Service	Celje	Pakman - Pogonska Tehnika d.o.o. UI. XIV. divizije 14 SLO - 3000 Celje	Tel. +386 3 490 83-20 Fax +386 3 490 83-21 pakman@siol.net		
Spanien					
Montagewerk Vertrieb Service	Bilbao	SEW-EURODRIVE ESPAÑA, S.L. Parque Tecnológico, Edificio, 302 E-48170 Zamudio (Vizcaya)	Tel. +34 94 43184-70 Fax +34 94 43184-71 http://www.sew-eurodrive.es sew.spain@sew-eurodrive.es		





Südafrika				
Montagewerke Vertrieb Service	Johannesburg	SEW-EURODRIVE (PROPRIETARY) LIMITED Eurodrive House Cnr. Adcock Ingram and Aerodrome Roads Aeroton Ext. 2 Johannesburg 2013 P.O.Box 90004 Bertsham 2013	Tel. +27 11 248-7000 Fax +27 11 494-3104 http://www.sew.co.za dross@sew.co.za	
	Capetown	SEW-EURODRIVE (PROPRIETARY) LIMITED Rainbow Park Cnr. Racecourse & Omuramba Road Montague Gardens Cape Town P.O.Box 36556 Chempet 7442 Cape Town	Tel. +27 21 552-9820 Fax +27 21 552-9830 Telex 576 062 dswanepoel@sew.co.za	
Durban		SEW-EURODRIVE (PROPRIETARY) LIMITED 2 Monaceo Place Pinetown Durban P.O. Box 10433, Ashwood 3605	Tel. +27 31 700-3451 Fax +27 31 700-3847 dtait@sew.co.za	
Thailand				
Montagewerk Vertrieb Service	Chonburi	SEW-EURODRIVE (Thailand) Ltd. 700/456, Moo.7, Donhuaroh Muang Chonburi 20000	Tel. +66 38 454281 Fax +66 38 454288 sewthailand@sew-eurodrive.com	
Tschechische Repo	ublik			
Vertrieb	Praha	SEW-EURODRIVE CZ S.R.O. Business Centrum Praha Lužná 591 CZ-16000 Praha 6 - Vokovice	Tel. +420 220121234 Fax +420 220121237 http://www.sew-eurodrive.cz sew@sew-eurodrive.cz	
Tunesien				
Vertrieb	Tunis	T. M.S. Technic Marketing Service 5, Rue El Houdaibiah 1000 Tunis	Tel. +216 71 4340-64 + 71 4320-29 Fax +216 71 4329-76 tms@tms.com.tn	
Türkei				
Montagewerk Vertrieb Service	Hareket Sistemleri San. ve Tic. Ltd. Sti. Fax +90 216 3 Bagdat Cad. Koruma Cikmazi No. 3 http://www.sew		Tel. +90 216 4419163 / 164 3838014/15 Fax +90 216 3055867 http://www.sew-eurodrive.com.tr sew@sew-eurodrive.com.tr	
Ukraine				
Vertrieb Service	Dnepropetrovsk	SEW-EURODRIVE Str. Rabochaja 23-B, Office 409 49008 Dnepropetrovsk	Tel. +380 56 370 3211 Fax +380 56 372 2078 http://www.sew-eurodrive.ua sew@sew-eurodrive.ua	
Vertrieb	Kiev	SEW-EURODRIVE GmbH S. Oleynika str. 21 02068 Kiev	Tel. +380 44 503 95 77 Fax +380 44 503 95 78 kso@sew-eurodrive.ua	
Ungarn				
Vertrieb Service	Budapest	SEW-EURODRIVE Kft. H-1037 Budapest Kunigunda u. 18	Tel. +36 1 437 06-58 Fax +36 1 437 06-50 office@sew-eurodrive.hu	
USA				
Fertigungswerk Montagewerk Vertrieb Service	Greenville	SEW-EURODRIVE INC. 1295 Old Spartanburg Highway P.O. Box 518 Lyman, S.C. 29365	Tel. +1 864 439-7537 Fax Sales +1 864 439-7830 Fax Manuf. +1 864 439-9948 Fax Ass. +1 864 439-0566 Telex 805 550 http://www.seweurodrive.com cslyman@seweurodrive.com	






Adressenliste

USA			
Montagewerke Vertrieb Service	San Francisco	SEW-EURODRIVE INC. 30599 San Antonio St. Hayward, California 94544-7101	Tel. +1 510 487-3560 Fax +1 510 487-6381 cshayward@seweurodrive.com
	Philadelphia/PA	SEW-EURODRIVE INC. Pureland Ind. Complex 2107 High Hill Road, P.O. Box 481 Bridgeport, New Jersey 08014	Tel. +1 856 467-2277 Fax +1 856 845-3179 csbridgeport@seweurodrive.com
	Dayton	SEW-EURODRIVE INC. 2001 West Main Street Troy, Ohio 45373	Tel. +1 937 335-0036 Fax +1 937 440-3799 cstroy@seweurodrive.com
	Dallas	SEW-EURODRIVE INC. 3950 Platinum Way Dallas, Texas 75237	Tel. +1 214 330-4824 Fax +1 214 330-4724 csdallas@seweurodrive.com
	Weitere Anschrifte	n über Service-Stationen in den USA auf Anfrage.	

Venezuela			
Montagewerk Vertrieb Service	Valencia	SEW-EURODRIVE Venezuela S.A. Av. Norte Sur No. 3, Galpon 84-319 Zona Industrial Municipal Norte Valencia, Estado Carabobo	Tel. +58 241 832-9804 Fax +58 241 838-6275 http://www.sew-eurodrive.com.ve sewventas@cantv.net sewfinanzas@cantv.net







How we're driving the world

With people who think fast and develop the future with you.

With a worldwide service network that is always close at hand.

With drives and controls that automatically improve your productivity.

With comprehensive knowledge in virtually every branch of industry today.

With uncompromising quality that reduces the cost and complexity of daily operations.





SEW-EURODRIVE Driving the world

With a global presence that offers responsive and reliable solutions. Anywhere.

With innovative technology that solves tomorrow's problems today.


With online information and software updates, via the Internet, available around the clock.







SEW-EURODRIVE GmbH & Co KG P.O. Box 3023 · D-76642 Bruchsal / Germany Phone +49 7251 75-0 · Fax +49 7251 75-1970 sew@sew-eurodrive.com



Installation and operating instructions for R+W Torque Limting couplings: Series SK



Please carefully and completely read the following installation, operation and maintenance procedures for the R+W torque limiting couplings. Failure to comply with these procedures may result in poor performance and/or the failure of the coupling.

Installation of the couplings should be performed by a qualified technician.

General functioning



Function:

R+W torque limiting couplings are ball detent style overload couplings. They protect drive and driven mechanical components from damage associated with torque overloads. Backlash free torque transmission is accomplished by a series of steel balls (4) nested in hardened detents (5). See figure 1. Disc springs push against an actuation ring (3) keeping the balls nested. The disengagement torque is adjustable by means of an adjustment ring (1). In the event of an overload, the actuation ring moves axially allowing the balls to come of the detents separating the drive and driven elements. The movement of the actuation ring can be sensed by means of a mechanical switch or proximity sensor triggering the drive to shut down.

Single-position / Multi-position




Figure 1

In a torque overload, for the single-position design (standard) and multi-position design, the spring disengages to allow the balls to come out of their detents separating the drive and driven elements. Very low residual spring pressure remains so that the coupling will re-engage once the torque is reduced below the overload setting. See diagram 1 too.



CAUTION: Re-engagement may only be effected at low speed.


Re-engagement: Full disengagement

The R+W Torque Limiter can be re-engaged with a low engagement force E (Table 2) on six positions within a 360° circle. The mar-kings of the re-engagement positions had to be lined up. Starting on series 200, the re-engagement can be done with 2 levers, which must be strutted on the adjustment nut. Also two screwdrivers can be used as levers. (see Pic. 3b)



IMPORTANT: Re-engagement must happen on shutdown only.

Full-disengage







Figure 2

With this design, when a torque overload is detected, the disc spring completely flips over and places no residual spring pressure on the actuation ring. The drive and driven elements are completely separated.

<u>^</u>

Re-engagement of the coupling is not automatic and must be performed manually (Figure 3).



Note:




Figure 3b

Transport

R+W couplings are delivered ready for installation. After incoming inspection the coupling should be stored in its original packaging until it is ready for installation. A copy of this installation, operation, and maintenance manual should be kept with the coupling.

Safety alert



Safety alert

Rotating couplings can be very dangerous. Proper guarding should be in place at all times and is the responsibility of the machine builder, user or operator. Do not approach or touch a coupling while it is rotating. Make sure that the machine is "locked out" and cannot be accidentally started during installation or maintenance of the coupling.

Manufacturer's declaration

According to EG guidelines for machinery 89/392 EWG Appendix 11B

In the sense of machine guidelines (MR) shaft couplings are no machines, but components for the installation in machines. Their putting into operation is subject to the fulfillment of all requirements of machine guidelines by or after integration in the final product.

Mounting preparation


All mounting surfaces including shafts, bores, keys, and key ways, must be clean and free of burrs, nicks, or dents. Inspect shaft diameters; coupling bore diameters, key and key-way dimensions and tolerances. All R+W coupling bores are machined to ISO tolerance H7. Clearances between shaft and hub bores are maintained to 0.01 and 0.05 mm. A light coating of oil is recommended to ease the mounting process and will not affect the clamping force of the hub.





CAUTION:

Do not use sliding grease, or oils and grease with molybdenum disulfide or other high-pressure additives.

Mounting drive elements to SK 1 couplings








Mounting of the drive element

Center the drive element (i.e. timing belt pulley or gear) onto the connecting flange of the coupling and fasten with screws. If the center of the radial load falls over the middle of the coupling an additional support bearing is not required (figure 4). If the radial load is not centered over the coupling an additional support bearing is required (figure 5). Please observe the maximum allowable radial load for each coupling size as indicated (Table 1). Excess radial load will affect the performance of the coupling.

Mounting and dismounting: Models SK 1 and SKP

Table 1

SKP with key




Mounting:

Slide the coupling onto the shaft. Lock it in position, with an end plate (8) for example. Figure 6.

Dismounting:

Remove the end plate and slide the coupling off the shaft using an appropriate tool.

SK 1 with clamping hub




Mounting:

Slide the coupling onto the shaft to the proper axial position. Using a torque wrench tighten the clamp screw to the proper tightening torque as indicated in Table 1.

Dismounting:

Simply loosen the clamp screw (P) and remove the coupling.

SK 1 with tapered bushing



Mounting:

Slide the coupling onto the shaft to the proper axial position. Using a torque wrench, uniformly tighten the clamping screws using a crosswise tightening pattern until all the clamping screws are evenly tightened to the correct tightening torque as given in Table 1. While tightening the coupling may move slightly towards the tapered bushing.



CAUTION: Further tightening of the clamping screws may destroy the tapered bushing connection.


NOTE: Prior to reassembly make sure that the jack-screws are raised to their original position.

Dismounting:


Loosen the clamping screw (N). Insert the three jack screws into the taped holes on the tapered segment apply even pressure to remove the tapered segment. Remove the coupling.

Mounting and dismounting: Models SK 2/3/5


SK 2 with clamping hub



SK 3 with tapered bushing



SK 5 with press-fit tapered bushings



Mounting:

Prior to mounting make sure that the shaft to be connected do not exceed the angular or lateral misalignment limits for the coupling size to be used. This data can be found in the catalog. Slide the coupling on the first shaft end to the proper axial position. Using a torque wrench, tighten the clamp screw to the correct tightening torque as indicated in Table 1. Insert the second shaft into the other end of the coupling to the proper axial position. Make sure that the coupling is free of any axial forces before tightening. Tighten the clamp screw as above using a torque wrench.

Mounting:

Prior to mounting make sure that the shaft to be connected do not exceed the angular or lateral misalignment limits for the coupling size to be used. This data can be found in the catalog. Slide the coupling onto the first shaft to the proper axial position. Using a torque wrench, uniformly tighten the clamping screws using a cross-wise tightening pattern until all the clamping screws are evenly tightened to the correct tightening torque as given in Table 1.



CAUTION: Further tightening of the clamp screws may destroy the tapered bushing connection.

Mounting:

Prior to mounting it is necessary to consider the overall length of the assembled coupling. The press-fit coupling requires a specific pre-tensioning (C) between the two coupling halves to ensure backlash free operation. Mount the "female" coupling half containing the bellow onto the first shaft end to the proper axial position. Using a torque wrench tighten the clamp screw to the proper tightening torque. Mount the "male" coupling segment onto the second shaft end. The proper axial position is when the two couplings come together and coupling is compressed by the proper pre-tension distance (C). See Table 2. When the coupling segment is properly positioned tighten the clamp screw to the proper torque.

Dismounting:

Simply loosen the clamp screw and remove the coupling.

Dismounting:

Loosen the clamping screws. Use the three jackscrews conveniently mounted in the taper segment to evenly back out the tapered segment. Remove the coupling.




CAUTION:

Prior to reassembly make sure that the jackscrews are raised to their original position.

Dismounting:

Pull the coupling apart. Simply loosen the clamp screws and remove the coupling from the shaft.

Axial misalignment








Figure 12

Maximum shaft misalignment

In addition to torque overload protection R+W torque limiters combined with a metal bellow compensate for lateral, axial and angular misalignment. Table 2 contains the maximum allowable values for each axis of misalignment for the different size couplings. It is important to remain within these limits to ensure maximum life and proper operation of the coupling.

Spites Jacod nicellighter 4x Andre Perspectual Straight Ham Ham Hard Hard Hard Hard Hard Hard Hard Hard											
	△ Kr	△ Ka	△Kw	С	D	E					
1.5	0.15/0.20	1/1.5	1/1.5	0.1-0.5	0.7	5-10					
2	0.15/0.20	1/2	1/1.5	0.2-0.7	0.8	8-15					
4.5	0.20/0.25	1/2	1/1.5	0.2-0.7	0.8	10-20					
10	0.20/0.30	1/2	1/1.5	0.2-1.0	1.2	15-30					
15	0.15/0.20	1/2	1/1.5	0.2-1.0	1.5	20-40					
30	0.20/0.25	1/2	1/1.5	0.3-1.5	1.5	25-50					
60	0.20/0.25	1.5/2	1/1.5	0.5-1.5	1.7	30-60					
80/150	0.20/0.25	2/3	1/1.5	0.5-1.0	1.9	35-70					
200	0.25/0.30	2/3	1.5/2	Х	2.2	50-100					
300	0.25/0.30	2.5/3.5	1.5/2	0.5-1.5	2.2	80-200					
500	0.30/0.35	2.5/3.5	2/2.5	0.5-2.0	2.2	200-500					
800	0.35	3.5	2.5	0.8-2.0	2.2	500-1000					
1500	0.35	3.5	2.5	0.8-2.2	3	2000-3000					
2500	0.4	4	2.5	1-2.5	3	3000-4000					

x/x First values are for bellows with 4-5 currigations. Second values are for bellows with 6-8 currigations.



CAUTION: Exact alignment of the R+W metal bellow coupling considerably increases the service life of the coupling. Reducing or eliminating lateral misalignment eliminates the radial loading of the adjacent bearings, increasing service life and reducing heat. For drives running at high speed it is recommended to align the coupling with a dial indicator.


Emergency switch function

Mechanical switch (PART No. 618.6740.425)

Technical Data Max. Voltage: Max. Permanent current: Protection type: Type of contact: Ambient temperature: Confirmation: Switch symbol

Figure 13

Proximity switch (PART No. 650.2703.1)



The axial movement of the actuation ring (3) can be sensed be either a mechanical switch or a proximity sensor. The distance the actuation ring moves is given in Table 2 and is important for the selection of the appropriate sensing devise. Mount the sensing devise on a solid support keeping the distance shown in figure 13+14. Without prior agreement it is not allowed to operate R+W torque limiters of the series SK and ES without end switch. In case of a eletronic circuit collapse, the coupling had to be checked visually right after the first disengagement for the preassigned disengagement torque. Here fore the marks on the adjustment nut are the reference val-

500 V AC

10 A

IP 65


Opener

(metal)

-30°C to +80°C



Disengagement torque setting



R+W torque limiters are factory set to the customer specified disengagement torque, which is marked onto the coupling. The adjustment range (min/max) is also marked on the adjustment ring. The customer can adjust the disengagement torque as long as it falls into the range indicated on the adjustment ring.




The adjustment range may not be left during setting.

To adjust the disengagement torque, loosen the locking screws (11) and rotate the adjustment ring using a spanner wrench to the desired new setting. Tighten the locking screws and test the coupling.



CAUTION: R+W torque limiters incorporate disc springs that exhibit a special spring characteristic. It is important to stay in the max-min range of the courding.



Maintenance



R+W torque limiters are maintenance free as long as they are properly mounted and the maximum misalignment and radial load values are not exceeded. The internal components are permanently greased for lifetime lubrication.

CAUTION: Disassembly of the coupling will void the warranty.



R+W Antriebselemente GmbH

Alexander-Wiegand-Str. $8 \cdot 63911$ Klingenberg Tel. +49-(0)9372 -9864-0 \cdot Fax +49-(0)9372 -986420 info@rw-kupplungen.de \cdot http://www.rw-couplings.com

The above-mentioned information is based on our present knowledge and experiences and does not free the user of his own regular checks. A legally binding guarantee is not given even in regard to protection rights of Third parties.

BEARINGS/PULLEYS

Since all bearings have taconite seals, there is very little misalignment allowance on the bearing housings. See assembly instructions for taconite seals.

All shafts mounted on frames are aligned and will have free running seals. If any adjustment is made during final alignment, care must be taken to make sure that the seals will run free after the adjustment.

Shafts mounted on screw take-ups need to be adjusted evenly \pm 3 mm in both sides when moving them back or forth on the take-ups. (Refer to take-up section)

LUBRICATION

An automatic lubrication system is provided. Bearings have been shop lubricated with TEXACO STARPLEX NLGI grease. Please refer to the Lincoln Operation and Maintenance Manual for operating instructions

SPLIT PILLOW BLOCKS

For Pillow Block Housings / Bearings assembly see FAG bearing manual

Grease used to pre-fill housings: EP1 - TEXACO STARPLEX 1

INSTALLING BEARINGS AND SEALS ONTO SHAFT



1. Mount seal & bearing



4. Fit seal/bearing into grooves



2. Grease rollers all around



5. Bring housing fully up



3. Bring bottom housing up



6. Fill with grease



7. Carefully install top housing





Ductile Iron Pillow Block Housings General and Heavy Duty

Ductile Iron Housings

Selecting the most appropriate housing material should be the result of careful analysis of the operating and environmental conditions of the application. When the demands placed upon the pillow block do not allow for compromises, the material choice becomes increasingly obvious: ductile iron.

Optimum Material, Maximum Performance

FAG utilizes ductile iron as a high grade material for standard housing production. This remarkably versatile material possesses a number of engineering advantages, including:

- the fluid casting properties of cast iron
- superb material consistency comparable to carbon cast steel,
 with the inherent high tensile and yield strengths (see chart)
- tremendous resistance to corrosion
- the strength to withstand substantial mechanical shock
- resilient to brittle fracture at low temperatures
- extended service life in severe operating conditions

Series Availability

FAG offers an extensive standard selection of ductile iron pillow blocks for general duty and heavy duty applications. Series SAF...D and AFD general duty housings are designed for shafts ranging from 1½6" to 7½6", whereas heavy duty series SDD accommodate shaft diameters as great as 43 inches. In addition to standard series production, FAG also utilizes ductile iron for special design housings unique to their specific industrial applications.



Comparison: Housing Material Properties

Material	A.S.T.M. Designation	Grade	Tensile Strength psi	Yield Strength psi	Elongation (% in 2 in.)
Cast Iron	A48-64	30	30,000	_	_
Ductile Iron	A-536	65-45-12	65,000	45,000	12
Cast Steel	A27	65-35	65,000	35,000	24

General Duty Series SAF...D

- series SAF...D housings are designed to accept a full range of shaft diameters from 1%6" to $7^{15}\%$ 6"
- housing sizes within this standard production program are machined to accommodate inch or metric shaft dimensions
- housings are supplied with a central grease inlet and nipple for relubrication of the bearing, and an outlet hole on each side of the block for drainage
- housings are equipped with a 2-bolt base for shaft sizes up to and including 3⁷/₁₆" (SAF520D), and with a 4-bolt base thereafter;
 4-bolt bases are also available by specifying
 FSAF...D for shafts ranging from 2³/₁₆" to 3⁷/₁₆"
 (FSAF513D to FSAF520D)
- series SAF...D housings can be supplied with triple seal rings for normal service conditions, or SuperTac II taconite seals for severe service conditions
- bearings can be installed as floating bearings, or located with fixing rings





• series AFD housings are available for the same range of shaft sizes as series SAFD, and with the same principle design features

SAF...D housing assembly featuring FAG SuperTac II taconite seals

 series AFD housings are equipped with 1st generation taconite seals for severe service conditions without substitution
 For detailed AFD assembly components and dimensions, see pages 8 & 9

Heavy Duty Series SDD


• series SDD housings are available for larger shaft

diameters as great as 43 inches
For SDD housing dimensions
and bearing selection,
see pages 10 & 11

Seals and Endcovers


Triple Seal Rings

- series SAF...D and SDD housings are generally equipped with an efficient noncontact radial labyrinth seal commonly referred to as a triple seal ring (series LER for SAF...D and TSG for SDD housings)
- this rotating ring automatically locates itself relative to the labyrinth groove of the housing (Figure 1)




Taconite Seals

- for severe service conditions, SAF...D
 housings can be equipped with SuperTac II
 taconite seals (Figure 2) without any
 modification to the housing (see additional
 information below and opposite)
- series AFD housings are standardly equipped with 1st generation FAG taconite seals (Figure 3) without substitution



taconite seals are also available for series
 SDD housings, and in special designs

If any housing is to be closed on one side, an endcover is installed in the annular groove of the housing.




At the Sign of Contamination, the Seal that Delivers: SuperTac II

Design Features

- FAG SuperTac II seals are manufactured from high grade steel with black oxide coating as standard; special design option of nickel plating is available upon request
- the internal design features a radial / axial web barrier to external contaminants
- a grease packed radial labyrinth is formed by high grade spring steel laminar rings that align into two close running barriers, separated by a lubricant distribution channel
- working together with the grease purged axial labyrinth, the result is a web that stands virtually impenetrable
- the seal flinger is equipped with 2 set screws spaced at a 65° interval for maximum holding power to the shaft
- an o-ring in the flinger bore prevents the ingress of fluids between the seal and shaft





Dimensions "g" and "g1" apply to SuperTac II seals installed with FAG series SAF5..D pillow blocks. Dimensions may vary when using SuperTac II seals with non-ductile iron FAG SAF series pillow blocks, or with a non-FAG pillow block SuperTac II seals are unavailable for some metric shaft sizes due to inadequate space between the shaft and housing seal grooves to accommodate the seal design.

FAG Sund	er Tac II Taconite S	eals							
Shaft in./mm	Pillow Block	FAG Seal No.	Dimensions g in./mm	g1 in./mm	Shaft in./mm	Pillow Block	FAG Seal No.	Dimensions g in./mm	8 ii
17/16	SAF509	TA17A	3.420 87	5.910 150	4 ³ / ₁₆	SAF524	TA113A	7.125 181	1
111/16	SAF510	TA20A	3.420 87	5.910 150	4 ⁷ / ₁₆ 115	SAF526	TA117A TA117A.M	7.750 197	1
1 ¹⁵ / ₁₆ 50	SAF511	TA24A TA24A.M	3.750 95	6.269 159	4 ¹⁵ / ₁₆ 125	SAF528	TA122A TA122A.M	7.375 187	1
23/16	SAF513	TA29A	4.250 108	6.782 172	5 ³ / ₁₆ 135	SAF530	TA125A TA125A.M	8.125 206	1
27/16	SAF515	TA37A	4.625 117	7.367 187	5½6 140	SAF532	TA130A TA130A.M	8.500 216	1
2 ¹¹ / ₁₆ 70	SAF516	TA44A TA44A.M	4.750 121	7.520 191	5 ¹⁵ ⁄ ₁₆ 150	SAF534	TA140A TA140A.M	9.250 235	1
2 ¹⁵ ⁄ ₁₆ 75	SAF517	TA53A TA53A.M	4.813 122	7.740 197	6½6 160	SAF536	TA148A TA148A.M	9.625 244	1
3 ³ / ₁₆ 80	SAF518	TA188A TA188A.M	5.500 140	8.138 207	6 ¹⁵ / ₁₆ 170	SAF538	TA155A TA155A.M	10.500 267	1
3½ ₁₆ 90	SAF520	TA102A TA102A.M	5.813 148	9.025 229	7 ³ / ₁₆ 180	SAF540	TA159A TA159A.M	11.000 279	1
3 ¹⁵ ⁄ ₁₆ 100	SAF522	TA109A TA109A.M	6.438 164	9.682 246	7 ¹⁵ / ₁₆ 200	SAF544	TA167A TA167A.M	11.750 298	1


Operating Benefits


- FAG SuperTac II is designed as a drop-in fit to the seal grooves of FAG series SAF pillow blocks, as well as many competitive designs, eliminating the need for special housing features
- the non-contact seal design eliminates shaft wear common to competitive designs
- SuperTac II seals accept greater misalignments than lip seals
- exceptional speed characteristics: equivalent to bearing speed limits




Series SAF...D Housings

SAF	D Assembl	y Componen	ts and Dime	nsions							
Shaft Diameter mm/in.	Pillow Block No.	Basic Bearing No.	Split Bearing No.	Adapter Sleeve No.	Triple Seal Ring No.	Super Tac II Seal No.	End Cover No.	Fixing Ring No.	pcs.	Comple Weight lbs.	ete t (approx) kgs.
40 1½6	SAF509-D	22209-E1-K		H309 H309X107	LER20.M40 LER17.0107	TA17A	EC509.D2	FRM85/6	1	10.5	4.8
45 1 ¹¹ / ₁₆	SAF510-D	22210-E1-K		H310 H310X111	LER20.M45 LER20.0111	TA20A	EC510.D2	FRM90/7	1	11.5	5.2
50 1 ¹⁵ / ₁₆	SAF511-D	22211-E1-K		H311 H311X115	LER24.M50 LER24.0115	TA24A.M TA24A	EC511.D2	FRM100/6	1	13.5	6.1
60 2 ³ / ₁₆	SAF513-D	22213-E1-K		H313 H313X203	LER35.M60 LER29.0203	TA29A	EC513.D2	FRM120/8	1	21	9.5
65 2 ⁷ / ₁₆	SAF515-D	22215-E1-K	222SM.65 222S.207	H315 H315X207	LER38.M65 LER37.0207	TA37A	EC515.D2	FRM130/6	1	24	10.9
70 2 ¹¹ / ₁₆	SAF516-D	22216-E1-K	222SM.70 222S.211	H316 H316X211	LER44.M70 LER44.0211	TA44A.M TA44A	EC516.D2	FRM140/10	1	32	14.5
75 2 ¹⁵ / ₁₆	SAF517-D	22217-E1-K	222SM.75 222S.215	H317 H317X215	LER53.M75 LER53.0215	TA53A.M TA53A	EC517.D2	FRM150/10	1	35	15.9
80 3 ³ / ₁₆	SAF518-D	22218-E1-K	222SM.80 222S.303	H318 H318X303	LER188.M80 LER188.0303	TA188A.M TA188A	EC518.D2	FRM160/10	1	44	20.0
90 3½ ₁₆	SAF520-D	22220-E1-K	222SM.90 222S.307	H320 H320X307	LER102.M90 LER102.0307	TA102A.M TA102A	EC520.D2	FRM180/10	1	74	33.6
100 3 ¹⁵ / ₁₆	SAF522-D	22222-E1-K	222SM.100 222S.315	H322 H322X315	LER109.M100 LER109.0315	TA109A.M TA109A	EC522.D2	FRM200/10	1	97	44.0
110 4 ³ / ₁₆	SAF524-D	22224-E1-K	222SM.110 222S.403	H3124 H3124X403	LER113.M110 LER113.0403	TA113A	EC524.D2	FRM215/10	1	121	54.9
115 4 ⁷ ⁄ ₁₆	SAF526-D	22226-E1-K	222SM.115 222S.407	H3126 H3126X407	LER117.M115 LER117.0407	TA117A.M TA117A	EC526.D2	FRM230/10	1	161	73.1
125 4 ¹⁵ / ₁₆	SAF528-D	22228-E1-K	222SM.125 222S.415	H3128 H3128X415	LER122.M125 LER122.0415	TA122A.M TA122A	EC528.D2	FRM250/10	1	174	79.0
135 5 ³ ⁄ ₁₆	SAF530-D	22230-E1-K	222SM.135 222S.503	H3130 H3130X503	LER125.M135 LER125.0503	TA125A.M TA125A	EC530.D2	FRM270/10	1	221	100.3
140 5½6	SAF532-D	22232-E1-K	222SM.140 222S.507	H3132 H3132X507	LER130.M140 LER130.0507	TA130A.M TA130A	EC532.D2	FRM290/10	1	246	111.7
150 5 ¹⁵ / ₁₆	SAF534-D	22234-E1-K	222SM.150 222S.515	H3134 H3134X515	LER140.M150 LER140.0515	TA140A.M TA140A	EC534.D2	FRM310/10	1	310	140.7
160 6 ⁷ / ₁₆	SAF536-D	22236-E1-K	222SM.160 222S.607	H3136 H3136X607	LER148.M160 LER148.0607	TA148A.M TA148A	EC536.D2	FRM320/10	1	345	156.6
170 6 ¹⁵ / ₁₆	SAF538-D	22238-K	222SM.170 222S.615	H3138 H3138X615	LER155.M170 LER155.0615	TA155A.M TA155A	EC538.D2	FRM340/10	1	400	181.6
180 7 ³ / ₁₆	SAF540-D	22240-K	222SM.180 222S.703	H3140 H3140X703	LER159.M180 LER159.0703	TA159A.M TA159A	EC540.D2	FRM360/10	1	492	223.4
200 7 ¹⁵ / ₁₆	SAF544-D	22244-K	222SM.200 222S.715	H3144 H3144X715	LER167.M200 LER167.0715	TA167A.M TA167A	EC544.D2	FRM400/10	1	672	305.1









D	h mm/in.	a mm/in.	b mm/in.	c mm/in.	m Max. mm/in.	Min. mm/in.	n mm/in.	h1 mm/in.	g mm/in.	g1 mm/in.	x mm/in.	k (Static) mm/in.	y mm/in.	Mounting 2 pcs. mm/in.	g Bolts 4 pcs. mm/in.
85	57.15 2¼	210 8¼	60 2 ³ / ₈	21 ¹³ / ₁₆	178 7	159 6¼		111 4¾8	87 3½ ₁₆	150 5 ¹⁵ / ₁₆	3.0 .118	25 ³¹ / ₃₂	30 1 ³ ⁄ ₁₆	M12 ½	
90	63.50 2½	210 8¼	60 2 ³ / ₈	24 15/ ₁₆	178 7	165 6½		121 4¾	87 3½ ₁₆	150 5 ¹⁵ / ₁₆	3.5 .138	28 1 ³ / ₃₂	30 1 ³ ⁄ ₁₆	M12 ½	
100	69.85 2¾	244 9 ⁵ / ₈	70 2¾	24 15/ ₁₆	200 7 ⁷ / ₈	187 7 ³ / ₈		133 5¼	95 3¾	159 6¼	3.0 .118	32 1 ³ ⁄ ₁₆	32 1¼	M16 5/8	
120	76.20 3	279 11	79 3½	25 1	241 9½	206 8½	51 2	151 5 ¹⁵ / ₁₆	108 4¼	172 6 ¹³ / ₁₆	4.0 .157	32 1 ³ / ₃₂	37 1/⁄ ₁₆	M16 %	M12 ½
130	82.55 3½	286 11 ¹ / ₄	79 3½	29 1½	244 9 ⁵ / ₈	219 8½	48 1½	162 6 ³ / ₈	117 4½	187 7 ³ / ₈	3.0 .118	32 1½	38 1½	M16 %	M12 ½
140	88.90 3½	330 13	89 3½	30 1 ³ ⁄ ₁₆	279 11	244 9 ⁵ / ₈	54 2½	175 6%	121 4¾	191 7½	5.0 .197	35 1¼	41 1½	M20 ¾	M16 5/8
150	95.25 3¾	330 13	89 3½	32 1¼	279 11	251 9 ⁷ / ₈	54 2½	186 7 ⁵ ⁄ ₁₆	122 4 ¹³ / ₁₆	197 7¾	5.0 .197	37 1 ³ / ₈	43 1 ¹¹ / ₁₆	M20 ¾	M16 5/8
160	101.60 4	349 13¾	98 3 ⁷ / ₈	33 1 ⁵ ⁄16	295 11 ⁵ / ₈	264 10 ³ / ₈	54 2½	197 7¾	140 5½	207 8½	5.0 .197	40 1½	44 1¾	M20 ¾	M16 5/8
180	114.30 4½	387 15 ¹ ⁄⁄ ₄	111 4 ³ / ₈	44 1¾	333 13½	295 11 ⁵ / ₈	60 2 ³ / ₈	213 8 ³ / ₈	148 5 ¹³ / ₁₆	229 9	5.0 .197	45 1 ²¹ / ₃₂	51 2	M24 %	M20 ³ / ₄
200	125.41 4 ¹⁵ ⁄ ₁₆	419 16½	121 4¾	51 2	368 14½	321 12 ⁵ / ₈	70 2¾	244 9%	164 6½	246 9 ¹¹ / ₁₆	5.0 .197	48 1 ²⁵ / ₃₂	54 2½		M20 ¾
215	133.35 5½	419 16½	121 4¾	54 2½	368 14½	337 13½	70 2¾	260 10 ¹ ⁄⁄ ₄	181 7½	262 10 ⁵ / ₁₆	5.0 .197	51 1 ²⁷ / ₃₂	59 2 ⁵ ⁄ ₁₆		M20 ¾
230	152.40 6	467 18 ³ / ₈	130 5½	60 2 ³ / ₈	406 16	371 14 ⁵ / ₈	83 3¼	292 11½	197 7¾	285 11 ³ ⁄ ₁₆	5.0 .197	63 2 ¹¹ / ₃₂	62 2½6		M24 ½
250	152.40 6	511 20 ¹ / ₈	149 5 ⁷ / ₈	60 2 ³ / ₈	435 17 ¹ / ₈	406 16	86 3 ³ / ₈	298 11¾	187 7 ³ / ₈	275 10 ¹³ / ₁₆	5.0 .197	56 2 ¹ / ₃₂	65 2 ⁹ / ₁₆		M24 1
270	160.34 6 ⁵ / ₁₆	540 21 ¹ / ₄	159 6¼	64 2½	464 18 ¹ ⁄⁄ ₄	432 17	95 3¾	318 12½	206 8½	302 11½	5.0 .197	56 2	70 2¾		M24 1
290	169.86 6 ¹¹ / ₁₆	559 22	159 6¼	67 2 ⁵ / ₈	489 19 ¹ ⁄⁄ ₄	441 17 ³ / ₈	95 3¾	338 13 ⁵ ⁄ ₁₆	216 8½	310 12 ³ / ₁₆	5.0 .197	57 2½16	75 2 ¹⁵ / ₁₆		M24 1
310	179.39 7½6	630 24¾	171 6¾	70 2¾	549 21 ⁵ / ₈	492 19 ³ / ₈	108 4¼	360 14 ³ / ₁₆	235 9 ¹ ⁄⁄ ₄	334 13 ¹ / ₈	5.0 .197	61 2 ⁵ / ₃₂	79 3½		M24 1
320	190.50 7½	679 26¾	181 7 ¹ / ₈	76 3	600 23 ⁵ / ₈	530 20 ⁷ / ₈	117 4 ⁵ / ₈	378 14 ⁷ / ₈	244 9 ⁵ / ₈	348 13¾	5.0 .197	67 2 ³ / ₈	79 3½		M24 1
340	200.03 7%	711 28	191 7½	79 3½	619 24 ³ / ₈	549 21%	114 4½	398 15 ¹¹ / ₁₆	267 10½	373 14 ¹¹ / ₁₆	5.0 .197	69 2 ⁷ / ₁₆	84 3 ⁵ ⁄ ₁₆		M30 1 ¹ / ₄
360		749 29½	203	86 3 ³ / ₈	635 25	572 22½	127 5	419 16½	279 11	392 15 ⁷ / ₁₆	5.0 .197	71 2 ¹⁵ / ₃₂	89 3½		M30 1 ¹ / ₄
400	241.30 9½	832 32 ³ / ₄	222 8¾	95 3¾	708 27 ⁷ / ₈	629 24¾	133 5¼	473 18 ⁵ / ₈	298 11¾	413 16 ¹ / ₄	5.0 .197	88 3½	97 3 ¹³ / ₁₆		M36 1½

Dimensions "g1" specific to SAF...D housings with SuperTac II seals
 Specify FSAF...D when ordering 4-bolt bases for pillow block sizes 513 to 520

Series AFD Housings

AED Ac	combly Com	ponents and D	imonsions									
Shaft Diameter mm/in.	Pillow Block No.	Basic Bearing No.	Split Bearing No.	Adapter Sleeve No.	Taconite Seal No.	End Cover No.	Fixing Ring No.	pcs.	Compl Weigh lbs.	ete t (approx) kgs.	D	h mm/in.
40 1 ⁷ / ₁₆	AFD509.D2	22209-E1-K		H309 H309X107	TA509.M40 TA509.107	AC509S	FRM85/8	1	12	5.4	85	57.15 2½
45 1 ¹¹ / ₁₆	AFD510.D2	22210-E1-K		H310 H310X111	TA510.M45 TA510.111	AC510S	FRM90/10	1	13	5.9	90	63.5 2½
50 1 ¹⁵ ⁄ ₁₆	AFD511.D2	22211-E1-K		H311 H311X115	TA511.M50 TA511.115	AC511S	FRM100/10	1	18	8.2	100	69.85 2¾
60 2 ³ / ₁₆	AFD513.D2	22213-E1-K		H313 H313X203	TA513.M60 TA513.203	AC513S	FRM120/10	1	26	11.8	120	76.2 3
65 2 ⁷ / ₁₆	AFD515.D2	22215-E1-K	222SM.65 222S.207	H315 H315X207	TA515.M65 TA515.207	AC515S	FRM130/10	1	31	14.1	130	82.55 3½
70 2 ¹¹ / ₁₆	AFD516.D2	22216-E1-K	222SM.70 222S.211	H316 H316X211	TA516.M70 TA516.211	AC516S	FRM140/10	1	38	17.2	140	88.9 3½
75 2 ¹⁵ ⁄16	AFD517.D2	22217-E1-K	222SM.75 222S.215	H317 H317X215	TA517.M75 TA517.215	AC517S	FRM150/10	1	45	20.4	150	95.25 3¾
80 3 ³ / ₁₆	AFD518.D2	22218-E1-K	222SM.80 222S.303	H318 H318X303	TA518.M80 TA518.303	AC518S	FRM160/10	1	51	23.1	160	101.6 4
90 3½ ₁₆	AFD520.D2	22220-E1-K	222SM.90 222S.307	H320 H320X307	TA520.M90 TA520.307	AC520S	FRM180/10	1	72	32.7	180	114.3 4½
100 3 ¹⁵ ⁄ ₁₆	AFD522.D2	22222-E1-K	222SM.100 222S.315	H322 H322X315	TA522.M100 TA522.315	AC522S	FRM200/10	1	100	45.4	200	125.41 4 ¹⁵ ⁄ ₁₆
110 4 ³ ⁄ ₁₆	AFD524.D2	22224-E1-K	222SM.110 222S.403	H3124 H3124X403	TA524.M110 TA524.403	AC524S	FRM215/10	1	126	57.2	215	133.35 5¼
115 4 ⁷ / ₁₆	AFD526.D2	22226-E1-K	222SM.115 222S.407	H3126 H3126X407	TA526.M115 TA526.407	AC526S	FRM230/10	1	151	68.5	230	152.4 6
125 4 ¹⁵ ⁄ ₁₆	AFD528.D2	22228-E1-K	222SM.125 222S.415	H3128 H3128X415	TA528.M125 TA528.415	AC528S	FRM250/10	1	184	83.5	250	152.4 6
135 5 ³ ⁄ ₁₆	AFD530.D2	22230-E1-K	222SM.135 222S.503	H3130 H3130X503	TA530.M135 TA530.503	AC530S	FRM270/10	1	234	106.1	270	160.34 6 ⁵ ⁄ ₁₆
140 5½6	AFD532.D2	22232-E1-K	222SM.140 222S.507	H3132 H3132X507	TA532.M140 TA532.507	AC532S	FRM290/10	1	283	128.4	290	169.86 6 ¹¹ / ₁₆
150 5 ¹⁵ ⁄ ₁₆	AFD534.D2	22234-E1-K	222SM.150 222S.515	H3134 H3134X515	TA534.M150 TA534.515	AC534S	FRM310/10	1	347	157.4	310	179.39 7½ ₁₆
160 6 ⁷ / ₁₆	AFD536.D2	22236-E1-K	222SM.160 222S.607	H3136 H3136X607	TA536.M160 TA536.607	AC536S	FRM320/10	1	382	173.3	320	190.5 7½
170 6 ¹⁵ / ₁₆	AFD538.D2	22238-K	222SM.170 222S.615	H3138 H3138X615	TA538.M170 TA538.615	AC538S	FRM340/10	1	464	210.5	340	200.03 7 ⁷ / ₈
180 7 ³ / ₁₆	AFD540.D2	22240-K	222SM.180 222S.703	H3140 H3140X703	TA540.M180 TA540.703	AC540S	FRM360/10	1	536	243.1	360	209.55 8½
200 7 ¹⁵ / ₁₆	AFD544.D2	22244-K	222SM.200 222S.715	H3144 H3144X715	TA544.M200 TA544.715	AC544S	FRM400/10	1	730	331.1	400	241.3 9½





a b c mm/lin,															
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$		Mounti 2 pcs. mm/in.		(Static)							Max.				
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$															
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$		M12	30				92			165				210	
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$		M16	32	32	5	127	98	133		187	200	29	70	251	
$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$		M16	37	32	5	146	114	151		206	241	30	79	279	
330	M12	M16	38	32	5	148	114	160		219	244	30	79	286	
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$		M20	41	35	5	159	127	171	54	244	279	32	89	330	
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	M16	M20	43	37	5	171	132	186	54	251	279	32	89	324	
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$		M20	44	40	5	185	152	197	54	264	295	35	98	349	
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$		M24	51	45	5	198	159	219	60	295	333	40	111	387	
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	3/4 M20	<u>//8</u>	54	48	5	216	176	243	70	321	368	44	121	419	
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	³ / ₄ M20		59	51	5	229	187	260	70	337	368	44	121	419	
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	3/4 M24		62	63		232	192	289	83	371		52	130	467	
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	7⁄8 M24							-							
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	1 M24						-	-							
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	1 M24		2¾	23/16	0.197	10½	85/8	121/16	3¾	17	181//4	2 1/8	61/4	211/4	
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	1 M24		215/16	21//4	0.197	111//8	91/4	13%16	3¾	17¾	19¼	2 1/8	61/4	22	
$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	1		31/8	23//8	0.197	111//8	9½	14½	41/4	19¾	21 1/8	2¾	6¾	24¾	
$\begin{array}{cccccccccccccccccccccccccccccccccccc$	M24 1		31//8	25//8	0.197	121/16	10	15	45/8	20 1/8	23 1/8	3	71/8	26¾	
$29\frac{1}{2}$ $8\frac{1}{16}$ 3 25 $22\frac{1}{2}$ 5 $17\frac{1}{8}$ 11 $13\frac{1}{4}$ 0.197 $2\frac{3}{4}$ $3\frac{1}{2}$	M30 1 ¹ / ₄		35/16	211/16	0.197	121/8	10 1/8	16¼	4½	211/8	24 1/8	2¾	7½	28	
022 222 05 700 (20 422 (0) 200 25/ 5 00 25	M30 1 ¹ / ₄		3½	2¾	0.197	13½	11	171//8	5	22½	25	3	81/16	29½	
832 222 95 708 629 133 484 298 356 5 88 97 $32\frac{3}{4}$ $8\frac{3}{4}$ $3\frac{3}{4}$ $27\frac{7}{8}$ $24\frac{3}{4}$ $5\frac{1}{4}$ $19\frac{1}{16}$ $11\frac{3}{4}$ 14 0.197 $3\frac{7}{16}$ $3\frac{1}{3}$	M36 1½		97 3 ¹³ / ₁₆	88 3½6	5 0.197	356 14	298 11¾	484 19 ¹ ⁄ ₁₆	133 5¼	629 24¾	708 27½	95 3¾	222 8¾	832 32¾	

Series SDD Housings

Heavy Duty Series SDD

Servicing requirements for large size pillow blocks has become a standard practice for FAG, as demonstrated with a complete standard series of extra large ductile iron housings.

Substantiating that size does not prohibit flexibility, series SDD housings are designed to:

- accept shaft diameters as large as 43"
- accommodate a wide variety of spherical roller bearing options

FAG general duty housings

 provide the optional seal designs and other engineered features relative to

SDD Housing Selection

Essentially, SDD housing size is determined by the outside diameter of the bearing. Each housing size can be machined to accept a range of outside diameters and therefore a variety of bearings as illustrated in the table opposite.


This table allows basic housing dimensions to be established when bearing selection has already been made from one of the eight common bearing series.


For final details, such as seal design, float requirement, or any optional feature, please consult an FAG engineering representative.

Hous	ing Di	mensions	by Bearin	g Selectio	on	
Dooring	- O D	Basic Bea	ring Number			
Bearing mm From	To	Series 239	*Series 230	Series 240	*Series 231	
270	280	23940	23036	24036	23132 23134	
290	300	23944	23038	24038	23136	
310	320	23948	23040	24040	23138	
340)		23044	24044	23140	
360	370	23952	23048	24048	23144	
400	420	23960	23052 23056	24052 24056	23148	
440)	23964			23152	
460	480	23968 23972	23060 23064	24060 24064	23156	
480	520	23976	23068	24068	23160	
540	560	23980 23984	23072 23076	24072 24076	23164	
580	600	23988	23080	24080	23168 23172	
620	650	23992 23996	23084 23088	24084 24088	23176 23180	
680	720	239/530	23092 23096 230/500	24092 24096 240/500	23184 23188	
760	800	239/600	230/530	240/530	23192 23196	
820	870	239/630	230/560 230/600	240/560 240/600	231/500 231/530	
920	980	239/710	230/630 230/670	240/630 240/670	231/560 231/600	
1030	1090	239/800	230/710 230/750	240/710 240/750	231/630 231/670	

^{*} Preferred bearing series







							Н	ousing Din	nensions					
Series 241	Series 222	*Series 232	Series 223	h mm/in.	a mm/in.	b mm/in.	c mm/in.	m Max. mm/in.	Min. mm/in.	n mm/in.	h1 mm/in.	g mm/in.	g1 mm/in.	Mounting Bolts mm/in.
	22230	23230	22326	170 6.693	510 20½16	180 7½	70 2¾	436 17 ³ / ₁₆	424 16 ¹¹ / ₁₆	100 3 ¹⁵ / ₁₆	335 13 ³ ⁄16	230 9½ ₁₆	240 9½ ₁₆	M24 1
	22232	23232	22328	180 7.087	530 20 ½	190 7½	75 3	456 18	444 17½	110 4 ¹¹ / ₃₂	355 14	240 9 ⁷ ⁄ ₁₆	250 $9^{27}/_{32}$	M24 1
24138	22234 22236	23234 23236	22330	190 7.480	560 22½16	210 8¼	80 3 ⁵ / ₃₂	486 19 ¹ / ₈	474 18 ²¹ / ₃₂	$\frac{120}{4^{23}/_{32}}$	375 14¾	260 10 ¹ / ₄	270 10 ⁵ / ₈	M24 1
24140	22238	23238	22332	210 8.268	610 24	230 9½16	85 3 ¹¹ / ₃₂	517 20 ¹¹ / ₃₂	503 19 ¹³ / ₁₆	130 5½	410 16 ⁵ / ₃₂	280 11 ¹ / ₃₂	290 11 ¹³ / ₃₂	M30 1 ¹ / ₄
24144	22240	23240	22334	220 8.661	640 25 ³ ⁄16	240 9½16	90 3 ¹ /⁄ ₃₂	547 21 ¹⁷ / ₃₂	533 21	140 5½	435 17 ¹ / ₈	290 11 ¹³ / ₃₂	300 11 ¹³ / ₁₆	M30 1 ¹ / ₄
	22244	23244	22338 22340	240 9.449	700 27 ⁹ / ₁₆	260 10 ¹ / ₄	95 3¾	607 23 ²⁹ / ₃₂	593 23 ¹ / ₃₂	150 5 ²⁹ / ₃₂	475 18 ²³ / ₃₂	310 12 ⁷ / ₃₂	326 12 ²⁷ / ₃₂	M30 1 ¹ / ₄
	22248	23248		260 10.236	775 30½	280 11 ¹ / ₃₂	100 3 ¹⁵ ⁄ ₁₆	658 25 ²⁹ / ₃₂	642 25%32	160 6 ⁵ ⁄ ₁₆	515 20%32	320 12 ¹⁹ / ₃₂	337 13¼	M36 1½
	22252		22344	280 11.024	790 31½	280 11 ¹ / ₃₂	105 4½	678 26 ¹¹ / ₁₆	662 26 ¹ / ₁₆	160 6 ⁵ ⁄ ₁₆	550 21½	335 13 ³ ⁄16	354 13 ¹⁵ ⁄16	M36 1½
24160	22256	23252 23256	22348	300 11.811	830 32 ¹¹ / ₁₆	310 12 ⁷ / ₃₂	110 4 ¹¹ / ₃₂	718 28¼	702 27 ⁵ / ₈	190 7½	590 23 ¹ / ₄	350 13 ²⁵ / ₃₂	360 14 ³ ⁄ ₁₆	M36 1½
	22260	23260	22352	320 12.598	885 34 ²⁷ / ₃₂	330 13	115 4 ¹ /⁄ ₃₂	758 29 ²⁷ / ₃₂	742 29 ⁷ / ₃₂	200 7½	630 24 ¹³ / ₁₆	370 14%	380 14 ³¹ / ₃₂	M36 1½
24168 24172	22264	23264	22356	360 14.173	1000 39 ³ / ₈	370 14%	120 4 ²³ / ₃₂	872 34 ¹¹ / ₃₂	848 33 ³ / ₈	230 9½16	705 27¾	410 16 ¹ / ₈	418 16 ⁷ / ₁₆	M45 1¾
	22268 22272	23268 23272	22360	390 15.354	1118 44	394 15½	127 5	978 38½	952 37½	235 9 ¹ ⁄⁄ ₄	762 30	457 18	468 18 ⁷ / ₁₆	M50 2
24184	22276 22280	23276 23280		425 16.732	1200 47¼	420 16 ¹⁷ / ₃₂	127 5	1048 41 ¹ ⁄⁄⁄	1022 40 ¹ ⁄⁄ ₄	251 9 ⁷ / ₈	841 33 ¹ / ₈	500 19 ¹¹ / ₁₆	510 20 ¹ ⁄ ₁₆	M50 2
24192 24196	22284 22288	23284 23288	22376	470 18.504	1454 57¼	470 18½	146 5¾	1257 49½	1232 48½	260 10 ¹ / ₄	940 37	562 22½	574 22 ¹⁹ / ₃₂	M56 2 ¹ / ₄
241/500	22292 22296	23292 23296	22380	520 20.472	1530 60¼	520 20½	160 6 ⁵ ⁄ ₁₆	1314 51¾	1286 50%	270 10 ⁵ / ₈	1030 40%	620 24½	626 24 ⁵ / ₈	M56 2 ¹ / ₄
241/560 241/600	222/500 222/530	232/500 232/530	22392 22396	575 22.638	1676 66	565 22 ¹ ⁄⁄₄	175 6¾	1455 57 ¹ ⁄⁄⁄	1430 56 ⁵ ⁄16	292 11½	1140 44 ⁷ / ₈	673 26½	704 27 ²³ / ₃₂	M64 2½
241/630 241/670	222/560 222/600	232/560 232/600	223/500 223/530	625 24.606	1830 72	610 24	185 7¼	1632 64¼	1600 63	314 12 ³ / ₈	1245 49	730 28¾	740 29½	M64 2½

<sup>This table applies only to SDD series housings
Bearing series 241.. can be used for direct shaft mount only, without locknut</sup>

Special Designs

When the size or application requirements of a bearing housing lie outside the parameter of standard series production, the design concept, the material selection and the manufacturing process require specialized insight and experience. Venturing into new technical territory to solve complex applications is a unique area of expertise for the FAG engineering group.

From meeting special sealing and lubrication requirements to accommodating unique bearing arrangements and mountings, FAG lends its engineering versatility towards functional design innovations that improve long term serviceability and operating costs.



Schaeffler Canada Inc.

2871 Plymouth Drive Oakville, ON Canada L6H 5S5 Tel.: (905) 829-2750

Tel.: (905) 829-2750 Fax: (905) 829-2563 Every care has been taken to ensure the correctness of the information contained in this publication but no liability can be accepted for any errors or omissions. We reserve the right to make changes in the interest of technical progress. © by Schaeffler Canada 2006

This publication or parts thereof may not be reproduced without our permission.

SuperTac II



The Drop-In Taconite Sealing Solution



At the Sign of Contamination

The Seal that Delivers

Given the severe service conditions to which FAG pillow blocks are so ideally suited, it is common for the rolling bearings and integral components of the pillow block assembly to be at risk of being adversely affected by environmental contamination. In order to prevent bearing failure due to localized pollutants, FAG has added a new solution to our line of seal design options: the drop-in SuperTac II.

Features

- SuperTac II drops in to fit the seal grooves of FAG series SAF housings, as well as many competitive designs
- Non-contact seal
- •Seal flinger equipped with 2 set screws, spaced at 65° interval, for optimum holding power to the shaft
- An O-ring in the flinger bore prevents the ingress of fluids between the seal and the shaft
- Available in a wide range of standard inch and/or metric shaft diameters

Benefits


- Promotes extended bearing life
- Drop-in design eliminates the need for special housing features
- Non-contact design eliminates shaft wear common to competitive designs
- Accepts greater misalignments than lip seals
- Exceptional speed characteristics; equivalent to bearing speed limits

Design

- New and exclusive FAG design for severe service conditions
- Features a grease packed labyrinth formed by high grade spring steel laminar rings
- Rings align into two close running barriers, separated by a lubricant distribution channel
- Complemented by the grease purged axial labyrinth, the result is a seal arrangement that stands virtually impenetrable to external contaminants
- Manufactured from high grade steel
 - Supplied with black oxide coating as standard
 - Special design option of nickel plating, with chromium nickel steel laminar rings also available



SHAFT DIAMETER INCH/MM	BASIC PILLOW BLOCKNO.	SUPERTAC II SEAL NO.	g INCH/MM	gı INCH/MM	SHAFT DIAMETER INCH/MM	BASIC PILLOW BLOCK NO.	SUPERTAC II SEAL NO.	g INCH/MM	gı INCH/MM
1 ⁷ / ₁₆ 50	SAF509	TA17 N/A	3.420 87	5.91 150	4 ³ / ₁₆ 110	SAF524	TA113 N/A	7.125 181	10.314 262
1 ¹¹ / ₁₆ 50	SAF510	TA20 N/A	3.420 87	5.91 150	4 ⁷ / ₁₆ 115	SAF526	TA117 TA117M	7.750 197	11.214 285
1 ¹⁵ / ₁₆ 50	SAF511	TA24 TA24M	3.750 95	6.269 159	4 ¹⁵ / ₁₆ 125	SAF528	TA122 TA122M	7.375 187	10.818 275
2 ³ / ₁₆ 60	SAF513	TA29 N/A	4.250 108	6.782 172	5 ³ / ₁₆ 135	SAF530	TA125 TA125M	8.125 206	11.890 302
2 ⁷ / ₁₆ 65	SAF515	TA37 N/A	4.625 117	7.367 187	5 ⁷ / ₁₆ 140	SAF532	TA130 TA130M	8.500 216	12.215 310
2 ¹¹ / ₁₆ 70	SAF516	TA44 TA44M	4.750 121	7.520 191	515/16 150	SAF534	TA140 TA140M	9.250 235	13.150 334
2 ¹⁵ / ₁₆ 75	SAF517	TA53 TA53M	4.813 122	7.740 197	6 ⁷ / ₁₆ 160	SAF536	TA148 TA148M	9.625 244	13.720 348
3 ³ / ₁₆ 80	SAF518	TA188 TA188M	5.500 140	8.138 207	6 ¹⁵ / ₁₆ 170	SAF538	TA155 TA155M	10.500 267	14.671 373
3 ⁷ / ₁₆ 90	SAF520	TA102 N/A	5.813 148	9.025 229	7 ³ / ₁₆ 180	SAF540	TA159 TA159M	11.000 279	15.417 392
3 ¹⁵ / ₁₆ 100	SAF522	TA109 TA109	6.438 164	9.682 246	7 ¹⁵ / ₁₆ 200	SAF544	TA167 TA167M	11.750 298	16.265 413



When operating conditions do not allow for compromises, demand the most from your housing selection with FAG ductile iron pillow blocks. FAG offers a full line of general duty housings designed to accept shaft

diameters ranging from 1%6° to $7^{15}\%6$ °, machined to fit inch or metric shaft dimensions.

WL 90 122 EC/ED

When the size or application requirements of a bearing housing lies beyond standard production, FAG lends its engineering versatility towards functional design innovations that improve long term serviceability and operating costs. Amid a receding list of competitors, FAG is continually breaking new ground with large size and special design housings.

WL 90 123 EC/ED



FAG Bearings Corporation

200 Park Avenue

Danbury CT USA 06813-1933

Tel.: (800) 243-2532 Fax: (203) 830-8171

FAG National Sales Division

6255 Cantay Road

Mississauga ON Canada L5R 3Z4

Tel.: (905) 890-9770 Fax: (905) 890-9779



FAG SUPERTAC II for "SAF" Series Housings

SEAL PREPARATION AND INSTALLATION INSTRUCTIONS

NOTE: Leave all parts in protective wrapping until ready to assemble


1. Separate the flinger from the adapter. Slight resistance is expected due to the inherent spring tension of the piston rings.

2. Pack the groove between the piston ring with the same grease as used for the bearing. It is not necessary to pack the piston—

rings themselves with grease.

3. Pack the labyrinth area of the flinger with grease.

4. Place the flinger on the bench with piston rings upward and centred in their grooves. Set the chamfered end of the adapter over the piston rings. With even pressure applied to the adapter ring, the unit will slide together.




ANNULAR GREASE DAM

- 5. Repeat packing and assembly instructions for the second seal.
- 6. Check that the set screws do not protrude into the flinger bore, then slide the inboard seal unit onto the shaft.

NOTE: A lead in chamfer is recommended on the shaft to avoid O-Ring damage. A small amount of lubricant will also be helpful.

- 7. Follow installation instructions for the bearing, sleeve and locknut as outlined in the FAG pillow block catalogue.
- 8. Install the outboard seal onto the shaft and locate both seals in the groove of the housing base. If one end of housing is closed, insert the endcover.
- 9. Before installing housing cap, adjust the flingers to provide 1/16" axial running clearance and tighten the two set screws in each flinger, then install housing cap. In the case of a floating unit the axial clearance may have to be adjusted.
- 10. If the grease fitting can be safely accessed during operation, the seal should be purged soon after start-up. Pump grease until purging around the flinger is visible and re-grease as the application schedule requires with the same grease used for the bearing. If the grease fitting cannot be safely reached, purge the seal at the next equipment shutdown.



FAG Supertac II Axial Clearance Setting

"SAF"	Shaft	Complete	* Flinger
Housing	Dia. (ref)	Seal No.	Protrusion (mm)
509	1 7/16	TA17	9.5
.000	40 mm	INA	- 0.0
510	1 11/16	TA20	9.5
310	45 mm	NA NA	- 0.0
511	1 15/16	TA24	9.5
	50 mm	TA24M	- 0.0
513	2 3/16	TA29	9.5
	60 mm	NA	
515	2 7/16	TA37	9.5
	65 mm	NA	
516	2 11/16	TA44	9.5
	70 mm	TA44M	
517	2 15/16	TA53	11.5
	75 mm	TA53M	
518	3 3/16	TA188	11.5
STEEL STATE OF THE	80 mm	TA188M	
520	3 7/16	TA102	11.5
	90 mm	TA102M	
522	3 15/16	TA109	11.3
	100 mm	TA109	
524	4 3/16	TA113	10.7
	110 mm	NA	
526	4 7/16	TA117	13.5
	115 mm	TA117M	
528	4 15/16	TA122	12.5
	125 mm	TA122M	
530	5 3/16	TA125	13.0
	135 mm	TA125M	
532	5 7/16	TA130	11.6
	140 mm	TA130M	
534	5 15/16	TA140	12.5
	150 mm	TA140M	
536	6 7/16	TA148	13.5
	160 mm	TA148M	
538	6 15/16	TA155	13.0
	170 mm	TA155M	
540	7 3/16	TA159	13.5
	180 mm	TA159M	
544	7 15/16	TA167	13.5
	200 mm	TA167M	

^{*} This is the distance from the adaptor side face to the outboard face of the flinger and may be helpful when positioning the flinger axially.

Mounting and Dismounting of Rolling Bearings



FAG Industrial Bearings AG

WL 80 100/3 EA



Mounting and Dismounting of Rolling Bearings

Publ. No. WL 80 100/3 EA

FAG Industrial Bearings AG A company of the FAG Kugelfischer Group

Postfach 12 60 · D-97419 Schweinfurt Tel. +49 97 21/91 31 42 · Fax +49 97 21/91 38 09 http://www.fag.com

Rolling bearings are heavy-duty machine elements with high-precision components. In order to fully utilize their capacity, the design engineer must select the right bearing type and design and match the bearing properties to those of the mating components. Mounting and dismounting, lubrication, sealing and maintenance must also be given special attention.

Appropriate means for mounting and dismounting of rolling bearings as well as utmost cleanliness and care at the assembly site are necessary in order to enable the bearings to reach a long service life.

This publication is intended to inform bearing servicemen and maintenancemen on handling, mounting and dismounting, lubrication and maintenance of rolling bearings. A special chapter deals with bearing failures and their causes. The tables in the annex specify bearing numbers, tolerances of bearings and their mating components, bearing clearance and FAG rolling bearing greases Arcanol.

For information on special mounting and dismounting tools and methods and on measuring instruments, further publications are available. Bearing mounting problems beyond the scope of this publication should be referred to our Engineering Service.

Table of Contents

1.	Rolling bearing storage	8
2.	How to prepare rolling bearings for mounting	
0.4	and dismounting	
2.1	Work planning.	
2.2	The "right" bearing	
2.3	Handling of rolling bearings before mounting	
2.4	Cleanliness in mounting	10 11
2.5	Surrounding parts	
2.6	Fits	
2.7.1	Cylindrical seats	12
2.7.1	Tapered seats	
2.1.2	Tapereu SeatS	15
3.	Rolling bearing mounting	18
3.1	Mechanical methods	
3.1.1	Mounting of cylindrical bore bearings	
3.1.2	Mounting of tapered bore bearings	24
3.2	Thermal methods	29
3.2.1	Heating plate	
3.2.2	Oil bath	
3.2.3	Hot air cabinet	32
3.2.4	Induction heating device	
3.2.5	Induction coil	
3.2.6	Cooling	
3.3	Hydraulic method	
3.4	Clearance adjustment on mounting	40
3.4.1	Angular contact ball bearings and tapered roller	
0.4.0	bearings	
3.4.2	Thrust bearings	
3.4.3	Machine tool bearings	46
4.	Rolling bearing dismounting	51
4.1	Mechanical methods	
4.1.1	Dismounting of cylindrical bore bearings	52
4.1.2	Dismounting of tapered bore bearings	55
4.1.2.1	Dismounting of adapter sleeve mounted bearings	
4.1.2.2	Dismounting of withdrawal sleeve mounted bearings	56
4.2	Thermal methods	57
4.2.1	Heating ring	57
4.2.2	Induction coil	58
4.2.3	Ring burner	
4.3	Hydraulic method	60
4.3.1	Dismounting of tapered bore bearings	61
4.3.2	Dismounting of cylindrical bore bearings	63

Table of Contents

5. 5.1	Lubrication	
5.1	GreasesOils	
5.3	Selection of lubricant	
5.5	Selection of lubricant	00
6.	Rolling bearing damage	70
6.1	Why does a bearing fail?	
6.1.1	Faulty mounting	
6.1.2	Contamination	
6.1.3	Corrosion	
6.1.4	Passage of electric current	
6.1.5	Imperfect lubrication	
6.2	How to recognize bearing damage in operation?	
6.3	How to pinpoint bearing damage?	
6.3.1	Observations prior to dismounting	
6.3.2	Observations during dismounting	
6.3.3	Bearing inspection	81
7.	Tables	83
7.1	Bearing designation	
7.1	Designation of bearing series	
7.3	Shaft tolerances	
7.3 7.4	Housing tolerances	
7.5	Normal tolerances of FAG radial bearings	70
7.5	(except tapered roller bearings)	94
7.6	Normal tolerances of FAG tapered roller bearings	
7.7	Normal tolerances of FAG thrust bearings	
7.8	Limit dimensions of chamfer	
7.9	Radial clearance of FAG deep groove ball bearings	
7.10	Radial clearance of FAG self-aligning ball bearings	
7.10	Radial clearance of FAG cylindrical roller bearings	
7.12	Radial clearance of FAG spherical roller bearings	
7.12	Radial clearance of FAG barrel roller bearings	
7.13	Axial clearance of FAG double row angular contact	100
7.14	ball bearings (series 32 and 33)	107
7.15	Axial clearance of FAG four-point bearings	
7.16	Radial clearance reduction of FAG cylindrical roller	100
7.10	bearings with tapered bore	109
7.17	Radial clearance reduction of FAG spherical roller	109
7.17		110
7 10	bearings with tapered bore	
7.18	FAG rolling bearing greases Arcanol	111
	Rolling bearing mounting cabinet and mounting sets –	
	Fundamental course for vocational training	112
	Selection of FAG publications	

Chart: Tools and Methods for Mounting and Dismoun

	Bearing type	Bearing bore	Bearing size	Mounting with heating				without heating
	Deep groove ball bearing Magneto bearing Angular contact ball bearing Spindle bearing Four-point bearing Tapered roller bearing Barrel roller bearing Spherical roller bearing	cylindrical	small			Summite.	8	
<u> </u>	Self-aligning ball bearing		large					
	Cylindrical roller bearing	cylindrical	small					
	Needle roller bearing		medium	111111				
			large	11				
-	Thrust ball bearing	cylindrical	small			Significant of the state of the	90	
$\overline{\mathbb{P}}$	Angular contact thrust ball bearing		medium				 	
丑	Cylindrical roller thrust bearing							
\longrightarrow	Spherical roller thrust bearing		large					
8	Self-aligning ball bearing Self-aligning ball bearing with adapter sleeve	tapered	small					5.
	Barrel roller bearing Barrel roller bearing with adapter sleeve Spherical roller bearing		medium	m				
	Spherical roller bearing with adapter sleeve Spherical roller bearing with withdrawal sleeve Adapter sleeve Withdrawal sleeve		large					
	Cylindrical roller bearing, double row	tapered	small					
			medium					
			large					

ting

Dismounting						Symbols		
	Hydraulic method	with heating	without heating			Hydraulic method		
								Oil bath
							Summit.	Heating plate
						N N		Hot air cabinet
								Induction heating device
							####	Induction coil
		####				X		Heating ring
								Hammer and mounting sleeve
								Mechanical and hydraulic presses
							3.	Double hook wrench
								Nut and hook wrench
								Nut and thrust bolts
								Axle cap
								Hydraulic nut
								Hammer and metal drift
								Extractor
						N N		Hydraulic method

1. Rolling Bearing Storage

- 1: Rolling bearing storage
- a: Large bearings especially should not be stored upright.
- They should be stored flat and supported over their entire circumference.





Leave bearings in their original package

Store bearings in their original package in order to protect them against contamination and corrosion. Open package only at the assembly site immediately prior to mounting.

Store larger bearings flat

Larger bearings with relatively thin-walled rings should not be stored upright (Figure 1a) but flat and supported over their whole circumference (Figure 1b).

Prior to packing, FAG rolling bearings are dipped in anticorrisive oil. This oil does not gum and harden and is compatible with all commercial rolling bearing greases. In their original package rolling bearings are safely protected against external influences.

Store bearings in dry rooms

During storage, the bearings must not be exposed to the effects of aggresive media such as gases, mists or aerosols of acids, alkaline solutions or salts. Direct sunlight should be avoided. The formation of condensation water is avoided under the following conditions:

- Temperatures + 6 to + 25 °C, for a short time 30 °C
- temperature difference day/night ≤ 8 K, relative air humidity ≤ 65 %.

With standard preservation, bearings can be stored up to 5 years if the said conditions are met.

If the permissible storage period is exceeded, it is recommended to check the bearings for its preservation state and corrosion prior to use. On request, FAG will help to judge the risk of longer storage or use of older bearings.

Bearings with shields or seals on both sides should not be kept to their very limit of storage time. The lubricating greases contained in the bearings may change their chemico-physical behaviour due to aging (see FAG catalogue WL 41 520).

How to Prepare Rolling Bearings for Mounting and Dismounting

2.1 Work Planning

Prior to mounting and dismounting of rolling bearings, several preparatory steps should be taken.

Study the shop drawing to familiarize yourself with the design details of the application and the assembly sequence. Phase the individual operations and get reliable information on heating temperatures, mounting and dismounting forces and the amount of grease to be packed into the bearing.

Whenever rolling bearing mounting and dismounting require special measures, the bearing serviceman should be provided with comprehensive instructions on mounting details, including means of transport for the bearing, mounting and dismounting equipment, measuring devices, heating facilities, type and quantity of lubricant.

Study shop drawing and phase individual operations

2.2 The "Right" Bearing

Prior to mounting, the bearing serviceman must make sure that the bearing number stamped on the package agrees with the designation given on the drawing and in the parts list. He should therefore be familiar with the bearing numbering and identification system (see tables 7.1 and 7.2, pp. 83 to 85).

Standard bearings are identified by the bearing number listed in the pertinent standards and rolling bearing catalogues. Its structure is a system of numerals and letters. The first group in the system identifies the bearing type and diameter series, also the width series for some bearings. The second group constitutes the bore reference number; for bearings of 20 to 480 mm bore, the actual bore diameter in millimetres is five times the bore reference number.

If operating conditions call for a bearing with special design features, the required bearing characteristics are indicated by suffixes added to the bearing number (see table 7.1, p. 83).

Non-standardized FAG bearings are identified by code numbers from the 500 000 or 800 000 series.

Compare inscription on package with data on drawing

Preparations

2.3 Handling of Rolling Bearings before Mounting

FAG rolling bearings are preserved in their original package, with an anticorrisive oil. The oil need not be washed out, when mounting the bearing. In service, the oil combines with the bearing lubricant and provides for sufficient lubrication in the run-in period.

Wipe clean seats and mating surfaces of anticorrosive oil

The seats and mating surfaces must be wiped clean of anticorrisive oil before mounting.

Wash out anticorrisive oil with cold-cleaning agent from tapered bearing bores prior to mounting in order to ensure a safe and tight fit on the shaft or sleeve. Then thinly coat the bore with a machine oil of medium viscosity.

Wash out used and contaminated bearings

Prior to mounting, wash used and contaminated bearings carefully with kerosene or cold-cleaning agent and oil or grease them immediately afterwards.

Do not rework rings

Do not perform any rework on the bearing. Subsequent drilling of lubrication holes, machining of grooves, flats and the like will disturb the stress distribution in the ring resulting in premature bearing failure. There is also the risk of chips or grit entering the bearing.

2.4 Cleanliness in Mounting

Keep work area dust-free and dry

Absolute cleanliness is essential! Dirt and humidity are dangerous offenders, since even the smallest particles penetrating into the bearing will damage the rolling surfaces. The work area must, therefore, be dust-free, dry and well removed from machining operations. Avoid cleaning with compressed air.

Wipe clean seats and mating surfaces of anticorrosive oil

Ensure cleanliness of shaft, housing and any other mating parts. Castings must be free from sand. Bearing seats on shaft and in housing should be carefully cleaned from anti-rust compounds and residual paint. Turned parts must be free from burrs and sharp edges. After cleaning, the housing bore should receive a protective coating.

2.5 Surrounding Parts

All surrounding parts should be carefully checked for dimensional and form accuracy prior to assembly

Non-observance of the tolerances for shaft and housing seat diameters, out-of-roundness of these parts, out-of-square of abutment shoulders etc. impair bearing performance and may lead to premature failure. The responsibility of such faults for bearing failure is not always easy to establish and much time can be lost in looking for the cause of failure.

Check mating parts for dimensional and form accuracy prior to bearing mounting

2.6 Fits

Good bearing performance is largely dependent on adherence to the fits specified for the rings in the drawing (see table 7.3 and 7.4, pp. 86 to 100).

No one can give a straight answer to the question of the "right" fit; indeed the selection of fits is determined by the operating conditions of the machine and the design characteristics of the bearing assembly. Basically, both rings should be well supported over their seating areas and should therefore be tight fits. This is, however, not always possible, since it makes mounting and dismounting more difficult and is unfeasible with applications calling for easy axial displacement of one ring, for instance with floating bearings.

The interference produced by tight fits expands the inner ring and contracts the outer ring resulting in a reduction of radial clearance. Therefore, the radial clearance should be adapted to the fits.

The shaft and housing tolerances should be checked. Too loose a fit causes the ring to creep on the shaft which tends to damage both ring and shaft. It also affects the working accuracy of the machine or causes premature raceway fatigue from poor support. On the other hand, too tight a fit may result in detrimental preload and hot running of the bearing.

As the walls of rolling bearing rings are relatively thin, possible poor geometry of the mating parts is transmitted to the raceways. The seats must therefore be checked for diameter and form tolerances. For cylindrical seats, cylindricity is checked (DIN ISO 1101). For tapered seats, roundness (DIN ISO 1101), taper angle and straightness (DIN 7178) are checked.

The seating surfaces of shaft and housing smoothen, when joined, the bearing surfaces usually to a lesser degree. The rougher the surfaces, the more marked is the loss in interference. Therefore, the roughness of the bearings seats (DIN 4768) is also checked.

Observe ring fits specified on drawing

Check shaft and housing tolerances

Check form tolerance of shaft and housing seats

Check roughness of bearing seats

Preparations

2.7 Inspection of Bearing Seats

For all measurements ensure that the measuring instrument has approximately the same temperature as the parts to be measured.

2.7.1 Cylindrical Seats

Shafts are generally checked with external micrometers (Fig. 2); The measuring accuracy must be checked by calibration.

2: External micrometer for measuring shaft diameters



3: A snap gauge ensures safe positioning and perfect measurement of cylindrical seats. The diameter for setting the gauge is marked on the master ring.



Another useful instrument is the snap gauge shown in fig. 3. It functions as a comparator and its correct setting is checked with master rings. These master rings are supplied by FAG for each diameter.

Bores are checked with internal micrometers (Fig. 4).

Conventional comparative measuring instruments are also used (Figs. 5 to 7).



4: Internal micrometer for bore measurements




5: Comparative measuring instruments are especially suitable for bore measurements. The master ring is used for setting.

6: A housing bore is measured with a bore measuring instrument.



7: Principle of the measurement with a bore measuring instrument (determination of the minimum dimension).





Check diameter and cylindricity of shaft and housing seats

Shaft and housing seats are checked for their diameter and their cylindricity.

Normally, the diameter is measured in two different cross sections and several planes (two-point measurement) (Figs. 8 and 9).

8, 9: Usually the cylindricity of shaft and housing seats is checked by measuring the diameter in two cross sections and several planes (two-point measurement).





Unless otherwise specified in the shop drawing, the cylindricity tolerance should not exceed half the diameter tolerance (two-point measurement).

According to DIN ISO 1101, the cylindricity tolerance refers to the radius. The tolerance values specified according to this standard must therefore be doubled for two-point measurements.

2.7.2 Tapered Seats

Full inner ring support on the shaft requires exact coincidence of shaft taper and inner ring bore taper.

The taper of rolling bearing rings is standardized. For most bearing series it is 1:12, for some large width series 1:30.

The master taper ring (Fig. 10) is the simplest measuring device.

Conformity of shaft and master taper is ascertained by blueing. An inadequate shaft taper must be improved, until the master ring shows full width support. FAG supply master tapers for taper diameters from 25 to 150 mm.

Bearing inner rings should not be used as master rings.

For the exact checking of tapered shaft seats FAG developed the taper measuring instruments MGK 133 and MGK 132. The use of a reference taper or segment enables exact measurement of the bearing seat taper and diameter. Both instruments are easy to handle; the workpiece to be measured need not be removed from the machine.

Do not use bearing inner rings as master taper rings Use FAG taper measuring instruments MGK 133 and MGK 132 for exact checking



 Master taper ring for checking small tapered bearing seats

11: Taper measuring instrument FAG MGK 133 for tapers with outside diameters of 27 to 205 mm and lengths of less than 80 mm



The taper measuring instrument FAG MGK 133 is provided for tapers of less than 80 mm length (Fig. 11).

Measuring Ranges

Taper measurir instrument	ng MGK 133A	MGK 133B	MGK 133C	MGK 133D	MGK 133E	MGK 133F	MGK 133G	
Taper dia. [mn	1] 2747	4767	6787	87115	115145	145175	175205	
Taper	Тар	Taper 1:12 and 1:30 (other angles on request)						
Min. taper length [mn	n] 17	21	28	34	42	52	65	
Dist. betw. mea		15	20	25	33	45	58	



12: Taper measuring instrument FAG MGK 132 for tapers with outside diameters of 90 to 820 mm and lengths of more than 80 mm

The taper measuring instrument FAG MGK 132 is used for tapers of a minimum length of 80 mm and a minimum diameter of 90 mm (Fig. 12).

Measuring Ranges

Taper measuring instrument	MGK 132B	MGK 132C	MGK 132D	MGK 132E	MGK 132F
Taper dia. [mm]	90210	190310	290410	390510	490820
Taper	Taper 1:12 and 1:30 (other angles on request)				
Min. taper length [mm]	80	80	110	125	140
Dist. betw. meas. planes [mm]	20	20	25	30	36

3. Rolling Bearing Mounting

The various bearing types and sizes require different mounting methods. Depending on the individual conditions these can be mechanical, hydraulic or thermal.

Do not subject bearing rings to hammer blows

For non-separable bearings apply mounting force directly to the ring to be mounted


As the hardened bearing rings are sensitive to blows, these must never be applied directly to the rings.


On mounting of non-separable bearings (Fig. 13), the mounting forces must always be applied to the ring which will have the tight fit and therefore is the first to be mounted. Forces applied to the ring with the loose fit would be transmitted by the rolling elements, thus damaging raceways and rolling elements.

Mounting of separable bearings (Fig. 14) is easier, since the two rings can be mounted separately. In order to avoid score marks during assembly, slightly rotate the parts.

13: If a tight fit is required for the inner ring of a non-separable bearing, the bearing will first be mounted on the shaft; then the shaft and bearing assembly is pushed into the housing.

14: With separable bearings the rings can be mounted independently. This is especially advantageous when both rings get a tight fit. In order to avoid score marks, slightly rotate the parts when installing inner ring and shaft into outer ring and housing.






3.1 Mechanical Methods

3.1.1 Mounting of Cylindrical Bore Bearings


Bearings with a maximum bore of approximately 80 mm can be mounted cold. The use of a mechanical or hydraulic press is recommended (Fig. 15).



15: Bearings with a max. bore of 80 mm can be mounted on the shaft with a hydraulic press.

If no press is available, the bearing can be driven on the shaft by gentle taps with a hammer or mallet. However, a mounting sleeve with a flat face must be used in order to distribute the mounting force evenly over the entire ring circumference and to avoid damage to the bearing (Fig. 16).

The FAG mounting tool sets EINBAU.SET.ALU and EINBAU.SET.ST with perfectly matched precision components are suitable for correct mounting, see TI No. WL 80-49.





16: If necessary, small bearings can be driven on the shaft with gentle hammer taps, using an appropriate mounting sleeve.

The inside diameter of the sleeve should just be little larger than the bearing bore and, to avoid damage to the cage, its outside diameter should not exceed the inner ring shoulder height.

If a self-aligning bearing has to be pressed on the shaft and pushed into the housing at the same time, a disk should be used which bears against both bearing rings, thus avoiding misalignment of the outer ring in the housing (Fig. 17).

17: Simultaneous shaft and housing assembly of a bearing with the aid of a mounting disk.





18: For some self-aligning ball bearings, the mounting disk must be relieved.


Heat also small bearings to achieve heavy interference fits

In some self-aligning ball bearings, the balls protrude beyond the rings. In such cases, the disk must be relieved (Fig. 18).

If very tight fits are required, even small bearings should be heated for mounting, chapter 3.2.

With light metal housings the seating areas might be damaged by press-fitting the outer ring in the housing bore. In such cases, the housing should be heated or the bearing cooled.

19: The outer rings of large cylindrical roller bearings are positioned by means of a mounting lever.



Heavy bearing outer rings with sliding fit can be mounted with a mounting lever (Fig. 19).

In order to avoid damage to the raceway and roller surfaces the end of the mounting lever should be wrapped with cloths (do not use cotton waste).

Mounting of Needle Roller Bearings


Needle Roller Bearings with Machined Rings

The same mounting principles apply to needle roller bearings as to cylindrical roller bearings. Bearings mounted in groups must have the same radial clearance to ensure uniform load distribution.

Drawn Cup Needle Roller Bearings

Due to their thin outer rings the form accuracy for the drawn cup needle roller bearings is achieved by means of tight fits in the housing, making a lateral location unnecessary.

For mounting drawn cup needle roller bearings, special mounting mandrels are used. Usually the mandrel abuts the stamped bearing face which is hardened with smaller sizes. If the mounting mandrel is accurately dimensioned, it can be applied to an unhardened lip without deforming or jamming the needle roller and cage assembly (Figs. 20 and 21).



Drawn cup needle roller bearings are pressed into the housing with a mounting mandrel.

20: Drawn cup needle roller bearing, open ends

21: Drawn cup needle roller bearing, closed end

Needle Roller and Cage Assemblies

Needle roller and cage assemblies are mounted between shaft and housing. In order to avoid score marks on the raceways and needle rollers, the needle roller and cage assemblies should be slightly turned and remain unloaded on mounting.


Needle roller and cage assemblies can be axially guided in the housing or on the shaft (Fig. 22).

The distance between the lateral cage guiding surfaces must be large enough (tolerance H11) to prevent the needle roller and cage assembly from jamming.

The radial clearance of needle roller and cage assemblies depends on the machining tolerances of the hardened and ground raceways on the shaft and in the housing. Needle roller and cage assemblies mounted in groups must be fitted with needle rollers of the same tolerance group.


22: Needle roller and cage assemblies can be guided in the housing or on the shaft.


- a: Guidance in the housing
- b: Guidance on the shaft



Combined Needle Roller Bearings

The tight fits for the combined needle roller bearings require relatively high mounting forces. This must be borne in mind especially for needle roller-thrust ball bearings and needle roller-cylindrical roller thrust bearings with dust shield, where the ball or roller assembly of the thrust bearing is non-separable. It is advantageous to heat the housings for pressing-in these bearings.






- 23: Combined needle roller thrust ball bearings and needle roller cylindrical roller thrust bearings with dust shield must be pressed into the housing.
- a: Needle roller thrust ball bearing
- b: Needle roller cylindrical roller thrust bearing

Yoke Type Track Rollers

Since, in most cases, the inner ring of yoke type track rollers is subjected to point load, a tight fit on the shaft is not required. On mounting, ensure that the lubricating hole is located in the unloaded raceway zone. The outer ring of yoke type track rollers without axial guidance must be guided by lateral backing surfaces.




24: On mounting yoke type track rollers, the lubricating hole must be located in the unloaded zone of the raceway. The outer rings of yoke type track rollers without axial guidance must be guided by lateral backing surfaces.

Stud Type Track Rollers

On mounting stud type track rollers, the radial lubricating hole should be located in the unloaded zone of the raceway.


On mounting a stud type track roller in the through-hole of a machine frame, the stud must usually be secured against rotating when tightening the nut. This is enabled by a slot at the flanged end of the stud (Fig. 25).

25: Rotation of the stud during tightening of a stud type track roller is prevented by the slot at the flanged end of the stud.



When a stud type track roller is screwed into a blind hole, the tightening torque must be applied through the slot. For this purpose, an appropriate tool is required (Fig. 26). About 75% of the tightening torques listed in the catalogues can be safely applied with these tools.

26: The stud of a stud type track roller can be screwed into a blind hole with special tools.



3.1.2 Mounting of Tapered Bore Bearings

Bearings with tapered bore are either fitted directly on the tapered shaft journal or, if the shaft is cylindrical, on an adapter sleeve or a withdrawal sleeve.

The oil film applied to the washed out bearing bore, shaft and sleeve should be very thin. A heavier coating would reduce friction and thus ease mounting; however, in operation the lubricant would be gradually forced out from the joint with a slackening effect on the tight fit, causing the ring or sleeve to creep and corrosion to develop on the surfaces.

Forcing the bearing onto the tapered seat expands the inner ring and reduces radial clearance. Therefore the reduction in radial clearance can be used as a measure of the seating condition of the inner ring.

Apply just a thin oil film to washed out bearing bore and seats on shaft and sleeve

The reduction in radial clearance is the difference between the radial clearance prior to mounting and the radial clearance after bearing mounting. It is necessary to determine the initial radial clearance before mounting and then to check the clearance repeatedly during mounting until the proper amount of reduction and thus the required tight fit are obtained.

Instead of measuring the reduction in radial clearance the distance the bearing is forced onto the tapered seat can be measured. For the standard inner ring bore taper of 1:12 the ratio of axial drive-up to radial clearance reduction is approximately 15:1. This ratio considers the fact that the expansion of the inner ring is more than 75 to 80% of the amount of interference existing between the fitted parts.

If, with small bearings, the exact axial drive-up cannot be measured, the bearing should be mounted outside the housing. The bearing should be driven up the tapered seat just enough to still turn smoothly and to allow the outer ring to be easily swivelled by hand. The serviceman must have a "touch" for the smooth running feature.

The radial clearance reduction, the axial drive-up distance or the expansion should also be measured, when a bearing is being refitted.

Special attention should be given to the locknut, the position of which may have changed due to the broaching effect in the seating areas and the settling of the threads. The values for the recommended reduction of radial clearance are listed in the appendix (tables 7.21 and 7.22, pp. 111 and 112).

The radial clearance is measured with feeler gauges (Fig. 27).


In case of spherical roller bearings, the clearance must be measured simultaneously over both rows of rollers (Fig. 28). Identity of clearance values, such as measured over both rows of rollers, ensures that there is no lateral offset of the inner ring relative to the outer ring. Aligning of the ring faces alone is, because of the width tolerances of the rings, no guarantee against such an offset position.

Check radial clearance reduction, drive-up distance or expansion

Check radial clearance reduction, drive-up distance or expansion also during reassembly

Check radial clearance with feeler gauges





27: measuring radial clearance with feeler gauges before mounting

28: For spherical roller bearings, the radial clearance must be measured simultaneously over both rows of rollers.

Check inner ring expansion of separable bearings

29: Measuring the expansion of a cylindrical roller bearing inner ring with an external micrometer

Cylindrical roller bearings offer the advantage of separate installation of inner and outer rings; the inner ring expansion can be measured - by means of an external micrometer - instead of the reduction of radial clearance (Fig. 29).




Mechanical and hydraulic equipment is available to pressfit the bearing on its tapered seat or to press a sleeve in place. Which method is the best to a given application depends on the mounting conditions.


Mount small bearings with shaft nut and hook spanner

Press fit small and medium-size bearings with shaft nut on the tapered seat (Fig. 30). Tighten nut with hook spanner.

The adapter sleeve nut and hook spanner are used for driving small bearings onto the tapered seat of the sleeve (Fig. 31).

Shaft nuts are also used to press small withdrawal sleeves into the space between shaft and bearing inner ring (Fig. 32).






30: Press-fitting a spherical roller bearing with a shaft nut


31: Press-fitting an adapter sleeve mounted spherical roller bearing with the adapter sleeve nut

Double hook spanners

The double hook spanner sets FAG 173556 and 173557 are used for mounting self-aligning ball bearings onto adapter sleeves. Both sets include torque wrenches for more exactly determining the starting position before the bearing is driven onto the shaft.

On every double hook spanner there are rotation angles engraved for the self-aligning ball bearings that have to be mounted by means of these spanners so that the drive-up distance and radial clearance reduction can be adjusted accurately (Fig. 33).






32: Press-fitting a withdrawal sleeve with the shaft nut

33: Double hook spanner with engraved rotation angles for fitting self-aligning ball bearings

34: Mounting nuts with thrust bolts facilitate mounting of large with-drawal sleeves. Between nut and sleeve a ring is inserted.



For larger bearings, considerable forces are required to tighten the nut. In such cases, the mounting nut with thrust bolts shown in Fig. 34 facilitates mounting.


To avoid tilting of the bearing or sleeve, the mounting nut should just be tightened enough to make nut and ring bear flush against their mating part. Then the thrust bolts of hardened steel, evenly spaced around the circumference of the nut, - their number depending on the forces required - are diagonally tightened, until the required reduction in radial clearance is obtained.

As the taper connection is self-locking, the mounting nut can then be removed and be replaced by the locknut. The procedure can also be applied to bearings mounted on an adapter sleeve or directly on the tapered journal.


Use FAG hydraulic nuts for mounting of larger bearings


When mounting larger bearings, it may be advisable to use a hydraulic press. Figs. 35 and 36 show how a spherical roller bearing is being press-fitted with the aid of a hydraulic nut ¹⁾. Hydraulic nuts are available for all regular sleeve and shaft threads. The hydraulic pro-

¹⁾ See "FAG Hydraulic Nuts", Publ. No. WL 80 103 for nomenclature and dimensions.



35: Hydraulic nut for mounting tapered bore bearings on a tapered shaft





- 36: Mounting of a spherical roller bearing with an annular piston press.
- a: Mounting on an adapter sleeve
- b: Press fitting of a withdrawal


cedure described in chapters 3.3 and 4.3 is another valuable mounting and particularly dismounting aid.


3.2 Thermal Methods

If tight fits are specified for the inner rings on cylindrical shaft seats, the bearings are heated for mounting. Sufficient expansion is obtained when heated between 80 and 100°C. Accurate temperature control is essential in heating the bearings. If the temperature exceeds 120°C there is the risk of alteration of bearing grain structure resulting in a drop of hardness and dimensional instability.

For bearings with moulded cages of glass fibre reinforced polyamide the same temperature limits are valid as for the other rolling bearings.


Bearings with shields (Fig. 37a) and with seals (Fig. 37b) are packed with grease during manufacture. They can be heated up to 80°C maximum, but never in an oil bath.





- 37: Never heat bearings with shields or seals in an oil bath. The maximum heating temperature is 80°C.
- a: Bearing with shields
- b: Bearing with seals

38: A ring is inserted between a heating plate without thermostatic control and the inner ring of an E spherical roller bearing with polyamide cage.



3.2.1 Heating Plate

Provisionally, rolling bearings can be heated on a heating plate which should be thermostatically controlled. Turn the bearing over several times in order to ensure uniform heating.


If the temperature of a heating plate without thermostatic control exceeds 120°C, polyamide cages must not contact the heating plate. This can be avoided by inserting a ring between the plate and the bearing inner ring (Fig. 38).


3.2.2 Oil Bath

For uniform heating, rolling bearings are generally immersed in an oil bath which is thermostatically controlled to a temperature of 80 to 100°C. The bearing should not be in direct contact with the heat source. The best arrangement is to have a screen several inches off the bottom of the oil tank which will prevent uneven heating of the bearing and protect it from contaminants settling on the tank bottom (Fig. 39).

The bearings may also be suspended in the oil bath (Fig. 40). After heating, any oil adhering to the bearing should be well drained off and the fitting surfaces should be carefully wiped clean.

- 39, 40: Heating in an oil bath ensures uniform heating of the bearings: A temperature of 80 to 100°C can be easily controlled. Disadvantage: Risk of contamination.
- 39: Heating a deep groove ball bearing in an oil bath





40: Heating cylindrical roller bearing inner rings in oil bath

Mounting of heated rings or bearings requires some skill (Fig. 41). The parts should be rapidly pushed on the shaft and positioned squarely against the shoulder. A slight twisting motion during fitting facilitates the work. It is advisable to use heat-protective gloves or non-fraying cloths, but never cotton waste.

Larger bearings are generally transported with a crane. In this case the bearing is suspensed in mounting grippers (Fig. 42) or in a rope sling. Working with the rope sling is not easy. Ensure alignment of ring and shaft in order to prevent tilting.


Heat larger bearings for mounting

Do not use cotton waste in mounting work



41: Heated bearing parts are rapidly pushed on the shaft and positioned squarely against the shoulder. This is facilitated by a slight twisting motion.

42: Mounting grippers



Provide for immediate axial location of mounted ring

When positioning, the inner ring should be immediately held tight against the shaft shoulder, until it has cooled down to avoid any clearance between ring face and shoulder after cooling. This also applies to a pair of rings mounted side by side.

3.2.3 Hot Air Cabinet

A safe and clean method of heating rolling bearings is by use of a hot air cabinet. Thermostat regulation enables accurate temperature control. Careful operation excludes contamination of the bearings. However, heating the bearings in hot air takes considerable time, therefore adequately dimensioned hot air cabinets should be provided for bath mounting.

3.2.4 Induction Heating Device

Rolling bearings are brought up to mounting temperature in a fast, secure and clean manner with induction heating devices, which operate on the transformer principle. The devices are used above all for batch mounting.

With the six FAG induction heating devices any rolling bearing types including greased and sealed bearings are heated. The smallest device AWG.MINI is used for bearings with 20 mm bores upwards. The maximum bearing mass is about 20 kg. The field of application of the largest device AWG40 starts at 85 mm bores. The maximum bearing mass may amount to approximately 800 kg.

See FAG TI No. WL 80-47 for description.



43,44: The induction heating devices ensure fast, clean and secure heating up to mounting temperature.

43: FAG AWG3,5



44: FAG AWG13

45: Induction coil for 380 V with bearing inner ring




3.2.5 Induction Coil*)

Induction coils heat the inner rings of cylindrical roller and needle roller bearings of 100 mm bore onward.

The induction coils shown in this chapter can be used for both mounting and dismounting. They are, however, mainly used for ring withdrawal (chapter 4.2.2). Since heating for dismounting tight-fitted inner rings is very fast, the amount of heat transferred to the shaft is minimized so that the rings such as axle box roller bearings in rail vehicles, or for frequent dismounting and remounting of large-size bearings, as is the case for roll exchange in rolling mills.

FAG induction coils can be connected between two phases to the common three-phase current mains (50 or 60 Hz). For heating inner rings of a bore up to approximately 200 mm, coils are used which are connected directly to the 380 V mains (Fig. 45). For larger bearings the harmless low voltage equipment with 20 to 40 V at 50 Hz (60 Hz) should be used

Low voltage induction coils are connected to the mains (380 V) via transformer (Fig. 46). The water-cooled winding provides for a better efficiency, easier handling and lower weight of the device.





46: Low-voltage induction coil with transformer EFB 125/1, for cylindrical roller bearing inner rings of 635 mm bore 390 kg Ring weight: Approx. coil weight:

70 kg

47: Demagnetization of the inner ring of a cylindrical roller bearing by means of the induction coil

When the induction coils are used for mounting work, ensure that the rings are not overheated. The heatup times are indicated in the operating instructions.

The operating instructions also describe the use of the coil for demagnetization of the bearing rings upon completion of induction heating (Fig. 47).

See operating instructions for heatup times


3.2.6 Cooling

For a tight fit of the outer ring, the housing is heated in most cases to mounting temperature. With large and bulky housings, this may cause problems. In this case, the rolling bearing is cooled in a mixture of dry ice and alcohol. The temperature should not drop below -50°C.

The condensation water resulting from temperature equalization must be completely rinsed out of the bearing with oil in order to prevent corrosion.

Never cool bearings below -50°C

48: Principle of hydraulic mounting; fluid film buildup between the mating surfaces.




3.3 Hydraulic Method


With the hydraulic method, oil is injected between the mating surfaces. This may be machine oil, or oil containing rust dissolving additives. The oil film greatly reduces the friction between the mating parts which can then be easily displaced in relation to one another without the risk of surface damage. Fretting corrosion can be dissolved by means of kerosene or rust-dissolving additives to the oil.


Tapered bore bearings can be mounted on, and dismounted from, their tapered counterpart by the hydraulic method. Cylindrical bore bearings or sleeves are heated for mounting, whilst dismounting is performed hydraulically. For oil injection, oil grooves, feed channels and threaded connections for the pump are machined into shaft or the sleeve (Figs. 49, 50). See FAG publication WL 80 102 EA "How to Mount and Dismount Rolling Bearings Hydraulically" for technical details.


Hydraulic mounting of tapered bore bearings which are directly fitted on the tapered shaft end, requires but a small amount of oil. Simple, low feed injectors are therefore satisfactory (Fig. 51). FAG supply two sizes of oil injectors with connecting threads G 3/8 and G 3/4. The smaller oil injector is good for shaft diameters up to 80 mm, the larger for diameter up to 150 mm.

49: Position of the oil groove for a tapered bore bearing









50: Larger adapter and withdrawal sleeves feature oil grooves and oil collecting grooves.

a: Adapter sleeve, design HG

b: Withdrawal sleeve, design H

51: Oil injector and valve nipple for connecting thread G 3/8:

Injector: FAG No. 107640 Nipple: FAG No. 107642 for connecting thread G 3/4:

Injector: FAG No. 107641 Nipple: FAG No. 107643

It is different with cylindrical bore bearings and with adapter and withdrawal sleeves. Here, the oil loss occurring at the edges of the mating surfaces must be compensated by a higher rate of oil feed. This is achieved by an oil pump (Figs. 52 to 54), see FAG TI No. WL 80-46.

The fluid used is a machine oil of medium viscosity. Mounting work should be performed with an oil having a viscosity of about 75 mm²/s at 20°C (nominal viscosity 32 mm²/s at 40°C).



52: FAG Hand pump set PUMPE1000.4L, consisting of a two-step piston pump (1000 bar) with 4-litre oil container, manometer, 1 HP tube, plug-in joint (connecting thread G 1/4), metal box

53: FAG Hand pump set PUMPE1600.4L, consisting of a two-step piston pump (1600 bar) with 4-litre oil container, manometer, 1 HP tube, plug-in joint (connecting thread G 1/4), metal box



54: FAG Hand pump set PUMPE2500.8L.V, consisting of a two-step piston pump (2500 bar) with 8-litre oil container, two-wayvalve, manometer, 2 HP tubes, 2 closing nipples G 1/4, 2 adapters and 6 reduction adapters, metal box




Use shaft nut, thrust bolts or FAG hydraulic nut for mounting

Mounting of Tapered Bore Bearings

The bearing is pressed into position by a shaft nut, thrust bolts or the FAG hydraulic nut (see Fig. 35). Hydraulic withdrawal sleeves and adapter sleeves are provided with threaded oil bore connections M6, M8, G 1/8, G 1/4, depending on sleeve size (see FAG catalogue WL 41 520). The pumps shown in Figs. 52 to 54 feature an extreme pressure hose and are connected to the sleeve by reducing socket R, ERMETO tube E1 and steel pipe S (Fig. 55).

55: Hydraulic connection of a withdrawal sleeve





56: Mounting of a tapered bore spherical roller bearing by the hydraulic method

For mounting, oil is pumped between the mating surfaces. The axial forces required for mounting are applied through six or eight bolts located in the shaft nut or the adapter sleeve nut (Figs. 56 to 59).

A spacer between the bolts and the sleeve or bearing ring prevents damage to the latter. When pressing in a withdrawal sleeve as shown in Fig. 58, the pipe for the hydraulic fluid passes through the shaft nut. The amount of axial drive-up of the bearing or the withdrawal sleeve depends on the required reduction of radial clearance (tables 7.21 and 7.22, pages 111 and 112). The bearing must not, of course, be under oil pressure, when the radial clearance is being measured.

After relieving the oil pressure, the bearing is still kept under axial preload. Wait for 10 to 30 minutes, until oil has completely drained off from the fitting surfaces. As a final step, the mounting device (nut with thrust bolts or hydraulic nut) is removed and the shaft or sleeve nut put in place and locked. Relieve bearing of oil pressure prior to measuring radial clearance

Keep bearing under axial preload for 10 to 30 minutes after relief of the oil pressure


57: Bearing seated on shaft: The oil is pumped between the mating surfaces; at the same time pressure from bolts or a nut drives the bearing up the tapered journal. The reduction in radial clearance or the axial drive-up distance is measured.


58: Bearing seated on withdrawal sleeve: The oil is pumped between the mating surfaces. The sleeve is pressed into the bearing bore with bolts and the reduction in radial clearance is measured.


59: Bearing seated on adapter sleeve: The oil is pumped between the mating surfaces. Bolts drive the bearing up the sleeve and the radial clearance reduction is measured.


a: Oil bore in small end of sleeve

b: Oil bore in large end of sleeve









3.4 Clearance Adjustment on Mounting

3.4.1 Angular Contact Ball Bearings and Tapered Roller Bearings

Angular contact ball bearings and tapered roller bearings are always mounted in pairs. The axial and radial clearance of two bearings mounted in opposition is adjusted on mounting, the clearance or preload depending on the operating conditions. Angular contact ball bearings of universal design can be mounted in pairs or groups in any arrangement.

High loads and high speeds cause a temperature rise at the bearing location. This leads to thermal expansion and clearance variation. The type of clearance variation, i. e. an increase or a decrease, depends on arrangement and size of the bearings, the shaft and housing material and on bearing centre distance.

If close shaft guidance is required, the clearance is adjusted by stages. Each adjustment should be followed by a trial run and a temperature check. Thus, it is ensured that the clearance does not become too small, resulting in a higher running temperature.

A welcome effect of trial runs is that the whole bearing mounting "settles" and that, afterwards, the clearance practically remains stable (see also page 51).


The right temperature for a bearing, operating in the medium to high speed range under medium load, can, indicatively, be defined as follows: In the absence of extraneous heat, a correctly adjusted bearing is allowed to attain, during the trial runs, a temperature of about 60 to 70°C. After 2 or 3 hours running, this temperature should, however, drop, especially when in the case of grease lubrication, the churning action diminishes, after the excess grease is expelled from the bearing interior.


Bearings exposed to vibration at low speeds are mounted with zero clearance or even preloaded to avoid the risk of the balls or rollers brinelling the raceways. Angular contact ball bearings and tapered roller bearings are adjusted against one another by nuts on the shaft (Fig. 60), by shims (Fig. 61) or threated rings in the housing.

Axial clearance or preload of adjustable bearings is established by loosening or tightening the adjusting nut or by the insertion of calibrated shims. From the thread pitch, axial clearance and preload can be converted into turns of the adjusting nut.

A high speeds, adjust axial clearance by stages

Provide for zero-clearance or preload of a bearing exposed to vibration at low speeds





60: Adjustment of tapered roller bearings of a loose wheel with the shaft nut

61: Axial location of paired angular contact ball bearings; clearance adjustment with shim

Adjust with torque wrench


The changeover from clearance to preload during adjustment is found by constant manual rotation of the shaft. Simultaneously, a dial gauge is applied to check the axial freedom of the shaft.

A simpler method for correct bearing adjustment is the use of a torque wrench. The adjusting nut is tightened to the appropriate torque (e. g. for passenger car front wheel bearings 30 or 50 Nm. The right torque is determined in tests; the values are specified in the repair instructions).


Loosening of the nut by approximately 1/12th of a turn provides for the required clearance. In tapered roller bearings, the rollers should bear against the cone back face rib during assembly. If the rollers were to contact the rib only after mounting is completed, i. e. when the bearing should therefore be alternatively turned in both directions during mounting.

In matched, multi row tapered roller bearings (Figs. 62 and 63), the axial clearance is a function of the spacer width. To determine distance "a" FAG developed the measuring devices of series MGS 155. Details are gladly supplied on request.

62: Matched tapered roller bearings in X arrangement (suffix N11CA)




63: Double row tapered roller bearing in O arrangement



Example:

Installation and adjustment of tapered roller bearings in the wheel hubs of motor vehicles (Fig. 64).





64: Passenger car front wheel with adjusted tapered roller bearings

Proceed as follows:

- 1. Clean hub and carefully remove any chips and burrs.
- 2. Apply thin oil film to bearing seats. Press the two cups in place with a die. Make sure the die contacts only the cup face. Take care that the cup faces fit well against the hub shoulders (Fig. 65).
- Grease cone of inner bearing.
 Pack grease also in the spaces between cage, cone, and rollers (Fig. 66).
- 4. Insert cone into hub.
- Press shaft seal ring into hub with sealing lip pointing towards bearing.
- 6. Mount protective cap and spacer on the shaft. Make sure spacer face has full support against shaft shoulder (Fig. 67).
- 7. Mount hub on shaft; make sure seal is not damaged.


65: Fitting of the bearing cup with a die.






66: Pack roller/cage assembly of tapered roller bearing with grease


67: After the protective cap, the spacer is mounted on the shaft.






68: Tighten castle nut while rotating the wheel, until drag is felt.
Back off castle nut by 1/12 turn at the most, until alignment with next cotter pin hole is obtained and fit cotter pin


- 8. Apply grease well to cone of outside bearing and mount on shaft.
- 9. Mount safety plate.
- 10. Fit castle nut.
- 11. Tighten castle nut while the wheel is being rotated until drag is felt (use torque wrench, if possible; follow repair instructions).
- 12. Back off castle nut approximately 1/12 turn, until alignment with the next cotter pin hole is obtained and fit cotter pin (Fig. 68).
- 13. Check bearing for running smoothness and wobble. The wheel must not drag, but rotate freely. Be sure the wheel does not wobble. If necessary, change safety plate or nut. If the illustrated dial gauge (Fig. 69) is available, check axial clearance. 0 to 0.05 mm are optimum values.
- 14. Mount cover.
- Perform test run to check for change of bearing clearance. Readjust, if necessary.



69: Measurement of axial clearance

70: Zero clearance double direction thrust ball bearing





71: Cylindrical roller thrust bearing preloaded with shim S

This is a field-proven method of adjusting wheel bearings requiring no special tools. There are other methods which, however, necessitate mounting tools and measuring instruments. They are primarily intended for batch mounting.

3.4.2 Thrust Bearings


With thrust bearings, the shaft washers are generally transition fits, tight fits being the exception. The housing washers are always loose fits. The shaft washer of double direction thrust bearings should always be positively locked axially (Fig. 70). The mounting and dismounting of thrust bearings offers no difficulties.

3.4.3 Machine Tool Bearings

For machine tool spindles, the correct adjustment of bearing clearance is of paramount importance because it controls the quality of the machined workpieces. For correct adjustment, on mounting, of the operating clearance or preload specified by the designer, FAG developed special measuring devices. These are used for today's widely employed spindle bearing arrangements with double row cylindrical roller bearings (Fig. 72). The correct preload of double direction angular contact thrust ball bearings is automatically adjusted during mounting.

The radial clearance of a mounted cylindrical roller bearing is equal to the difference between the boundary circle diameter of the rollers, and the raceway diameter of the lipless ring. For gauging the boundary circle, FAG supply the boundary circle measuring instruments MGI 21 and MGA 31.

The raceway diameter of cylindrical roller bearings NNU49SK is measured with a snap gauge, the raceway diameter of series NN30ASK with a plug gauge.



72: Bearing assembly of a fineboring spindle (work end). The radial clearance of the double row cylindrical roller bearing is adjusted on mounting.

FAG boundary circle measuring instruments are comparators allowing to measure the radial clearance within a measuring accuracy of ± 1 micron.

For precise adjustment of the radial clearance, the form accuracy of the bearing seats, i. e. their roundness, cylindricity or taper, is important (also see p. 12 "Inspection of bearing seats").


Boundary Circle Measuring Instrument MGI 21

The radial clearance or preload of cylindrical roller bearings with separable inner ring (NNU49SK) is the difference between the diameter of the circle under the rollers H_i and the raceway diameter F. The circle under the rollers is the circle which contacts all rollers from inside, when they are in contact with the outer ring raceway (Fig. 73).

The circle under the rollers is measured with the aid of the instrument MGI21; the radial clearance of the mounted bearing can be determined together with a snap gauge (Fig. 74).

The two opposed steel segments of the boundary circle measuring instrument form the measuring surfaces. The lower segment is stationary, the upper can be displaced; the movement being read from the dial gauge.

73: Diameter under rollers H_i of cylindrical roller bearings NNU49SK (separable inner ring)




After having determined the boundary circle of the mounted outer ring roller assembly, this value is transmitted to the snap gauge. During inner ring mounting on the tapered shaft seat, the expansion of its raceway diameter is constantly checked with the aid of the snap gauge. Positive values on the dial gauge indicate preload, negative values indicate radial clearance; a zero value indicates a clearance-free bearing.

74: The measured diameter under rollers is transmitted to the dial indicator snap gauge. The boundary circle measuring instrument FAG MGI 21 is used for cylindrical roller bearings with separable inner ring, such as FAG NNU49SK.



Mounting



75: Diameter over rollers H_a of cylindrical roller bearings NN30ASK (separable outer ring)

Boundary Circle Measuring Instrument MGA 31

The radial clearance or preload of cylindrical roller bearings with separable outer ring (NN30ASK) is the difference between the diameters of the raceway E and the circle over the rollers $\rm H_a$. The circle over the rollers is the circle which circumscribes all rollers when they are in contact with the inner ring raceway (Fig. 75).



76: The measured raceway diameter is transmitted to the boundary circle measuring instrument with the aid of an internal dial gauge. The boundary circle measuring instrument FAG MGA 31 is used for cylindrical roller bearings with separable outer ring, such as FAG NN30ASK.

Mounting

The circle over the rollers is measured with the instrument MGA 31; the radial clearance of the mounted bearing can thus be determined together with an internal dial gauge (Fig. 76).

The two opposed steel segments of the boundary circle measuring instrument form the measuring surfaces. One segment is stationary; the other can be displaced. The movement can be read from the dial gauge.

During measuring, the bearing outer ring has to be mounted in the housing. After having determined the outer ring raceway diameter with the aid of an internal dial gauge, this value is transmitted to the boundary circle measuring instrument.

During mounting, the inner ring with cage and roller assembly is pushed onto the tapered shaft seat until positive contact is established. The boundary circle measuring instrument is applied and the inner ring driven onto the taper seat, until the dial gauge indicates the required value.

Positive values indicate preload, negative values indicate radial clearance; a zero value indicates a clearance-free bearing.


The Steady-State Temperature as a Means of Clearance Control

In the case of high-speed spindles, the operating clearance or preload can be verified from the bearing temperature registered during trial runs.

For temperature control, the bearing housing must be provided with bores for the insertion of temperature sensors (Fig. 77). These bores should be drilled prior to bearing installation. To obtain the true bearing temperature, the sensors must be in direct contact with the bearing rings. Controlling merely the temperature of the cylindrical roller bearing will not do; the temperature of the preloaded angular contact thrust ball bearing should also be measured.

Sensors should contact bearing rings

77: Arrangement of heat sensors



4. Rolling Bearing Dismounting


The trial run should be long enough to allow the operating temperature to come to a steady state; this will happen after half an hour to three hours depending on machine size. Steady-state temperatures from 50 to 60°C are acceptable, when the spindle operates at its top speed; experience has shown that at this temperature bearing clearance is optimum.


4. Rolling Bearing Dismounting

If the bearings are intended for re-use, dismounting must be performed most carefully; it is imperative that the extracting tool be applied to the ring to be extracted to prevent the rolling elements from brinelling the raceways (Fig. 78a). In addition, thin-walled outer rings involve the risk of ring fracture (Fig. 78b).

With non-seperable bearings, first withdraw the ring with sliding fit from its seat and then dismount the tight-fitted ring. The force required for dismounting is generally higher than the mounting force, since, as time passes, the ring becomes embedded on its seat. Even with loose-fitted rings, fretting corrosion may make dismounting work difficult.


Apply tool to the ring to be extracted






78a: Wrong! Do not apply dismounting force through the rolling elements, if you want to re-use the bearing.

78b: If dismounting through the rolling elements is unavoidable, put a collar of unhardened steel round the outer ring (thickness 1/4 greater than bearing cross section height). This applies especially to bearings with small cross section height and small contact angle (such as tapered roller and spherical roller bearings). The bearings shall not be reused.





79: Start dismounting of nonseparable bearings with the loose-fitted ring.

80: The ring of separable bearings can be dismounted separately.

4.1 Mechanical Methods


4.1.1 Dismounting of Cylindrical Bore Bearings


Small bearings are usually dismounted with the aid of mechanical extracting devices (Figs. 81, 82) or hydraulic presses (Fig. 83). These are applied either directly to the tight-fitted ring or to the mating parts, such as the labyrinth ring.

81: Dismounting of a barrel roller bearing with an extractor




- 82: Extracting devices for rolling bearings
- a: Extractor with puller arms for split ring
- b: Extractor with three adjustable arms





83: Dismounting is facilitated by use of a press.



Provisionally, small bearings can be driven off their seat with a hammer and a metal drift (Fig. 84, right). The light hammer blows should be applied evenly round the whole circumference of the tight-fitted ring.


Dismounting is greatly facilitated, if extracting slots are provided so that the extractor can be directly applied to the tight-fitted bearing ring (Figs. 85, 86 and 87).


Provide extracting slots






84: Provisional bearing dismounting by hammering left: wrong right: correct (use soft metal drift)






Do not subject the bearing rings to hammer blows

85: Slots in the shaft shoulder to apply bearing extractor




87: Slots for bearing outer ring removal



When the inner ring abuts the shaft shoulder and when no extracting slots are provided, ball bearings, tapered roller bearings and cylindrical roller bearings can be dismounted with a special extractor. With the ball bearing extractor (Figs. 88, 89c), the clamping piece inserted in the extractor engages with finger-shaped extensions between the balls at the inner ring raceway edge; with extractors for cylindrical and tapered roller bearings the clamping piece engages behind the rollers (Fig. 89a).

88: Ball bearing extractor with clamping piece



89a: Collet for tapered roller bearings and cylindrical roller bearings with separable outer rings/cups

89b: Collet for tapered roller bearings and N-type cylindrical roller bearings with unseparable outer rings (cups).

89c: Collet for deep groove ball bearings



The clamping piece forms part of a collet and is clamped against the inner ring with a tapered clamping ring. The extraction force is generated by a spindle. This extractor enables bearings mounted in the housing to be withdrawn from the shaft.


Mechanical FAG extractors see TI No. WL 80-48.

4.1.2 Dismounting of Tapered Bore Bearings


4.1.2.1 Dismounting of Adapter Sleeve Mounted Bearings

For dismounting bearings directly seated on the tapered shaft or an adapter sleeve, loosen the locking device of the shaft or sleeve nut. Loosen nut by an amount corresponding to the drive-up distance. Drive inner ring off the adapter sleeve or tapered shaft seat by gentle hammer taps, using a soft metal drift (Fig. 90) or, even better, a piece of tubing (Fig. 91).

When a press is used, support the adapter sleeve or the loosened adapter sleeve nut and withdraw the bearing from the sleeve.




90: Dismounting of a small, adapter sleeve mounted spherical roller bearing. The inner ring is driven off the sleeve by means of a metal drift.



91: Dismounting of an adapter sleeve mounted self-aligning ball bearing. The use of a piece of tubing prevents damage to the bearing.

92: Hydraulic nut for dismounting an adapter sleeve mounted spherical roller bearing




Adapter sleeves can be released with a hydraulic nut provided the bearing rests against an angular support ring. The nut should take support on a plate or the like (Fig. 92).


4.1.2.2 Dismounting of Withdrawal Sleeve Mounted Bearings


Withdrawal sleeve mounted bearings are removed by means of the extraction nut (Fig. 93a). For this purpose, the shaft nut must be removed. In difficult cases (for large-size bearings), extraction nuts with additional thrust bolts can be used (Fig. 93b). A washer is inserted between inner ring and thrust bolts.

Dismounting of withdrawal sleeves is much easier and less costly with hydraulic nuts (Fig. 94). Withdrawal sleeves projecting beyond the shaft end, should be backed up by a thick-walled support ring.

- 93: Dismounting of a withdrawal sleeve
- a: with extraction nut
- b: with nut and thrust bolts applied to the inner ring through a washer







94: Hydraulic nut for dismounting a withdrawal sleeve mounted spherical roller bearing. The projecting portion of the sleeve is backed up by a thick-walled support ring.

4.2 Thermal Methods

4.2.1 Heating Ring *)

Heating rings are used for dismounting cylindrical roller bearing and needle roller bearing inner rings without lip or with one lip only. The heating rings of light alloy are radially slotted. Their insulated handles provide for easy handling (Fig. 95).

With an electric heating plate, the heating rings are heated to a temperature of 200 to 300 °C, placed around the inner ring to be extracted and clamped by means of the handles. The heat is rapidly transferred from the heating ring to the inner ring. When the tight inner ring fit on the shaft is loosened, withdraw both rings simultaneously. After extraction, remove the inner ring immediately from the heating ring to avoid overheating. Heating rings are of great advantage for occasional withdrawal of small or medium-size bearing rings, each bearing size requiring its own heating ring.

*) For details see TI No. WL 80-9 "FAG Aluminium Heating Ring".



95: Heating rings are used for dismounting cylindrical roller and needle roller bearing inner rings.

4.2.2 Induction Coil*)


Induction coils (also see chapter 3.2.5) are used for withdrawing shrunk-on cylindrical roller and needle roller bearing inner rings of 100 mm bore onward from the shaft. Since the coil heats up at a very fast rate, the amount of heat transferred to the shaft is minimized so that the rings can be easily withdrawn.

Induction coils can be connected between two phases to the common three-phase mains (50 Hz or 60 Hz). For dismounting rolling bearings with a maximum bore of 200 mm, coils are used which are connected directly to the 380 V mains. For larger bearings, the harmless low voltage equipment - 20 to 40 V/50 Hz (60 Hz) - should be used.

Low voltage induction coils are connected to the mains (380 V) via a transformer (Fig. 96). The water-cooled winding provides for a better efficiency, easier handling and lower weight of the coil.

For extraction, the induction coil is pushed over the inner ring and the fingers provided on the coil grip the ring at its back face. The labyrinth ring features milled recesses to allow positioning of the fingers. The current is switched on and, as soon as the ring is heated to 80 to 100° C, the current is disconnected and the ring together with the appliance removed from the shaft.

 $^{\star}\!)$ For details see publ. no. WL 80107 EA "FAG Induction Heating Equipment".



70 kg

Approx. coil weight


4.2.3 Ring Burner

If no oil grooves are provided in the shaft for hydraulic mounting, and if electric devices are not economical, inner rings of larger separable bearings can also be dismounted by heating them with a flame.

Never should a welding torch be used because of the danger of overheating or unequal heating of the ring. The uniform, high hardness and dimensional stability of the bearing ring could be affected.

Ring burners (fig. 97) have proven to be an acceptable solution. The burner should clear the ring surface by 40 to 50 mm. At the usual gas pressure, the diameter of the burner jet is 2 mm. Flame temperature and flame length are adjusted by the addition of air. The burner jets should be bored in staggered arrangement and be spaced 20 to 45 mm apart. For small rings and heavy interference fits, the burner should be operated for maximum heat output. Air should only be added after burner ignition. There must be provisions for the air pressure to be delicately adjustable, since excessive pressure may force the gas back into the mains.

Use ring burner



97: Ring burner for dismounting inner rinas

The surfaces of the hardened bearing rings are susceptible to overheating which reduces hardness and changes the dimensions. The burner should, therefore, always be held concentric to the bearing ring. The burner should be moved slowly and evenly across the bearing ring in the axial direction. This will avoid a tempering effect and additional stressing in the ring.

Sometimes heavy fretting corrosion or cold welding can make the regular removal of bearing rings impossible. In such cases which, of course, only apply to unserveiceable rings, these are heated by a welding torch to 350°C and hosed with cold water. The heavy internal stresses thus produced in the ring will make it crack. Since the ring is likely to burst, the area of dismounting must be well screened or cov-

Crack unserviceable rings for a removal

Safety information


If - for example when a bearing is dismounted by means of a welding torch - a temperature of approx. 300°C and above is reached, fluorinated materials can release gases and vapours that are detrimental to human health. FAG uses fluorinated materials for seals made of flurocaoutchouc (FKM, FPM, e. g. Viton®) or for fluorinated lubricating greases such as the rolling bearing grease Arcanol L79V. If high temperatures cannot be avoided, the safety data sheet valid for the fluorinated material in question has to be observed that can be obtained on request.

4.3 Hydraulic Method

ered to avoid accidents.

With the hydraulic method, oil is injected between the mating surfaces. The oil film greatly reduces the friction between the mating parts which can then be conveniently displaced in relation to one another without the risk of damaging the mating surfaces (see chapter 3.3).

The hydraulic method is suitable for dismounting bearings with tapered and cylindrical bore. In both cases, oil grooves, ducts and threaded connections for the pump must be provided (Fig. 98). Larger adapter and withdrawal sleeves feature the corresponding grooves and holes (Figs. 101, 102).



98: Position of oil grooves for dismounting by the hydraulic method.

- a: Tapered shaft seat;
- b: Cylindrical shaft seat, bearing width B \leq 80 mm, a $\approx \sqrt{d}$:
- c: Cylindrical shaft seat, bearing width B > 80 mm, $a \approx \sqrt{d}$; $b \approx (0.5 \text{ to } 0.6) \text{ B}$;
- d: Cylindrical shaft seat, two inner rings mounted side by side; bearing width B > 80 mm; $a \approx \sqrt{d}$, $c \approx B$ $(1.5 \text{ to } 2) \sqrt{d}$

For dismounting tapered bore bearings directly seated on the shaft, injectors will do for pressure generation (Fig. 51). Cylindrical bore bearings and adapter and withdrawal sleeve mounted bearings require a pump (Fig. 52, chapter 3.3).

For dismounting, a thicker oil with a viscosity of about 150 mm²/s (cSt) at 20°C (nominal viscosity 46 mm²/s at 40°C) can be used. If the contact surfaces are damaged, a high-viscosity oil of about 1,150 mm²/s (cSt) at 20°C (nominal viscosity 320 mm²/s at 40°C) should be used. Fretting corrosion can be dissolved by anti-corrisive additives in the oil.

4.3.1 Dismounting of Tapered Bore Bearings

For hydraulic dismounting of bearings, mounted on a tapered journal, a withdrawal sleeve or an adapter sleeve, oil is pumped between the surfaces in contact. This releases the press fit instantly. The release being rather abrupt, a stop should be provided to control the movement. This may be a shaft or sleeve nut or any other convenient means (Figs. 99 to 102).

Restrict axial movement!





99: Dismounting a withdrawal sleeve mounted spherical roller bearing by the hydraulic method.

Dissolve fretting corrosion by the addition of rust solvents


The incidence of fretting corrosion may render dismounting more difficult. In this case, a rust-dissolving hydraulic oil should be used, especially for bearings of long service. For a seized withdrawal sleeve, the extra force required to set it moving can be applied through the withdrawal nut. If the withdrawal nut features thrust bolts (Fig. 103), a plate or washer should be inserted between the bolts and the bearing, to avoid damaging the lips of the bearing ring.

100: Bearing seated on shaft; the oil is pumped between the surfaces in contact; bearing disengages spontaneously. Stop to be left on shaft to restrict bearing movement.







101: Bearing seated on withdrawal sleeve: Oil is pumped into withdrawal sleeve bore and O. D.; withdrawal sleeve disengages spontaneously. Nut to be left on shaft.




- a: Oil connection in small end of sleeve
- b: Oil connection in large end of sleeve





103: Dismounting in difficult cases: Oil containing rust solvents is pumped between the mating surfaces. Higher-viscosity oils should be used. Sleeve extraction is facilitated by applying nut provided with thrust bolts.





4.3.2 Dismounting of Cylindrical Bore Bearings


For cylindrical bore bearings, the use of the hydraulic technique is generally limited to dismounting.

The first step is to apply a bearing extractor to the bearing ring (Figs. 104 a-c). Then, hydraulic oil is pumped into the oil grooves.

When the bearing ring moves easily, it should be displaced far enough to expose the rear oil groove; the oil feed to this groove is stopped.







104: dismounting of a cylindrical bore inner ring with the hydraulic method

- a: Apply extractor to the inner ring and pump oil into the two oil grooves.
- b: Pull ring far enough to expose the rear oil groove and stop oil feed to this groove. The ring is given a further pull, until it covers the forward oil groove at either side by an identical length. The oil feed is stopped so that the ring will freeze.
- c: The extracting device is preloaded with a spring. Rebuilding the oil film enables the ring to slide off the shaft.

Then the ring is given a further pull, until the ring covers the forward oil groove at either side by an identical length (Fig. 104 b).

The oil feed to the forward groove is stopped which means that the ring will freeze again. A spring is inserted into the guide sleeve of the extractor and preloaded (Fig. 104 c).

The travel stroke of the extractor spring should be a little greater than the length occupied by the ring on the shaft. Rebuilding the oil film by vigorous pumping enables the extractor to slide the ring off the shaft. It is recommended to catch the ring on its way off.

The spring preload should be approximately $F = 20 \cdot d$ (F in N and d in mm). Whenever several rings are mounted on the shaft side by side, they are dismounted separately.


The displacement of the ring up to the point where the forward oil groove is still covered evenly, can generally be done by hand, since upon injection of the hydraulic oil, the rings are easily displaceable. The better the ring "floats" in the extraction phase, when the spring pressure pulls it from the shaft, the less the probability of its getting caught at the shaft end.

In the absence of oil grooves and ducts in the shaft, the oil can be injected between the mating surfaces from the inner ring front face (Fig. 105). To this effect, a sealed oil injection ring is placed in front of the bearing feeding pressurized oil into the fitting joint. Mounting a sleeve to the shaft end allows oil to be pumped between the mating surfaces all the time the dismounting operation lasts. If the use of such a sleeve is not possible, a high-viscosity oil of 320 mm²/s (cSt) at 40°C must be used. An oil of this viscosity maintains an adequate oil film for approximately 5 minutes which is sufficient for bearing removal.

Catch ring on its way off the shaft

Use oil injection ring for the removal of bearing from plain shafts

105: Special device for extracting a cylindrical bore spherical roller bearing from a shaft without oil grooves. The oil is fed into the fitting joint from the inner ring front face.



These special extracting devices are relatively complicated. They are, for example, used for applications where no oil grooves are provided in the shafts or axles for strength reasons, but which require frequent dismounting (e. g. for rail vehicles).

5. Lubrication

The primary purpose of the lubricant is to build a load-carrying film separating the bearing components in rolling and sliding contact in order to minimize friction and wear. The lubricant should also protect the bearing against corrosion. If required, it should also act as a sealant, and in case of circulating oil lubrication, as a coolant.

Due to deterioration and mechanical stressing, the lubricants become unuseable. Change of oil or grease or replenishment, i. e. bearing maintenance, has a favorable influence on the bearing service life. Under certain sealing and environmental conditions, appropriate lubricant selection allows for a lubrication for life. For detailed information see also FAG Publ. No. WL 81115 "Rolling Bearing Lubrication".

5.1 Greases

Only high-grade greases - generally on a metal soap basis - should be used. Rolling bearing greases for extreme temperatures contain different thickeners and a synthetic oil instead of the mineral oil.

Greases containing extreme pressure (EP) additives are used in high-load and low-speed applications. High-speed bearings and bearings which ask for low friction, are lubricated with greases containing a thin synthetic base oil.

The operating temperatures specified by the grease supplier should be kept in mind. Rolling bearing greases should be stable against deterioration and must not change their structure, even after long periods of operation.

Only use time-tested greases

Consider grease application range

Lubrication

The table 7.23 on p. 113 lists the FAG rolling bearing greases Arcanol and their properties.

5.2 Oils

Only use time-tested oils

For rolling bearing lubrication, mineral oils are generally used. They should have the following properties:

Utmost cleanliness, stability against deterioration, good viscosity-temperature behaviour and good water repellency. In addition, the lubricating oil must ensure satisfactory protection of the bearing against corrosion. Very high and very low operating temperatures require the use of synthetic oils. Oils for highly loaded and low-speed bearings should contain EP-additives.

5.3 Selection of Lubricant

Greases are generally preferred to oils because they simplify maintenance and can be used as sealants. The asset of oil is that it readily feeds into all areas of contact and carries off heat. Its disadvantage is that it involves a more complex design of the bearing location and especially of the sealing system.

The following factors determine the selection of lubricant:

Operating Temperature

Depending on the speed, the temperature of a bearing location is a function of bearing friction, lubricant friction, heat dissipation to the outside, and, as the case may be, heat supply from the outside.

Watch steady-state temperature

A bearing mounting is reliable, if the steady-state temperature settles at a level acceptable for the application. A continuous temperature increase, on the other hand, necessitates special measures (extra cooling, change-over to a different lubricant etc.). A short-term temperature rise occurs with grease relubrication.

The viscosity of lubricating oils decreases with increasing temperature and increases when the temperature drops. Preference should be given to oils the viscosity of which varies little with temperature (good V-T behaviour).

Watch viscosity at operating temperature

The higher the expected operating temperature, the higher should be the nominal viscosity of the oil. The nominal or mid-point viscosity is the viscosity for oils at 40°C. The oils are classified in viscosity grades (ISO VG) (DIN 51519).

Lubrication

The permissible temperature range of greases varies with the saponification bases. As a rule, the upper limits are:

Calcium soap base: + 50°C (120°F)

Sodium soap base: + 70°C (160°F) to 120°C (250°F)

Lithium soap base: + 110°C (230°F) to 130°C (265°F)

Diverse complex soap greases, gels, and greases containing entirely synthetic thickeners feature temperature limits beyond 130°C (265°F). Greases with thin synthetic base oils are especially applicable for low temperatures.

Exact values for the commercial greases are available from manufacturers' catalogues.

In selecting oils and greases, it should be borne in mind that a high temperature speeds up deterioration and decreases the lubricant service life. Exact values of greases with different saponification bases are available from manufacturers' catalogues

Loads and speed

Under the given operating conditions, the lubricant must form a load carrying lubricating film. With oil, the load carrying capacity of the film is primarily a function of viscosity. The lower the bearing speed, the higher the oil viscosity in operating condition. Information on viscosity ν_1 can be seen in the FAG catalogue WL 41520. Consideration must be given to the fact that bearing temperatures depend on load and speed. The operating temperature required for determination of the nominal viscosity must be estimated.

High-viscosity oils for low speeds

Increases in speed are associated with increasing lubricant friction and accordingly, increasing bearing temperature. The friction will be higher, the more viscous the lubricant is. On the other hand, higher temperatures lower viscosity which decreases the load carrying capacity of the lubricant film.

Observe relationship between speed, lubricant friction, temperature and viscosity

The permissible speeds for the various types and sizes of rolling bearings for grease and oil lubrication are listed in the FAG catalogues.

Permissible speeds for oil and grease lubrication see FAG Rolling Bearing Catalogues

The use of solid lubricants as e. g. graphite and ${\rm MoS}_2$ is limited to ultralow speeds and creeping motions only.

Solid lubricants only for creeping speeds

High-load applications call for oils containing EP additives. Greases for high-load applications are characterized by base oils of high viscosity and EP additives.

Lubrication

Bearing Size

Small bearings are generally lubricated with a low-viscosity oil or with a very soft grease to minimize lubricant friction in the bearing. In large bearings, the lubricant friction plays a minor role, and the choice between oil or grease is, in this respect, of secondary importance.

Moisture

Consider lubricant behaviour with moisture

The reaction of rolling bearing greases against moisture is different from one grease to the other. Only the water-repellent calcium base greases (Ca-greases) possess a safe sealing action against water. They are used, therefore, in labyrinths for operating temperatures not exceeding 50°C, acting as sealing agents.

The sodium base greases feature a higher limiting temperature than the calcium greases. They emulsify with water and are indicated for applications with a limited amount of moisture (e. g. condensation water). Since the sodium base greases are water-absorbing, there is the risk that so much water will be absorbed that they will wash out of the bearing.

Lithium base greases do not absorb as much water as sodium base greases. Because of their reasonable resistance to water and their wide temperature range they have become the greases of preference for rolling bearings.

Also with oils, their moisture and water resisting properties must be considered. Oils that separate water well should be preferred, because they allow the water to settle in the oil sump or reservoir when the machine is at rest.

The protection against corrosion is improved by anti-corrosive additives in the oils or greases.

Contamination

Maintain cleanliness of lubricant reservoir, lubricators and grease nipples.

Relubrication involves the risk of bearing contamination. High standards of cleanliness should, therefore, be maintained for the lubricant reservoir and the lubricators and also when handling the lubricant. Grease nipples should be cleaned before relubrication.

Mixing of Lubricants

Lubricants of different saponification bases should not be mixed to avoid impairment of temperature stability and lubricating properties. The same applies to oils.

Never mix different lubricants

Lubricant Quantity

With grease lubrication, the bearing cavities should be packed to capacity. Only partly fill (20 to 35% of free space) extremely fast running bearings. The amount of grease to be filled into both lateral housing cavities depends on n \cdot d_m.

(n = maximum operating speed

$$d_m = \frac{D+d}{2}$$
 mean bearing diameter)

Speed index	Amount of grease filled in the housing space			
$n \cdot d_m < 50000 \text{ min}^{-1} \cdot \text{mm}$	full			
$n \cdot d_{m} = 50000 \text{ up to } 500000 \text{ min}^{-1} \cdot \text{mm}$	60%			

Overgreasing at medium and higher speeds causes churning resulting in an undesirable temperature rise which may harm both bearing and lubricant.

Rolling bearings with seals or shields are packed with grease to approx. 35% only during manufacture.

With oil lubrication, too much oil in the housing has similarly detrimental effects: the churning action overheats the oil and exposes it to air oxygen, causing oxidation and foaming.

With sump lubrication, the oil level in the housing should be no higher than the centre point of the lowest ball or roller when the bearing is at rest.

6. Rolling Bearing Damage

The life of a rolling bearing depends on the total number of stress cycles and the loads incurred by rolling elements and raceways.


The standardized calculation method for dynamically stressed bearings is based on material fatigue (pitting) causing the damage.

Normal fatigue manifests itself by flaking or spalling of the rolling surfaces (Fig. 106). An increasing local stress may result in fracture of the ring (Fig. 107).

If the bearing fails earlier than predicted by the life calculation, it should be checked for overloading. With this failure cause excluded, faulty mounting or poor maintenance or wear might be the cause for the damage. The following pages describe some of the more common forms of bearing damage and their causes.

106: Flaked inner ring of a deep groove ball bearing





107: Fracture of the inner ring of a deep groove ball bearing as final stage of fatigue

6.1 Why Does a Bearing Fail?

6.1.1 Faulty Mounting

Local damage to the raceways, such as nicks, score marks or indentations suggest faulty mounting. This type of damage occurs, if, for instance, the inner ring of a cylindrical roller bearing is inserted out-of-square into the outer ring, or if the mounting force is applied through the rolling elements (Figs. 108 to 111).

Surface damage is also caused, when foreign particles enter the bearing and are cycled (see chapter 6.1.2).

The damage can be recognized for instance by a louder running noise; in the long run, it may lead to premature fatigue of the functional surfaces.

The typical sign for surface damage are the raised edges of the indentations.




108: Ball indentations in the raceway of a deep groove ball bearing resulting from faulty mounting

109: Scored raceway of a cylindrical roller bearing inner ring



110: Premature fatigue of a cylindrical roller bearing outer ring caused by score marks visible at "a"




111: Fractured lip of a barrel roller bearing inner ring driven up its seat by hammer blows



The location of the load zone in a bearing ring results from the direction of the externally applied loads and from the conditions of rotation. The load zone can soon be recognized by slight frosting on the raceways indicating whether the bearing was loaded as specified.





112: Running tracks caused by offsquare mounting of a stationary deep groove ball bearing inner ring

113: One-sided flaking caused by off-square mounting of a stationary tapered roller bearing cone

Unusual running tracks suggest detrimental preloading which may be caused by too tight fits, excessive axial adjustment, form inaccuracies of shaft or housing, misalignment or by a tight fit of the floating bearing (Figs. 112 and 113).

6.1.2 Contamination

Foreign particle indentations in the functional surfaces may lead to premature fatigue (see chapter 6.1.1). Foreign particles with abrasive effect, however, accelerate bearing failure due to wear. The surfaces are roughened and look dull. Progressive wear causes excessive clearance.

Possible causes:

Contaminated parts
Moulding sand in housings
Inadequate seals
Contaminated lubricants
Metallic abrasion from gears brought into the bearing by the lubricant.

6.1.3 Corrosion

Corrosion in rolling bearings may occur in various forms and have different causes. The damage shows in an uneven and loud running noise. The rust abraded by the rolling elements causes wear.

Figures 114 and 115 show corrosion damage due to moisture or other corrosive media.

Possible causes:

Inadequate sealing against moisture, acid fumes, lubricants containing acids, condensation, unsuitable storage of the rolling bearings in the warehouse.

False brinelling is identified by marks in the raceways at rolling element spacing. In contrast to the rolling element indentations caused by incorrect mounting, they have no raised edges (Fig. 116). The increased number of indentations shown in Fig. 117 is a result of occasional turning of the bearing.

False brinelling is caused by vibrations in the contact areas of parts while these are stationary, resulting in wear. Susceptible to such damage are machines which are subjected to vibrations while stationary or during transportation. Possible remedy: Securing by wedges

114: Corrosion of tapered roller bearing cone





115: Corrosion marks in the raceway of a self-aligning ball bearing outer ring

or similar means for transportation or keeping the bearing in rotation (e. g. on ships).

Fretting corrosion, however, occurs at the fitting surfaces, i. e. in the bearing bore or at the bearing outside diameter. It is caused by relatively loose fits or too soft mating components. Minute motions (micro-slipping) in the fitting joint may cause heavy wear resulting in an impeded floating bearing function or fracture of the shaft due to notch stresses. Possible remedy: Tight bearing fits or reinforcement of mating structure.

6.1.4 Passage of Electric Current

Continuous passage of electric current causes brownish flutes parallel to the axis over the entire circumference of one or both raceways as well as on the rolling elements (Fig. 118 and 119).

6.1.5 Imperfect Lubrication

Starved lubrication is caused by an insufficient lubricant supply or by use of an improper lubricant. If the lubricating film does not sufficiently separate the parts in rolling contact, sliding motion and wear result. Since maximum material stressing occurs at the raceway surfaces, micro pits and consequently large-area superficial flaking is produced (Fig. 120).






116: Indents caused by false brinelling of the raceway of a selfaligning ball bearing outer ring

117: False brinelling in the raceway of a cylindrical roller bearing inner ring - due to vibrations

118: Fluted rollers of a spherical roller bearing due to the passage of electric current







119: Fluted raceway of a spherical roller bearing outer ring due to the passage of electric current

In the case of overlubrication, the lubricant heats up due to the churning action and looses its lubricity. Overheating, i. a. catastrophic failure of the bearing, may be the result. Prevent lubricant retention within the bearing, especially for high-speed bearings.

The possible consequences of contaminated lubricants are described in chapter 6.1.2.

120: A non load-carrying lubricating film causes large-area superficial flaking on cylindrical rollers.





6.2 How to Recognize Bearing Damage in Operation?

Symtoms	Examples			
Uneven running	Damaged rings or rolling elements Contamination Excessive clearance	Motor vehicles: Increased wheel wobble and vibration of steering system Fans: Increasing vibration Sawmills: Increasing knocking in connection rods Combustion engines: Increased vibration in crankshaft		
Reduced working accuracy	Wear due to contaminants or insufficient lubrication Damaged rings or rolling elements	Lathe: Gradual development of chatter marks on workpiece Grinders: Waviness of ground surface Cold Rolling Mill: Period surface defects on rolled material such as stretcher strains, ghost lines etc.		
Unusual running noise: Whining or high pitched noise	Insufficient operating clearance			
Low pitched rumbling or irregular noise	Excessive operating clearance Damaged running surfaces Contamination Inadequate lubricant	Electric motors, gears; with gearboxes, the bearing noise is hard to identify, since it is generally drowned in the running noise of the gears		
Gradual change in running noise	Changes in operating clearance caused by temperature. Damaged raceway (from contamination or fatigue)			

6.3 How to Pinpoint Bearing Damage?

The examples shown in Figs. 106 to 120 are striking damage cases. They can be clearly defined and diagnosed. A detailed discussion of all imaginable combinations of bearing damage would certainly go beyond the scope of this manual.

In the field, the diagnosis of the primary cause of failure is not always easy. In many cases an examination of, for instance, the running tracks, allows certain conclusions to be drawn. Advice for the avoidance of future trouble can, however, hardly be given without knowing operating conditions, lubrication and overall design of the machine. Information should, moreover, be available on the damage symptoms in evidence and on relevant secondary phenomena.

Keep track of operating behaviour and record observations

6.3.1 Observations prior to Dismounting

Prior to dismounting, the following four conditions should be surveyed and the survey result be made a matter of record. The importance of this procedure cannot be overemphasized, since, after bearing dismounting and cleaning of bearing and housing, this evidence is irretrievably lost.

Contamination

What are the overall conditions of the machine, particularly near the bearing location? Are there deposits of dirt or residues of the machined or processed material? Could water, causics, cutting fluids, vapours and fumes have entered the bearing housing?

Loss of Lubricant

Was there any chance of lubricant escape? To find out, check the oil gauge level and the sealing gaps at the shaft outlet, all joints between housing and cover, and the seals of the oil pipes, drain plug and oil gauge.

Running Noise

Bearing damage can frequently be recognized by changes in the running noise. The nature of the noise should be specified as exactly as possible by indicating whether it is even or pulsating, recurrent or nonrecurrent, rumbling, whining, singing, or knocking. If the noise is recurrent, its frequency should be recorded. For higher speeds, this may require complicated recording equipment; for low speeds,

however, it has been found practical to tap with a pencil on a piece of paper at the rate of noise recurrency, and to count the dots after a given number of seconds. The result should give a clue as to whether the trouble occurs, for instance, at inner ring or cage frequency. An attempt should also be made to assess the noise level.

Before disassembly, the bearing should once more be turned by hand. Often this allows easy identification and accurate characterization of running irregularities.

Keep track of behaviour and record observations

Case History and Secondary Evidence

The damage should be recorded, while still fresh in mind. It is important that all details be listed, i. e. the time the malfunction was first noticed, the initial symptoms and the alterations in noise or temperature occurring with time. If the trouble starts suddenly, the position of the control handles and the operating position of the machine should be noted. Any former modifications made on the machine, for instance clearance adjustment, installation of new shafts, sleeves, or spacers, increases in capacity and speed should be included in the analysis. When these modifications and the onset of the bearing trouble coincide, the expert will certainly be able to draw significant conclusions.

6.3.2 Observations during Dismounting

The following four conditions should be watched:

Lubrication

In order to examine the cause of failure of the dismounted bearing, the lubricant must not be removed. Even an expert cannot define the cause of failure of a damaged, but cleaned bearing. Avoid additional contamination of the damaged bearing.

Do not wash out lubricant, but take samples

Oil Lubrication

With oil-lubricated bearings, the oil and, as the case may be, the coolant, are drained. The oil should be collected in a clean container, especially, if there is suspicion of dirt, metal chips or an unusual amount of grit from nearby gears. If the suspicion proves true, enough oil will thus be available for a thorough investigation.

Grease Lubrication

Dismounting of grease-lubricated bearings starts with the removal of covers, caps or shields. These parts should not be immediately washed out, but stored in a clean place, until the nature of bearing failure is clarified. The same applies to felt and rubber seals and to any other seals and shields. Even if maintenance instructions call for the installation of new seals at each overhaul, the old ones should be kept for some time, as their condition may be indicative of the efficiency of the sealing system.

Two grease samples should be taken, one from the bearing interior and another from the housing. Dirty grease nipples may contaminate grease used for relubrication; in this case a sample should be taken from the grease duct.

A generous quantity should always be sampled. The sampled grease should be kept in clean containers or spread on clean oil-paper and identified such that its origin can be traced back any time.

Looseness of Locating Devices

As dismounting progresses, check tightness of the nuts which provide for axial location of the bearing inner ring. This is of particular importance with double row angular contact ball bearings with split inner ring, and with four-point bearings. Any loosening of axial location entails a change in bearing kinematics and clearance. This also applies to tapered roller bearings and angular contact ball bearings mounted in opposition. In the case of adapter and withdrawal sleeves and tapered seats, the tightness of the clamping or locknuts should be checked.

Position of Bearing Rings

Upon removal of the nuts, the ring faces should be cleaned to check the position of the rings relative to the housing and the shaft.

Generally, the running tracks on the raceways give sufficient evidence of the direction of load; this evidence is, however, of little value, if the running tracks are unusual and nothing is known on how the outer ring was mounted in the housing and the inner ring on the shaft. For this purpose, a sketch should be made showing the position of the bearing number stamping relative to a reference point in the housing or on the shaft. The sketch should also show the direction into which the stamped face of the bearing ring points, i. e. towards the shaft center or the shaft end. For separable bearings, such as cylindrical roller bearings, magneto bearings and four-point bearings, this applies to both rings. If, upon disassembly, the running tracks are found to be unusual, conclusions can be drawn as to the type and direction of load, perhaps also on detrimental preload, furnishing a clue to the cause of damage.

Check tightness of locating nuts

Prepare sketch of bearing arrangement

Examination of Bearing Seats

When extracting the bearing, a note should be made of any unusually easy or difficult removal of the rings from their seats. The bearing components of separable bearings must be kept together and not be mixed up with parts of other bearings.

An inspection of the adjacent machine parts should be made at the same time, especially when the machine has to be quickly reassembled with the new bearings to avoid a prolonged close-down. The shaft and housing seat diameters should always be measured. Special care should be given to the roundness of the seats. The condition of the driving and the driven machine elements, especially of gears and other moving parts, should also be inspected. Sliding marks and the contact pattern will frequently furnish evidence on the shaft misalignment.

Measure shaft and housing diameter, check roundness of seat


6.3.3 Bearing Inspection

Upon completion of dismounting, the damaged bearing itself should be examined. Check cleanliness, condition of the mating surfaces (dimensional stability) and function (bearing clearance, smooth running) of the complete bearing. The damage in evidence on the bearing and the recorded secondary phenomena are, in most cases, sufficient to obtain a clear picture of the damage history. Doubtful cases should be reported to the nearest FAG Engineering Office.

There are, of course, many applications where no necessity exists for going into such detail. This is the case with machines built in large numbers, where the "weak points" are known. Neither will one go to great lengths with low-cost bearings. However, in customer built or special purpose machines where a seemingly unexplainable bearing damage occurs, the described secondary evidence should, in any case, be a valuable diagnostic aid.

In case of doubt, contact the nearest FAG Engineering Office

7.1 Bearing Designation



Tables

7.2 Designation of Bearing Series: Ball Bearings

Bearing Series	Ball Bearings										
G 0.130	Deep Groove Ball Bear- ings	Angular Contact Ball Bear- ings	Type Self- Align- ing Ball Bear- ings	Thrust Ball Bear- ings	Angular Contact Thrust Ball Bear- ings	Single Row or Single Direc- tion	Double Row or Double Direc- tion	With Flat Hous- ing Wash- er	With Spheri- cal Hous- ing Wash- er	Width or Height Series	Diam- eter Series
618 160 60	X X X					X X X				1 0 1	8 0 0
62 63 64	X X X					X X X				0 0 0	2 3 4
42 43	x x						X X			2 2	2 3
12 112 13 113			X X X				X X X			0 0 0 0	2 2 3 3
22 23			x x				x x			2 2	2 3
B 719 B 70 B 72 72 73		x x x x x				x x x x x				1 1 0 0 0	9 0 2 2 3
QJ 2 QJ 3		x x				x x				0 0	2 3
32 33		X X					X X			3 3	2 3
511 512 513 514				X X X		X X X X		X X X		1 1 1 1	1 2 3 4
532 533 534				X X X		X X X			X X X		2 3 4
522 523 524				X X X			X X X	x x x		2 2 2	2 3 4
542 543 544				X X X			x x x		X X X		2 3 4
2344 2347					x x		x x				
7602 7603					x x	x x					

7.2 Designation of Bearing Series: Roller Bearings

Bearing Series	Roller Be	arings								
Jenes				Type					Width or	Diam- eter
	Cylin- drical Roller Bear-	Tapered Roller Bear- ings	Barrel Roller Bear- ings	Spheri- cal Roller Bear-	Cylin- drical Roller Thrust	Spheri- cal Roller Thrust	Single Row	Double Row	Height Series	Series
	ings	""go	gs	ings	Bear- ings	Bear- ings				
N 2; NU 2; NJ 2; NUP 2	х						х		0	2
N 3; NU 3; NJ 3; NUP 3	х						х		0	3
N 4; NU 4; NJ 4; NUP 4	х						х		0	4
NU 10	х						х		1	0
NU 22; NJ 22; NUP 22	х						х		2	2
NU 23; NJ 23; NUP 23	х						х		2	3
NN 30 NNU 49	X X							X X	3 4	0 9
302 303 313 320 322 323		X X X X X					x x x x x		0 0 1 2 2 2	2 3 3 0 2 3
329 330 331 332		X X X					X X X		2 3 3 3	9 0 1 2
202 203 204			X X X				X X X		0 0 0	2 3 4
213 222 223 230 231 232 233 239 240 241				x x x x x x x x				x x x x x x x x	0 2 2 3 3 3 3 3 4 4	3 2 3 0 1 2 3 9 0 1
292 293 294						X X X	X X X		9 9 9	2 3 4
811 812					X X		X X		1 1	1 2

7.3 Shaft Tolerances

oncione	

Nominal shaft over diameter to	3	6	10	18	30	50	65	80	100	120	140	160	180
	6	10	18	30	50	65	80	100	120	140	160	180	200
	Tolera	nce in m	icrons (r	normal t	olerance	e)							
Bearing bore diameter Deviation $\Delta_{ m dmp}$	0	0	0	0	0	0	0	0	0	0	0	0	0
	-8	-8	-8	–10	–12	–15	–15	-20	-20	-25	-25	-25	-30

Diagra Shaft	nm of fit Bearing	Shaft tolerance in microns												
e 7		-20 -32	-25 -40	-32 -50	-40 -61	-50 -75	-60 -90	-60 -90	-72 -107	-72 -107	-85 -125	-83 -125	-85 -125	-100 -146
e 8		-20 -38	-25 -47	-32 -59	-40 -73	-50 -89	-60 -106	-60 -106	-72 -126	-72 -126	-85 -148	-85 -148	-85 -148	-100 -172
f 6		-10 -18	-13 -22	-16 -27	-20 -33	-25 -41	-30 -49	-30 -49	-36 -58	-36 -58	-43 -68	-43 -68	-43 -68	–50 –79
f 7		-10 -22	-13 -28	-16 -34	-20 -41	-25 -50	-30 -60	-30 -60	-36 -71	-36 -71	-43 -83	-43 -83	-43 -83	-50 -96
g 5		-4 -9	-5 -11	-6 -14	-7 -16	-9 -20	-10 -23	-10 -23	-12 -27	-12 -27	-14 -32	-14 -32	-14 -32	–15 –35
g 6		-4 -12	-5 -14	-6 -17	-7 -20	-9 -25	-10 -29	-10 -29	-12 -34	-12 -34	-14 -39	-14 -39	-14 -39	–15 –44
h 5		0 -5	0 -6	0 -8	0 -9	0 –11	0 -13	0 –13	0 -15	0 -15	0 -18	0 -18	0 -18	0 -20
h 6		0 -8	0 -9	0 –11	0 -13	0 –16	0 –19	0 –19	0 -22	0 -22	0 -25	0 -25	0 -25	0 -29
j 5		+3 -2	+4 -2	+5 -3	+5 -4	+6 -5	+6 -7	+6 -7	+6 -9	+6 -9	+7 –11	+7 –11	+7 –11	+7 -13
j 6		+6 -2	+7 -2	+8 -3	+9 -4	+11 -5	+12 -7	+12 -7	+13 -9	+13 -9	+14 -11	+14 -11	+14 -11	+16 -13
js 3		+1,25 -1,25	+1,25 -1,25	+1,5 –1,5	+2 -2	+2 -2	+2,5 -2,5	+2,5 -2,5	+3 -3	+3 -3	+4 -4	+4 -4	+4 -4	+5 -5
js 4		+2 -2	+2 -2	+2,5 -2,5	+3 -3	+3,5 -3,5	+4 -4	+4 -4	+5 -5	+5 -5	+6 -6	+6 -6	+6 -6	+7 -7
js 5		+2,5 -2,5	+3 -3	+4 -4	+4,5 -4,5	+5,5 -5,5	+6,5 -6,5	+6,5 -6,5	+7,5 -7,5	+7,5 -7,5	+9 -9	+9 -9	+9 -9	+10 -10
js 6		+4 -4	+4,5 -4,5	+5,5 -5,5	+6,5 -6,5	+8 -8	+9,5 -9,5	+9,5 -9,5	+11 -11	+11 -11	+12,5 -12,5	+12,5 -12,5	+12,5 -12,5	+14,5 -14,5
k 3		+2,5 0	+2,5 0	+3 0	+4 0	+4 0	+5 0	+5 0	+6 0	+6 0	+8 0	+8 0	+8 0	+10 0
k 4		+5 +1	+5 +1	+6 +1	+8 +2	+9 +2	+10 +2	+10 +2	+13 +3	+13 +3	+15 +3	+15 +3	+15 +3	+18 +4
k 5		+6 +1	+7 +1	+9 +1	+11 +2	+13 +2	+15 +2	+15 +2	+18 +3	+18 +3	+21 +3	+21 +3	+21 +3	+24 +4
k 6		+9 +1	+10 +1	+12 +1	+15 +2	+18 +2	+21 +2	+21 +2	+25 +3	+25 +3	+28 +3	+28 +3	+28 +3	+33 +4

	200	225	250	280	315	355	400	450	500	560	630	710	800	900	1000	1120
	225	250	280	315	355	400	450	500	560	630	710	800	900	1000	1120	1250
	0 -30	0 -30	0 -35	0 -35	0 -40	0 -40	0 -45	0 -45	0 -50	0 -50	0 -75	0 -75	0 -100	0 -100	0 -125	0 -125
Ī																
	-100	-100	-110	-110	-125	-125	-135	-135	-145	-145	-160	-160	-170	-170	-195	-195
	-146	-146	-162	-162	-182	-182	-198	-198	-215	-215	-240	-240	-260	-260	-300	-300
	-100	-100	-110	-110	-125	-125	-135	-135	-145	-145	-160	-160	-170	-170	-195	-195
	-172	-172	-191	-191	-214	-214	-232	-232	-255	-255	-285	-285	-310	-310	-360	-360
	-50	-50	-56	-56	-62	-62	-68	-68	-76	-76	-80	-80	-86	-86	-98	-98
	-79	-79	-88	-88	-98	-98	-108	-108	-120	-120	-130	-130	-142	-142	-164	-164
_	-50	-50	-56	-56	-62	-62	-68	-68	-76	-76	-80	-80	-86	-86	-98	-98
	-96	-96	-108	-108	-119	-119	-131	-131	-146	-146	-160	-160	-176	-176	-203	-203
	-15	-15	-17	-17	-18	-18	-20	-20	-22	-22	-24	-24	-26	-26	-28	-28
	-35	-35	-40	-40	-43	-43	-47	-47	-51	-51	-56	-56	-62	-62	-70	-70
_	-15	-15	-17	-17	-18	-18	-20	-20	-22	-22	-24	-24	-26	-26	-28	-28
	-44	-44	-49	-49	-54	-54	-60	-60	-66	-66	-74	-74	-82	-82	-94	-94
_	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	-20	-20	-23	-23	-25	-25	-27	-27	-29	-29	-32	-32	-36	-36	-42	-42
_	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	-29	-29	-32	-32	-36	-36	-40	-40	-44	-44	-50	-50	-56	-56	-66	-66
_	+7 -13	+7 -13	+7 -16	+7 -16	+7 -18	+7 -18	+7 -20	+7 -20								
	+16	+16	+16	+16	+18	+18	+20	+20	+22	+22	+25	+25	+28	+28	+33	+33
	-13	-13	-16	-16	-18	-18	-20	-20	-22	-22	-25	-25	-28	-28	-33	-33
	+5 -5	+5 -5	+6 -6	+6 -6	+6,5 -6,5	+6,5 -6,5	+7,5 -7,5	+7,5 -7,5								
	+7 -7	+7 -7	+8 -8	+8 -8	+9 -9	+9 -9	+10 -10	+10 -10								
_	+10	+10	+11,5	+11,5	+12,5	+12,5	+13,5	+13,5	+14,5	+14,5	+16	+16	+18	+18	+21	+21
	-10	-10	-11,5	-11,5	-12,5	-12,5	-13,5	-13,5	-14,5	-14,5	-16	-16	-18	-18	-21	-21
	+14,5	+14,5	+16	+16	+18	+18	+20	+20	+22	+22	+25	+25	+28	+28	+33	+33
	-14,5	-14,5	-16	-16	-18	-18	-20	-20	-22	-22	-25	-25	-28	-28	-33	-33
	+10 0	+10 0	+12 0	+12 0	+13 0	+13 0	+15 0	+15 0								
	+18 +4	+18 +4	+20 +4	+20 +4	+22 +4	+22 +4	+25 +5	+25 +5								
	+24	+24	+27	+27	+29	+29	+32	+32	+29	+29	+32	+32	+36	+36	+42	+42
	+4	+4	+4	+4	+4	+4	+5	+5	0	0	0	0	0	0	0	0
	+33	+33	+36	+36	+40	+40	+45	+45	+44	+44	+50	+50	+56	+56	+66	+66
	+4	+4	+4	+4	+4	+4	+5	+5	+0	+0	+0	+0	+0	+0	+0	+0

Nominal shaft over

to

diameter

p 7

r 6

r 7

s 6

s 7

7.3 Shaft Tolerances (continuation)

+24 +12

+23

+15

+27

+15

+27

+19

+31

+19

+36

+18

+34

+23

+23

+39

+28

+46

+28

+30

+15

+28

+19

+34

+19

+32

+23

+38

+23

	nsio		

Tolerance in microns (normal tolerance)													
Bearing bore diameter	r 0	0	0	0	0	0	0	0	0	0	0	0	0
Deviation Δ _{dmp}	-8	-8	-8	–10	-12	–15	–15	–20	-20	-25	-25	-25	-30
Diagram of fit Shaft tolerance in microns													
Shaft Bearing	+9	+12	+15	+17	+20	+24	+24	+28	+28	+33	+33	+33	+37
m 5	+4	+6	+7	+8	+9	+11	+11	+13	+13	+15	+15	+15	+17
m 6	+12	+15	+18	+21	+25	+30	+30	+35	+35	+40	+40	+40	+46
	+4	+6	+7	+8	+9	+11	+11	+13	+13	+15	+15	+15	+17
n 5	+13	+16	+20	+24	+28	+33	+33	+38	+38	+45	+45	+45	+51
	+8	+10	+12	+15	+17	+20	+20	+23	+23	+27	+27	+27	+31
n 6	+16	+19	+23	+28	+33	+39	+39	+45	+45	+52	+52	+52	+60
	+8	+10	+12	+15	+17	+20	+20	+23	+23	+27	+27	+27	+31
p 6	+20	+24	+29	+35	+42	+51	+51	+59	+59	+68	+68	+68	+79
	+12	+15	+18	+22	+26	+32	+32	+37	+37	+43	+43	+43	+50

+62 +32

+60

+41

+41

+72

+53

+83

+53

+62

+32

+62

+43

+43

+78

+59

+89

+59

+72 +37

+73

+51

+86

+51

+93

+71

+106

+71

+72 +37

+76

+54

+89

+54

+101

+79

+114

+79

+83

+43

+88

+63

+103

+63

+117

+132

+92

+92

+83

+43

+90

+65

+105

+65

+125

+100

+140

+100

100

120

160

180

+96

+50

+106

+77

+123

+151

+122

+168

+122

+77

+83

+43

+93

+68

+108

+133

+108

+148

+108

+68

100

+43 Shaft tolerance for withdrawal sleeves and adapter sleeves (microns)

+51

+26

+50

+34

+59

+34

+59

+43

+68

+43

+22

+41

+28

+49

+28

+48

+35

+56

+35

h7/ <u>IT5</u>	0 -12 2,5	0 -15 3	0 -18 4	0 -21 4,5	0 -25 5,5	0 -30 6,5	0 -30 6,5	0 -35 7,5	0 -35 7,5	0 -40 <mark>9</mark>	0 -40 9	0 -40 <mark>9</mark>	0 -46 10
h8/ <u>IT5</u>	0 -18 2,5	0 -22 3	0 -27 4	0 -33 4,5	0 -39 5,5	0 -46 6,5	0 -46 6,5	0 -54 7,5	0 -54 7,5	0 -63 9	0 -63 9	0 -63 9	0 -72 10
h9/ <u>IT6</u>	0 -30 4	0 -36 4,5	0 -43 5,5	0 -52 6,5	0 -62 8	0 -74 <mark>9,5</mark>	0 -74 9,5	0 -87 11	0 -87 11	0 -100 12,5	0 -100 12,5	0 -100 12,5	0 -115 14,5
h10/ <u>IT7</u>	0 -48 6	0 -58 7,5	0 -70 <mark>9</mark>	0 -84 10,5	0 -100 12,5	0 -120 15	0 -120 15	0 -140 17,5	0 -140 17,5	0 -160 20	0 -160 20	0 -160 20	0 -185 23

The cylindricity tolerance (blue numbers) refers to the radius (DIN ISO 1101). Double the tolerance values for measuring the shaft diameter. For general mechanical engineering, h7 and h8 values are preferable.

200	225	250	280	315	355	400	450	500	560	630	710	800	900	1000	1120
225	250	280	315	355	400	450	500	560	630	710	800	900	1000	1120	1250
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
-30	-30	-35	-35	-40	-40	-45	-45	-50	-50	-75	-75	-100	-100	-125	-125
+37	+37	+43	+43	+46	+46	+50	+50	+55	+55	+62	+62	+70	+70	+82	+82
+17	+17	+20	+20	+21	+21	+23	+23	+26	+26	+30	+30	+34	+34	+40	+40
+46	+46	+52	+52	+57	+57	+63	+63	+70	+70	+80	+80	+90	+90	+106	+106
+17	+17	+20	+20	+21	+21	+23	+23	+26	+26	+30	+30	+34	+34	+40	+40
+51	+51	+57	+57	+62	+62	+67	+67	+73	+73	+82	+82	+92	+92	+108	+108
+31	+31	+34	+34	+37	+37	+40	+40	+44	+44	+50	+50	+56	+56	+66	+66
+60	+60	+66	+66	+73	+73	+80	+80	+88	+88	+100	+100	+112	+112	+132	+132
+31	+31	+34	+34	+37	+37	+40	+40	+44	+44	+50	+50	+56	+56	+66	+66
+79	+79	+88	+88	+98	+98	+108	+108	+122	+122	+138	+138	+156	+156	+186	+186
+50	+50	+56	+56	+62	+62	+68	+68	+78	+78	+88	+88	+100	+100	+120	+120
+96	+96	+108	+108	+119	+119	+131	+131	+148	+148	+168	+168	+190	+190	+225	+225
+50	+50	+56	+56	+62	+62	+68	+68	+78	+78	+88	+88	+100	+100	+120	+120
+109	+113	+126	+130	+144	+150	+166	+172	+194	+199	+225	+235	+266	+276	+316	+326
+80	+84	+94	+98	+108	+114	+126	+132	+150	+155	+175	+185	+210	+220	+250	+260
+126	+130	+146	+150	+165	+171	+189	+195	+220	+225	+255	+265	+300	+310	+355	+365
+80	+84	+94	+98	+108	+114	+126	+132	+150	+155	+175	+185	+210	+220	+250	+260
+159	+169	+190	+202	+226	+244	+272	+292	+324	+354	+390	+430	+486	+526	+586	+646
+130	+140	+158	+170	+190	+208	+232	+252	+280	+310	+340	+380	+430	+470	+520	+580
+176	+186	+210	+222	+247	+265	+295	+315	+350	+380	+420	+460	+520	+560	+625	+685
+130	+140	+158	+170	+190	+208	+232	+252	+280	+310	+340	+380	+430	+470	+520	+580
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
-46	-46	-52	-52	-57	-57	-63	-63	-70	-70	-80	-80	-90	-90	-105	-105
10	10	11,5	11,5	12,5	12,5	13,5	13,5	14,5	14,5	16	16	18	18	21	21
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
-72	-72	-81	-81	-89	-89	-97	-97	-110	-110	-125	-125	-140	-140	-165	-165
10	10	11,5	11,5	12,5	12,5	13,5	13,5	14,5	14,5	16	16	18	18	21	21
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
-115	-115	-130	-130	-140	-140	-155	-155	-175	-175	-200	-200	-230	-230	-260	-260
14.5	14.5	16	16	18	18	20	20	22	22	25	25	28	28	33	33
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
-185	-185	-210	-210	-230	-230	-250	-250	-280	-280	-320	-320	-360	-360	-420	-420
23	23	26	26	28,5	28,5	31,5	31,5	35	35	40	40	45	45	52,5	52,5

7.4 Housing Tolerances

n:ma	nsion	~ i~	

Nomin. housing over bore diameter to	6 10	10 18	18 30	30 50	50 65	65 80	80 100	100 120	120 140	140 160	160 180	180 200	200 225
	Toler	ance in m	icrons (r	normal t	olerance	e)							
Bearing outside dia. Deviation $\Delta_{{ m Dmp}}$	0 -8	0 -8	0 -9	0 –11	0 –13	0 –13	0 –15	0 –15	0 –18	0 –18	0 -25	0 -30	0 -30
Diagram of fit Housing Bearing	Hous	sing tolera	ınce in n	nicrons									
D 10	+98 +40	+120 +50	+149 +65	+180 +80	+220 +100	+220	+260 +120	+260 +120	+305 +145	+305 +145	+305 +145	+355	+355 +170

Housi	ng Bearing	Housi	ng tolera	ance in n	nicrons									
D 10		+98 +40	+120 +50	+149 +65	+180 +80	+220 +100	+220 +100	+260 +120	+260 +120	+305 +145	+305 +145	+305 +145	+355 +170	+355 +170
E 8		+47 +25	+59 +32	+73 +40	+89 +50	+106 +60	+106 +60	+126 +72	+126 +72	+148 +85	+148 +85	+148 +85	+172 +100	+172 +100
F 7		+28 +13	+34 +16	+41 +20	+50 +25	+60 +30	+60 +30	+71 +36	+71 +36	+83 +43	+83 +43	+83 +43	+96 +50	+96 +50
G 6		+14 +5	+17 +6	+20 +7	+25 +9	+29 +10	+29 +10	+34 +12	+34 +12	+39 +14	+39 +14	+39 +14	+44 +15	+44 +15
G 7		+20 +5	+24 +6	+28 +7	+34 +9	+40 +10	+40 +10	+47 +12	+47 +12	+54 +14	+54 +14	+54 +14	+61 +15	+61 +15
H 5		+6 0	+8 0	+9 0	+11 0	+13 0	+13 0	+15 0	+15 0	+18 0	+18 0	+18 0	+20 0	+20 0
H 6		+9 0	+11 0	+13 0	+16 0	+19 0	+19 0	+22 0	+22 0	+25 0	+25 0	+25 0	+29 0	+29 0
H 7		+15 0	+18 0	+21 0	+25 0	+30 0	+30 0	+35 0	+35 0	+40 0	+40 0	+40 0	+46 0	+46 0
H 8		+22 0	+27 0	+33 0	+39 0	+46 0	+46 0	+54 0	+54 0	+63 0	+63 0	+63 0	+72 0	+72 0
J 6		+5 -4	+6 -5	+8 -5	+10 -6	+13 -6	+13 -6	+16 -6	+16 -6	+18 -7	+18 -7	+18 -7	+22 -7	+22 -7
J 7		+8 -7	+10 -8	+12 -9	+14 -11	+18 -12	+18 -12	+22 -13	+22 -13	+26 -14	+26 -14	+26 -14	+30 –16	+30 -16
JS 4		+2 -2	+2,5 -2,5	+3 -3	+3,5 -3,5	+4 -4	+4 -4	+5 -5	+5 -5	+6 -6	+6 -6	+6 -6	+7 -7	+7 -7
JS 5		+3 -3	+4 -4	+4,5 -4,5	+5,5 -5,5	+6,5 -6,5	+6,5 -6,5	+7,5 -7,5	+7,5 -7,5	+9 -9	+9 -9	+9 -9	+10 -10	+10 -10
JS 6		+4,5 -4,5	+5,5 -5,5	+6,5 -6,5	+8 -8	+9,5 -9,5	+9,5 -9,5	+11 -11	+11 -11	+12,5 -12,5	+12,5 -12,5	+12,5 -12,5	+14,5 –14,5	+14,5 -14,5
JS 7		+7,5 -7,5	+9 -9	+10,5 -10,5	+12,5 -12,5	+15 -15	+15 -15	+17,5 –17,5	+17,5 –17,5	+20 -20	+20 -20	+20 -20	+23 -23	+23 -23
K 4		+0,5 -3,5	+1 -4	0 -6	+1 -6	+1 -7	+1 -7	+1 -9	+1 -9	+1 -11	+1 -11	+1 -11	0 -14	0 -14
K 5		+1 -5	+2 -6	+1 -8	+2 -9	+3 -10	+3 -10	+2 -13	+2 -13	+3 –15	+3 -15	+3 –15	+2 -18	+2 -18
K 6		+2 -7	+2 -9	+2 –11	+3 -13	+4 -15	+4 –15	+4 -18	+4 -18	+4 -21	+4 -21	+4 -21	+5 -24	+5 -24

	225	250	280	315	355	400	450	500	560	630	710	800	900	1000	1120	1250
	250	280	315	355	400	450	500	560	630	710	800	900	1000	1120	1250	1400
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	-30	-35	-35	-40	-40	-45	-45	-50	-50	-75	-75	-100	-100	-125	-125	-160
Ī																
	+355	+400	+400	+440	+440	+480	+480	+540	+540	+610	+610	+680	+680	+770	+770	+890
	+170	+190	+190	+210	+210	+230	+230	+260	+260	+290	+290	+320	+320	+350	+350	+390
	+172	+191	+191	+214	+214	+232	+232	+255	+255	+285	+285	+310	+310	+360	+360	+415
	+100	+110	+110	+125	+125	+135	+135	+145	+145	+160	+160	+170	+170	+195	+195	+220
	+96	+108	+108	+119	+119	+131	+131	+144	+144	+160	+160	+176	+176	+203	+203	+235
	+50	+56	+56	+62	+62	+68	+68	+76	+76	+80	+80	+86	+86	+98	+98	+110
	+44	+49	+49	+54	+54	+60	+60	+66	+66	+74	+74	+82	+82	+94	+94	+108
	+15	+17	+17	+18	+18	+20	+20	+22	+22	+24	+24	+26	+26	+28	+28	+30
	+61	+69	+69	+75	+75	+83	+83	+92	+92	+104	+104	+116	+116	+133	+133	+155
	+15	+17	+17	+18	+18	+20	+20	+22	+22	+24	+24	+26	+26	+28	+28	+30
	+20 0	+23 0	+23 0	+25 0	+25 0	+27 0	+27 0									
	+29	+32	+32	+36	+36	+40	+40	+44	+44	+50	+50	+56	+56	+66	+66	+78
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	+46	+52	+52	+57	+57	+63	+63	+70	+70	+80	+80	+90	+90	+105	+105	+125
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	+72	+81	+81	+89	+89	+97	+97	+110	+110	+125	+125	+140	+140	+165	+165	+195
	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	+22 -7	+25 -7	+25 -7	+29 -7	+29 -7	+33 -7	+33 -7									
	+30 -16	+36 -16	+36 -16	+39 -18	+39 -18	+43 -20	+43 -20									
	+7 -7	+8 -8	+8 -8	+9 -9	+9 -9	+10 -10	+10 -10									
	+10 -10	+11,5 -11,5	+11,5 -11,5	+12,5 -12,5	+12,5 -12,5	+13,5 -13,5	+13,5 -13,5									
	+14,5	+16	+16	+18	+18	+20	+20	+22	+22	+25	+25	+28	+28	+33	+33	+39
	-14,5	-16	-16	-18	-18	-20	-20	-22	-22	-25	-25	-28	-28	-33	-33	-39
	+23	+26	+26	+28,5	+28,5	+31,5	+31,5	+35	+35	+40	+40	+45	+45	+52	+52	+62
	-23	-26	-26	-28,5	-28,5	-31,5	-31,5	-35	-35	-40	-40	-45	-45	-52	-52	-62
	0 -14	0 –16	0 -16	0 –17	0 -17	0 -20	0 -20									
	+2 -18	+3 -20	+3 -20	+3 -22	+3 -22	+2 -25	+2 -25									
	+5	+5	+5	+7	+7	+8	+8	0	0	0	0	0	0	0	0	0
	-24	-27	-27	-29	-29	-32	-32	-44	-44	-50	-50	-56	-56	-66	-66	-78

7.4 Housing Tolerances (continuation)

-			
I)ım	ensions	ı nı a	mm

Nomin. housing over bore diameter to	6	10	18	30	50	65	80	100	120	140	160	180	200
	10	18	30	50	65	80	100	120	140	160	180	200	225
	Tolera	ınce in r	nicrons ((normal t	olerance	e)							
Bearing outside dia. Deviation Δ_{Dmp}	0	0	0	0	0	0	0	0	0	0	0	0	0
	-8	-8	-9	-11	-13	-13	–15	-15	–18	–18	-25	-30	-30

Diagram Housing	of fit Bearing	Housi	ng tolera	ance in r	nicrons									
K 7		+5 -10	+6 -12	+6 -15	+7 -18	+9 -21	+9 -21	+10 -25	+10 -25	+12 -28	+12 -28	+12 -28	+13 -33	+13 -33
M 6		-3 -12	-4 -15	-4 -17	-4 -20	-5 -24	-5 -24	-6 -28	-6 -28	-8 -33	-8 -33	-8 -33	-8 -37	-8 -37
M 7		0 -15	0 -18	0 -21	0 -25	0 -30	0 -30	0 -35	0 -35	0 -40	0 -40	0 -40	0 -46	0 -46
N 6		-7 -16	-9 -20	-11 -24	-12 -28	-14 -33	-14 -33	-16 -38	-16 -38	-20 -45	-20 -45	-20 -45	-22 -51	-22 -51
N 7		-4 -19	-5 -23	-7 -28	-8 -33	-9 -39	-9 -39	-10 -45	-10 -45	-12 -52	-12 -52	-12 -52	-14 -60	-14 -60
P 6		-12 -21	-15 -26	-18 -31	-21 -37	-26 -45	-26 -45	-30 -52	-30 -52	-36 -61	-36 -61	-36 -61	-41 -70	-41 -70
P 7		-9 -24	-11 -29	-14 -35	-17 -42	-21 -51	-21 -51	-24 -59	-24 -59	-28 -68	-28 -68	-28 -68	-33 -79	-33 -79
R 6		-16 -25	-20 -31	-24 -37	-29 -45	-35 -54	-37 -56	-44 -66	-47 -69	-56 -81	-58 -83	-61 -86	-68 -97	-71 -100
S 6		-20 -29	-25 -36	-31 -44	-38 -54	-47 -66	-53 -72	-64 -86	-72 -94	-85 -110	-93 -118	-101 -126	-113 -142	-121 -150

225	250	280	315	355	400	450	500	560	630	710	800	900	1000	1120	1250
250	280	315	355	400	450	500	560	630	710	800	900	1000	1120	1250	1400
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
-30	-35	-35	-40	-40	-45	-45	-50	-50	-75	-75	-100	-100	-125	-125	-160
+13	+16	+16	+17	+17	+18	+18	0	0	0 -80	0	0	0	0	0	0
-33	-36	-36	-40	-40	-45	-45	-70	-70		-80	-90	-90	-105	-105	-125
-8	-9	-9	-10	-10	-10	-10	-26	-26	-30	-30	-34	-34	-40	-40	-48
-37	-41	-41	-46	-46	-50	-50	-70	-70	-80	-80	-90	-90	-106	-106	-126
0 -46	0 -52	0 -52	0 -57	0 -57	0 -63	0 -63									
-22	-25	-25	-26	-26	-27	-27	-44	-44	-50	-50	-56	-56	-66	-66	-78
-51	-57	-57	-62	-62	-67	-67	-88	-88	-100	-100	-112	-112	-132	-132	-156
-14 -60	-14 -66	-14 -66	-16 -73	-16 -73	-17 -80	-17 -80									
-41	-47	-47	-51	-51	-55	-55	-78	-78	-88	-88	-100	-100	-120	-120	-140
-70	-79	-79	-87	-87	-95	-95	-122	-122	-138	-138	-156	-156	-186	-186	-218
-33	-36	-36	-41	-41	-45	-45	-78	-78	-88	-88	-100	-100	-120	-120	-140
-79	-88	-88	-98	-98	-108	-108	-148	-148	-168	-168	-190	-190	-225	-225	-265
-75	-85	-89	-97	-103	-113	-119	-150	-155	-175	-185	-210	-220	-250	-260	-300
-104	-117	-121	-133	-139	-153	-159	-194	-199	-225	-235	-266	-276	-316	-326	-378
-131 -160	-149 -181	-161 -193	-179 -215	-197 -233	-219 -259	-239 -279									

7.5 Normal Tolerances of FAG Radial Bearings (Except Tapered Roller Bearings)

Inner ring

Dimensions in mm

diameter d to 10 18 30 50 80 120 180 250 315 400 500 630 800 1000 1250
--

Tolerance class PN (normal tolerance)

Tolerance in microns

Bore, cyling Deviation	drical Δ _{dmp}	0 -8	0 -8	0 -10	0 -12	0 -15	0 -20	0 -25	0 -30	0 -35	0 -40	0 -45	0 -50	0 -75	0 -100	0 -125
Variation V _{dp}	diameter series 7 · 8 · 9	10	10	13	15	19	25	31	38	44	50	56	63			
	0 · 1	8	8	10	12	19	25	31	38	44	50	56	63			
	2 · 3 · 4	6	6	8	9	11	15	19	23	26	30	34	38			
Variation	V _{dmp}	6	6	8	9	11	15	19	23	26	30	34	38			
Bore, taper Deviation	1:12 Δ _{dmp}	+15 0	+18 0	+21 0	+25 0	+30 0	+35 0	+40 0	+46 0	+52 0	+57 0	+63 0	+70 0	+80 0	+90 0	+105 0
Deviation	$\Delta_{\rm d1mp}$ – $\Delta_{\rm dmp}$	+15 0	+18 0	+21 0	+25 0	+30 0	+35 0	+40 0	+46 0	+52 0	+57 0	+63 0	+70 0	+80 0	+90 0	+105 0
	V_{dp}	10	10	13	15	19	25	31	38	44	50	56				
Bore, taper						+15 0	+20 0	+25 0	+30 0	+35 0	+40 0	+45 0	+50 0	+75 0	+100 0	+125 0
Deviation	Δ_{d1mp} – Δ_{dmp}					+35 0	+40 0	+50 0	+55 0	+60 0	+65 0	+75 0	+85 0	+100 0	+100 0	+115 0
	V _{dp}					19	25	31	38	44	50	56	63			
Width deviation	Δ_{Bs}	0 -120	0 -120	0 -120	0 -120	0 -150	0 -200	0 -250	0 -300	0 -350	0 -400	0 -450	0 -500	0 -750	0 -1000	0 -1250
Width variation	V _{Bs}	15	20	20	20	25	25	30	30	35	40	50	60	70	80	100
Radial runout	K _{ia}	10	10	13	15	20	25	30	40	50	60	65	70	80	90	100

Bore diameter

 $\Delta_{\, \, dmp}$ Single plane mean bore diameter deviation

 $\Delta_{\rm d1mp}$ — Deviation of mean large diameter from nominal dimension (tapered bore)

Bore diameter variation in a single radial plane

V_{dmp} Mean bore diameter variation; difference between maximum and minimum mean

bore diameter

Outside diameter

 $\begin{array}{ll} \Delta_{\rm \ Dmp} & {\rm \ Single\ plane\ mean\ outside\ diameter\ deviation} \\ V_{\rm \ Dn} & {\rm \ Outside\ diameter\ variation\ in\ a\ single\ radial\ plane} \end{array}$

 $V_{\scriptscriptstyle Dmn}$ Mean outside diameter variation; difference between maximum and minimum mean out-

side diameter

Outer ring

		Dimer	nsions	in mm													
Nominal				100													
outside diameter D	over to	6 18	18 30	30 50	50 80	80 120	120 150	150 180	180 250	250 315	315 400	400 500	500 630	630 800	800 1000	1000 1250	
ulameter D	ιο	10	30	30	80	120	150	100	250	313	400	300	030	800	1000	1230	1000

Tolerance class PN (normal tolerance)

Tolerance in microns

Deviation	Δ_{Dmp}	0 -8	0 -9	0 –11	0 –13	0 –15	0 –18	0 -25	0 -30	0 -35	0 -40	0 -45	0 -50	0 -75		0 -125	0 –160
Variation V _{Dp}	diameter series 7·8·9	10	12	14	16	19	23	31	38	44	50	56	63	94	125		
	0-1	8	9	11	13	19	23	31	38	44	50	56	63	94	125		
	2.3.4	6	7	8	10	11	14	19	23	26	30	34	38	55	75		
	sealed bearings 2.3.4		12	16	20	26	30	38									
Variation	V_{Dmp}	6	7	8	10	11	14	19	23	26	30	34	38	55	75		
Radial runout	K _{ea}	15	15	20	25	35	40	45	50	60	70	80	100	120	140	160	190

The width tolerances $\Delta_{\rm Cs}$ and $\rm V_{\rm Cs}$ are identical to $\Delta_{\rm Bs}$ and $\rm V_{\rm Bs}$ for the pertinent inner ring.

Width

 $\begin{array}{ll} \Delta_{B'}\,\Delta_{Cs} & \text{Deviation of a single ring width (inner and outer ring) from nominal dimension} \\ V_{Bs'}\,V_{Cs} & \text{Variation of inner ring width and outer ring width} \end{array}$

Running accuracy

 $egin{array}{ll} K_{ia} & Radial \, runout \, of \, assembled \, bearing \, inner \, ring \, K_{ea} & Radial \, runout \, of \, assembled \, bearing \, outer \, ring \, inner \, ring \, ring$

7.6 Normal Tolerances of FAG Tapered Roller Bearings in Metric Dimensions

Cone

-			
I)ime	ensions	ın	mm

diameter d to 18 30 50 80 120 180 250 315 400 500 630	Nominal bore over diameter d to	10 18	18 30	30 50	50 80	80 120	120 180	180 250	250 315	315 400	400 500	500 630
---	---------------------------------	----------	----------	----------	----------	-----------	------------	------------	------------	------------	------------	------------

Tolerance class PN (normal tolerance)

Tolerance in microns

Deviation	$\Delta_{\rm dmp}$	0 -12	0 -12	0 -12	0 –15	0 -20	0 -25	0 -30	0 -35	0 -40	0 -45	0 -50
Variation	V_{dp}	12	12	12	15	20	25	30	35	40	45	50
	V_{dmp}	9	9	9	11	15	19	23	26	30		
Width deviation	Δ_{Bs}	0 -120	0 -120	0 -120	0 -150	0 -200	0 -250	0 -300	0 -350	0 -400	0 -450	0 -500
Radial runout	K _{ia}	15	18	20	25	30	35	50	60	70	70	85
Width deviation	Δ_{TS}	+200 0	+200 0	+200 0	+200	+200 -200	+350 -250	+350 -250	+350 -250	+400 -400	+400 -400	+500 -500
	Δ_{T1s}	+100 0	+100 0	+100 0	+100 0	+100 -100	+150 -150	+150 -150	+150 -150	+200 -200		
	Δ_{T2s}	+100 0	+100 0	+100 0	+100 0	+100 -100	+200 -100	+200 -100	+200 -100	+200 -200		

Cup

Dimensions in mm

Nominal		B	.0.00											
outside diameter D	over to	18 30	30 50	50 80	80 120	120 150	150 180	180 250	250 315	315 400	400 500	500 630	630 800	800 1000
diameter D	10	30	30	00	120	130	100	230	313	400	300	030	000	1000

Tolerance class PN (normal tolerance)

Tolerance in microns

Deviation	Δ_{Dmp}	0 -12	0 -14	0 -16	0 –18	0 -20	0 -25	0 -30	0 -35	0 -40	0 -45	0 -50	0 -75	0 -100
Variation	V _{Dp}	12	14	16	18	20	25	30	35	40	45	50	75	100
	V_{Dmp}	9	11	12	14	15	19	23	26	30	34	38		
Radial runou	t K _{ea}	18	20	25	35	40	45	50	60	70	80	100	120	120

The width tolerance Δ_{Cs} is identical with Δ_{Bs} for the pertinent inner ring.

Overall width of a tapered roller bearing, measured at a single position

Overall width of a tapered roller bearing, measured at a single position by cone and master cup

Overall width of a tapeted folier bearing, measured at a single position by cup and master cup T_{2s} Overall width of a tapeted folier bearing, measured at a single position by cup and master cone $\Delta_{TS} = T_s - T_1$, $\Delta_{T1S} = T_{1s} - T_1$, $\Delta_{T2S} = T_{2s} - T_2$ Deviation of a single tapered roller bearing overall width from nominal dimension H_{s} ; H_{1s} , H_{2s} ; H_{3s} , H_{4s} Overall thrust bearing height measured at a single position $\Delta_{HS} = H_s - H_1$, $\Delta_{H1S} = H_{1s} - H_1$, ... Deviation of a single overall thrust bearing height from nominal dimension $H_{s} = H_{s} - H_{s}$

Overall height of a double direction thrust bearing

Overall height of a double direction thrust bearing with seating rings

Overall height of a spherical roller thrust bearing

7.7 Normal Tolerances of FAG Thrust Bearings

Shaft washer

			mm

Nominal bore	over	I	18	30	50	80	120	180	250	315	400	500	630	800	1000
diameter d_w	to	18	30	50	80	120	180	250	315	400	500	630	800	1000	1250

Tolerance class PN (normal tolerance)

Tolerance in microns

Deviation	$\Delta_{\rm dmp}$	0 -8	0 -10	0 -12	0 –15	0 -20	0 -25	0 -30	0 -35	0 -40	0 -45	0 -50	0 -75	0 -100	0 -125
Variation	V_{dp}	6	8	9	11	15	19	23	26	30	34	38			
Wall thickness variation	S _{i*)}	10	10	10	10	15	15	20	25	30	30	35	40	45	50
Seating ring deviation	Δ	+70 0	+70 0	+85 0	+100 0	+120 0	+140 0	+140 0	+160 0	+180 0	+180 0				

Housing washer

Dimensions in mm

Nominal															
outside	over	18	30	50	80	120	180	250	315	400	500	630	800	1000	1250
diameter D _a	to	30	50	80	120	180	250	315	400	500	630	800	1000	1250	1600

Tolerance class PN (normal tolerance)

Tolerance in microns

Deviation	Δ_{Dmp}	0 -13	0 -16	0 -19	0 -22	0 -25	0 -30	0 -35	0 -40	0 -45	0 -50	0 -75	0 -100	0 -125	0 -160
Variation	V_{Dp}	10	12	14	17	19	23	26	30	34	38	55	75		
Seating ring deviation	Δ_{D}	0 -30	0 -35	0 -45	0 -60	0 -75	0 -90	0 -105	0 -120	0 -135	0 -180				

^{*)} The values of the wall thickness variation apply to shaft and housing washers

Construction Heights of Thrust Bearings

Dimensions in mm

Nominal bore over diameter d _w to 30 50 80	80	120	180	250	315	400	500	630	800	1000
	120	180	250	315	400	500	630	800	1000	1250

Tolerance classes PN ... P4

Tolerance in microns

Deviation

Δ_{Hs}	+20	+20	+20	+25	+25	+30	+40	+40	+50	+60	+70	+80	+100
	-250	-250	-300	-300	-400	-400	-400	-500	-500	-600	-750	-1000	-1400
$\Delta_{\rm H1s}$	+100	+100	+100	+150	+150	+150	+200	+200	+300	+350	+400	+450	+500
	-250	-250	-300	-300	-400	-400	-400	-500	-500	-600	-750	-1000	-1400
$\Delta_{\rm H2s}$	+150	+150	+150	+200	+200	+250	+350	+350	+400	+500	+600	+700	+900
	-400	-400	-500	-500	-600	-600	-700	-700	-900	-1100	-1300	-1500	-1800
Δ_{H3s}	+300	+300	+300	+400	+400	+500	+600	+600	+750	+900	+1100	+1300	+1600
	-400	-400	-500	-500	-600	-600	-700	-700	-900	-1100	-1300	-1500	-1800
Δ_{H4s}	+20	+20	+20	+25	+25	+30	+40	+40	+50	+60	+70	+80	+100
	-300	-300	-400	-400	-500	-500	-700	-700	-900	-1200	-1400	-1800	-2400

7.8 Limit Dimensions of Chamfer

Symbols

 ${\bf r}_{{\bf 1s'}}\,{\bf r}_{{\bf 3s}}$ chamfer in radial direction ${\bf r}_{{\bf 2s'}}\,{\bf r}_{{\bf 4s}}$ chamfer in axial direction

 r_{smin} general symbol for the minimum chamfer $r_{1smin'}$ $r_{2smin'}$ $r_{3smin'}$ r_{4smin}

 $r_{1smax'}$ r_{3smax} maximum chamfer in radial direction $r_{2smax'}$ r_{4smax} maximum chamfer in axial direction

Chamfer of radial bearings (except tapered roller bearings)

		Dime	nsions	in mm										
$r_{\rm smin}$		0,1	0,15	0,2	0,3		0,6		1		1,1		1,5	
Nominal bore diameter d	over to				40	40	40	40	50	50	120	120	120	120
r _{1smax}		0,2	0,3	0,5	0,6	0,8	1	1,3	1,5	1,9	2	2,5	2,3	3
r _{2smax}		0,4	0,6	0,8	1	1	2	2	3	3	3,5	4	4	5

Chamfer of tapered roller bearings in metric dimensions Cone

Dimensions in mm

Cone		Dime	nsions	in mm									
r _{smin}		0,3		0,6		1		1,5			2		
Nominal bore diameter d	over to	40	40	40	40	50	50	120	120 250	250	120	120 250	250
r _{1smax}		0,7	0,9	1,1	1,3	1,6	1,9	2,3	2,8	3,5	2,8	3,5	4
r _{2smax}		1,4	1,6	1,7	2	2,5	3	3	3,5	4	4	4,5	5

Cup

r _{smin}		0,3		0,6		1		1,5			2		
Nominal outside diameter D	over to	40	40	40	40	50	50	120	120 250	250	120	120 250	250
r _{3smax}		0,7	0,9	1,1	1,3	1,6	1,9	2,3	2,8	3,5	2,8	3,5	4
r _{4smax}		1,4	1,6	1,7	2	2,5	3	3	3,5	4	4	4,5	5

Chamfer of thrust bearings

	Dime	ension	s in mi	m																
r _{smin}	0,1	0,15	0,2	0,3	0,6	1	1,1	1,5	2	2,1	3	4	5	6	7,5	9,5	12	15	19	
r _{1smax} , r _{2smax}	0,2	0,3	0,5	0,8	1,5	2,2	2,7	3,5	4	4,5	5,5	6,5	8	10	12,5	15	18	21	25	

Radial bearings Tapered roller bearings Thrust bearings D_g 2 2,1 2,5 7,5 9,5 12 15 19 3 5 6 80 220 220 280 100 280 280 280 100 80 280 280 3 3,5 4,5 4,5 5 5 5,5 6,5 8 10 12,5 15 21 25 3,8 3,8 18

13

2,5			3				4				5		6	
120 250 250		120	120 250	250 400	400	120	120 250	250 400	400	180	180	180	180	
3,5	4	4,5	4	4,5	5	5,5	5	5,5	6	6,5	6,5	7,5	7,5	9
5	5,5	,	5,5	7.5	7	7 5	7	7,5	8	8,5	0	0	10	11

6,5

2,5			3				4				5		6	
120	120 250	250	120	120 250	250 400	400	120	120 250	250 400	400	180	180	180	180
3,5	4	4,5	4	4,5	5	5,5	5	5,5	6	6,5	6,5	7,5	7,5	9
5	5.5	6	5.5	6.5	7	7.5	7	7.5	8	8.5	8	9	10	11

38

7.9 Radial Clearance of FAG Deep Groove Ball Bearings

		Dime	nsions	in mm													
Nominal bore diameter	over to	2,5 6	6 10	10 18	18 24	24 30	30 40			50 65	65 80	80 100	100 120	120 140	140 160	160 180	180 200
		Beari	ng cle	arance	in mic	rons											
Clearance group C2	min max	0 7	0 7	0 9	0 10	1 11	1 11	1		1 15	1 15	1 18	2 20	2 23	2 23	2 25	2 30
Clearance group CN (norr	min n.) max	2 13	2 13	3 18	5 20	5 20	6 20	6 2		8 28	10 30	12 36	15 41	18 48	18 53	20 61	25 71
Clearance group C3	min max	8 23	8 23	11 25	13 28	13 28	15 33			23 43	25 51	30 58	36 66	41 81	46 91	53 102	63 117
Clearance group C4	min max		14 29	18 33	20 36	23 41	28 4 <i>6</i>			38 61	46 71	53 84	61 97	71 114	81 130	91 147	107 163
		Dime	nsions	in mm													
Nominal bore diameter	over to	200 225	225 250	250 280	280 315	315 355	355 400	400 450	450 500	500 560			710 800	800 900	900 1000	1000 1120	
		Beari	ng cle	arance	in mic	rons											
Clearance group C2	min max	4 32	4 36	4 39	8 45	8 50	8 60	10 70	10 80	20 90	20 100	30 120	30 130	30 150	40 160	40 170	40 180
Clearance group CN (norr	min n.) max	28 82	31 92	36 97	42 110	50 120	60 140	70 160	80 180	90 200	100 220	120 250	130 280	150 310	160 340	170 370	180 400
Clearance group C3	min max	73 132	87 152	97 162	110 180	120 200	140 230	160 260	180 290	200 320		250 390	280 440	310 490	340 540	370 590	400 640
Clearance group C4	min max	120 187	140 217	152 237	175 260	200 290	230 330	260 370	290 410	320 460		390 560	440 620	490 690	540 760	590 840	640 910

100 | 120 | 140

7.10 Radial Clearance of FAG Self-Aligning Ball Bearings

14 18

Dimensions in mm

2,5 6

Nominal bore over

Clearance min group CN (norm.) max

min

max

min

max

Clearance

group C3

Clearance

group C4

diameter	to	6	10	14	18	24	30	40	50	65	80	100	120	140	160
with cylind	drical b	ore													
		Bearin	g cleara	ınce in n	nicrons										
Clearance group C2	min max	1 8	2 9	2 10	3 12	4 14	5 16	6 18	6 19	7 21	8 24	9 27	10 31	10 38	15 44
Clearance group CN (norr	min n.) max	5 15	6 17	6 19	8 21	19 23	11 24	13 29	14 31	16 36	18 40	22 48	25 56	30 68	35 80
Clearance group C3	min max	10 20	12 25	13 26	15 28	17 30	19 35	23 40	25 44	30 50	35 60	42 70	50 83	60 100	70 120
Clearance group C4	min max	15 25	19 33	21 35	23 37	25 39	29 46	34 53	37 57	45 69	54 83	64 96	75 114	90 135	110 161
with taper	ed bor	e													
		Bearin	g cleara	ınce in n	nicrons										
Clearance group C2	min max					7 17	9 20	12 24	14 27	18 32	23 39	29 47	35 56	40 68	45 74

 24 30

7.11 Radial Clearance of FAG Cylindrical Roller Bearings

		Dime	nsions ir	n mm											
Nominal bore	over	24	24	30	40	50	65	80	100	120	140	160	180	200	225
diameter	to		30	40	50	65	80	100	120	140	160	180	200	225	250
with cylind	rical l	bore													
		Beari	ng clear	ance in i	microns										
Clearance	min	5	5	5	5	5	10	10	10	10	10	10	15	15	15
group C1NA ¹)	max	15	15	15	18	20	25	30	30	35	35	40	45	50	50
Clearance	min	0	0	5	5	10	10	15	15	15	20	25	35	45	45
group C2	max	25	25	30	35	40	45	50	55	60	70	75	90	105	110
Clearance	min	20	20	25	30	40	40	50	50	60	70	75	90	105	110
group CN (norm	.) max	45	45	50	60	70	75	85	90	105	120	125	145	165	175
Clearance	min	35	35	45	50	60	65	75	85	100	115	120	140	160	170
group C3	max	60	60	70	80	90	100	110	125	145	165	170	195	220	235
Clearance	min	50	50	60	70	80	90	105	125	145	165	170	195	220	235
group C4	max	75	75	85	100	110	125	140	165	190	215	220	250	280	300

with tapered bore

		Beari	ng clear	ance in r	nicrons										
Clearance	min	10	15	15	17	20	25	35	40	45	50	55	60	60	65
group C1NA ¹)	max	20	25	25	30	35	40	55	60	70	75	85	90	95	100
Clearance	min	15	20	20	25	30	35	40	50	55	60	75	85	95	105
group C2	max	40	45	45	55	60	70	75	90	100	110	125	140	155	170
Clearance	min	30	35	40	45	50	60	70	90	100	110	125	140	155	170
group CN (norm	ı.) max	55	60	65	75	80	95	105	130	145	160	175	195	215	235
Clearance	min	40	45	55	60	70	85	95	115	130	145	160	180	200	220
group C3	max	65	70	80	90	100	120	130	155	175	195	210	235	260	285
Clearance	min	50	55	70	75	90	110	120	140	160	180	195	220	245	270
group C4	max	75	80	95	105	120	145	155	180	205	230	245	275	305	335

250	280	315	355	400	450	500	560	630	710	800	900	1000	1120	1250	1400	1600	1800
280	315	355	400	450	500	560	630	710	800	900	1000	1120	1250	1400	1600	1800	2000
20	20	20	25	25	25	25	30	30	35	35	35	50	60	60	70	80	100
55	60	65	75	85	95	100	110	130	140	160	180	200	220	240	270	300	320
55	55	65	100	110	110	120	140	145	150	180	200	220	230	270	330	380	400
125	130	145	190	210	220	240	260	285	310	350	390	430	470	530	610	700	760
125	130	145	190	210	220	240	260	285	310	350	390	430	470	530	610	700	760
195	205	225	280	310	330	360	380	425	470	520	580	640	710	790	890	1020	1120
190	200	225	280	310	330	360	380	425	470	520	580	640	710	790	890	1020	1120
260	275	305	370	410	440	480	500	565	630	690	770	850	950	1050	1170	1340	1480
260	275	305	370	410	440	480	500	565	630	690	770	850	950	1050	1170	1340	1480
330	350	385	460	510	550	600	620	705	790	860	960	1060	1190	1310	1450	1660	1840

75	80	90	100	110	120	130	140	160	170	190	210	230	250	270	300	320	340
110	120	135	150	170	190	210	230	260	290	330	360	400	440	460	500	530	560
115	130	145	165	185	205	230	260	295	325	370	410	455	490	550	640	700	760
185	205	225	255	285	315	350	380	435	485	540	600	665	730	810	920	1020	1120
185	205	225	255	285	315	350	380	435	485	540	600	665	730	810	920	1020	1120
255	280	305	345	385	425	470	500	575	645	710	790	875	970	1070	1200	1340	1480
240	265	290	330	370	410	455	500	565	630	700	780	865	960	1070	1200	1340	1480
310	340	370	420	470	520	575	620	705	790	870	970	1075	1200	1330	1480	1660	1840
295	325	355	405	455	505	560	620	695	775	860	960	1065	1200	1330	1480	1660	1840
365	400	435	495	555	615	680	740	835	935	1030	1150	1275	1440	1590	1760	1980	2200

¹⁾ Clearance group C1NA applies to single and double row cylindrical roller bearings of tolerance classes SP and UP.

7.12 Radial Clearance of FAG Spherical Roller Bearings

Dimer		

								i e	i e			r e	r e	1	
Nominal bore	over		24	30	40	50	65	80	100	120	140	160	180	200	225
diameter	to	24	30	40	50	65	80	100	120	140	160	180	200	225	250
ularrietei	ιO	24	30	40	50	03	00	100	120	140	100	100	200	223	230

with cylindrical bore

Bearing clearance in microns

Clearance	min	10	15	15	20	20	30	35	40	50	60	65	70	80	90
group C2	max	20	25	30	35	40	50	60	75	95	110	120	130	140	150
Clearance	min	20	25	30	35	40	50	60	75	95	110	120	130	140	150
group CN (norm	n.) max	35	40	45	55	65	80	100	120	145	170	180	200	220	240
Clearance	min	35	40	45	55	65	80	100	120	145	170	180	200	220	240
group C3	max	45	55	60	75	90	110	135	160	190	220	240	260	290	320
Clearance	min	45	55	60	75	90	110	135	160	190	220	240	260	290	320
group C4	max	60	75	80	100	120	145	180	210	240	280	310	340	380	420

with tapered bore

Bearing clearance in microns

Clearance	min	15	20	25	30	40	50	55	65	80	90	100	110	120	140
group C2	max	25	30	35	45	55	70	80	100	120	130	140	160	180	200
Clearance	min	25	30	35	45	55	70	80	100	120	130	140	160	180	200
group CN (nor	m.) max	35	40	50	60	75	95	110	130	160	180	200	220	250	270
Clearance	min	35	40	50	60	75	95	110	135	160	180	200	220	250	270
group C3	max	45	55	65	80	95	120	140	170	200	230	260	290	320	350
Clearance	min	45	55	65	80	95	120	140	170	200	230	260	290	320	350
group C4	max	60	75	85	100	120	150	180	220	260	300	340	370	410	450

100	110	120	130	140	140	150	170	190	210	230	260	290	320	350	380
170	190	200	220	240	260	180	310	350	390	430	480	530	580	630	700
170	190	200	220	240	260	180	310	350	390	430	480	530	580	630	700
260	280	310	340	370	410	440	480	530	580	650	710	770	840	910	1020
260	280	310	340	370	410	440	480	530	580	650	710	770	840	910	1020
350	370	410	450	500	550	600	650	700	770	860	930	1050	1140	1240	1390
350	370	410	450	500	550	600	650	700	770	860	930	1050	1140	1240	1390
460	500	550	600	660	720	780	850	920	1010	1120	1220	1430	1560	1700	1890
150	170	190	210	230	260	290	320	350	390	440	490	540	600	660	740
220	240	270	300	330	370	410	460	510	570	640	710	780	860	940	1060

850 960 1070 1190 1300 1420 1550 1750 1090 1220 1370 1520 1650 1800 1960 2200

900

1000 | 1120 | 1250 | 1400 1120 | 1250 | 1400 | 1600

1220

1380

710

800

280 315

300

390 430 490 540

330

430

400

400

440 490 540

720

790

355

500

630

750 840

7.13 Radial Clearance of FAG Barrel Roller Bearings

		Dimer	nsions i	n mm												
Nominal bore	over	30	30	40	50	65	80	100	120	140	160	180	225	250	280	315
diameter	to		40	50	65	80	100	120	140	160	180	225	250	280	315	355
with cylind	rical	bore														
		Bearin	ng cleai	rance ir	n micro	ns										
Clearance	min	2	3	3	4	5	7	10	15	20	25	30	35	40	40	45
group C2	max	9	10	13	15	20	25	30	35	40	45	50	55	60	70	75
Clearance	min	9	10	13	15	20	25	30	35	40	45	50	55	60	70	75
group CN (norm	.) max	17	20	23	27	35	45	50	55	65	70	75	80	85	100	105
Clearance	min	17	20	23	27	35	45	50	55	65	70	75	80	85	100	105
group C3	max	28	30	35	40	55	65	70	80	95	100	105	110	115	135	140
Clearance	min	28	30	35	40	55	65	70	80	95	100	105	110	115	135	140
group C4	max	40	45	50	55	75	90	95	110	125	130	135	140	145	170	175
with taper	ed bo	re														
		Bearir	ng cleai	rance ir	n micro	ns										
Clearance	min	9	10	13	15	20	25	30	35	40	45	50	55	60	70	75
group C2	max	17	20	23	27	35	45	50	55	65	70	75	80	85	100	105
Clearance	min	17	20	23	27	35	45	50	55	65	70	75	80	85	100	105
group CN (norm	.) max	28	30	35	40	55	65	70	80	95	100	105	110	115	135	140
Clearance	min	28	30	35	40	55	65	70	80	95	100	105	110	115	135	140
group C3	max	40	45	50	55	75	90	95	110	125	130	135	140	145	170	175

75 95 90 95 120 125 110 125

140 155 160 165 170 175

130 135 140 145

170 175

205 210

Clearance

group C4

min 40 max 55 45 50 55 60 65 75

7.14 Axial Clearance of FAG Double Row Angular Contact Ball Bearings

Series 32, 32B, 33 and 33B

Dimer		

Nominal bore diameter	over	6 10	10 18	18 24	24 30	30 40	40 50	50 65	65 80	80 100	100 120	120 140
ularrietei	lU	10	10	24	30	40	50	03	00	100	120	140

Bearing clearance in microns

Clearance	min	1	1	2	2	2	2	3	3	3	4	4
group C2	max	11	12	14	15	16	18	22	24	26	30	34
Clearance	min	5	6	7	8	9	11	13	15	18	22	25
group CN (norm.)	max	21	23	25	27	29	33	36	40	46	53	59
Clearance	min	12	13	16	18	21	23	26	30	35	42	48
group C3	max	28	31	34	37	40	44	48	54	63	73	82
Clearance	min	25	27	28	30	33	36	40	46	55	65	74
group C4	max	45	47	48	50	54	58	63	71	83	96	108

Series 32DA and 33 DA

Bearing clearance in microns

Clearance	min	5	6	7	8	9	11	13	15	18	22	25
group C2	max	22	24	25	27	29	33	36	40	46	53	59
Clearance	min	11	13	14	16	18	22	25	29	35	42	48
group CN (norm.)	max	28	31	32	35	38	44	48	54	63	73	82
Clearance	min max	20 37	23 41	24 42	27 46	30 50	36 58	40 63	46 71	55 83	65 96	

7.15 Axial Clearance of FAG Four-Point Bearings

Dimensions in mm

Nominal bore diameter	over to	18	18 40	40 60	60 80	80 100	100 140	140 180	180 220	220 260	260 300	300 355	355 400	400 450	450 500
		Beari	ng clea	ırance i	n micro	ons									
Clearance group C2	min max	20 60	30 70	40 90	50 100	60 120	70 140	80 160	100 180	120 200	140 220	160 240	180 270	200 290	220 310
Clearance group CN (norm.)	min max	50 90	60 110	80 130	90 140	100 160	120 180	140 200	160 220	180 240	200 280	220 300	250 330	270 360	290 390
Clearance group C3	min max	80 120	100 150	120 170	130 180	140 200	160 220	180 240	200 260	220 300	260 340	280 360	310 390	340 430	370 470
		Dime	nsions	in mm											
Nominal bore diameter	over to	500 560	560 630	630 710	710 800	800 900	900 1000								
		Beari	ng clea	ırance i	n micro	ons									
Clearance group C2	min max	240 330	260 360	280 390	300 420	330 460	360 500								
Clearance group CN (norm.	min) max	310 420	340 450	370 490	400 540	440 590	480 630								
Clearance group C3	min max	400 510	430 550	470 590	520 660	570 730	620 780								

7.16 Radial Clearance Reduction of FAG Cylindrical Roller Bearings with Tapered Bore

Nomi diam	nal bore eter	prior t	l clear to mou	nting				Reduction rad			displad 12 tape	cement r 1)	i .	cleara	est rad ance mounti	
d over mm	to		ormal) max		max	C4 min	max	min mm	max	Shaft min mm	max	Sleeve min	e max	CN min mm	C3 min	C4 min
24 30 40	30 40 50	0,035 0,04 0,045		0,045 0,055 0,06		0,055 0,07 0,075	0,08 0,095 0,105	0,015 0,02 0,025	0,025	0,3 0,35 0,4	0,35 0,4 0,45	0,3 0,35 0,45	0,4 0,45 0,5	0,02 0,02 0,02	0,025 0,025 0,03	0,035 0,04 0,045
50 65 80	65 80 100	0,05 0,06 0,07		0,07 0,085 0,095		0,09 0,11 0,12	0,12 0,145 0,155	0,03 0,035 0,04	0,035 0,04 0,045	0,45 0,55 0,6	0,55 0,6 0,7	0,5 0,65 0,65	0,65 0,7 0,8	0,02 0,025 0,03	0,035 0,04 0,05	0,05 0,07 0,075
100 120 140	120 140 160	0,09 0,1 0,11	0,13 0,145 0,16	0,13	0,155 0,175 0,195	0,16	0,18 0,205 0,23	0,055	0,055 0,065 0,075	0,7 0,85 0,9	0,85 1 1,2	0,8 0,95 1	0,95 1,1 1,3	0,045 0,045 0,05		0,085 0,095 0,105
160 180 200	180 200 225	0,14	0,175 0,195 0,215	0,18	0,21 0,235 0,26	0,22	0,245 0,275 0,305	0,075	0,085 0,095 0,105	1 1,2 1,3	1,3 1,5 1,6	1,1 1,3 1,4	1,5 1,7 1,8	0,06 0,065 0,07	0,08 0,09 0,1	0,11 0,125 0,14
225 250 280	250 280 315	0,17 0,185 0,205	0,235 0,255 0,28		0,285 0,31 0,34		0,335 0,365 0,4		0,115 0,125 0,14	1,5 1,6 1,8	1,8 2 2,2	1,6 1,7 1,9	2 2,3 2,4	0,075 0,08 0,09	0,105 0,125 0,13	
315 355 400	355 400 450	0,255	0,305 0,345 0,385	0,33	0,37 0,42 0,47	0,405	0,435 0,495 0,555	0,13 0,14 0,15	0,16 0,17 0,185	2 2,2 2,3	2,5 2,6 2,8	2,2 2,5 2,6	2,7 2,9 3,1	0,095 0,115 0,135	0,165	0,195 0,235 0,27
450 500 560	500 560 630	0,315 0,35 0,38	0,425 0,47 0,5		0,52 0,575 0,62		0,615 0,68 0,74	0,16 0,17 0,185	0,195 0,215 0,24	2,5 2,7 2,9	3 3,4 3,7	2,8 3,1 3,5	3,4 3,8 4,2		0,215 0,24 0,26	0,31 0,345 0,38
630 710 800	710 800 900		0,575 0,645 0,71	0,565 0,63 0,7	0,705 0,79 0,87		0,835 0,935 1,03	0,2 0,22 0,24	0,26 0,28 0,31	3,1 3,4 3,7	4,1 4,4 4,8	3,6 3,9 4,3	4,7 5,3 5,5	0,235 0,26 0,3	0,305 0,35 0,39	0,435 0,495 0,55
900 1000 1120 1250	1000 1120 1250 1400	0,6 0,665 0,73 0,81	0,79 0,875 0,97 1,07	0,78 0,865 0,96 1,07	0,97 1,075 1,2 1,33	0,96 1,065 1,2 1,33	1,15 1,275 1,44 1,59	0,26 0,28 0,31 0,34	0,34 0,37 0,41 0,45	4,1 4,4 4,8 5,3	5,3 5,8 6,4 7	4,8 5,2 5,7 6,3	6,2 7 7,6 8,3	0,34 0,385 0,42 0,47	0,44 0,5 0,55 0,62	0,62 0,7 0,79 0,85

Note: Bearings whose radial clearance is in the upper half of the tolerance range are mounted with the greater value of radial clearance reduction/axial drive-up distance. Bearings whose radial clearance is in the lower half of the tolerance range are mounted with the smaller value of radial clearance reduction/axial drive-up distance.

¹⁾ Valid only for solid steel shafts and hollow shafts whose bore diameter does not exceed half the shaft diameter.

7.17 Radial Clearance Reduction of FAG Spherical Roller Bearings with Tapered Bore

Nomi bore diam d over mm		prior to Cleara	I cleara to mou ance gro ormal) max	nting Dup	max	C4 min	max	Reductin radiceleara	al		displace 12 tape max				displace 30 tape min	cemen er ²) Sleev min		cleara	nountin	g 24
24 30 40 50	30 40 50 65	0,03 0,035 0,045 0,055		0,04 0,05 0,06 0,075	0,065 0,08	0,055 0,065 0,08 0,095	0,085 0,1	0,015 0,02 0,025 0,03	0,02 0,025 0,03 0,04	0,3 0,35 0,4 0,45	0,35 0,4 0,45 0,6	0,3 0,35 0,45 0,5	0,4 0,45 0,5 0,7	-	-	-	- - - -	0,015 0,015 0,02 0,025	0,02 0,025 0,03 0,035	0,035 0,04 0,05 0,055
65 80 100	80 100 120	0,07 0,08 0,1	0,095 0,11 0,135		0,14	0,12 0,14 0,17	0,15 0,18 0,22	0,04 0,045 0,05	0,05 0,06 0,07	0,6 0,7 0,7	0,75 0,9 1,1	0,7 0,75 0,8	0,85 1 1,2	- 1,7 1,9	- 2,2 2,7	1,8 2	2,4 2,8	0,025 0,035 0,05	0,04 0,05 0,065	0,07 0,08 0,1
120 140 160	140 160 180	0,12 0,13 0,14	0,16 0,18 0,2	0,16 0,18 0,2	0,2 0,23 0,26	0,2 0,23 0,26	0,26 0,3 0,34	0,065 0,075 0,08	0,09 0,1 0,11	1,1 1,2 1,3	1,4 1,6 1,7	1,2 1,3 1,4	1,5 1,7 1,9	2,7 3 3,2	3,5 4 4,2	2,8 3,1 3,3	3,6 4,2 4,6	0,055 0,055 0,06	0,08 0,09 0,1	0,11 0,13 0,15
180 200 225	200 225 250	0,16 0,18 0,2	0,22 0,25 0,27	0,22 0,25 0,27	0,29 0,32 0,35	0,29 0,32 0,35	0,37 0,41 0,45	0,09 0,1 0,11	0,13 0,14 0,15	1,4 1,6 1,7	2 2,2 2,4	1,5 1,7 1,8	2,2 2,4 2,6	3,5 4 4,2	4,5 5,5 6	3,6 4,2 4,6	5 5,7 6,2	0,07 0,08 0,09	0,1 0,12 0,13	0,16 0,18 0,2
250 280 315	280 315 355	0,22 0,24 0,27	0,3 0,33 0,36	0,3 0,33 0,36	0,39 0,43 0,47	0,39 0,43 0,47	0,49 0,54 0,59	0,12 0,13 0,15	0,17 0,19 0,21	1,9 2 2,4	2,6 3 3,4	2 2,2 2,6	2,9 3,2 3,6	4,7 5 6	6,7 7,5 8,2	4,8 5,2 6,2	6,9 7,7 8,4	0,1 0,11 0,12	0,14 0,15 0,17	0,22 0,24 0,26
355 400 450	400 450 500	0,3 0,33 0,37	0,4 0,44 0,49	0,4 0,44 0,49	0,52 0,57 0,63	0,52 0,57 0,63	0,65 0,72 0,79	0,17 0,2 0,21	0,23 0,26 0,28	2,6 3,1 3,3	3,6 4,1 4,4	2,9 3,4 3,6	3,9 4,4 4,8	6,5 7,7 8,2	9 10 11	5,8 8 8,4	9,2 10,4 11,2	0,13 0,13 0,16	0,19 0,2 0,23	0,29 0,31 0,35
500 560 630	560 630 710		0,54 0,6 0,67	0,54 0,6 0,67	0,68 0,76 0,85		0,87 0,98 1,09	0,24 0,26 0,3	0,32 0,35 0,4	3,7 4 4,6	5 5,4 6,2	4,1 4,4 5,1	5,4 5,9 6,8	9,2 10 11,5	12,5 13,5 15,5	9,6 10,4 12	12,8 14 16	0,17 0,2 0,21	0,25 0,29 0,31	0,36 0,41 0,45
710 800 900	800 900 1000	0,64		0,75 0,84 0,93	1,07	0,96 1,07 1,19	1,22 1,37 1,52	0,34 0,37 0,41	0,45 0,5 0,55	5,3 5,7 6,3	7 7,8 8,5	5,8 6,3 7	7,6 8,5 9,4		17,5 19,5 21	13,6 14,8 16,4	18 20 22	0,23 0,27 0,3	0,35 0,39 0,43	0,51 0,57 0,64
1120	1120 1250 1400	0,86	1,02 1,12 1,22	1,02 1,12 1,22	1,42	1,3 1,42 1,55	1,65 1,8 1,96	0,45 0,49 0,55	0,6 0,65 0,72	6,8 7,4 8,3	9 9,8 10,8	7,6 8,3 9,3	10,2 11 12,1	17 18,5 21	23 25 27	18 19,6 22,2	24 26 28,3	0,32 0,34 0,36	0,48 0,54 0,59	0,7 0,77 0,84

Note: Bearings whose radial clearance is in the upper half of the tolerance range are mounted with the greater value of radial clearance reduction/axial drive-up distance. Bearings whose radial clearance is in the lower half of the tolerance range are mounted with the smaller value of radial clearance reduction/axial drive-up distance.

¹⁾ Valid only for solid steel shafts and hollow shafts whose bore diameter does not exceed half the shaft diameter.

7.18 FAG Rolling Bearing Greases Arcanol – Chemico-physical data and directions for use

Grease	Thickener	Base oil viscosity at 40°C	Consistency	Operating temperature	Main characteristics	Typical applications
Arcanol		mm²/s	NLGI Class	°C		
MULTITOP (so far L135V)	Lithium soap with EP additives	85	2	-40+150	Universal grease for bearings at increased speeds, high loads, low and high temperatures	Rolling mills, construction machines, cars, spinning and grinding spindles
MULTI2 (so far L78V)	Lithium soap	ISO VG 100	2	-30+140	Universal grease for ball bearings with Ø D ≤ 62 mm	small electric motors, agri- cultural and construction machines, household appliances
MULTI3 (so far L71V)	Lithium soap	80	3	-30+140	Universal grease for ball bearings with Ø D > 62 mm	large electric motors, agricultural and construction machines, blowers
LOAD220 (so far L215V	Lithium/ calcium soap with EP additives	ISO VG 220	2	-20+140	Special grease for bearings at high loads, large speed range, high degree of humidity	Rolling mills, rail vehicles
LOAD400 (so far L186V)	Lithium/ calcium soap with EP additives	400	2	-25+140	Special grease for bearings at extreme loads, medium speeds, medium temperatures	Mining machines, construction machines
LOAD1000 (so far L223V	Lithium/ calcium soap with EP additives	ISO VG 1000	2	-20+140	Special grease for bearings at extreme loads, medium temperatures, low speeds	Mining machines, construction machines, preferably for shock loads and large bearings
TEMP90 (so far L12V)	Calcium polyurea with EP additives	130	2	-40+160	Special grease for bearings at high temperatures, high loads	Couplings, electric motors, cars
TEMP110 (so far L30V)	Lithium complex soap	ISO VG 150	2	-40+160	Special grease for bearings at high temperatures, high speeds	Electric machines, cars
TEMP120 (so far L195V)	Polyurea with EP additives	ISO VG 460	2	-35+180	Special grease for bearings at high temperatures, high loads	Continuous casting plants
TEMP200 (so far L79V)	PTFE	400	2	-40+260	Special grease for bearings at extremely high temperatures (safety advice page 60), chemically aggressive environment	Support rollers in baking machines, piston pins in compressors, kiln trucks, chemical plants
SPEED2,6 (so far L75)	Polyurea	ISO VG 22	2-3	-50+120	Special grease for ball bearings at extremely high speeds, low temperatures	Machine tools, instruments
VIB3 (so far L166V)	Lithium complex soap with EP additives	170	3	-30+150	Special grease for bearings at high temperatures, high loads, oscillating motion	Blade adjusters in rotors of wind power plants, packing machines
BIO2	Lithium/ calcium soap	58	2	-30+140	Special grease for bearings in environmentally hazardous applications	
FOOD2	Aluminium complex soap	192	2	-30+120	Special grease for bearings in applications with food contact; USDA H1	

Fundamental Course

Mounting Cabinet and Mounting Sets – Fundamental Course for Vocational Training

Plenty of literature is available on the correct mounting of rolling bearings. In most cases, however, the apprentices lack means and components for practical training. Therefore, the instructors of the FAG apprentice shops have prepared a fundamental course.

The target of this fundamental course is to impart the knowledge of the selection of the suitable bearing, appropriate mounting and dismounting, and maintenance. Therefore, the course has two parts.

The theoretical part deals with rolling bearing fundamentals, the practical part with the basic skill required for mounting and dismounting.

For the theoretical part, great store has been set by reasonably combining technical drawing, arithmetic, and instruction in mechanical engineering. For the practical part, simplified models of the mating parts of rolling bearings (shafts and housings) are available by means of which the mounting and dismounting of the current bearing types can be practised with mechanical and hydraulic equipment.

The subjects taught are based on instruction records and do not exceed the degree of difficulty required today in vocational training.

Based on this fundamental course, other units such as transmissions, pumps, spindles, motor car wheels etc. can be prepared for practical training.

Technical Data

Mounting cabinet:
Dimensions 1135x710x380 mm
Weight (with contents) 94 kg
suitable for 10 mounting exercises:
5 with shafts, 2 with housings,
3 with shafts and housings
Smallest shaft diameter 15 mm
Largest shaft diameter 55 mm
Angle plate: Dimensions 500x300x300 mm
Weight 40 kg

Manual 1 (Theoretical Part)

Instructions in mechanical engineering Technical arithmetic Technical drawing

Manual 2 (Practical Part)

Mounting of bearings with cylindrical bore Mounting of bearings with tapered bore Hydraulic technique Mounting of heated bearings Practical training with shafts and housings

In addition to the mounting cabinet with contents and the mounting angle also single mounting sets can be ordered, see Publ. No. WL 80 111.

Please direct enquiries and orders to

FAG Industrial Services

P.O. Box 12 60 · D-97419 Schweinfurt Phone +49 97 21/91 36 91 · Telefax +49 97 21/91 38 09 http://www.fag.com





Selection of FAG Publications

The following publications are selected from the numerous FAG publications available. Further information on request.

Catalogue WL 41520	FAG Rolling Bearings
Publ. No. WL 00106	W.L.S. Rolling Bearing Learning System
Publ. No. WL 80102	How to Mount and Dismount Rolling Bearings Hydraulically
Publ. No. WL 80103	FAG Hydraulic Nuts
Publ. No. WL 80107	FAG Induction Heating Equipment
Publ. No. WL 80111	Rolling Bearing Mounting Cabinet and Mounting Sets – A fundamental course for vocational training
Publ. No. WL 80123	All about the Rolling Bearing – FAG Training Courses on Rolling Bearings Theory and Practice
Publ. No. WL 80134	FAG Video: Mounting and Dismounting of Rolling Bearings
Publ. No. WL 80135	FAG Video: Hydraulic Methods for the Mounting and Dismounting of Rolling Bearings
Publ. No. WL 80250	FAG Mounting and Maintenance Equipment and Services for Rolling Bearings – Greater operational reliability for rolling bearings
Publ. No. WL 81115	Rolling Bearing Lubrication
Publ. No. WL 81116	Arcanol · Rolling bearing-tested grease
Publ. No. WL 82102	Rolling Bearing Damage
Publ. No. WL 82102	Rolling Bearing Damage
Publ. No. WL 82102	Rolling Bearing Damage FAG Videos on Rolling Bearings
TI No. WL 00-11	FAG Videos on Rolling Bearings
TI No. WL 00-11 TI No. WL 80-9	FAG Videos on Rolling Bearings Aluminium Heating Ring for Cylindrical Roller Bearing Inner Rings Mounting and Dismounting of Spherical Roller Bearings with
TI No. WL 00-11 TI No. WL 80-9 TI No. WL 80-14	FAG Videos on Rolling Bearings Aluminium Heating Ring for Cylindrical Roller Bearing Inner Rings Mounting and Dismounting of Spherical Roller Bearings with Tapered Bore
TI No. WL 00-11 TI No. WL 80-9 TI No. WL 80-14 TI No. WL 80-38	FAG Videos on Rolling Bearings Aluminium Heating Ring for Cylindrical Roller Bearing Inner Rings Mounting and Dismounting of Spherical Roller Bearings with Tapered Bore Mounting of Self-aligning Ball Bearings on Adapter Sleeves
TI No. WL 00-11 TI No. WL 80-9 TI No. WL 80-14 TI No. WL 80-38 TI No. WL 80-46	FAG Videos on Rolling Bearings Aluminium Heating Ring for Cylindrical Roller Bearing Inner Rings Mounting and Dismounting of Spherical Roller Bearings with Tapered Bore Mounting of Self-aligning Ball Bearings on Adapter Sleeves FAG Hand Pump Sets
TI No. WL 00-11 TI No. WL 80-9 TI No. WL 80-14 TI No. WL 80-38 TI No. WL 80-46 TI No. WL 80-47	FAG Videos on Rolling Bearings Aluminium Heating Ring for Cylindrical Roller Bearing Inner Rings Mounting and Dismounting of Spherical Roller Bearings with Tapered Bore Mounting of Self-aligning Ball Bearings on Adapter Sleeves FAG Hand Pump Sets FAG Induction Heating Devices
TI No. WL 00-11 TI No. WL 80-9 TI No. WL 80-14 TI No. WL 80-38 TI No. WL 80-46 TI No. WL 80-47 TI No. WL 80-48	FAG Videos on Rolling Bearings Aluminium Heating Ring for Cylindrical Roller Bearing Inner Rings Mounting and Dismounting of Spherical Roller Bearings with Tapered Bore Mounting of Self-aligning Ball Bearings on Adapter Sleeves FAG Hand Pump Sets FAG Induction Heating Devices FAG Mechanical Extractors FAG sets of mounting tools EINBAU.SET.ALU
TI No. WL 00-11 TI No. WL 80-9 TI No. WL 80-14 TI No. WL 80-38 TI No. WL 80-46 TI No. WL 80-47 TI No. WL 80-48 TI No. WL 80-49	FAG Videos on Rolling Bearings Aluminium Heating Ring for Cylindrical Roller Bearing Inner Rings Mounting and Dismounting of Spherical Roller Bearings with Tapered Bore Mounting of Self-aligning Ball Bearings on Adapter Sleeves FAG Hand Pump Sets FAG Induction Heating Devices FAG Mechanical Extractors FAG sets of mounting tools EINBAU.SET.ALU and EINBAU.SET.ST




Mounting and Dismounting of Rolling Bearings


Every care has been taken to ensure the correctness of the information contained in this publication but no liability can be accepted for any errors or omissions. We reserve the right to make changes in the interest of technical progress.

© by FAG 2002 · This publication or parts thereof may not be reproduced without our permission.

WL 80 100/3 EA/96/3/02 · Printed in Germany by Weppert GmbH & Co. KG, Schweinfurt









Split Taper Bushings

						Dimensi	ons						Bore R	ange		Cap S	Screv	vs		<u> </u>
PART NO.	L	U	Т	Large End	D Small End	н	V	w	х	Υ	R	S	Type 1	Type 2	No.		Siz	е	AV.Wt. Lbs	Wrench Torque Ln-Lbs.
G	1"	1/4"	3/4"	1.172"	1.133	2"	1 ⁹ /16"	-	5/8"	3/16"	1/8"	3/16"	3/8"-15/16"	1"	2	1/4"	×	5/8"	.5	95
Н	1 ¹ /4	1/4	1	1.625	1.570	2 ¹ /2	2	-	7/8	3/16	1/8	3/16	3/8-1 3/8	1 7/16-1 1/2	2	1/4	×	3/4	.8	95
P1	1 ¹⁵ /16	13/32	1 ¹⁷ /32	1.9375	1.8555	3	2 ⁷ /16	3/8'	1 ⁵ /16	7/32	7/32	1/4	1/2 -1 7/16	1 1/2-1 3/4	3	5/16	×	1	1.3	192
P2	2 ¹⁵ /16	13/32	2 ¹⁷ /32	1.9375	1.7930	3	2 ⁷ /16	3/8	2 ⁵ /16	7/32	7/32	1/4	3/4-1 7/16	1 1/2-1 3/4	3	5/16	×	1	1.5	192
P3	4 ⁷ /16	13/32	4 ¹ /32	1.9375	1.6993	3	2 ⁷ /16	3/8	3 ¹³ /16	7/32	7/32	1/4	1 1/8-1 3/8	1 5/8	3	5/16	×	1	2	192
В	1 ¹⁵ /16	1/2	1 ⁷ /16	2.625	2.5567	3 ¹¹ /16	3 1/8	1/2	1 ³ /16	7/32	1/4	1/4	1/2-1 15/16	2-2 7/16	3	5/16	×	1 1/4	1.8	192
Q1	2 ¹ /2	17/32	1 ³¹ /32	2.875	2.7657	4 ¹ /8	3 3/8	1/2	1 ³ /4	7/32	7/32	9/32	3/4-2 1/16	2 1/8-2 11/16	3	3/8	×	1 1/4	3.5	348
Q2	3 ¹ /2	17/32	2 ³¹ /32	2.875	2.7032	4 ¹ /8	3 3/8	1/2	2 ³ /4	7/32	7/32	9/32	1-2 1/16	2 1/8-2 5/8	3	3/8	×	1 1/4	4.5	348
Q3	5	17/32	4 ¹⁵ /32	2.875	2.6094	4 ¹ /8	3 3/8	1/2	4 ¹ /4	7/32	7/32	9/32	1 3/8-2 1/16	2 1/8-2 1/2	3	3/8	×	1 1/4	5.5	348
R1	2 ⁷ /8	5/8	2 ¹ /4	4.000	3.8750	5 ³ /8	4 5/8	3/4	2	1/4	1/4	9/32	1 1/8-2 13/16	2 7/8-3 3/4	3	3/8	×	1 3/4	7.5	348
R2	4 ⁷ /8	5/8	4 ¹ /4	4.000	3.7500	5 ³ /8	4 5/8	3/4	4	1/4	1/4	9/32	1 3/8-2 13/16	2 7/8-3 5/8	3	3/8	×	1 3/4	11	348
S1	4 ³ /8	3/4	3 ⁵ /8	4.625	4.4180	6 ³ /8	5 3/8	3/4	3 ⁵ /16	5/16	5/16	3/8	1 11/16-3 -3/16	3 1/4-4 1/4	3	1/2	×	2 1/4	13.5	840
S2	6 ³ /4	3/4	6	4.625	4.2696	6 ³ /8	5 3/8	3/4	5 ¹¹ /16	5/16	5/16	3/8	1 7/8-3 3/16	3 1/4-4 3/16	3	1/2	×	2 1/4	19	840
U0	5 ¹ /4	1 ¹ /16	4 ³ /16	6.000	5.7656	8 ³ /8	7	1 ¹ /4	3 ³ /4	7/16	7/16	15/32	2 3/8-3 1/16	-	3	5/8	×	2 3/4	30	1680
U0	4 ¹⁵ /16	3/4	4 ³ /16	6.000	5.7656	8 ³ /8	7	1 ¹ /4	3 ³ /4	7/16	7/16	15/32	3 1/4-4 1/4	4 3/8-5 1/2	3	5/8	×	2 3/4	27	1680
U1	7 ¹ /8	1 ¹ /16	6 ¹ /16	6.000	5.6485	8 ³ /8	7	1 ¹ /4	5 ⁵ /8	7/16	7/16	15/32	2 3/8-4 1/4	4 3/8-5 1/2	3	5/8	×	2 3/4	40	1680
U2	10 ¹ /8	1 ¹ /16	9 ¹ /16	6.000	5.4610	8 ³ /8	7	1 ¹ /4	8 ⁵ /8	7/16	7/16	15/32	2 7/16-4 1/4	4 3/8-5	3	5/8	×	2 3/4	50	1680
W1	8 ¹ /4	1 ⁷ /16	6 ¹³ /16	8.500	8.1016	12 ¹ /2	10	1 ¹ /4	6 ³ /8	7/16	7/16	9/16	3 3/8-6 3/16	6 1/4-7 7/16	4	3/4	×	3	104	3000
W2	11 ¹ /4	1 ⁷ /16	9 ¹³ /16	8.500	7.9141	12 ¹ /2	10	1 ¹ /4	9 ³ /8	7/16	7/16	9/16	3 3/8-6 3/16	6 1/4-7 7/16	4	3/4	×	3	133	3000
Y0	11 ¹ /8	2	9 ¹ /8	12.000	11.4688	16 ¹ /2	14 1/2	2	8 ¹ /2	5/8	5/8	5/8	6-7 15/16	8-10	4	1	×	5	270	7200

Note: Taper on all Bushings is 3/4"Per Foot on Diameter.



R1

R2

Split Taper Bushings

COMPLETE ROUND SHAF	COVERAGE Plus	MILLIMETER	AND SPLINE BORES

Table No.1 Stock Inch Bore Bushings Table No.2																				
Stock Bores	Keyseat	G	Н	P1	P2	Р3	В	Q1	Q2	Q3	R1	R2	S1	Stock Bores	Keyseat	W1	W2			
3/8"	None	×	×	-	-	-	-	-	-	-	-	-	_	5 5/8	1 1/2×3/4	×	×	•		
7/16	None	×	×	-	-	-	-	-	-	-	-	-	-	5 3/4	1 1/2×3/4	×	×			
1/2	1/8×1/16	×	×	×	-	-	×	-	-	-	-	-	-	5 7/8	1 1/2×3/4	×	×			
9/16	1/8×1/16	×	×	×	-	-	×	-	-	-	-	-	-	5 15/16	1 1/2×3/4	×	×			
19/32	3/16×3/32	-	×	-	-	-	-	-	-	-	-	-	-	6	1 1/2×3/4	×	×			
5/8	3/16×3/32	×	×	×	-	_	×	-	-	-	-	-	-	6 1/8	1 1/2×3/4	×	×			
21/32	3/16×3/32	_	×	×	_	_	_	_	_	_	_	_	_	6 3/16	1 1/2×3/4	×	×			
11/16	3/16×3/32	×	×	×	_	_	×	_	_	_	_	_	-	6 1/4	1 1/2×3/4	×	×			
3/4	3/16×3/32	×	×	×	×	-	×	×	- 1	-	-	-	-	6 3/8	1 1/2×3/4	×	×			
25/32	3/16×3/32	-	×	×	-	-	- 1	_	- 1	_	_	-	_	6 7/16	1 1/2×3/4	×	×			
13/16	3/16×3/32	×	×	×	×	_	×	×	_	_	_	_	-	6 1/2	1 1/2×3/4	×	×			
7/8	3/16×3/32	×	×	×	×	_	×	×	_	_	_	_	_	6 5/8	1 3/4×3/4	×	×			
15/16	1/4×1/8	×*	×	×	×	l -	×	×	l -	_	_	_	-	6 3/4	1 3/4×3/4	×	×			
31/32	1/4×1/8	_	×	×	_	_	l -	_	_	_	_	_	_	6 7/8	1 3/4×3/4	×	×			
1	1/4×1/8	×*	×	×	×	_	×	×	×	_	_	_	_	6 15/16	1 3/4×3/4	×	×			
1 1/16	1/4×1/8	_	×	×	×	_	×	×	×	_	_	_	_	7	1 3/4×3/4	×	×			
1 1/8	1/4×1/8	-	×	×	×	×	×	×	×	-	×	_	-	7 1/8	1 3/4×3/4	×	×			
1 3/16	1/4×1/8	_	×	×	×	_	×	×	×	_	×	_	_	7 3/16	1 3/4×3/4	×	×			
1 1/4	1/4×1/8	_	×*	×	×	_	×	×	×	_	×	_	_	7 1/4	1 3/4×3/4	×	×			
1 5/16	5/16×5/32	_	×*	×	×	l _	×	×	×	_	×	_	_	7 3/8	1 3/4×3/4	×	×			
1 3/8 **	5/16×5/32	_	×*	×	×	×*	×	×	×	×	×	×	_	7 7/16	1 3/4×3/4	×	×			
1 3/8 **	3/8×3/16	_	×*	×	×	_	×	×	×	_	×	_	_	- 1710				•		
1 7/16	3/8×3/16		×*	×	×*	l -	×	×	×	×	×	×			Stock Millin	neter	Bore	e Bus	shing	S
1 1/2	3/8×3/16		×*	×	×		×	×	×	×	×	×								
1 9/16	3/8×3/16	_	_	×	×		×	×	×	×	×	×		Table No.3						
1 5/8	3/8×3/16	_		×	×	×	×	×	×	×	×	×			Keyseat					
1 11/16	3/8×3/16	_	-	×	×	 ^	×	×	×	×	×	×	×	Stock Bores		G	Н	P1	В	Q1
1 3/4	3/8×3/16	_	l -	×	×		×	×	×	×	×	×	×	10 mm.	(Millimeters) None	×	×	-	-	QΊ
1 3/4	3/0^3/10	В	Q1	Q2	Q3	- R1	R2		S2	V0		U2		10 mm.	None	×	×]	_	_
1 13/16	1/2×1/4	×	×	×	×	X	X	-	- 52	-	-	-	-	12 mm.	None	×	×	_	_	_
1 7/8	1/2×1/4 1/2×1/4	×	×	×	×	×	×	×	×	-	_	_		14 mm.	5×2.5	×	×	×	_	_
1 15/16	1/2×1/4 1/2×1/4	×	×	×	×	×	×	×	×	_	-	_		15 mm.	5×2.5		_	×	×	_
2	1/2×1/4 1/2×1/4	×	×	×	×	×	×	×	×	_	-	-		16 mm.	5×2.5	×	×	×	×	_
2 1/16	1/2×1/4 1/2×1/4	×	×	×	×	×	×	^	l ^		-	_		18 mm.	6×3	×	×	×	×	×
								_]	-	-	-								
2 1/8	1/2×1/4	×	×	×	×	×	×	×	×	-	-	-		19 mm.	6×3	×	×	×	×	×
2 3/16	1/2×1/4	×	×	×	×	×	×	×	×	-	-	-		20 mm.	6×3	×	×	×	×	×
2 1/4	1/2×1/4	×	×	×	×	×	×	×	×	-	-	-		22 mm.	6×3	×	×	×	×	×
2 5/16	5/8×5/16	×	×	×	×	×	×	×	×	-	-	-		24 mm.	8×3.5	×	×	×	×	×
2 3/8	5/8×5/16	×	×	×	×	×	×	×	×	×	×	-		25 mm.	8×3.5	×	×	×	×	×
2 7/16	5/8×5/16	×	×	×	×	×	×	×	×	×	×	×		28 mm.	8×3.5	-	×	×	×	×
2 1/2	5/8×5/16	-	×	×	×	×	×	×	×	×	×	×		30 mm.	8×3.5	-	×	×	×	×
2 9/16	5/8×5/16	-	×	×	-	×	×	×	×	×	×	×		32 mm.	10×4	-	×	×	×	×
2 5/8	5/8×5/16	-	×	×	-	×	×	×	×	×	×	×		35 mm.	10×4	-	×	×	×	×
2 11/16	5/8×5/16	-	×	-	-	×	×	×	×	×	×	×		36 mm.	10×4	-	×	×	×	×
2 3/4	5/8×5/16	-	-	-	-	×	×	×	×	×	×	×		38 mm.	10×4	-	×	×	×	×
2 13/16	3/4×3/8	-	-	-	-	×	×	-	-	-	-	-		39 mm.	12×4	-	-	×	×	-
2 7/8	3/4×3/8	-	-	-	-	×	×	×	×	×	×	×		40 mm.	12×4	-	-	×	×	×
2 15/16	3/4×3/8	-	-	-	-	×	×	×	×	×	×	×		42 mm.	12×4	-	-	×	×	×
3	3/4×3/8	-	-	-	-	×	×	×	×	×	×	×		45 mm.	14×4.5	-	-	-	×	×
3 1/8	3/4×3/8	-	-	-	-	×	×	×	×	×	×	×		48 mm.	14×4.5	-	-	-	×	×
3 3/16	3/4×3/8	-	-	-	-	×	×	×	×	×	×	×		50 mm.	14×4.5	-	-	-	×	×
3 1/4	3/4×3/8	<u>L</u> -	L-	L-	<u>_</u> -	×	×	×	×	×	×	×	_	55 mm.	16×5	-	-	-	×	×
Stook Sulli	ao Poro P	.hir	ac										-	60 mm.	18×5.5	-	-	-	×	×
Stock Spill	ne Bore Bus	SHILL	ys							ea S				65 mm.	18×5.5	-	-	-	-	×
Table No.4	ı									(eys				70 mm.	20×6	-	-	-	-	-
Spline	Н	P1	Q1	Q2		to fit		ndard	dep	oth ke	eyse	ats ir	า	75 mm.	20×6	-	-	-	-	-
					_	cna	TC.								•					

Table No.	•			
Spline	Н	P1	Q1	Q2
.978-10 Inv.	×	×	1	-
1 1/8-6B	×	×	×	-
1 1/4-10B	-	×	-	-
1 3/8-6B	×	×	×	×
1 3/8-10B	-	×	×	-
1 3/8-21Inv.	×	×	×	-

shafts.

******1 3/8 Bore Bushings with5/16×5/32 Keyway will be supplied unless the 3/8×3/16 Keyway is specified on the

75 mm. 80 mm. 22×7 × 85 mm. 22×7 90 mm. 25×7 95 mm. 25×7

Stock bore tolerances: up to and incl. 1" -.000/ +.001", 1" up to and incl. 3" -.000/ +.002", over 3" -.000/ +.003"



Split Taper Bushings

COMPLETE ROUND SHAFT COVERAGE Plus MILLIMETER AND SPLINE BORES

Table No.1 Stock Inch Bore Bushings

I able N	/. I	0.0	٠				40	9	•		
Stock Bores	Keyseat	R1	R2	S1	S2	U0	U1	U2	W1	W2	
3 3/8	7/8×7/16	×	×	×	×	×	×	×	×	×	
3 7/16	7/8×7/16	×	×	×	×	×	×	×	×	×	
3 1/2	7/8×7/16	×	×	×	×	×	×	×	×	×	
3 5/8	7/8×7/16	×	×	×	×	×	×	×	×	×	
3 11/16	7/8×7/16	×	-	×	×	×	×	×	×	×	
3 3/4	7/8×7/16	×	-	×	×	×	×	×	×	×	
3 7/8	1×1/2	-	-	×	×	×	×	×	×	×	
3 15/16	1×1/2	-	-	×	×	×	×	×	×	×	
4	1×1/2	-	-	×	×	×	×	×	×	×	
4 1/8	1×1/2	-	-	×	×	×	×	×	×	×	
4 3/16	1×1/2	-	-	×	×	×	×	×	×	×	
4 1/4	1×1/2	-	-	×	-	×	×	×	×	×	
4 3/8	1×1/2	-	-	-	-	×	×	×	×	×	
4 7/16	1×1/2	-	-	-	-	×	×	×	×	×	
4 1/2	1×1/2	-	-	-	-	×	×	×	×	×	
4 5/8	1 1/4×5/8	-	-	-	-	×	×	×	×	×	
4 11/16	1 1/4×5/8	-	-	-	-	×	×	×	-	-	
4 3/4	1 1/4×5/8	-	-	-	-	×	×	×	×	×	
4 7/8	1 1/4×5/8	-	-	-	-	×	×	×	×	×	
4 15/16	1 1/4×5/8	-	-	-	-	×	×	×	×	×	
5	1 1/4×5/8	-	-	-	-	×	×	×	×	×	
		UO	U1	W1	W2						
5 1/8"	1 1/4×5/8	×	×	×	×	1					
5 3/16	1 1/4×5/8	×	×	×	×						
5 1/4	1 1/4×5/8	×	×	×	×						
5 3/8	1 1/4×5/8	×	×	×	×						
5 7/16	1 1/4×5/8	×	×	×	×						

Table No.2

5 1/2

Stock Bore	Keyseat	W1	W2	
5 5/8	1 1/2×3/4	×	×	
5 3/4	1 1/2×3/4	×	×	
5 7/8	1 1/2×3/4	×	×	
5 15/16	1 1/2×3/4	×	×	
6	1 1/2×3/4	×	×	
6 1/8	1 1/2×3/4	×	×	
6 3/16	1 1/2×3/4	×	×	
6 1/4	1 1/2×3/4	×	×	
6 3/8	1 1/2×3/4	×	×	
6 7/16	1 1/2×3/4	×	×	
6 1/2	1 1/2×3/4	×	×	
6 5/8	1 3/4×3/4	×	×	
6 3/4	1 3/4×3/4	×	×	
6 7/8	1 3/4×3/4	×	×	
6 15/16	1 3/4×3/4	×	×	
7	1 3/4×3/4	×	×	
7 1/8	1 3/4×3/4	×	×	
7 3/16	1 3/4×3/4	×	×	
7 1/4	1 3/4×3/4	×	×	
7 3/8	1 3/4×3/4	×	×	
7 7/16	1 3/4×3/4	×	×	

Stock Millimeter Bore Bushings

Table No.3

Stock Bores	Keyseat (Millimeters)	G	Н	P1	В	Q1	R1	R2
10 mm.	None	×	×	-	-	-	-	-
11 mm.	None	×	×	-	-	-	-	-
12 mm.	None	×	×	-	-	-	-	-
14 mm.	5×2.5	×	×	×	-	-	-	-
15 mm.	5×2.5	-	-	×	×	-	-	-
16 mm.	5×2.5	×	×	×	×	-	-	-
18 mm.	6×3	×	×	×	×	×	-	-
19 mm.	6×3	×	×	×	×	×	-	-
20 mm.	6×3	×	×	×	×	×	-	-
22 mm.	6×3	×	×	×	×	×	-	-
24 mm.	8×3.5	×	×	×	×	×	-	-
25 mm.	8×3.5	×	×	×	×	×	-	-
28 mm.	8×3.5	-	×	×	×	×	×	-
30 mm.	8×3.5	-	×	×	×	×	×	-
32 mm.	10×4	-	×	×	×	×	×	-
35 mm.	10×4	-	×	×	×	×	×	×
36 mm.	10×4	-	×	×	×	×	×	×
38 mm.	10×4	-	×	×	×	×	×	×
39 mm.	12×4	-	-	×	×	-	×	×
40 mm.	12×4	-	-	×	×	×	×	×
42 mm.	12×4	-	-	×	×	×	×	×
45 mm.	14×4.5	-	-	-	×	×	×	×
48 mm.	14×4.5	-	-	-	×	×	×	×
50 mm.	14×4.5	-	-	-	×	×	×	×
55 mm.	16×5	-	-	-	×	×	×	×
60 mm.	18×5.5	-	-	-	×	×	×	×
65 mm.	18×5.5	-	-	-	-	×	×	×
70 mm.	20×6	-	-	-	-	-	×	×
75 mm.	20×6	-	-	-	-	-	×	×
80 mm.	22×7	-	-	-	-	-	×	×
85 mm.	22×7	-	-	-	-	-	×	×
90 mm.	25×7	-	-	-	-	-	×	×
95 mm.	25×7			-	-		×	-


Stock Spline Bore Bushings

Table No.4

Spline	Н	P1	Q1	Q2
.978-10 Inv.	×	×	-	-
1 1/8-6B	×	×	×	-
1 1/4-10B	-	×	-	-
1 3/8-6B	×	×	×	×
1 3/8-10B	-	×	×	-
1 3/8-21Inv.	×	×	×	

Stock bore tolerances: up to and incl. 1" -.000/ +.001", 1" up to and incl. 3" -.000/ +.002", over 3" -.000/ +.003"





Steel Hubs for Split Taper Bushings

Part	For		Dimensions										les	Wt.
No.	Bushing	O.D.	Α	В	С	K	Bolt circle	W	Х	а	d	No.	Size	Lbs.
HG1	G	2"	0.174"	1.168	1.875"	_	1 9/16"	_	5/8"	_	5/8"	2	1/4-20	0.4
HH1	Н	2 1/2	0.174	1.621	2.375	_	2	_	7/8	_	7/8	2	1/4-20	0.6
HCH1	Н	2 1/2	0.625	1.621	2.375	_	2	_	7/8	_	7/8	2	1/4-20	0.7
HP1	P1	3	0.292	1.9375	2.875	1 3/32"	2 7/16	3/8"	1 5/16	60°	5/8	3	5/16-18	1.4
HCP1	P1	3	1.000	1.9375	2.875	1 3/32	2 7/16	3/8	1 5/16	60	5/8	3	5/16-18	1.1
HP2	P2	3	1.100	1.9375	2.875	1 3/32	2 7/16	3/8	2 5/16	60	5/8	3	5/16-18	2.5
HB1	В	3 7/8	0.292	2.623	3.750	1 7/16	3 1/8	1/2	1 5/16	60	13/16	3	5/16-18	2.3
HB2	В	4 1/2	0.709	2.623	4.375	1 7/16	3 1/8	1/2	1 3/4	60	13/16	3	5/16-18	4.7
HQ1	Q1	4 1/2	0.709	2.875	4.375	1 9/16	3 3/8	1/2	1 3/4	60	7/8	3	3/8-16	4.4
HCQ1	Q1	4 1/2	1.250	2.875	4.375	1 9/16	3 3/8	1/2	1 3/4	60	7/8	3	3/8-16	4.4
HQ2	Q2	4 1/2	1.606	2.875	4.375	1 9/16	3 3/8	1/2	2 3/4	60	7/8	3	3/8-16	6.9
HR1	R1	5 3/4	0.709	4.000	5.625	2 3/16	4 5/8	3/4	2	60	1 1/8	3	3/8-16	7.3
HR2	R2	5 3/4	1.606	4.000	5.625	2 3/16	4 5/8	3/4	4	60	1 1/8	3	3/8-16	15.4
HS1	S1	6 3/4	0.946	4.625	6.500	2 9/16	5 3/8	3/4	3 5/16	60	1 5/8	3	1/2-13	17.3
HS2	S2	6 3/4	2.963	4.625	6.500	2 9/16	5 3/8	3/4	5 11/16	60	1 5/8	3	1/2-13	30.4
HU0	U0	8 1/2	2.000	6.000	8.250	3 1/4	7	1 1/4	3 3/4	60	2	3	5/8-11	32.0
HU1	U1	8 1/2	2.963	6.000	8.250	3 1/4	7	1 1/4	5 5/8	60	1 3/4	3	5/8-11	44.6
HU2	U2	8 1/2	6.016	6.000	8.250	3 1/4	7	1 1/4	8 5/8	60	1 3/4	3	5/8-11	69.0
HW1	W1	12 1/2	2.963	8.500	12.250	4 9/16	10	1 1/4	6 3/8	22 1/2	1 3/4	4	3/4-10	130.0

Type "B" Steel Hubs

Part		Е	imension		Во	Wt.		
No.	O.D.	Α	С	Р	Х	Stock	Max.	Lbs.
HB40	3"	0.281"	2.875"	27/32"	1 1/8"	1/2"	1 7/8"	2.3
HB50	3 1/4	0.344	3.125	1 1/32	1 3/8	5/8	2 1/4	3.0
HB60	4	0.469	3.875	1 1/32	1 1/2	5/8	2 3/8	5.0
HB80	5	0.563	4.875	1 1/2	2 1/16	3/4	3	11.1
HB100	5 1/4	0.688	5.125	2 1/16	2 3/4	1	3 1/4	16.3

NOTE-"A" dimension is plate thickness of sprocket for chain indicated in part number.Other plates can be used by remachining "A"dimension.

HYDRAULIC ASSIST TAKE-UP - TECHNICAL OPERATION

The hydraulic assist take-up system comprises:

- Screw type take-up unit for hydraulic cylinder assist
- Two single-acting hydraulic cylinders
- Hydraulic power unit

The hydraulic assist is to be used to tension the belt (or chain) after installation and periodically during operation as required. The screws on the take-up units are used to hold the take-ups in position against belt/chain tension. The system is not designed to be a constant tension device by constantly holding cylinders in a pressurized state.

Single acting cylinders are used and can only be reversed by manually pushing the rods in or by driving the take-ups back using the screws. Always move take-ups simultaneously or 2-3 mm each side at a time to prevent damage to the bearings and seals in the pillow blocks.

Calculate the required cylinder pressure to achieve the design belt/chain tension if his has not been provided for your specific application. During initial installation, the initial tensioning should be to 80% of the set pressure. Final tensioning would be to 100% of the pressure required (i.e., 100% of required tension).

The relief valve on the pump must be set to the required pressure. This will ensure that the belt/chain will not be over-tensioned, which could cause damage to the belt, bearings, pulleys, shafts or frame.

Operation

Power Unit for Hydraulic Take-Up Assist

- 1. Ensure that there is sufficient volume in the reservoir to fully extend both hydraulic cylinders and still leave 20% capacity in the tank.
- 2. Fill reservoir with clean new hydraulic oil, with suitable viscosity, to meet the ambient and operating temperatures. Check with your oil supplier for the correct oil.
- 3. Ensure hoses are properly connected.
- 4. If the relief valve has not been set to required pressure, refer to relief adjustment section for instructions.
- 5. Ball valves should be opened to allow flow to both cylinders for the initial cylinder fill. Close release valve and manually stroke the pump to provide flow to the cylinders.
- 6. Once the cylinders meet with resistance, there will be an increase of pressure. This will be seen on the pressure gauge. Always move the cylinders simultaneously or 2-3 mm each side at a time to prevent damage to the bearings or seals in the pillow blocks.
- 7. As the pressure approaches the desired pressure, you may choose to leave both valves open (flow going to both cylinders) or you may choose to pump to one

cylinder only by closing one ball valve.

Caution: Refer to 6. above.

8. Once you have positioned the take-up and locked it mechanically into position, both ball valves should be left in the open position *as well as the* release *valve*. This releases the pressure in the hydraulic system.

Relief Valve Adjustment

Refer to Brand Hydraulics technical and parts information sheets attached to find location of the relief valve adjusting screw.


To make adjustments:

- Loosen the nut locking the adjustment setscrew.
- Using an allen wrench, turn the setscrew counter-clockwise two turns.
- Close both ball valves.
- Close release valve (clockwise).
- Start pumping and check pressure. When pressure remains constant when pumping, the gauge will indicate the relief setting.
- If the pressure reading is below that required, gradually increase the relief valve setting by turning the setscrew clockwise until the required pressure setting has been achieved. Continue pumping to check if reading is constant. If so, lock setscrew using locknut.

Open release valve.

Industrial Equipment Manufacturing Ltd.

#109 - 19433 96th Ave, Surrey, BC, Canada V4N 4C4 Phone (604) 513-9930 Fax (604) 513-9905



Tailshaft Take-Up Showing Dovetail Guide



Hydraulic Assist Take-Up Cylinder (optional)

#109 - 19433 96th Ave, Surrey, BC, Canada V4N 4C4 Phone (604) 513-9930 Fax (604) 513-9905

Typical Hydraulic Assist for Feeder Take-Up

Arrangement varies depending on type of feeder and size.


The hydraulic cylinder is single-acting, pressurized to extend. Cylinder is retracted using the screw take-up and opening the release valve in the hand pump (refer to operating manual for instructions). The cylinder is only used for assisting tensioning of chain (or conveyor belt)--**not to be used as a holding cylinder.**



Typical Hydraulic Power Unit, Manual Operation

Mounting arrangement varies depending type of feeder and orientation.

The hand-operated pump is used to provide the flow for the assist cylinders. The valves on the power unit can are used to direct flow to either of the two cylinders individually or both at the same time.






Shipping: 2332 So 25th St (Zip 68105) Mailing: P.O. Box #6069 (Zip 68106) **Omaha NE**

Phone: (402) 344-4434 Fax: (402) 341-5419





HAND OPERATED HYDRAULIC PUMPS



- **O'R**ING **O**UTLET **C**HECK for zero leakage.
- **O'R**ING **S**EAL between tank and casting.
- **S**TEEL **B**ALL **R**ELEASE **V**ALVE allows oil to travel to tank and relieves pressure on the outlet line.
- **E**VERY **HP** IS **T**ESTED for outlet check leakage, double or single pump action and relief setting.
- **O**PTIONAL **H**ORIZONTAL **M**OUNTING **B**RACKETS allows for horizontal handle actuation.

SPECIFICATIONS:

- **Volume Displacement** $HP22SA - 0.20 \text{ in}^3 (3.3 \text{ cm}^3)$ (When handle is
 - $HP61DA 0.60 \text{ in}^3 (9.8 \text{ cm}^3) \text{ per full cycle.}$ $HP121DA - 1.20 \text{ in}^3 (19.7 \text{ cm}^3) \text{ per full cycle.}$
- Tank sizes 95 in³ (1557 cm³), 80 in³ (1311 cm³), 65 in³ (1065 cm³), and 50 in³. (819 cm³). TL - 2 in. (50.8 mm) tank used with remote reservoir.
- Pressure rating and (Standard relief setting). HP22SA - 6000 psi, 414 bar (4000 psi, 276 bar). HP61DA - 3000 psi (3000 psi, 207 bar). HP121DA - 2000 psi (2000 psi, 138 bar).

- Outlet Port Size #6 SAE (9/16-18).
- Filler Port Size 1/4" NPT.

MATERIALS:

- **Cast Iron Body**
- **Buna N O'Rings**
- **Delrin Inlet Seat**
- **Stainless Steel Piston**

02-08 Page H-1



HP – GENERAL INFORMATION

The Brand, hand operated hydraulic pump comes in three basic models HP121DA, HP61DA and HP22SA. Each one of these models comes with a relief that can be adjusted manually to suit the customer's requirements. Brand has also redesigned the outlet check seat for zero leakage. The zero leak seat was created by utilizing an o'ring seal to replace the steel ball seal. The NT (no tank) option does not have a tank, pressure relief and release valve. To use the NT option the customer must connect the inlet of the hand pump to an external reservoir (external reservoir is not supplied by Brand). The TL (2 in. tank) option has a small tank, pressure relief and release valve. To use the TL option the customer must connect the fill port on the tank to an external reservoir (external reservoir is not supplied by Brand). When mounting the NT or TL option, the pump should be placed below the fluid level of the external reservoir. All standard tanks have a 1/4" NPT filler plug at the top of the tank.

HP22SA – has a single-acting piston that can pump 0.20 in³ (3.3 cm³) per full cycle. The term single-acting means that the piston only pumps fluid when the handle is pulled away from the pump. The piston does not displace fluid when the handle is pushed towards the pump. The pressure rating is higher then the HP121DA because it takes less force to displace the smaller surface area of the piston. This pump is typically used in applications that require low volume displacement and high pressure.

HP61DA – has a double-acting piston that can pump 0.60 in³ (9.8 cm³) per full cycle. The term double-acting means that the piston pumps fluid when the handle is pushed and pulled. The pressure rating is higher then the HP121DA because it takes less force to displace the piston. This pump is typically used in applications that require medium volume displacement and medium pressure.

HP121DA – has a large double-acting piston that can pump 1.20 in³ (19.7 cm³) per full cycle. The term double-acting means that the piston pumps fluid when the handle is pushed and pulled. The pressure rating is lower then the HP22SA and HP61DA because it takes a greater amount of force to displace a piston that has a large surface area. This pump is typically used in applications that require high volume displacement and lower pressure.

HP – EXAMPLES OF COMMON MODEL CODES:

HP22SA50	0.20 in ³ (3.3 cm ³) displacement, single acting and 50 in ³ (8	19 cm ³) ta	nk.
HP61DA95	0.60 in ³ (9.8 cm ³) displacement, double acting and 95 in ³ (1557 cm^3	tank.
HP121DA65	1.20 in ³ (19.7 cm ³) displacement, double acting and 65 in ³	(1065 cm ³) tank.

HP - CREATING A COMMON MODEL CODE FOR HP'S:

ΗP

DISPLACEMENT PER CYCLE AND PUMP

ACTION:

 $22SA - 0.20 \text{ in}^3 (3.3 \text{ cm}^3)$ and single acting $61DA - 0.60 \text{ in}^3 (9.8 \text{ cm}^3)$ and double acting $121DA - 1.20 \text{ in}^3 (19.7 \text{ cm}^3)$ and double acting

HAND PUMP MOUNTING:

Omit – Standard vertical mounting

H – Horizontal-mounting brackets (must use 50, 65, 80, or 95 tank option)



95 – 95 in³ 1.55 Litters) (12 in. (30.5 cm) height)

 $80 - 80 \text{ in}^3$ (1.31 Litters) (10 in. 25.4 cm) height)

 $65 - 65 \text{ in}^3$ (1.06 Litters) (8 in. (20.3 cm) height)

 $50 - 50 \text{ in}^3 (0.82 \text{ Litters}) (6 \text{ in.} (15.2 \text{ cm}) \text{ height})$

TL - 2 in. tank used in conjunction with customer's external reservoir (1/4" NPT filler port).

NT – Does not come with tank, adjustable relief and release valve. (61DA and 121DA only)

RP – Return port (1/4" NPT return port, cannot be used with the NT option.).

HP – COMPLETE LIST OF OPTIONS AND ACCESSORIES:


HP22-K	Seal kit for HP22SA.
HP22-K-EPR	Ethylene propylene rubber (EPR) seal kit for HP22SA.
HP61-K	Seal kit for HP61DA.
HP121-K	Seal kit for HP121DA.





DIMENSIONAL DATA: inches & [millimeters]

DIMENSIONS LISTED ARE THE SAME FOR ALL THREE PUMP SERIES NOTE: HP121 & HP61 MOUNTING HOLE (NEXT TO PRESSURE RELEASE LEVER) IS NOT IN THE SAME LOCATION AS THE MOUNTING HOLE ON THE HP22. (HP61DA SHOWN)









DIMENSIONAL DATA CONTINUED: inches & [millimeters]


DIMENSIONS LISTED ARE THE SAME FOR ALL THREE PUMP SERIES (HP61DA AND HP121DA SHOWN) $\,$







MAL MODEL - SPECIFICATIONS




Pressure (PSI)									
Operating	Testing								
3000	5600								

MAL CYLINDER DIMENSIONS

	TUBE	Λ.	ØB	K		PORTS
	DIA.	A	PIN	N.	L	(SAE)
in.	1.500	8.000	0.750	2.000	2.250	6
mm	38.10	203.20	19.05	50.80	57.15	6
in.	2.000	8.000	1.000	2.250	2.750	6
mm	50.80	203.20	25.40	57.15	69.85	O
in.	2.500	8.000	1.000	2.250	3.250	8
mm	63.50	203.20	25.40	57.15	82.55	O
in.	3.000	8.000	1.000	2.250	3.750	8
mm	76.20	203.20	25.40	57.15	95.25	O
in.	3.500	10.000	1.250	2.250	4.250	8
mm	88.90	2540	31.750	57.15	107.95	O
in.	4.000	10.000	1.500	2.500	4.750	8
mm	101.60	254.00	38.10	63.50	120.65	U
in.	5.000	12.000	1.750 / 2.000	3.250	6.000	12
mm	127.00	304.80	44.45	82.55	152.40	12

MODEL NUMBER FOR MAL







MAL MODELS

MODEL	BORE X STROKE	ROD DIA.	PIN DIA.	CENTER T OF PI	O CENTER	PORTS	WEIGHT	LIST PRICE	SEAL	. KIT
WIODEL	(in.)	(in.)	(in.)	Retracted	Extended	PORTS	(lb)	LIST PRICE	PART#	PRICE
HYS 15MAL04-10	1 1/2 X 4			12	16		8			
HYS 15MAL06-10	1 1/2 X 6			14	20		9			
HYS 15MAL08-10	1 1/2 X 8			16	24		10			
HYS 15MAL10-10	1 1/2 X 10	1	3/4	18	28		12		HYS MF 151000-10	
HYS 15MAL12-10	1 1/2 X 12			20	32		13		151000-10	
HYS 15MAL14-10	1 1/2 X 14			22	36		14			
HYS 15MAL16-10	1 1/2 X 16			24	40		15			
HYS 20MAL04-10	2 X 4			12	16		11			
HYS 20MAL06-10	2 X 6			14	20		13			
HYS 20MAL08-10	2 X 8			16	24		15			
HYS 20MAL10-10	2 X 10			18	28		16			
HYS 20MAL12-10	2 X 12			20	32	SAE-6	18			
HYS 20MAL14-10	2 X 14			22	36		20			
HYS 20MAL16-10	2 X 16			24	40		21			
HYS 20MAL18-10	2 X 18	1-1/4		26	44		23		HYS MF 201250-10	
HYS 20MAL20-10	2 X 20			28	48		25			
HYS 20MAL24-10	2 X 24			32	56		28			
HYS 20MAL28-10	2 X 28			36	64		31			
HYS 20MAL30-10	2 X 30			38	68		33			
HYS 20MAL32-10	2 X 32			40	72		35			
HYS 20MAL36-10	2 X 36			44	80		39			
HYS 20MAL40-10	2 X 40			48	88		42			
HYS 20MAL48-10	2 X 48			56	104		49			
HYS 25MAL04-10	2 1/2 X 4		_	12	16		15			
HYS 25MAL06-10	2 1/2 X 6		1	14	20		17			
HYS 25MAL08-10	2 1/2 X 8			16 18	24 28		20 22			
HYS 25MAL10-10	2 1/2 X 10 2 1/2 X 12			20	32		24			
HYS 25MAL12-10	2 1/2 X 12 2 1/2 X 14			22	36		26			
HYS 25MAL14-10 HYS 25MAL16-10	2 1/2 X 14 2 1/2 X 16			24	40		28			
HYS 25MAL18-10	2 1/2 X 18			26	44		31		111/0 145	
HYS 25MAL20-10	2 1/2 X 10	1-1/2		28	48		33		HYS MF 251500-10	
HYS 25MAL24-10	2 1/2 X 24			32	56	SAE-8	37		E01000-10	
HYS 25MAL28-10	2 1/2 X 24 2 1/2 X 28			36	64	O/ (L=0	42			
HYS 25MAL30-10	2 1/2 X 20			38	68		44			
HYS 25MAL32-10	2 1/2 X 32			40	72		46			
HYS 25MAL36-10	2 1/2 X 36			44	80		51			
HYS 25MAL40-10	2 1/2 X 40			48	88		55			
HYS 25MAL48-10	2 1/2 X 48			56	104		64			
HYS 30MAL06-10	3 X 6			14	20		21			
HYS 30MAL08-10	3 X 8	1-1/2		16	24		24		HYS MF	
HYS 30MAL10-10	3 X 10			18	28		26		301500-10	



MAL MODELS

	BORE			CENTER T	O CENTER				SEAL KIT	
MODEL	X STROKE	ROD DIA. (in.)	PIN DIA. (in.)		N (in.)	PORTS	WEIGHT (lb)	LIST PRICE	SEAL	. KIT
	(in.)	(111.)	(111.)	Retracted	Extended		(ID)		PART#	PRICE
HYS 30MAL12-10	3 X 12			20	32		29			
HYS 30MAL14-10	3 X 14			22	36		31			
HYS 30MAL16-10	3 X 16			24	40		33			
HYS 30MAL18-10	3 X 18			26	44		36			
HYS 30MAL20-10	3 X 20			28	48		38		HYS MF	
HYS 30MAL24-10	3 X 24	1-1/2	1	32	56	SAE-8	43			
HYS 30MAL28-10	3 X 28	/_	·	36	64	O, 12 0	48		301500-10	
HYS 30MAL30-10	3 X 30			38	68		50			
HYS 30MAL32-10	3 X 32			40	72		53			
HYS 30MAL36-10	3 X 36			44	80		58			
HYS 30MAL40-10	3 X 40			48	88		63			
HYS 30MAL48-10	3 X 48			56	104		73			
HYS 35MAL06-10	3 1/2 X 6			16	22		30			
HYS 35MAL08-10	3 1/2 X 8			18	26		33			
HYS 35MAL10-10	3 1/2 X 10		1-1/4	20	30	SAE-8	36			
HYS 35MAL12-10	3 1/2 X 12			22	34		39			
HYS 35MAL14-10	3 1/2 X 14			24	38		42			
HYS 35MAL16-10	3 1/2 X 16			26	42		45			
HYS 35MAL18-10	3 1/2 X 18	4.044		28	46		48		HYS MF	
HYS 35MAL20-10	3 1/2 X 20	1-3/4		30	50		51		351750-10	
HYS 35MAL24-10	3 1/2 X 24			34	58		57			
HYS 35MAL28-10	3 1/2 X 28			38	66		63			
HYS 35MAL30-10	3 1/2 X 30			40	70		66			
HYS 35MAL32-10	3 1/2 X 32			42	74		69			
HYS 35MAL36-10	3 1/2 X 36			46	82		75			
HYS 35MAL40-10	3 1/2 X 40			50	90		81			
HYS 35MAL48-10	3 1/2 X 48			58	106		93			
HYS 40MAL08-10	4 X 8 4 X 10			18 20	26 30		46 50			
HYS 40MAL10-10	4 X 10 4 X 12			20	34		55			
HYS 40MAL12-10	4 X 12 4 X 14			24	38		55 59			
HYS 40MAL14-10	4 X 14 4 X 16			26	42		63			
HYS 40MAL16-10	4 X 18			28	46		67			
HYS 40MAL18-10 HYS 40MAL20-10	4 X 20			30	50		71		UVOME	
HYS 40MAL24-10	4 X 24	2	1-1/2	34	58	SAE-8	80		HYS MF 402000-10	
HYS 40MAL28-10	4 X 28			38	66		88		.02000 10	
HYS 40MAL30-10	4 X 30			40	70		92			
HYS 40MAL32-10	4 X 32			42	74		96			
HYS 40MAL36-10	4 X 36			46	82		105			
HYS 40MAL40-10	4 X 40			50	90		113			
HYS 40MAL48-10	4 X 48			58	106		130			



MAL MODELS

MODEL	BORE X STROKE	X STROKE ROD DIA. PIN DIA.		CENTER T OF PI	O CENTER N (in.)	PORTS	WEIGHT (lb)	LIST PRICE	SEAL KIT	
	(in.)	(in.)	(in.)	Retracted	Extended		(ID)		PART #	PRICE
HYS 50MAL08-10	5 X 8			20	28		82			
HYS 50MAL10-10	5 X 10			22	32		89			
HYS 50MAL12-10	5 X 12			24	36		95		HYS MF 502500-10	
HYS 50MAL14-10	5 X 14			26	40	SAE-12	101			
HYS 50MAL16-10	5 X 16			28	44		108			
HYS 50MAL18-10	5 X 18			30	48		114			
HYS 50MAL20-10	5 X 20	2-1/2	1-3/4 & 2	32	52		121			
HYS 50MAL24-10	5 X 24	2-1/2	1-3/4 & Z	36	60	SAE-12	133			
HYS 50MAL28-10	5 X 28			40	68		146			
HYS 50MAL30-10	5 X 30			42	72		152			
HYS 50MAL32-10	5 X 32			44	76		159			
HYS 50MAL36-10	5 X 36			48	84		172			
HYS 50MAL40-10	5 X 40			52	92		184			
HYS 50MAL48-10	5 X 48			60	108		210			

CYLINDER PARTS & ACCESSORIES





PIN & BUSHING KIT











PIN ONLY Dimensions in inches

Difficitions in filtries										
PIN ONLY										
MODEL	Ø PIN	USABLE LENGTH	FOR CYLINDER MODEL	LIST PRICE						
HYSPIN1X2750	1	2.750	20AGU-10 25AGU-10 30AGU-10 35AGU-10 40AGU-10							
HYSPIN1X2250	1	2.250	20FEM-10 25FEM-10 30FEM-10							
HYSPIN125X2500	1-1/4	2.500	35FEM-10							
HYSPIN150X3250	1-1/2	3.250	40FEM-10							
HACDINISA 1320	2	4 250	50FEM-10							

PIN & BUSHING KIT (includes 2 pins & 4 bushings)									
MODEL	Ø PIN	FOR CYLINDER MODEL	LIST PRICE						
HYSHYF-35-075-K	1-1/4 to 1	35FEM-10							
HYSHYF-40-075-ASAE-K	1-1/2 to 1	40FEM-ASAE-10							
HYSHYF-40-075-K	1-1/2 to 1	40FEM-10							
HYSHYF-50-075-K	2 to 1-1/2	50FEM-10							
HYSHYM-50-075	2 to 1 3/4	50MAL-10 (2 bushings only)							
HYSITC12-18-001	1 1/2 to 1	12ITC-10 (1 bushing only)							

FEMALE CLEVIS									
MODEL	THREAD	FOR CYLINDER MODEL	LIST PRICE						
HYSAGU-20-070	1-1/8 12UNF	20AGU-10 25AGU-10							
HYSAGU-30-070	1-1/4 12UNF	30AGU-10 35AGU-10							
HYSAGU-40-070	1-1/4 12UNF	40AGU-10							

STROKE LIMITER ADJUSTABLE FROM 2 1/8" TO 5 3/16"								
MODEL Ø ROD FOR CYLINDER MODEL								
HYSSL-1125-3000-001	1-1/8	20AGU-10 25AGU-10						
HYSSL-1250-3000-001	1-1/4	30AGU-10 35AGU-10 40AGU-10						
HYSSL-1250-3000-002	1-1/2 1-3/4 2	35AGU-10 40AGU-10						

ASK FOR HY-SPEC QUALITY



HIGH PRESSURE BALL VALVES - 2 WAY

SPECIFICATIONS

BODY: STEEL STEEL


TEMPERATURE RANGE: -25° C to 100° C

BALL SEAL: DELRIN SHAFT SEAL: BUNA-N



DIMENSIONS

5000 PSI to 7250 PSI



Dimensions in inches

DIMENSI	ONS	A	В	С	D	Е	F	G	н	L	М	sw	LW
	1/4	1.38	0.55	2.80	1.65	0.43	1.93	1.18	4.33	0.63	1/4	0.35	0.24
	3/8	1.57	0.67	2.87	1.73	0.43	2.13	1.38	4.33	0.63	3/8	0.35	0.39
FULL BORE	1/2	1.69	0.71	3.27	1.89	0.43	2.24	1.46	4.33	0.67	1/2	0.35	0.51
	3/4	2.17	0.91	3.74	2.44	0.51	2.87	1.77	7.09	0.87	3/4	0.55	0.79
	1	2.56	1.42	4.45	2.60	0.51	3.27	2.17	7.09	0.98	1	0.55	0.98
REDUCED	1-1/4	2.56	1.42	4.76	2.60	0.51	3.27	2.17	7.09	0.98	1-1/4	0.55	0.98
BORE	1-1/2	2.56	1.42	4.76	2.60	0.51	3.27	2.17	7.09	0.98	1-1/2	0.55	0.98
	1-1/4	3.31	1.65	4.53	3.74	0.53	3.98	3.31	13.27	0.94	1-1/4	0.55	1.26
FULL BORE	1-1/2	3.86	1.89	5.16	4.25	0.53	4.53	4.01	13.27	1.06	1-1/2	0.55	1.58
	2	4.06	2.03	5.51	4.53	0.53	4.72	4.25	13.27	1.10	2	0.55	1.97

	NPT MODEL	PORTS	LIST PRICE	SAE MODEL	PORTS	LIST PRICE	WORKING PRESSURE (PSI)	WEIGHT (lb)	HANDLE PART #	LOCKING KIT PART#
	HYS GE2-N1/8-DN4-PSI7250	1/8 NPT		•	-	-	-	-		
	HYS GE2-N1/4-DN6-PSI7250	1/4 NPT		HYS GE2-SAE4-DN6-PSI7250	SAE-4		7250	1.00	UVC 040407D	IIVO DALLIKO II
FIII L DODE	HYS GE2-N%-DN10-PSI7250	3/8 NPT		HYS GE2-SAE6-DN10-PSI7250	SAE-6		7250	1.25	HYS C1010ZB	HYS BALLK6-U
FULL BORE	HYS GE2-N1/2-DN13-PSI7250	1/2 NPT		HYS GE2-SAE8-DN13-PSI7250	SAE-8		7250	1.61		
	HYS GE2-N%-DN20-PSI5800	3/4 NPT		HYS GE2-SAE12-DN20-PSI5800	SAE-12		5800	3.00		
	HYS GE2-N1-DN25-PSI5075	1 NPT		HYS GE2-SAE16-DN25-PSI5075	SAE-16		5075	4.80	UVC 040007D	LIVO DALLIZOO II
REDUCED	HYS GE2-N11/4-DN25-PSI5075	1-1/4 NPT		HYS GE2-SAE20-DN25-PSI5075	SAE-20		5075	5.25	HYS C1200ZB	HYS BALLK20-U
BORE	HYS GE2-N11/2-DN25-PSI5075	1-1/2 NPT		HYS GE2-SAE24-DN25-PSI5075	SAE-24		5075	5.25		
	HYS GB2-N11/4-DN32-PSI5075	1-1/4 NPT		HYS GB2-SAE20-DN32-PSI5075	SAE-20		5075	8.25		
FULL BORE	HYS GB2-N11/2-DN40-PSI5075	1-1/2 NPT		HYS GB2-SAE24-DN40-PSI5075	SAE-24		5075	12.75	HYS C2890AV	HYS BALLK20-F
	HYS GB2-N2-DN50-PSI5075	2 NPT		HYS GB2-SAE32-DN50-PSI5075	SAE-32		5075	14.25		

OTHER MODELS AVAILABLE ON REQUEST

ASK FOR HY-SPEC QUALITY



GAUGES

LIQUID FILLED PRESSURE GAUGES

STEM MOUNT

MODEL		DESCRIPTION		WEIGHT (lb)	LIST PRICE
HYS 25KL4V-15-0 PSI	0-30 in Hg	STAINLESS STEEL CASE	VACUUM		
HYS 25KL4P 0-30PSI	0-30 PSI	STAINLESS STEEL CASE			
HYS 25KL4P 0-100PSI	0-100 PSI	STAINLESS STEEL CASE			
HYS 25KL4P 0-600PSI	0-600 PSI	STAINLESS STEEL CASE		0.44	
HYS 25KL4P 0-1000PSI	0-1000 PSI	STAINLESS STEEL CASE		0.44	
HYS 25KL4P 0-1500PSI	0-1500 PSI	STAINLESS STEEL CASE			
HYS 25KL4P 0-3000PSI	0-3000 PSI	STAINLESS STEEL CASE			
HYS 25KL4P 0-5000PSI	0-5000 PSI	STAINLESS STEEL CASE			

PANEL MOUNT

MODEL	DESCRIPTION	WEIGHT (lb)	LIST PRICE
HYS 25KV4V -15- 0 PSI	0-30 in Hg STAINLESS STEEL CASE VACUUM		
HYS 25KV4P 0-500PSI	0-500 PSI STAINLESS STEEL CASE	0.51	
HYS 25KV4P 0-3000PSI	0-3000 PSI STAINLESS STEEL CASE	0.51	
HYS 25KV4P 0-5000PSI	0-5000 PSI STAINLESS STEEL CASE		

STEM MOUNT

MODEL		DESCRIPTION	WEIGHT (lb)	LIST PRICE	
HYS 4KL4V -15-0PSI-1/2 NPT	0-30 in Hg	STAINLESS STEEL CASE	VACUUM		
HYS 4KL4P 0-30PSI-1/2 NPT	0-30 PSI	STAINLESS STEEL CASE			
HYS 4KL4P 0-100PSI-1/2 NPT	0-100 PSI	STAINLESS STEEL CASE			
HYS 4KL4P 0-600PSI-1/2 NPT	0-600 PSI	STAINLESS STEEL CASE		1.3	
HYS 4KL4P 0-1000PSI-1/2 NPT	0-1000 PSI	STAINLESS STEEL CASE		1.3	
HYS 4KL4P 0-1500PSI-1/2 NPT	0-1500 PSI	STAINLESS STEEL CASE			
HYS 4KL4P 0-3000PSI-1/2 NPT	0-3000 PSI	STAINLESS STEEL CASE			
HYS 4KL4P 0-5000PSI-1/2 NPT	0-5000 PSI	STAINLESS STEEL CASE			

PANEL MOUNT

MODEL		DESCRIPTION	WEIGHT (lb)	LIST PRICE	
HYS 4KV4V -15-0PSI-1/2 NPT	0-30 in Hg	STAINLESS STEEL CASE	VACUUM		
HYS 4KV4P 0-30PSI-1/2 NPT	0-30 PSI	STAINLESS STEEL CASE			
HYS 4KV4P 0-100PSI-1/2 NPT	0-100 PSI	STAINLESS STEEL CASE			
HYS 4KV4P 0-600PSI-1/2 NPT	0-600 PSI	STAINLESS STEEL CASE		1.4	
HYS 4KV4P 0-1500PSI-1/2 NPT	0-1500 PSI	STAINLESS STEEL CASE			
HYS 4KV4P 0-3000PSI-1/2 NPT	0-3000 PSI	STAINLESS STEEL CASE			
HYS 4KV4P 0-5000PSI-1/2 NPT	0-5000 PSI	STAINLESS STEEL CASE			

2 1/2"





DESCRIPTION

Body Case: Stainless Steel 304
Case Diameter: 2.5"
Window: Polycarbonate
Connection: Brass 1/4 NPT

Connection: Brass 1/4 NPT
Pressure scale: Red: PSI
Blue: BAR

4"





DESCRIPTION

Body Case: Stainless Steel 304

Case Diameter: 4"

Window: Polycarbonate
Connection: Brass 1/2 NPT
Pressure scale: Red: PSI
Blue: BAR


N.B. Our Pressure Gauges must be mounted upright and the rubber tip must be cut after installation. Performance: accuracy +/- 3.33%

SIGHT LEVEL AND TEMPERATURE GAUGES

	A	В	С	D	Е	F	WEIGHT	
MODEL	mm in.	mm in.	mm in.	mm in.	mm in.		WEIGHT (lb)	LIST PRICE
HYS LS3	120 4.72	44 1.73	76 3.00	49 1.93	20 0.80	M10 X 1.5	0.4	
HYS LS5	175 6.89	48 1.89	127 5.00	45 5.71	21 4.76	M12 X 1.75	0.6	

MODELS WITH THERMOMETER





ASK FOR HY-SPEC QUALITY



Metal Filler Breathers SMBB / SMBT / SMBP


Group size 80 - Breather cap diameter 80 mm

SMBB-80


Metal Filler Breather Bayonet style, 3" metal basket standard

Ontions

- Metal Dipstick non-pressurized
- Plastic Dipstick pressurized
- Locking version
- Pressurized, opening pressure 5 PSI (0.35 bar) and 10 PSI (0.7 bar)
- Seal material: cork non-pressurized Buna-N – pressurized
- 6" (150 mm) and 8" (200 mm) metal and 4" (100 mm) plastic baskets available
- 3μ , 10μ or 40 micron breather element
- Chrome plated or epoxy coated
- Extended Bayonet options available



Non-pressurized version




Pressurized version

SMBT-80


Metal Breather Screw-in style

Options:

- Metal Dipstick non-pressurized
- Plastic Dipstick pressurized
- NPT thread standard, BSP available on request
- Pressurized, opening pressure 5 PSI (0.35 bar) or 10 PSI (0.7 bar)
- \bullet 3 μ , 10 μ or 40 micron breather element
- Chrome plated or epoxy coated



Non-pressurized version




Pressurized version

SMBP-80

Metal Breather, epoxy coated standard Push-on style

Options:

• Plastic Dipstick



The SMBP is only available without pressurization

Bayonet Flange Options

Standard Bayonet - "B"

Part No. EBF-1 - "B1" 38 mm (1.5 in) high (See A13 for details)


Part No. EBF-2 - "B2" 69 mm (2.7 in) high (See A13 for details)

Part No.	Micron Rating	Air Flow	/ Capacity	Oil Displ	Screws	
		cfm	m³/min	gpm	lpm	
SMBB/SMBT 80	3	10	0.28	72	272	10-32x1/2
SMBB/SMBT 80	10	16	0.45	110	416	10-32x1/2
SMBB/SMBT 80	40	26	0.75	190	720	10-32x1/2




Metal Filler Breathers SMBB / SMBT / SMBP


Ordering Code (bayonet style, cap ø80)



Ordering Code (screw-in style, cap ø80)



Ordering Code (push-on style, cap ø80)





Pressure Gauges Type SPG, WPG Series

Specifications

- Glycerine Filled for Accuracy
- Copper Alloy Bourden Tube
- Dual Scales
- Built in Relief Valve
- Operating Temperatures
 Ambient -4°F to 140°F (-20°C to 60°C)
 Media 140°F (+60°C)
- Acrylic Lens
- Accuracy + 1.5% of Full Scale
- Built in Snubber

Options

- 21/2" or 4" Diameter Available
- Forged Brass Case Available in 2¹/₂" Version.
- Stainless Steel Case Available in 2¹/₂" and 4" Version.
- Front Flange
- Rubber Protective Cover Available for SPG-063 Series Only
- Custom Dials & Pressure Gauges Available on Special Request.
- ⁷/₁₆"-20 SAE Thread Available on Popular Ranges of SPG-063 Series







Protective Gauge Cover - SPG63 Series



Dimensions








Pressure Gauges Type SPG, WPG Series


Standard Stock Pressure Ranges

	SP 063 S STE	Series	063	PG Series NEL	SPG 100 Series STEM	SPG 100 Series PANEL	WPG 063 Series STEM
	NPT	SAE	NPT	SAE			
-30" Hg - 0 PSI	•						
-30" Hg - 30 PSI	•		•				•
0 - 30 PSI	•	•					•
0 - 60 PSI	•		•				•
0 - 100 PSI	•						
0 - 160 PSI	•	•	•				•
0 - 200 PSI	•						
0 - 300 PSI	•		•	•	•	•	•
0 - 500 PSI	•						
0 - 600 PSI	•	•	•		•	•	•
0 - 1000 PSI	•	•	•		•	•	•
0 - 1500 PSI	•	•	•		•	•	•
0 - 2000 PSI	•	•	•		•	•	
0 - 3000 PSI	•	•	•	•	•	•	•
0 - 4000 PSI	•		•				
0 - 5000 PSI	•	•	•	•	•	•	•
0 - 6000 PSI	•		•				•
0 - 7500 PSI							•
0 - 10000 PSI	•	•	•		•	•	

Series	Style	Size		Α	В	С	D	Е	F	G
	STEM MOUNT	2 1/2"	in	2.5	2.1	1.2	0.51	0.26	-	¹/₄ NPT
	OTEM MOOITI	2 1/2	mm	63	53	31	13	6,5	-	⁷ / ₁₆ - 20 UNF
	PANEL MOUNT	2 1/2"	in	2.5	2.8	2.4	1.2	0.26	-	1/4 NPT
	U-BOLT	2 1/2	mm	63	72	62	31	6,5	-	⁷ / ₁₆ - 20 UNF
SPG	PANEL MOUNT	2 1/2"	in	3.3	2.9	2.5	2.44	1.2	0.08	1/4 NPT
	FRONT FLANGE		mm	85	75	63	62	31	2	⁷ / ₁₆ - 20 UNF
	STEM MOUNT	4"	in	4.2	3.4	1.85	0.3	0.64	-	¹/₂ NPT
			mm	107	86	47	7.5	16,3	1	,
	PANEL MOUNT	4"	in	4.2	4.25	3.15	1.85	0.3	-	¹/₂ NPT
	U-BOLT	·	mm	107	108	80	47	7,5	-	,
	PANEL MOUNT	4"	in	5.2	4.7	4.2	3.15	1.85	0.05	¹/₂ NPT
	FRONT FLANGE		mm	132	118	107	80	47	1,25	-
WPG	STEM MOUNT	2 1/2"	in	2.5	2.13	1.5	0.44	0.50	-	¹/₄ NPT
ŭ		_ '/_	mm	63,5	54	38	11	12,2	-	/- 141 1



Adjustable Gauge Fitting EMV



Two-Way Valves - BBVM Series Medium Duty

Specifications

- Block Body, Medium Duty High Pressure Shut-off Valves
- 1/8"-1" Fully Ported-(11/4" & 11/2" with reduced bore)
- NPT SAE O-Ring Connectors
- Delrin +MoS2 Ball Seats
- Buna O-Ring
- Pressure Range: Up to 7250 PSI (500 bar) (depending on material combination and size)
- Standard Carbon Steel Construction

• Standard Temperature Range: -20°F to 212°F (-17°C to 100°C)

- · Zinc Plated Body
- Brass Ball

Options

- · Locking Kits
- · Limit Switch
- Straight Handles



Description

Housing

Brass Ball

Seat
Connector 0-Ring
Connector
Stop Pin
Stem
Thrust Ring

Stem 0-Ring

Cam Plate


Snap Ring

Handle

Stem Screw

Flow Indicator

Technical Information





Siz	ze	Part Number	Maxi Working	Si	ze	Part	Maximum Working Pressure		
		Number	PSI	Bar			Number	PSI	Bar
1/8"	NPT	BBVM20020200K	7250 PSI	500	3/"	NPT	BBVM20120200K	6000 PSI	420
78	SAE	BBVM21020200M	7250 PSI	500	3/4"	SAE	BBVM21120200M	6000 PSI	420
1/4"	NPT	BBVM20040200K	7250 PSI	500	1"	NPT	BBVM20160200K	5000 PSI	345
74	SAE	BBVM21040200M	7250 PSI	500		SAE	BBVM21160200M	5000 PSI	345
3/8"	NPT	BBVM20060200K	7250 PSI	500	1 ¹ / ₄ "	NPT	BBVM20200200K	5000 PSI	345
/8	SAE	BBVM21060200M	7250 PSI	500	1 '/4	SAE	BBVM21200200M	5000 PSI	345
1/2"	NPT	BBVM20080200K	7250 PSI	500	1½"	NPT	BBVM20240200K	3600 PSI	250
/2	SAE	BBVM21080001M	7250 PSI	500	1 /2	SAE	BBVM21240001M	3600 PSI	250




Two-Way Valves - BBVM Series Medium Duty

Dimensional Information





Size	d NPT	d SAE	i NPT	i SAE	L NPT	L SAE	LW NPT	LW SAE	ı	В	н	h	m	v	sw	K 1	K 2	Weight
			in mm	in mm	in mm	in mm	in mm	in mm	in mm	in mm	in mm	in mm	in mm	in mm	in mm	in mm	in mm	lbs kg
1/8"	1/8 –27	0.51 - 12.9	5/	2.72 69.09		0.24 6.10		1.57 39.88	1.02 25.91	1.85 46.99	1.30	0.53	0.43	0.35	5.91 150.11	4.53 115.06	0.50	
1/4"	1/4 –18	,0.67 %6 –20 17.0	0.55 2 13.97	2.72	2.72	0.24 6.10	0.2 5.08	1.57 39.88	1.02 25.91	1.85 46.99	1.30	0.53	0.43	0.35	5.91 150.11	4.53 115.06	0.66	
3/8"	3/8 −18	0.69 %6–18 17.5		3.07 77.98	2.83 71.88	0.39	0.39	1.69	1.26 32.00	2.05 52.07	1.50 38.10	0.69 17.53	0.43	0.35	5.91 150.11	4.53 115.06	1.10	
1/2"	1/2-14	0.98 ¾-16 24.8	0.69 17.53	4.09	3.27 83.06	0.51	0.51	1.89 48.01	1.38 35.05	2.13 54.10	1.57 39.88	0.75 19.05	0.43	0.35	5.91 150.11	4.53 115.06	1.65 0.75	
3/411	3/4-14	0.91 1/16 –12 23.1	0.91	4.02	3.74 95.00	0.79	0.79	2.44 61.98	1.93	2.95 74.93	2.24 56.90	0.96 24.38	0.55	0.55	7.87 199.90	6.30	3.65 1.66	
1"	1-11½	1.09 1‰ –12 27.6	0.91 23.11	4.69 119.13	4.45 113.03	0.98	0.98	2.60	2.28 57.91	3.27 83.06	2.56 65.02	1.16 29.46	0.55	0.55	7.87 199.90	6.30 160.02	5.06	
11/4"	11/4 -111/2	1,10 1% –12 27.9	0.91 4 23.11	5.10 129.54	5.10 129.54	0.98	0.98	2.60	2.28 57.91	3.27 83.06	2.56 65.02	1.16 29.46	0.55	0.55	7.87 199.90	6.30 160.02	5.50 2.50	
11/2"	1½ –11½	1,19 1%-12 30.2	0.91 3 23.11	5.20 132.08	5.20 132.08	0.98	0.98	2.60	2.28 57.91	3.27 83.06	2.56 65.02	1.16 29.46	0.55	0.55	7.87 199.90	6.30	5.75 2.61	





AFU SAFETY SWITCH




Figure 1

WARNING

Make certain power is OFF before starting installation.

MOUNTING BODY

- Fasten AFU body to mounting surface using screws or bolts through mounting holes provided. Each body has three 1" conduit hubs — two for horizontal through-feed and one at bottom. Cast mounting lugs permit attachment to web of standard 3" angle iron.
- 2. Remove access cover and gasket.
- 3. Thread conduit into body and pull wires.

BODY AND SWITCH ASSEMBLY

Strip insulation from ends of individual conductors (3/4" recommended).

- 2. Slip gasket(s) over snap switch(es).
- 3. Using wire nuts connect leads from snap switch(es) to line leads.

AFU switch assemblies are furnished with one or two end units, each unit containing one or two normally closed (N.C.) snap switches having single circuit contacts. Second switch provides auxiliary circuit for audible or visual alarm signal.

Contacts are momentary motor control push buttons, with contact maintained by spring loaded shaft rotation.

- 4. Switches are to be positioned as indicated on drawing. Right switch assembly is marked R1 on indicating arm; left switch assembly is marked L1.
- Replace access cover and gasket, making sure gasket is properly seated.
- Connect pull rope or cable to ring on switch assembly housing.

Depending on size and length of line, supports at properly spaced intervals may be necessary to insure that line or cable weight will not actuate switch. See Table I for pull requirements.

OPERATION

In installation, actuating line or cable is connected from a fixed point to loop on the switch unit. Pulling line moves shaft $1/4^{\prime\prime}$ which opens switch and trips red indicating arm, locking shaft into switch open position. Mechanism is reset by returning indicating arm to its normal position.

Table I

			Snap Sw Heavy Duty 600 V	
Description	Max. Lbs. Wgt. for Line or Cable so Switch is not Actuated	Operating Lbs. Force Required	Catalog #	Catalog #
Single End Left	15	25	AFU0333-10	AFU0333-50
	25	50	AFU0333-20	AFU0333-60
Single End Right	15	25	AFU0333-01	AFU0333-05
	25	50	AFU0333-02	AFU0333-06
Double End	15	25	AFU0333-11	AFU0333-55
	25	50	AFU0333-22	AFU0333-66





With Follower



Without Follower



Table of Contents

	Page
Introduction	
Explanation of Symbols Used	
User's Responsibility	
Environmental Protection	
Service	3
Cafaty Instructions	
Safety Instructions Appropriate Use	1
Misuse	
Exclusion of Liability	
Regulation for Prevention of Accidents	
General Safety Instructions	
Operation, Maintenance and Repair	
Repair	
Disposal	
Operation/Maintenance	
Installation	
Assembly and Maintenance of the Hydraulic Hoses	
rissormsty and maintenance of the Hydraune Floods	
Description of Pump	6
P/N Identification Code	7
PCB Identification Code	
Description of Operation	
Pump Element Operation	
Pump with Internal Pressure Switch	
Pump with Internal and External Pressure Switch	11
Pump with Internal Pressure Transducer	12
Pump with Internal and External Pressure Transducer	12
Venting Cycle/Depressurization	
Filling Reservoir with Grease	
Air Expel Procedure	
Pump with Folllower Plate	
Pump without Follower Plate	
Keypad and Display	
Factory Set Parameters	
Acknowledging a Fault	
Programming the Pump	
Review of Pump Parameters	
Technical Data	
Wiring Connections for DC Pump	
Wiring Connections for AC Pump	
Jumper Setting for PCB	
Centro-Matic System	
List of Lubricants	32
Dimensions	35
Refill and Maintenance	39
Mounting Template	
Troubleshooting Guide	
Parts List	42



Introduction

Explanation of Symbols Used

The following description standards are used in this manual:

Safety Instructions

Structure of safety instructions:

- Pictogram
- Signal words
- Danger text
- Danger notes
- How to avoid danger

The following pictograms are used in this manual and are combined with corresponding signal words:



- ATTENTION
- CAUTION
- WARNING



- ATTENTION
- CAUTION
- WARNING



- NOTE - IMPORTANT

The signal words give the seriousness of danger if the following text is not observed:

ATTENTION refers to faults or damages on machines. CAUTION refers to bad damages and possible injuries. WARNING refers to possible dangerous injuries. NOTE indicates improved operation of the device. IMPORTANT indicates special operating features of the device.

Example:



ATTENTION!

When making use of other than the tested spare parts, serious damage may affect your device.

Therefore, for the operation of your device always use original parts made by Lincoln Industrial.

Furthermore, you will find the following text symbols in this manual:

- Listing of applicable statements
 - Sub point of applicable statements
- 1. Determination of the number or sequence of contents
 - → Procedural instruction

User's Responsibility

To ensure the safe operation of the unit, the user is responsible for the following:

- The pump/system shall be operated only for the intended use (see next chapter "Safety Instructions") and its design shall neither be modified nor transformed.
- The pump/system shall be operated only if it is in a proper functioning condition and if it is operated in accordance with the maintenance requirements.
- The operating personnel must be familiar with this Owner Manual and the safety instructions mentioned within, and observe these carefully.

The correct installation and connection of tubes and hoses, if not specified by Lincoln Industrial, is the user's responsibility. Lincoln Industrial Technical Services will gladly assist you with any questions pertaining to the installation.

Environmental Protection

Waste (e.g. used oil, detergents, lubricants) must be disposed of in accordance with relevant environmental regulations.

Service

The personnel responsible for the handling of the pump/system must be suitably qualified. If required, Lincoln Industrial offers you full service in the form of advice, on-site installation assistance, training, etc. Please contact the Technical Service department for assistance.

In the event of inquiries pertaining to maintenance, repairs and spare parts, we require model specific data to enable Technical Services to clearly identify the components of your pump/system.

Therefore, always indicate the part, model and series number.

Form 404034 Page Number - 3



Safety Instructions

Appropriate Use

The electric Centro-Matic pump P653S has been designed for the automatic lubrication of commercial vehicles, industrial, construction and agricultural machines and wind power plants. The P653S pump has been designed for intermittent operation and is not suitable for continuous operation. The pump is capable of supplying lubricants up to NLGI # 2 grades. (see page 28 for list of recommended greases).

Misuse

Any use of the P653S pump that is not expressly mentioned in this User Manual will be regarded as misuse. If the P653S pump is used or operated in a manner other than specified, any claim for warranty or liability will be null and void.



CAUTION!

If personal injury or material damage occurs as a result of inappropriate operation, (e.g. if the safety instructions are ignored or resulting from an incorrect installation of the P653S pump), no claims or legal actions may be taken against Lincoln Industrial

Exclusion of Liability

The manufacturer of the P653S pump will not accept any liability for damages caused by:

- a lack of lubricant due to an irregular refilling of the pump
- the use of contaminated lubricants
- the use of greases which are not or only conditionally pumpable by P653S pump
- inadequate disposal of used or contaminated lubricants as well as of components that have been in touch with lubricant
- unauthorized modification of the system components
- · the use of unapproved parts
- operation without adhering to the minimum pause time and respectively the maximum lubrication time (see chapter "Technical Data")

Regulations for Prevention of Accidents

To prevent accidents, observe all city, state and federal safety regulation of the country in which the product will be used.

General Safety Instructions

- Pump P653S is designed for safe operation.
- Incorrect use may result in bearing damage caused by poor or excessive lubrication.
- P653S pump with follower can be mounted vertically, horizontally or upside down.
- Pump without the follower should be mounted vertically upright only.
- Unauthorized modifications or changes to an installed system are not admissible. Any modification of the pump must be subject to prior authorization by manufacturer.
- Install the components of the P653S pump in such way that operator can always see the low-level position of the pump reservoir.
- Each time the reservoir has been refilled, make sure that no air has been trapped under the follower and pump is pumping lubricant.

Operation, Maintenance and Repair



WARNING!

Before carrying out any maintenance or repair on the P653S pump, make sure that all lubrication lines of the carrier unit are depressurized.

Repair

Repair should only be performed by authorized and instructed personnel who are familiar with the instructions.

Operation/Maintenance

Pumps P653S:

- must be refilled at regular intervals with clean lubricant recommended by the manufacturer without air entrapments under follower plate.
- operate automatically. However, a regular check (approx. every 2 days) should be made to ensure that lubricant is pumped to all lubrication points.

Disposal

Dispose of used or contaminated lubricants as well as of parts that were in touch with lubricant according to the legal regulations pertaining to environmental protection. Make sure to observe the safety data sheets of the lubricants used.

Page Number - 4 Form 404034



Operation, Maintenance, and Repair (continued)



WARNING!

Pump P653S must be installed by qualified personnel. The connection of the 120 VAC must be done according to the National Electrical code. **Before installing or working on the pump, disconnect and lock out the incoming power.**



WARNING!

Failure to observe the safety instructions, (e. g. touching electrically charged parts when the pump is opened, or improper handling of the pump P653S) may cause serious injury or death. If the values specified in the Technical Data are exceeded, the device may overheat. It may damage the pump P653S and thus impair the electric safety.

- Repairs should only be performed by authorized personnel who are familiar with the instructions.
- Defective printed circuit boards should be appropriately packed and returned to the factory.



CAUTION!

Electric Voltage!

In the case of pumps where grease is filled from top, the power supply must be switched off before the lubricant is filled in



CAUTION!

Danger of injury in case of pumps being filled from the reservoir top: Never put your hand into the open reservoir while pump is running!



ATTENTION!

Risk of bursting if the reservoir is over-filled! When filling the reservoir by means of pumps with a large delivery volume do not exceed the max. filling mark.



CAUTION!

Do not use the pump in potentially explosive applications.

Installation

- Any safety equipment already installed on the vehicle:
 - should not be modified or made ineffective;
 - should only be removed for the purpose of installing the system and must be replaced afterwards.
- Use only original Lincoln spare parts or parts approved by Lincoln.



IMPORTANT

Adhere to:

- the installation instructions of the vehicle manufacturer with regard to all drilling and welding procedures.
- the specified minimum distances between the holes and the upper/lower rim of the frame or between two holes.



IMPORTANT

Route supply lines professionally. Firmly bolt together any components that are subject to pressure.

Installation and Maintenance of Hydraulic Hoses



ATTENTION!

Operational safety of the P653S pump can only be ensured in the case of a professional installation and maintenance of the hose lines. Make sure to observe the following recommendations!

Lubrication hose lines

- must never be subjected to torsion
- · must be installed twist-free
- must not rub against metal components or edges
- are to undergo regular visual checks and must be exchanged in the case of wear (at the latest 2 years after installation)

Pay attention to non-linear installations to allow for a larger bending radius as possible. Avoid kinks. In constricted installation conditions use pipe elbow unions to avoid the danger of kinking behind the hose socket. Use high pressure hydraulic hose for lubrication lines.

Form 404034 Page Number - 5



Pump with Follower Plate



Components of the P653S pump with follower Fig. 1

- 1 Reservoir
- 3 Pump elements
- 5 Pump outlet
- 7 Keypad
- 9 Refill Grease Fitting
- 10 Top Lid

- 4 Pump housing
- connection

Pump without Follower Plate



- 1 Reservoir
- 3 Pump elements 5 - Pump outlet
- 7 Keypad
- 9 Refill Grease Fitting
- 11 Top Lid

- 2 Mounting plate
- 6 Relief valve
- 8 Low-level control
- 11- Vent Hole

Fig. 2 Single-line pump P653S, No follower (Note: Low-level control see Fig. 15 & 16)

- 2 Mounting plate
- 4 Pump housing
- 6 Relief valve
- 8 Stirring paddle
- 10 Stationary paddle

Description

P653S pump is designed for single line (S) parallel Centro-Matic type lubrication systems. The pumps integrated design includes all necessary components to support Centro-Matic lubrication systems:

- controller to program and monitor lubrication cycle
- choice of internal pressure switch or internal pressure transducer
- internal vent valve
- three pumping elements connected together
- external pressure relief valve
- reservoir low-level control
- end of lubrication line pressure switch or pressure transducer choice
- contacts for remote monitoring
- 24 VDC or 120/230 VAC power supply option, etc.

Pump for 24 VDC power supply is ready for installation on medium and small mobile construction equipment. Pump can supply adequate lubrication for up to 35 bearings using SL-V, SL-V XL, SL-1, SL-33 or SL-32* Lincoln injectors. Can support up to 9 SL-V XL injectors.

Pump for 120/230 VAC power supply can be installed in any stationary industrial type of applications requiring lubrication for the same number of medium size bearings.

Pump basic model can be supplied with follower plate or without follower plate. Follower plate is recommended in stationary industrial type applications with heavy consistency greases (NLGI #1 and #2) and for pumps used at low temperatures applications in all installations.

*Note: Installations using SL-32 aand SL-33 Lincoln injectors can lubricate more than 35 bearings.

Typical Centro-Matic system schematic is shown on page 31.



CAUTION! Use only supply line hose and fittings that are appropriate for the programmed/set system pressure.

Pump P653S

- pumps greases up to NLGI 2 (per approved list) at temperatures from -40° F to 158°F (-40°C to 70°C)
- develop maximum pressure up to 3,500 psig (240 bar) with pressure switch and up 4,600 psig (317 bar) with pressure transducer.

Reservoir sizes

- 4-I transparent plastic reservoir
- 8-I transparent plastic reservoir
- 15-I transparent plastic reservoir
- 20-I transparent plastic reservoir

Electrical connection

- For industrial 120/230 VAC applications P653S pumps are provided with 4-pole square type connector. Electric cable is provided by installer.
- For mobile applications P653S pumps are equipped with an electric cable 32 ft. (10.0 m) and 7-pole bayonet type connector.

Page Number - 6 Form 404034



Code example

Pump model, basic

Reservoir size and configuration

4 = 4L, transparent plastic

8 = 8L, transparent plastic

15 = 15L, transparent plastic

20 = 20L, transparent plastic

X = Grease pump

L = Low-level control

BO = Without follower

F = With follower

Power supply

24 = 24 VDC

AC = 110 - 240 V; 50 - 60 Hz

Electrical cord and connections

1A DC;

- 33 ft. (10 m) cord, 7 conductors

2A DC;

- 33 ft. (10 m) cord, 7 conductors
- 33 ft. (10 m) cord, 4 conductors with bayonet plugs for external pressure switch or transducer

2A = AC;

- 33 ft. (10 m) cord, 7 conductors
- 4-pole square plug

2A1 = AC;

- 7 poles bayonet plug
- 4-pole square plug

3A = AC;

- 33 ft. (10 m) cord, 7 conductors
- 4-pole square plug,
- 33 ft. (10 m) cord, 4 conductors with bayonet plugs for external pressure switch or transducer

Pressure control, PCB setting

AS01 - AS08 = Pressure switch (see jumper setting table)

AS09 - AS16 = Pressure transducer (see jumper setting table)

Example: P653S-4XLF-24-2A-AS06: Pump consists of the following:

- 24 VDC grease pump with follower
- Four liter reservoir
- Low-level control
- Internal pressure switch
- 33 ft (10 m) power cord
- External pressure switch with 33 ft (10m) cord

Identification code P653S pump

Page Number - 7

Form 404034



Jumper setting combinations - Centro-Matic pumps

Pump combinations		Application: Industrial (S) -o; Mobil (M) - x	Time (TC) or count control (CC); TC -o; CC - x	Number of pressure switches or transducers. o - one; x - two	Low-level control; NO- o; NC - x	(31) switch to	F2 fault relay; (31) switch to ground - x	
			Jumper setting (plugged - x; unplugged - o)					
Pressure switch	AS01	Industrial (AC) (S)	0	0	o	x	x	х
	AS02		0	o	x	х	х	х
	AS03		o	0	О	О	x	х
	AS04		0	0	x	О	x	х
	AS05	Mobile (DC) (M)	x	0	o	x	x	x
	AS06		Х	0	x	x	x	х
	AS07		x	0	o	o	x	X
	AS08		X	o	x	0	х	х
Pressure transducer	AS09	Industrial (AC) (S)	o	0	О	x	x	х
	AS10		0	0	x	x	x	х
	AS11		0	0	o	О	x	X
	AS12		0	0	x	o	х	х
	AS13	Mobile (DC) (M)	х	0	o	х	х	х
	AS14		х	0	x	x	x	х
	AS15		х	0	o	o	х	х
	AS16	2	x	0	x	o	x	x

An external pressure switch or external pressure transducer is included with the pumps that have the feature of external pressure monitoring. Also included is a 33 ft (10m) cord to connect the external monitoring device to the pump.

Page Number - 8 Form 404034



Description of Operation Pump Operation

Drive

- The pump housing consists of the following components: gear motor, final gear drive, three pumping elements connected together by internal passages and vent valve.
 Pump can be configured with internal pressure switch or transducer.
- The gear motor shaft is connected to the final stage gear drive. The final gear has incorporated eccentric and cam to drive the pumping elements and to control the internal vent valve (Fig. 4).
- Vent valve is a two way normally closed spring biased valve.
- Pressure switch is not adjustable and preset to 3,500 psig (240 bar).
- Pressure transducer is adjustable. Factory setting is 3,500 psig (240 bar). Pressure setting of the pressure transducer can be adjusted from 1,400 to 4,600 psig (96 to 317 bar) in 100 psig (6.9 bar) increments.

2

Fig. 3 Disassembled pump housing - view from the bottom

- 1 Venting element
- 3 Motor
- 2 Integrated pressure switch
- 4 Pump elements with intergrated lubrication lines

Lube Cycle/Pressurization

- The motor turns the cam (7) clockwise to start lubrication cycle. As soon as pump starts to operate, the display rotating segment is turning clockwise also (Fig. 20).
 Maximum time to build the preset pressure is 12 minutes. If pump does not build preset pressure, fault signal E1 or E2 will appear on the display.
- Vent valve (1) is normally closed and stays closed during lubrication cycle, preventing lubricant flow back to the reservoir (see Fig. 4).
- The output of three pump elements (4) (Fig. 3) is combined by internal passages.
- The eccentric drives the pump elements to pump the lubricant from the reservoir and build the line pressure.
- The cam (7) will keep the vent valve (1) closed.
- Supply line can be connected to any one of the pump element outlets. The remaining two pump elements outlets should be plugged.




Fig. 4 Idle run of the switch joint on the venting element

- 1 Inactive venting element
- 6 Switch joint
- 7 Cam (driven clockwise by the motor)

Form 404034 Page Number - 9






Fig. 6 Activated vent cycle diagram

- 1 activated venting element
- 6 activated vent lever
- 7 cam (driven by the motor counterclockwise)



Fig. 7 Display during braking application of pump motor.



Fig. 8 Display during change of moving direction of pump motor.



Fig. 9 Rotating segmented display during venting (counterclockwise)




Fig. 10 Venting in the vent valve1 - Venting element

- 1.1 inlet hole
- 1.2 -outlet hole
- 8 plunger, venting

Pump Element operation

The pump element (Fig. 13 and 14) is a single stroke spring biased pump. Motor drives the eccentric (1). Eccentric is in constant contact with the plunger (2).

Compression spring (3) is pushing plunger (2) to open lubricant passage to create vacuum to prime the pump with lubricant from the reservoir. Check valve (4) is closed to isolate the supply lines of the system.

Eccentric (1) is pushing the plunger (2) in opposite direction to pump lubricant, developing the operating pressure. Check valve (4) is open to pass the lubricant to supply lines.

The body of the pump element has a lateral outlet (5) (Fig. 12) for lubricant crossporting to the internal material passages to combine the outlet of all three pump elements.

Any one of the three elements can be used as a pump outlet. The remaining two elements should be closed with plug (A) (Fig. 12).



Fig. 12 Pump element Z7 for internal lubricant crossporting

- A Closure plug (connection G 1/4" for main line)
- 2 Piston
- 3 Spring
- 5 Lateral outlet for lubricant crossporting




Fig. 13




Fig. 14

NOTE: Use only pump elements designed for operation in the P653S and P603S pumps. No other pump elements should be used. See the parts listing for the correct pump element part number.

Page Number - 10 Form 404034

LINCOLN

Electric Operated Centro-Matic Pump P653S

Pressure Control/Hold Time/Vent Cycle

Pump with internal pressure switch only:

Internal pressure switch will close at 3500 psig and open at 2600 psig.

After pump starts a lubrication cycle, motor stops when pressure at pump reaches preset pressure of 3,500 psig (240 bar). Pump will go through two holding periods, H1 and H2.

Holding Time (H1)

Internal pressure switch must stay closed for 15 consecutive seconds before going to H2. If internal pressure switch opens during the 15 seconds, pump will restart and run until internal pressure switch closes.

Holding Time (H2) - Will last for 30 seconds

- At the end of 30 seconds, if the internal pressure switch is closed, the pump will begin a vent cycle.
- If at the end of the 30 seconds the internal pressure switch is open, the pump will restart and run until the internal pressure switch closes. When it closes a vent cycle will take place.
- If at the end of 30 seconds the internal pressure switch is closed, but during the H1 hold time the internal pressure switch did open, the pump will restart and pump for 2 seconds before a vent cycle begins.

Possible Faults

- E1 Fault A failure to build pressure at the pump within the allotted 12 minutes of pumping time.
- E3 Fault A failure to vent at the pump. The internal pressure switch has 10 seconds to open when the motor reverses to locate the vent position

Pump with internal and external pressure switch:

Internal pressure switch will close at 3500 psig and open at 2600 psig. The external pressure switch will close at 2500 psig and open at 1900 psig

After pump starts a lubrication cycle, motor stops when pressure at pump reaches preset pressure of 3,500 psig (240 bar). Pump can go through three holding periods, H1, H2 and H3.

Holding Time (H1)

Internal pressure switch must stay closed for 15 consecutive seconds before going to H2. If the internal pressure switch opens during the 15 seconds, the pump will restart and run until the internal pressure switch closes.

Holding Time (H2) - Will last for 30 seconds

- At the end of H2, if the internal pressure switch is closed and the external pressure switch is closed, pump will begin a vent cycle.
- At the end of H2, if the internal pressure switch is open or both the internal and external pressure switches are open an H3 will appear on the display. Pump will turn on again and pump until the internal pressure switch is closed.
 When both the internal and external pressure switches are closed a vent cycle will take place.
- If at the end of H2 the internal pressure switch is closed but the external pressure switch is open, the pump will turn on for 2 seconds and then stop and wait until the external pressure switch closes. An H3 will appear on the display. When both the internal and external pressure switches are closed a vent cycle will take place.

Holding Time (H3)

Holding time H3 will remain until both the internal and external pressure switches are closed and then a vent cycle will take place. If both pressure switches do not close within the allotted pumping time of 12 minutes, an alarm will occur. If the internal pressure switch opens during H3, it will repump until the internal pressure switch closes.

Possible Faults

- E1 Fault A failure to build pressure at the pump within the allotted 12 minutes of pumping time.
- E2 Fault A failure to build pressure at the end of the supply line.
- E3 Fault A failure to vent at the pump. The internal pressure switch has 10 seconds to open when the motor reverses to locate the vent position.
- E4 Fault A failure to vent at the end of the supply line.
 The external pressure switch must be open before the next lube cycle takes place.

Form 404034 Page Number - 11



Pump with internal pressure transducer only:

The internal pressure transducer is factory set to close at 3500 psig (241 bar). The internal transducer can be adjusted from 1,400 psig to 4,600 psig (96 to 317 bar) using the key pad on the pump. The adjustment is in 100 psig (6.9 bar) increments. The internal pressure transducer is set to open at 900 psig (62 bar) below the point where it closed at.

After the pump starts a lubrication cycle, the motor stops when pressure at pump reaches the preset pressure. The pump will go through two holding periods, H1 and H2. The following will use the factory setting of 3500 psig (241 bar) and the opening pressure of 2600 psig (179 bar).

Holding Time (H1)

 Internal pressure transducer must reach 3500 psig and stay above 2600 psig (179 bar) for 15 consecutive seconds before going to H2. If the internal pressure transducer drops below 2600 psig during the 15 seconds, the pump will restart and run until internal pressure transducer reaches 3500 psig (241 bar).

Holding Time (H2) - Will last for 30 seconds

- At the end of 30 seconds, if the internal pressure transducer is above 2600 psig. (179 bar) the pump will begin a vent cycle.
- If at the end of the 30 seconds the internal pressure transducer is below 2600 psig (179 bar), the pump will restart and run until the internal pressure transducer reaches 3500 psig (241 bar). When this happens a vent cycle will take place.
- If at the end of 30 seconds the internal pressure transducer is above 2600 psig (179 bar), but during the H1 hold time the internal pressure transducer dropped below 2600 psi (179 bar), the pump will restart and pump for 2 seconds before a vent cycle begins.

Possible Faults

- E1 Fault A failure to build pressure at the pump within the allotted 12 minutes of pumping time.
- E3 Fault A failure to vent at the pump. The internal pressure switch has 10 seconds to open when the motor reverses to locate the vent position.
- E3 Fault A failure to vent at the pump. If at the end of the pause time the pressure of the internal pressure transducer has not dropped below 900 psig (62 bar) an E3 fault will occur.

Pump with internal and external pressure transducer:

The internal pressure transducer is factory set to close at 3500 psig (240 bar). The internal transducer can be adjusted from 1,400 psig to 4,600 psig (96 to 317 bar) using the key pad on the controller. The adjustment is in 100 psig (6.9 bar) increments. The internal pressure transducer is set to open at 900 psig (62 bar) below the point where it closed at.

The external pressure transducer is set to close at 2500 psig (172 bar). The opening point of the external pressure transducer is adjustable from 200 psig to 1000 psig (14 to 69 bar). It is factory set to open at 900 psig.

After the pump starts a lubrication cycle, the motor stops when pressure at the pump reaches preset pressure of 3,500 psig (240 bar). The pump can go through three holding periods, H1, H2 and H3.

The following will use the factory settings for P7 and P8.

Holding Time (H1)

 Internal pressure transducer must reach 3500 psig and stay above 2600 psig for 15 consecutive seconds before going to H2. If the internal pressure transducer drops below 2600 psig during the 15 seconds, the pump will restart and run until the internal pressure transducer reaches 3500 psig.

Holding Time (H2) - Will last for 30 seconds

- At the end of H2, if the internal pressure transducer is above 2600 psig and the external pressure transducer has reached 2500 psig, the pump will begin a vent cycle.
- At the end of H2, if the internal pressure transducer is below 2600 psig, or both the internal pressure transducer is below 2600 psig and the external pressure transducer has not reached 2500 psig, an H3 will appear on the display. The pump will turn on again and pump until the internal pressure transducer has reached 3500 psig. When the internal pressure transducer is above 2600 psig and external pressure transducer has reached 2500 psig, a vent cycle will take place.
- If at the end of H2 the internal pressure transducer is above 2600 psi but the external pressure transducer has not reached 2500 psig, the pump will turn on for 2 seconds and then stop and wait until the external pressure transducer reaches 2500 psig. An H3 will appear on the display. When the internal pressure transducer is above 2600 psig and external pressure transducer has reached 2500 psig a vent cycle will take place.

Holding Time (H3)

 Holding time H3 will remain until the internal pressure transducer is above 2600 psig and the external pressure transducer has reached 2500 psig, and then a vent cycle will take place. If both pressure transducers do not reach their preset settings within the allotted pumping time of 12 minutes an alarm will occur. If the internal pressure transducer drops below 2600 psig during H3 it will repump until the internal pressure transducer reaches 3500 psig.

Page Number - 12 Form 404034



Possible Faults

- E1 Fault A failure to build pressure at the pump within the allotted 12 minutes of pumping time.
- E2 Fault A failure to build pressure at the end of the supply line.
- E3 Fault A failure to vent at the pump. The internal pressure transducer has 10 seconds to drop below 2600 psig when the motor reverses to locate the vent position.
- E4 Fault A failure to vent at the end of the supply line.
 The external pressure transducer has to drop below 900 psig before the next lube cycle takes place.

Venting Cycle/Depressurization

- After pump completes preset pressure hold time and pump maintains specified pressure, controller will initiate vent cycle. "Hr" will be displayed momentarily.
- The motor will turn counterclockwise to engage and open the vent valve. Motor will stop in a position to hold vent valve open.
- The display rotating segment is turning counter clockwise as well.
- The cam (7) (Fig. 6) engages the vent lever (6) depressing the vent valve plunger (8) (Fig 10). This opens the valve passage of the supply line to the reservoir.
- Lubricant is flowing back to the reservoir venting pressure from the system. The valve stays open during pause time.

Filling reservoir with grease

Use grease fitting (9) (Fig 1) to fill the reservoir. Filling reservoir for the first time is critical to the proper pump operation. Make sure no air is trapped under the follower plate. Grease should be in full contact with the surface of the follower. It's recommended to run the motor by initiating the lubrication cycle during the first reservoir fill. The stirring paddle of the running motor will help to evenly spread the grease under follower minimizing air pockets.

Air Expelling Procedures for Pumps with Follower

Disconnect the low-level square type bayonet plug 8 (Fig. 1) and unscrew the top lid (1)0 (Fig. 1) of the reservoir. Remove lid and spring from the pump. Start filling the pump. As soon as the grease level starts lifting the follower, stop filling and check for air trapped under the follower. Use a plastic wire tie to expel the air: push plastic tie between the follower seal and wall of the reservoir and push the follower with hand until it completely contacts the grease. Replace the lid and connect the low-level electric plug. Finish the filling of the reservoir.

WARNING

The follower spring is completely compressed if reservoir is full of grease. Exercise extreme caution removing the top of the pump.

Stirring paddle

The stirring paddle (3) (Fig. 2) is attached to the motor and rotates during the lubrication cycle. The paddle is working grease in the reservoir to make it more pumpable and at the same time pushing the grease down into the housing and pumping elements to prevent cavitation.

Low-level control

The pump model P653S is equipped with a low-level grease control as a standard feature.

Pump with Follower Plate

Low-level control electromagnetic reed switch is located in the central rod of the reservoir. The switch is sealed and does not have any contact with grease.

The follower plate bushing has a magnet. As soon as the follower reaches the preset position at the bottom of the reservoir, a magnetic field will close the switch to indicate the low-level of the grease. The control panel display "LL" will be on. The pump can be operational for some time since there is a small amount of grease left under follower in the reservoir and pump housing. The pump should be refilled as soon as possible. Always refill the pump to the maximum of the reservoir capacity. The "LL" display should be "off" as soon as pump is refilled.



Caution!

Make sure there is no air trapped under follower plate. Grease should be in full contact with surface of the follower. Use "Air Expelling Procedures" if necessary.

Form 404034 Page Number - 13



Pump Without Follower Plate




Figure 15 Switching parts of the low-level control for grease (when reservoir is filled).

- 1. Pivot bracket with round magnet
- 3. Control Cam
- A. Inner orbit of the round magnet
- B. Position of the pivot bracket (LL not activated)




Figure 16 Switching parts of the low-level control for grease (when the reservoir is empty).

- 1. Pivot Bracket with round magnet.
- 2. Low-level Switch
- 3. Control Cam
- C. Outer orbit of the round magnet
- D. Position of the Pivot bracket (LL activated)

Grease Reservoir Full of Grease - Fig. 15

- The stirring paddle rotates clockwise during the lubrication cycle.
- The pivot bracket of the stirring paddle (B) (Fig. 15) is completely submerged into grease and grease resistance to paddle rotation guides the bracket with round magnet 1 inward to orbit (A).
- Control Cam (3) (Fig. 15) guides the pivot bracket with magnet and outwards, in the direction of the reservoir wall. Since reservoir is full, grease resistance guides pivot bracket inward to orbit (A) as soon as bracket passes the cam (3).
- Magnet and low-level switch (2) (fig. 16) are not aligned and switch can not be activated.

NOTE: The above mentioned switching parts (1 to 3) (Fig. 15 & 16) must not be used with fluid grease or oil. In this case, use a float magnetic switch.

Grease Reservoir Empty - Fig. 16

- Control cam (3) guides the pivot bracket with magnet (1) outward. Since there is no grease resistance, the bracket with magnet (1) will stay outward in the Orbit C.
- Magnet (1) will align with Low-level Switch and activate LL indicator on a pump display.

Page Number - 14 Form 404034



Keypad and Display

Membrane Key Pad





Fig. 17 P653S membrane key pad

- 1 Display
- 2 Key for acknowledgment of fault indications and changing programming screens.
- 3 Key for triggering an additional lubrication cycle and for changing programming values.

Test Display of the Membrane Key Pad








Fig. 18 Green segment right, power supply "on", iginition switch open ("off").



Fig. 19 Green segment left & right are "On"/ Ignition switch closed ("on").

 A test display is made when voltage is applied: all segments and decimal points are illuminated for 2 seconds.



NOTE

If *EP* is displayed after the display test, this indicates that the button or the keypad is defective.

When power is applied to the pump the display will indicate if a pressure switch or pressure transducer is connected to the pump. The example indicates an internal pressure switch.

There are four possibilities:

- S- Internal pressure switch
- T- Internal pressure transducer
- TT Internal and external pressure transducer (must be connected)
- SS Internal and external pressure switch (must be connected)

Operating mode

- As soon as voltage is applied (On), the lower right-hand segment in the display window flashes (Fig. 18). If there is only one segment at the bottom this indicates that the ignition switch is open.
- When switching on the ignition switch, the left-hand segment in the display window lights up (Fig. 19).
- During the lubricating time of the pump, a circulating illuminated segment appears in the display window of the membrane key pad (Fig. 20).
- If the power supply is interrupted during the pause time, the pause time continues at the point of interruption after switching power on again.
- If the power supply is interrupted during the lubricating time the operating time will start at the beginning after switching power on again.

Form 404034 Page Number - 15



Keypad and Display



Fig. 20 Green circulating illuminated segment, lubricating time, pump is running.



Fig. 21 Display of a low-level indication





Fig. 22 Display of Holding Time



Low-level control

In the event of a low-level signal the display will flash LL.



IMPORTANT

If a low-level signal occurs during the lubricating time, the current operating cycle will still be completed. However the pump does not switch on automatically any more. It can only be switched on again by a manual lube cycle. Furthermore, it is not possible to change to the programming mode while there is a lowlevel signal.

Display is indicating holding times when pump reaches preset pressure.

Malfunctions

If there is no feedback from the pressure switch or pressure transducer within 12 minutes of pumping time, the pump switches off immediately. One of the fault signals E1 to E4 (Error, Fig. 23 to 26) will be shown flashing in the display of the membrane key pad.



IMPORTANT

If a malfunction is present, E1, E2, E3 or E4 will be flashing. The pump does not switch on automatically any longer. It can only be triggered via an additional lubrication cycle. Furthermore, a change to the programming mode is not possible while in alarm.



Fig. 23 Display of the malfunction E1, failure to build pressure at the pump.

E1 fault is a failure to build pressure at the pump.

If either the pressure switch or pressure transducer fails to actuate within 12 minutes of pumping this fault will occur.

Page Number - 16 Form 404034



Keypad and Display



Fig. 24 Display of the malfunction E2, failure to build pressure at the end of the line.

E2 fault is a failure to build pressure at the end of the supply line. You must use an external pressure switch or pressure transducer to detect this.

 If either the external pressure switch or pressure transducer fails to reach 2500 psi within 12 minutes of pumping this fault will occur.



Fig. 25 Display of the malfunction E3, failure to vent at the pump.




Fig. 26 Display of the malfunction E4, failure to vent at the end of the line.




Fig. 27 Operator key to trigger an additional lubrication cycle



Fig. 28 Operator key to acknowledge a fault.

E3 fault is a failure to vent at the pump.

- Failure of the internal pressure switch to open during the 10 seconds that the pump motor reverses to locate the vent position.
- Failure of the internal pressure transducer to drop 900 psi below the P7 parameter (P7 minus 900 psi) during the 10 seconds that the pump motor reverses to locate the vent position.
- If at the end of the pause time the internal pressure transducer has not dropped below 900 psi an E3 fault will occur.

E4 fault is a failure to vent at the end of the supply line. You must use an external pressure switch or pressure transducer to detect this.

- If at the end of the pause time the external pressure switch has not opened an E4 fault will occur.
- If at the end of the pause time the external pressure transducer has not dropped below the P8 parameter an E4 fault will occur.

To trigger an additional lubrication cycle via the pushbutton, press the button for 2 seconds.



NOTE

Existing fault signals (Fig. 21 to 26) must be acknowledged before triggering an additional lubrication cycle.

To trigger additional lubrication cycles externally

- Press the pushbutton to trigger additional lubrication cycles externally. Press the pushbutton for 2 seconds.
 - Mobile pump w/ignition switch open.....up to two times
 - Industrial pump w/machine switch open...unlimited




Factory Settings For Parameters

Programming steps	Factory Setting	Description
min h	01	Pause time 0 to 59 hours
	00	Pause time 0 to 59 minutes
	NO	Output of both fault relays no (normally open) nc (normally closed)
_ on min h	o2	Two options for signaling a fault o1 (Option 1) F1 relay contact a) Low-level fault will cause F1 contact to repeatedly open and close. b) Pressure fault will cause F1 contact to close and stay closed. F2 relay contact A low-level fault or a pressure fault will cause the F2 contact to close and stay closed. o2 (Option 2) F1 fault relay's contact will close on a low-level fault F2 fault relay's contact will close on a pressure fault Both of these contacts can be used for remote signaling.
	SP	Option to have the pump start with a pause time or a lube cycle. SP – Pump starts with a pause time SO – Pump starts with a lube cycle
min h 35		The P7 programming step will only appear if you have a pump that uses an internal pressure transducer. (Reading x 100) 35 x 100 = 3500 psi. 3500 psi is the maximum pressure that the pump will build. Adjustable from 1400 psi to 4600 psi in 100 psi increments.
	09	The P8 programming step will only appear if you have a pump that uses an external pressure transducer. (Reading x 100) 09 x 100 = 900 psi. 900 psi is where the external pressure transducer will open (VENT) adjustable from 200 psi to 1000 psi in 100 psi increments.

Page Number - 18 Form 404034



Acknowledging a Fault




To acknowledge a malfunction:


- The flashing display changes into continuous light by pressing the button (acknowledging). By acknowledging the fault signal, the flashing E1, E2, E3, E4 or LL changes into permanent light.
- Messages which have been acknowledged but have not yet been remedied will flash again after the pump is switched off and on again.
- After fault has been acknowledged no more lube cycles will take place until a successful manual lube cycle has taken place.



Programming the Pump

Programming Mode: Pump with Pressure Switch








IMPORTANT! Pump Power must be on to start programming.

Step 1

Display



Setting of Pause Time P1 (hours) and P2 (minutes). To access the programming mode, press both buttons at the

same time > 4 seconds, so that "P1" appears in the display.

Programming options: P1

P2 Min. pause time

Max. pause time

Pause time: 0 - 59 hours 0 - 59 minutes

4 minutes 59 hours 59 minutes

Step 2



h

min



When releasing the two buttons, the currently set value appears.

Example: factory-set value: 1 hour "Hour" is indicated by a dot on the right-hand side.






Press button.

Settings are made in one direction:	. 0, 1, 2, 3,59 hours
Button pressed once	increase by 1 hour
Button pressed continuously	quick sequence
Example:	12 hours

Step 3





P2: Setting minutes

Press button, so that "P2" appears in the display.

When releasing the button, the currently set value appears (here the factory-set value: 0 minutes).

"Minute" is indicated by a dot on the left-hand side.





Press button.

Settings are made in one direction:	0, 1, 2, 3, 4, 5, 59 min
Button pressed once	increase by 1 minute
Button pressed continuously	quick sequence
Example:	30 minutes



IMPORTANT


If "Hours" are set to "00", the display will show minimum pause time of 4 minutes.

Page Number - 20 Form 404034



Programming Mode, continued

Step 4



P4: Programming of the output signal for both alarm relays. The default setting on the printed circuit board for the alarm contacts is switching to battery minus.

Press button so that "P4" appears in the display.

When releasing the button, the currently set value appears in the display (here the factory-set value NO, normally open contact). On a fault condition the alarm contact will close.

Press button.


The external fault contact is modified by programming it as NC normally closed contact. On a fault condition the alarm contact will open.

Step 5









Factory Setting





P5: Two options for signaling a fault condition with alarm relays F1 and F2.

Press button so that "P5" appears in the display.

- o1 (Option 1) P4 is set to the default of Normally Open.
- F1 relay contact
- a) A low-level fault will cause the F1 contact to repeatedly open and close.
- b) A pressure fault will cause the F1 contact to close and stay closed.
- F2 relay contact
- A low-level fault or a pressure fault will cause the F2 contact to close and stay closed.
- o2 (Option 2) P4 is set to the default of Normally Open.
- F1 fault relay's contact will close on a low-level fault and stay closed.
- F2 fault relay's contact will close on a pressure fault and stay closed.
- Both of these contacts can be used for remote signaling.

Press pushbutton to change to Option 1.



Programming Mode, continued

Step 6

P6: Upon applying power to the pump you can program whether it starts with a pause time SP or starts with a lube cycle SO.

Press button, so that "P6" appears in the display. The currently set values appear as to whether the cycle is to start with the pause time or the lubricating time.

The default setting for the pump is set to start with a pause time **SP** (Start Pause time).

Press button.

Each time the pump is switched on, it will start with the lubricating time **SO** (**Start Operation**). After the first lubricating time the preset pause time will be valid.

Step 7









Completing the programming

Press button. "P -" is displayed.



IMPORTANT

Always carry out the programming completely in order to save the new values.

Press this key (additional lubrication) to complete the programming and to save the entered parameters.



NOTE

If the button "additional lubrication" is not pressed within 30 seconds, the changed parameters will not be saved and the previous programming remains valid.

IMPORTANT

After completion of the programming, check the parameter settings in the operating mode once again.


Programming of the pump with pressure switch is complete.

Page Number - 22 Form 404034



Programming Mode: Pump with Pressure Transducer

Complete Steps 1 through 6 of Pump with Pressure switch





IMPORTANT

The P7 programming will only appear if you have a pump that has an internal pressure transducer.

P7: Programs the setting of where the internal pressure transducer will close. This is the maximum pressure that the pump can reach. Factory setting is 3,500 psi.

Press button to change value. Reading x 100 = Transducer setting in psi $35 \times 100 = 3500$ psi.

This setting is adjustable from 1400 psi to 4600 psi in 100 psi increments.















IMPORTANT

The P8 programming parameter will only appear if you have a pump that has an external pressure transducer connected.

P8: Programs the setting of where the external pressure transducer will open. The opening point (vent pressure) is adjustable from 200 psi to 1,000 psi in 100 psi increments. Factory set opening point (vent pressure) is 900 psi. The closing point of the external pressure transducer is fixed in software at 2500 psi.


Press button to change value. Reading x 100 = Transducer setting in psi 9 x 100 = 900 psi.



Programming Mode, continued

Step 9







Completing the programming

Press button. "P -" is displayed.



IMPORTANT

Always carry out the programming completely in order to save the new values.

 Press this key (additional lubrication) to complete the programming and to save the entered parameters.



NOTE

If the button "additional lubrication" is not pressed within 30 seconds, the changed parameters will not be saved and the previous programming remains valid.

IMPORTANT


After completion of the programming, check the parameter settings in the review mode.

Programming of the pump with pressure transducer is complete.

Page Number - 24 Form 404034



Review of the Pump Parameters







Press the button > 2 seconds.




NOTE

The following display sequence is shown **once**. The change of display occurs every two seconds. Example of the pump set to lubricate each 12 hours 30 minutes and remaining pause time (rP) is 5 hours 10 minutes.



Pause Time



after one sec.

12. (hours)



after one sec.

. 30 (minutes)



after one sec.

rP (remaining pause time)



after one sec.

5. (hours)



after one sec.

. 10 (minutes)



Review of the Pump Parameters

Operating Mode					
min h	after one sec.	NO	Both relay contacts are normally open		
	after one sec.	o2	Option 2 - How F1 and F2 will signal a fault.		
	after one sec.	SP	Pump starts with a pause time		
min h	after one sec.	Will only appear if pump has an internal pressure transduct Maximum pressure the pump will build.			
	after one sec.	Indicates that the internal pressure transducer will close at 3500 psi.			
	after one sec.		nly appear if pump has an internal and external pressure lucer. Setting where external transducer will open.		
	after one sec.	Extern	al pressure transducer will open at 900 psi.		
		Indicate	es software version.		
min h		The ne	ext two displays will indicate software version.		
or min h	— On min h	Termina	ation of the Reviewing of Parameters.		

Page Number - 26 Form 404034




Technical Data

Technic	cal Data
Electrical data for DC pump Incoming voltage	Pump elements K7 Piston diameter
Frequency	Return line connector on housing8.8 ft-lb (10-12 Nm) Tie rods for 15 and 20 I reservoir7.4 ft-lb (10 Nm) Weights
Common electrical data for DC and AC pumps Minimum pause time	15-I reservoir with 3 pump elements K7, without pressure relief valve, empty Pump P653S without connecting cable
Pump P653S Operating pressure with: -pressure switch	4-I reservoir, standard Pump P653S without connecting cable
End of line pressure switch setting	Packing (cardboard box)
End of line pressure transducer setting2,500 psig (172 bar) not adjustable.	Attaching parts Operating Instructions
End of the line transducer vent pressure is factory preset at 900 psi (62 bar). Pressure can be adjusted from 200 to 1,000 psig (14 to 70 bar) in 100 psig (7 bar) increments. Operating temperature range for DC pumps 40 °F to + 158°F ¹) (- 40 °C to +70 °C) ¹) Operating temperature	 Installation Use only high pressure 5,000 psig minimum hydraulic hose for supply lines. Use only hose connection fittings that are appropriate for the programmed/pre-set system pressure.
range for AC pumps	Note #1: See the list of the approved and recommended lubricants. Contact Lincoln if lubricant is not in the list.
Lubricant	Note #2: The lubricant output is measured at + 70 °F (+ 21 °C) and backpressure 1,450 psig (100 bar). Different pressures, temperature and grease can change the output results.




CONNECTIONS FOR 24 VDC 653 PUMP



Page Number - 28 Form 404034



CONNECTIONS FOR 110-230 VAC 50/60 Hz 653 PUMP




^{*} P4 PROGRAMMING PARAMETER SET TO N.O. P5 PROGRAMMING PARAMETER SET TO OPTION 2

^{**} Must connect red and black wires together if no machine switch is used. You can also use a special 7 conductor bayonet plug (P/N 664-34550-1).




JUMPER SETTINGS FOR 653 PUMP PCB



Page Number - 30 Form 404034



Centro-Matic System Schematic with P653S Pump



- 1 PUMPING HOUSING (3 PUMP ELEMENTS)
- 2 MOTOR
- 3 CONTROLLER, KEY BOARD WITH DISPLAY
- 4 INTERNAL PRESSURE SWITCH (P.S.) OR PRESSURE TRANSDUCER (P.T.)
- 5 INTERNAL VENT VALVE
- 6 RESERVOIR WITH Low-level CONTROL
- 7 PRESSURE RELIEF, 5,000 PSI (350 BAR) EXTERNAL
- 8 HIGH PRESSURE SUPPLY LINE
- 9 INJECTORS, SL-V, SL-1, OR SL-32, SL-33, and SL-V XL INJECTORS
- 10 PRESSURE SWITCH (P.S.) OR PRESSURE TRANSDUCER (P.T.), EXTERNAL, OPTIONAL.
- A POWER SUPPLY (24 VDC OR 120 VAC, OPTIONAL)

Note: For proper operation of the Centro-Matic systems, vent pressure before next lubrication cycle at the end of line should be:

- below 900 psig (62 bar) for SL-V and SL-V XL type of injectors
- below 600 psig (41 bar) for SL-1 type of injectors
- below 200 psig (13.8 bar) for SL-32/33 type of injectors.



Lincoln List of Lubricants



IMPORTANT

Absolute cleanliness is essential when handling lubricants. Impurities will remain suspended in the lubricant and cannot settle. This will result in damage to the lubrication system and thus to the bearing.

The Centro-Matic pump can dispense commercial greases up to NLGI grade 2 at specified operating temperature range.

The **proven lubricants** (see following tables) have been tested by Lincoln with regard to their pumpability and venting behavior. Lincoln can recommend them for an application up to the indicated **minimum delivery temperature** in Centro-Matic lubrication systems. During the tests these lubricants did not cause any damage due to incompatibility with the material used by Lincoln.

The lubricants Lincoln recommends on the basis of the manufacturer's data sheet (see following tables) can be used in Lincoln's lubrication systems up to the indicated **minimum delivery temperature.**

Grease pumpability and venting behavior depend on ambient temperature range of the application, and may be different for the same NLGI grade of grease. This refers in particular to greases with more than 3% graphite. Lincoln can test the grease and develop recommendations for specific applications.



IMPORTANT

The manufacturer of the centralized lubrication system can accept no liability for:

- damages due to the use of greases that are not or only conditionally pumpable in centralized lubrication systems.
- damages on parts of the centralized lubrication system caused by chemical or biological changes of the lubricant used.
- damages due to the incompatibility with other materials.

The liability is limited to pumpable lubricants in centralized lubrication systems.



IMPORTANT

Consult Lincoln or Lincoln Distributor/Representative before using lubricants with solid additives.

Proven Lubricants

Manufacturer	Designation	Thickener	Min. Operating Temp.
CATERPILLAR	Moly Ultra 5 NLGI #1	CA-Complex	10° F (-12° C)
CATERPILLAR	Arctic Platinum NLGI #0	CA-Complex Synthetic Base Oil	-40° F (-40° C)
CATERPILLAR	Auto-Lube NLGI #1	Ca-Complex	10° F (-12° C)
FUCHS-LUBRITECH	Stabil Eco EP2	Li/Ca	-13° F (-25° C)
FUCHS	Gleitmo 585	Li	-40° F (-40° C)
FUCHS	Renocal FN 745	Ca-12-OH-stearat	-13° F (-25° C)
FUCHS	Renoral FN3	Ca	-4° F (-20° C)
FUCI-IS	Renolit LZR 2 t l	Li	-4° F (-20° C)
FUCHS	Renolit HLT 2	Li	-13° F (-25° C)
MOBIL	Mobilith SHC 100	Li-complex	-13° F (-25° C)
SHELL	Retinax EPL 2	Li-12-OH-stearat	14° F ('-10° C)
SHELL	Retinax CSZ	Li/Ca	-31° F (-35° C)

Page Number - 32 Form 404034



Lincoln List of Lubricants, continued



IMPORTANT

Consult Lincoln or Lincoln Distributor/Representative before using lubricants with solid additives.

Lubricant recommendations based on the manufacturer's data sheet

Manufacturer	Designation	Thickener	Min. delivery temperature
AGIP	F1 Grease 24	Ca	-15 °C
ARAL	Multipurpose grease	Li-12-OH-stearat	-15 °C
ARAL	Multipurpose grease ZS 1/2	Li/Ca	-20 °C
AVIA	Avialith 2 EP	Li-12-OH-stearat	-15 °C
BP	Energrease LC 2	Li-complex	-15 to -10 °C
BP .	Energrease MP-MG 2	Ca-complex	-5 °C
CASTROL / TRIBOL	Molub Alfoy 6780	Li-12-OH-stearat	-30 to -25 °C
CASTROL.	CLS - Grease	Li/Ca	-25 °C
CASTROL	Olista Longtime 2	LI	-20 ° C
CASTROL	Optimol Olit 2 EP	Li ·	-20 °C
DEA	Glissando 20	Li-12-OH-stearat	-15 to -10 °C
ESSO	Ronex Extra Duty 2	Li-complex	5 °C
ESSO	Ronex MP2	Li-complex	-5 °C
ESSO	Beacon EP2	Li	-5 °C
ESSO	Cazar K2	Са	-15 °C
FIAT LUBRIFICANTI	Comar 2	Li Li	-25 °C
KLÜBER	Centoplex 1 DL	Ll/Ca	-20 °C
KLÜBER	Isoflex NBU 15	Ва	-25 °C
KLÜBER	Klüberplex BEM 34-132	Ca-complex	-20 °C
KLUEBER	Klüberplex BEM 41-141	Li-complex	-25° C
KLÜBER	Petamo GHY 133 N	Polycarbamide	-15 °C .
MOBIL	Mobilgrease XHP 221	Li-complex	-10 °C
MOBIL.	Mobilgrease XHP 461	Li-complex	-10 °C
MOBIL	Mobilgrease XHP 222	Li-complex	-5 °C
MOBIL	Mobilith SHC 220	Li-complex	-20 °C
SHELL	Alvania EP(LF) 1	Li-12-OH-stearat	-15°C +/- 5°C
SHELL	Alvania EP(LF) 2	Li-12-OH-stearat	-10°C +/- 5°C
SHELL	Alvania RL2	Li-12-OH-stearat	-15°C +/- 5°C
SHELL	Malleus GL	Gel	GL205 -20 °C, GL300 -10 °C GL400 0 °C, GL500 +5 °C
SHELL	Retinax CS	Lí	-20 °C
SHELL	Retinax LX 2	Li	-5°C +/- 5°C
SHELL	Retinax HDX`2	Li/Ca	-10°C +/- 5°C
TEXACO	Premium RB	Li	-20 °C
TOTAL	Ceran AD	Ca-complex	- 15° C
TOTAL	Ceran I.T	Ca-complex	-20 °C
TOTAL	Ceran WR2	Ca-complex	-10 °C
ZELLER & GMELIN	Divinol Lithogrease G 421	Li-complex	-15 °C



Lincoln List of Lubricants, continued



IMPORTANT

Consult Lincoln or Lincoln Distributor/Representative before using lubricants with solid additives.

Biodegradable lubricants

Proven lubricants:

Manufacturer	Designation	Thickener	min. delivery temperature
ARAL	Aralub BAB EP 2	Li/Ca	-25 °C
ВР	Biogrease EP 2	Li/Ca	-25 °C
FUCHS-LUBRITECH	Stabyl ECO EP 2	Li/Ca	-25 °C

Lubricant recommendations based on the manufacturer's data sheet:

Manufacturer	Designation	Thickener	min. delivery temperature
AUTOL	Top Bio 2000	Ca	-25 °C
AVIA	Biogrease 1	Li	up to 0 °C
DEA	Dolon E 2	Li »	-15 °C
FUCHS	Plantogel 2 S	Li/Ca	-15 °C
KLÜBER	Klüberbio M72-82	Polycarbamide	-20 °C

Lubricants for the food & beverage industry

Lubricant recommendations based on the manufacturer's data sheet:

Manufacturer	Designation	Thickener	min. delivery temperature
ARAL EURAL	Grease EPF 2	Al-complex	-5°C
BREMER & LEGUIL	Rivolta F.L.G 4 – 2	Al-complex	-20 °C
ELKALUB	GLS 364	organic thickener	-10 °C
ELKALUB	GLS 367/N2	inorganic thickener	-5°C
ELKALUB	GLS 380/N1	Al-complex	~10 °C
ELKALUB	GLS 380/N2	Al-complex	-5°C
FUCHS.	Renolit G 7 FG 1	Bentonite	-5°C
FUCHS-LUBRITECH	Gleitmo 585 M (KTW-drinking water release)	Li	-10 °C
INTERFLON	Fin Food Grease EP	Al-complex	-5°C
KLUEBER	Paraliq GA 343	Al-complex	-10 °C
KLUEBER	Kluebersynth UH1 14-151	Al-complex	-20 °C
MOBIL	Mobilgrease FM 462	Al-complex	-15 °C
Nordischer Maschinenbau BAADER	Special grease GLS 380/N3	Al-complex	-5°C
OKS	470	Li-12-OH-stearat	-15 °C
OPTIMOL	Obeen UF 1	Al-complex	-15 °C
OPTIMOL	Obeen UF 2	Al-complex	-10 °C
RHENUS NORPLEX	AFD 2	Al-complex	-5°C
RHENUS NORPLEX	AFP 2	Al-complex	-5°C
RHENUS NORPLEX	AFS 2	Al-complex	-25 °C
RHENUS NORPLEX	AFW 2	Al-complex	-5°C
SHELL	Cassida Grease EPS 1	Al-complex	-15 °C
SHELL	Cassida Grease EPS 2	Al-complex	-10 °C
TOTAL	Lubriplate FGL 2	Al-complex	-5°C
TRIBOL MOLUB-ALLOY	FoodProof 823-2 FM	Al-complex	-15 °C
TRIBOL MOLUB-ALLOY	9830 high-temperature grease	PTFE	0°C

Page Number - 34 Form 404034



Dimensions: 4-liter reservoir




Fig. 45 Dimensions P 6535, 4-liter reservoir

Reservoir with follower plate: Reservoir with stirring paddle: A1 = 509 MM (20 in) A2 = 467 mm (18.4 in)



Dimensions: 8-liter reservoir




Fig. 46 Dimensions P 663, 8-liter reservoir

Reservoir with follower plate: Reservoir with stirring paddle: B1 = 557 mm (22 lb) B2 = 515 mm (20 lb)



Dimensions: 15-liter reservoir




Fig. 47 Dimensions P 653, 15-liter reservoir

Reservoir with follower plate: Reservoir with stirring paddle: C1 = 800 mm (31 lh) C2 = 758 mm (30 lh)



Dimensions: 20 Liter Reservoir




Fig. 48 Dimensions P 653, 20-liter reseroivr

Reservoir with Follower Plate: D1 = 935 mm (37 ln) Reservoir with Stirring Paddle: D2 = 893 mm (35 ln.)

Page Number - 38 Form 404034



Refill and Maintenance



Caution! First time filling of the reservoir with grease is very critical for proper pump operation. The pump may be shipped with a small amount of Fuchs Renocal FN 745/LINCOLN grease used for final testing and inspection. The grease thickener is Ca-12-OH-stearat. Check compatibility of the Renocal FN 745/LINCOLN with the grease you are going to use and remove the test grease if necessary.

Pump with follower plate:

Use grease fitting (9) (Fig. 1) to fill or refill reservoir. Make sure no air is trapped under the follower plate. Grease should be in full contact with the surface of the follower. It's recommended to run the motor by initiating the lube cycle during the first fill of the reservoir. The stirring paddle of the running motor will help to evenly distribute grease under follower minimizing air pockets. The reservoir has a vent hole (11) (Fig.1). Fill grease to the maximum follower position until follower seal will slightly cross the vent hole. If air is still trapped under the follower, add some more grease to expel air through the vent hole.

Pump without follower plate:

Use the same grease fitting (9) (Fig. 1) to fill or refill reservoir. It's recommended to run the motor by initiating the lube cycle during the first fill of the reservoir. The stirring paddle of the running motor will help to evenly distribute grease in the reservoir minimizing air pockets.

To speed up filling or refilling of the pump, grease fitting can be replaced with 1/8" swivel connection to attach a hose from a larger output filling pump.




Caution! There is a risk of reservoir bursting if overfilled. When filling the reservoir with large output fill or refill pump, do not exceed the maximum fill mark.

Pump cleaning:

Use petroleum or benzene based cleaning solutions. Do not use tri-, perchloroethylene or similar solvents. Do not use polar organics such as alcohol, methyl alcohol, acetone or similar solvents.





Page Number - 40 Form 404034



Troubleshooting

Mode of failure

Solution

Pump motor does not run. No green right corner segment lit on display (Fig. 18 page 15).

Check power supply and fuses.

Pump does not deliver lubricant but runs if manual lube switch 3 (Fig. 17 page 15) is pushed. No green left corner segment lit on display (Fig. 19 page 15).

Connect "ignition" or "machine" switch per electrical schematic on pages 28 and 29.

"LL" display is flashing. Reservoir is almost empty.

Pump with follower - refill reservoir. Pump without follower - refill reservoir and push switch (3) (Fig 17) to initiate manual lube cycle.

"E1" display is flashing. Pump failed to develop internal pressure in 12 minutes.

Push switch (2) (Fig 17) to acknowledge the fault. Initiate manual lube cycle. Investigate and correct possible causes – air pockets, broken line, connections leakage, worn pumping element, failed internal pressure switch or pressure transducer. Initiate manual lube cycle.

"E2" display is flashing. Pump failed to develop pressure at the end of the line (pump with external pressure switch or pressure transducer)

Push switch (2) (Fig 17) to acknowledge the fault. Initiate manual lube cycle. Investigate and correct possible causes – air pockets in lubrication line, connections leakage, grease consistency changed with low temperatures, failed end of line pressure switch or pressure transducer.

"E3" display is flashing. Pump failed to vent at the pump.

Push switch (2) (Fig 17) to acknowledge the fault. Initiate manual lube cycle. Investigate and correct possible causes – pump eccentric did not stop in a proper position, vent valve failed


"E4" display is flashing. Pump failed to vent at the end of the line (pump with external pressure switch or pressure transducer).

Push switch (2) (Fig 17) to acknowledge the fault. Initiate manual lube cycle. Investigate and correct possible causes – restriction in lubrication line, grease consistency changed with low temperature, failed end of line pressure transducer or pressure switch.

Grease is coming out of the pressure relief valve (6) (Fig.1).


Check and adjust setting of the pressure transducer or failed pressure switch.





Page Number - 42 Form 404034





Pump with Follower



P653S PUMP with follower (housing and reservoir)


Item #	Part Number	Description	QTY	Item #	Part Number	Description	QTY
1	316-16444-1©	HOUSING	1	45	445-71543-1	SUPPORT SLEEVE, 4L RESERVOIR	4
2	275702	MOTOR, DRIVE 24VDC	1		445-71542-1	SUPPORT SLEEVE, 8L RESERVOIR	4
3	445-71524-1	INTERMEDIATE BOTTOM	1		445-71528-1	SUPPORT SLEEVE, 15L RESERVOIR	4
4	275557	PINION GEAR, DRIVE	1		445-71536-1	SUPPORT SLEEVE, 20L RESERVOIR	4
5	445-71527-1	THREADED SLEEVE	1	46	545-33045-1	RESERVOIR, 4L W/VENT TUBE AND LABELS	1
7	250-10683-1	BEARING D12/24X 6	1		545-33044-1	RESERVOIR, 8L W/VENT TUBE AND LABELS	1
8	645-29818-1	PUMP ELEMENT, Z7	3		545-33041-1	RESERVOIR, 15L W/VENT TUBE AND LABELS	1
9	250-14009-7	BEARING D10/26X 8	1		545-33043-1	RESERVOIR, 20L W/VENT TUBE AND LABELS	1
10	220-12231-3	SEAL, RADIAL BA 75FKM 10X22X 7	1	47	300-19860-1	SPRING, FOLLOWER, FOR 4L AND 8L RESERVOIR	1
11	275558	GEAR, ECCENTRIC	1		300-16288-1	SPRING, FOLLOWER, FOR 15L AND 20L RESERVOIR	1
12	250-14064-6	BEARING d12/32x10	1	48	219-10684-6	O-RING 72NBR 180.000 X 4.00	1
13	445-71266-1	SHAFT F.DRIVE with RETAINING RING AND KEY	1	49	445-71532-1	INSERT, RESERVOIR	1
14	209-13011-9	WASHER ST 12 C -200HV	1	50	200-13022-7	SCREW, HEX, 8.8 M6x20C	4
17	250-14064-7	BEARING D 8/22X 7	1	51	201-12019-9	SCREW, SOCKET HEX, 8.8 M6x16C	2
18	445-71253-1	CAM, RELIEF UNIT	1	52	444-70113-1	COVER, RESERVOIR	1
20	444-24439-1	PRESS RING	1	53	234-10693-6	CONTACT ROD, 4L RESERVOIR	1
21	201-12016-8	SCREW, SOCK,HEX. 8.8 M 5X 20C	6		234-10693-7	CONTACT ROD, 8L RESERVOIR	1
22	219-10684-6	O-RING 72NBR 180,00X4,00	1		234-10693-8	CONTACT ROD, 15L RESERVOIR	1
23	219-10390-3	O-RING 72NBR 195,00x3,00	1		234-10693-9	CONTACT ROD, 20L RESERVOIR	1
24	545-32906-1	ROCKER ARM, ASS'Y, RELIEF UNIT	1	54	207-12247-2	NUT, CAP WITH WASHER 209-13011-5	2
25		NOT USED©	1	55	234-10663-6	PRESSURE TRANSDUCER WITH SEAL RING 209-12158-6	1
26		NOT USED©	1	56	234-10825-3	EXTERNAL PRESSURE TRANSDUCER	1
27		NOT USED©	4	57	664-34456-9	CABLE ASSY,10M.4/4 POLE	1
28	445-71441-1	FRONT COVER W/KEYBOARD 236-14340-7	1	58	644-34550-6	CONNECTOR FOR EXTERNAL PRESSURE SWITCH/ TRANSDUCER	1
29	445-72277-1©	PROFILE PACKING	1	59	664-34428-3©	CABLE ASSY,10M,7/7 POLE	1
30	236-10655-1	PRINTED CIRCUIT BOARD*	1	60	664-34569-1	CONECTOR FOR SIGNAL CABLE 7 POLES (AC PUMP)	1
31	275666	COVER, HOUSING	1		664-34303-7	CONECTOR FOR SIGNAL CABLE 7 POLES (DC PUMP)	1
32	201-12016-6	SCREW, SOCK, HEX. 8.8 M 5X 16C	4	61	236-13277-9	AC POWER CABLE PLUG	1
33	545-33042-1	RELIEF ELEMENT	1	62	664-34517-6	LOW LEVEL CONTROL SWITCH CABLE (4L RESERVOIR)	1
35	206-13710-6	SCREW,6.0x40Z WITH SEAL 220-14101-1	3		664-34517-7	LOW LEVEL CONTROL SWITCH CABLE (8L RESERVOIR)	1
37	234-10723-8	PRESSURE SWITCH WITH SEAL RING 209-12158-6	1		664-34517-5	LOW LEVEL CONTROL SWITCH CABLE (15L RESERVOIR)	1
39	206-13796-9	SCREW W/WASHER	4		664-34517-8	LOW LEVEL CONTROL SWITCH CABLE (20L RESERVOIR)	1
40	304-19619-1	ADAPTER M22x1.5 W/GREASE FITTING 251-14045-9	1	63	644-34550-11©	PLUG, 7 POLE JUMPER	1
41	545-33031-1	STIRING PADDLE ASSE'Y	1	64	275906	POWER SUPPLY	1
42	445-71267-1	BUSHING	1	65	664-34428-1	MOTOR CONNECTOR	1
43	544-33307-1©	FOLLOWER PLATE ASS'Y	1	66	664-34569-2	INTERNAL CABLE FOR AC PUMP	1
44	200-12000-3	SCREW, HEX, 8.8 M6x40C	4	67	234-10825-4	EXTERNAL PRESSURE SWITCH	1
				-	624-77144-1©	VLAVE SVTE - 400 - R 1/4-1/4 NPT	1
				-	271249	HORIZONTAL MOUNTING BRACKET	1
				-	226-14105-5	ADAPTER S2520-1/4-1/4-25	1

^{*} When replacing Printed Circuit Board 236-10655-1, special attention must be given to the jumper settings. The replacement Printed Circuit Boards are shipped with a standard factory setting. For your pumpt o work properly, the replacement Printed Circuit Board jumper settings must duplicate the original Printed Circuit Board.


Page Number - 44 Form 404034











Page Number - 46 Form 404034



P653S Pump without Follower (Housing and Reservoir)

Item #	Part Number	Description	QTY	Item #	Part Number	Description	QTY
1	316-16445-1©	HOUSING	1	40	304-19619-1	ADAPTER M22x1.5 W/GREASE FITTING 251-14045-9	1
2	275702	MOTOR, DRIVE 24VDC	1	41	234-10423-6	PROXIMITY SWITCH	1
3	445-71524-1	INTERMEDIATE BOTTOM	1	42	545-33093-1	STIRING PADDLE ASSE'Y	1
4	275557	PINION GEAR, DRIVE	1	43	200-12000-3	SCREW, HEX, 8.8 M6x40C	4
5	445-71527-1	THREADED SLEEVE	1	44	445-71543-1	SUPPORT SLEEVE, 4L RESERVOIR	4
7	250-10683-1	BEARING D12/24X 6	1		445-71542-1	SUPPORT SLEEVE, 8L RESERVOIR	4
8	645-29818-1	PUMP ELEMENT, Z7	3		445-71528-1	SUPPORT SLEEVE, 15L RESERVOIR**	4
9	250-14009-7	BEARING D10/26X 8	1		445-71536-1	SUPPORT SLEEVE, 20L RESERVOIR**	4
10	220-12231-3	SEAL, RADIAL BA 75FKM 10X22X 7	1	45	545-33045-1	RESERVOIR, 4L W/VENT TUBE AND LABELS	1
11	275558	GEAR, ECCENTRIC	1		545-33044-1	RESERVOIR, 8L W/VENT TUBE AND LABELS	1
12	250-14064-6	BEARING d12/32x10	1		545-33041-1	RESERVOIR, 15L W/VENT TUBE AND LABELS***	1
13	445-71266-1	SHAFT F.DRIVE with RETAINING RING AND KEY	1		545-33043-1	RESERVOIR, 20L W/VENT TUBE AND LABELS***	1
14	209-13011-9	WASHER ST 12 C -200HV	1	46	219-10684-6	O-RING 72NBR 180.000 X 4.00	1
17	250-14064-7	BEARING D 8/22X 7	1	47	445-71532-1	INSERT, RESERVOIR	1
18	445-71253-1	CAM, RELIEF UNIT	1	48	200-13022-7	SCREW, HEX, 8.8 M6x20C	4
20	444-24439-1	PRESS RING	1	49	444-70490-1	FIXED PADDLE	1
21	201-12016-8	SCREW, SOCK,HEX. 8.8 M 5X 20C	6	50	444-70641-1	COVER, RESERVOIR	1
22	219-10684-6	O-RING 72NBR 180,00X4,00	1	55	234-10663-6	PRESSURE TRANSDUCER WITH SEAL RING 209-12158-6	1
23	219-10390-3	O-RING 72NBR 195,00x3,00	1	56	234-10825-3	EXTERNAL PRESSURE TRANSDUCER	1
24	545-32906-1	ROCKER ARM, ASS'Y, RELIEF UNIT	1	57	664-34456-9	CABLE ASSY,10M.4/4 POLE	1
25		NOT USED©	1	58	644-34550-6	CONNECTOR FOR EXTERNAL	1
26		NOT USED©	1			PRESSURE SWITCH/TRANSDUCER	
27		NOT USED©	4	59	664-34428-3©	CABLE ASSY,10M,7/7 POLE	1
28	445-71441-1	FRONT COVER W/KEYBOARD 236-14340-7	1	60	664-34569-1	CONECTOR FOR SIGNAL CABLE 7 POLES (AC PUMP)	1
29	445-72277-1©	PROFILE PACKING	1		664-34303-7	CONECTOR FOR SIGNAL CABLE 7 POLES (DC PUMP)	1
30	236-10655-1	PRINTED CIRCUIT BOARD 24 V*	1	61	236-13277-9	AC POWER CABLE PLUG	1
31	275666	COVER, HOUSING	1	63	664-34550-11©	PLUG, 7 POLE JUMPER	1
32	201-12016-6	SCREW, SOCK, HEX. 8.8 M 5X 16C	4	64	275906	POWER SUPPLY	1
33	545-33042-1	RELIEF ELEMENT	1	66	664-34569-2	INTERNAL CABLE FOR AC PUMP	1
35	206-13710-6	SCREW,6.0x40Z WITH SEAL 220-14101-1	3	67	234-10825-4	EXTERNAL PRESSURE SWITCH	1
37	234-10723-8	PRESSURE SWITCH WITH SEAL RING 209-12158-6	1	-	624-77144-1©	VALVE SVTE - 400 - R1/4 - 1/4 NPT	1
39	206-13796-9	SCREW W/WASHER	4	-	271249	HORIZONTAL MOUNTING BRACKET	1
				-	226-14105-5	ADAPTER S2520-1/4-1/4-25	1

^{*} When replacing Printed Circuit Board 236-10655-1, special attention must be given to the jumper settings. The replacement Printed Circuit Boards are shipped with a standard factory setting. For your pump to work properly, the replacement Printed Circuit Board jumper settings must duplicate the original Printed Circuit Board.

^{**} Components available in kit to convert 4 and 8 liter to 15 liter - part # 276764.

^{***} Components available in kit to convert 4 and 8 liter to 20 liter - part # 276765.



Americas: One Lincoln Way St. Louis, MO 63120-1578 USA Phone +1.314.679.4200 Fax +1.800.424.5359

Heinrich-Hertz-Str 2-8 D-69183 Walldorf Germany Phone +49.6227.33.0 Fax +49.6227.33.259

Europe/Africa:

Asia/Pacific: 51 Changi Business Park Central 2 #09-06 The Signature Singapore 486066 Phone +65.6588.0188 Fax +65.6588.3438 © Copyright 2009 Printed in USA

Web site: www.lincolnindustrial.com



Model No. 85770-1, -2, -3, -4, -5, -6 85771, 85772 85780-1, -2, -3, -4, -5, -6 85781 and 85782 SL-V INJECTOR

Series "A"


SINGLE AND MANIFOLD TYPE INJECTORS

for dispensing fluid lubricants and greases not exceeding Lincoln ventmeter viscosity of 600 psi.

SPECIFICATIONS


Minimum operating pressure — 1850 psi [128 bar]
Maximum operating pressure — 6000 psi [413 bar]
Recommended operating pressure — 2500 psi [172 bar]
Maximum vent (recharge) pressure — 1000 psi [69 bar]
Temperature Range - -40°F to 180°F [-40°C - 80°C]
Lubricant output (adjustable):

SL-V - 0.015 to 0.080 cu. in. [0.25 to 1.31 ccm]
SL-V HO - 0.015 to 0.305 cu. in. [0.25 to 5.00 ccm]
Injectors can be mounted in any position and can be used in circuits with SL-1, SL-11, SL-32 and/or SL33 injectors.





U.S Patent Number 6,705,432 Foreign Patents Pending






One Lincoln Way St. Louis, MO 63120-1578 Phone +1.314.679.4200 Fax +1.800.424.5359

© Copyright 2003 Printed in USA Web site: www.lincolnindustrial.com Section - C8


Page - 301





MANIFOLD TYPE INJECTORS

Injector	Model	Туре	Dimension "A"		Dimension "B"		Dimension "C"	
			in.	[mm.]	in.	[mm.]	in.	[mm.]
SL-V	85770-1	Single injector manifold	*	*	2-1/2	[63.5]		THE REAL PROPERTY.
	85770-2	Tw o injector manifold	*	*	3	[76.2]		
	85770-3	Three injector manifold	1-1/4	[31.8]	4-1/4	[108]		
	85770-4	Four injector manifold	2-1/2	[63.5]	5-1/2	[140]	8-3/4	[222]
	85770-5	Five injector manifold	3-3/4	[95.3]	6-3/4	[171]		
-	85770-6	Six injector manifold	5	[127]	-8	[203]		
	85771	Replacement injector	N/A		N/A .			
	85780-1	Single injector manifold	*	*	2-1/2	[63.5]		CONTRACTOR
	85780-2	Tw o injector manifold	*	*	3	[76.2]	†	
	85780-3	Three injector manifold	1-1/4	[31.8]	4-1/4	[108]		
SL-V HO	85780-4	Four injector manifold	2-1/2	[63.5]	5-1/2	[140]	11-3/16	[284]
	85780-5	Five injector manifold	3-3/4	[95.3]	6-3/4	[171]		
	85780-6	Six injector manifold	5	[127]	8	[203]		
	85781	Replacement injector	N/A		N/A			



SINGLE UNIT INJECTORS

	Injector	Model	Туре	Dimension "D"		-
.*	APPARAMENTAL DESIGNATION DE LA CONTRACTION DEL CONTRACTION DE LA C			in.	[mm.]	
	SL-V	85772	Single unit injector	7-3/4	[191]	THE PERSON
	SL-V HO	85782	Single unit injector	10-3/16	[248]	
				REPORTED BY A PROPERTY OF THE PARTY OF THE P	ACCRECATION OF THE PARTY.	8



Model No. 85770-1, -2, -3, -4, -5, -6 85771, 85772 85780-1, -2, -3, -4, -5, -6 85781, 85782 SL-V INJECTOR

-13

15


16

-17

- 18

19


20 Torque to





ltem	Description Qty.		Part No.		
No.			SL-V	SL-V HO	
1	Protective Cap (polycarbonate)	1	273088	273089	
2	O-ring (nitrile)			*	
3	Adjusting Screw		272803 272819		
4	Lock Nut	1	11	624	
5	Piston Stop Plug	1	273090	273091	
6	O-ring	1		*	
7	Backup Washer	1		*	
8	U-cup (polyurethane)	1		*	
9	O-ring (polyurethane)	- 1		*	
10	Piston As sembly	1	273092	273093	
11	O-ring (polyurethane)	1		ż	
12	Fitting Assembly	1	90	471	
13	Injector Body	1	273094	273095	
14	O-ring (fluorocarbon)	2		*	
15	O-ring (fluorocarbon)	1		*	
16	Spring	1		*	
17	Spring	1		*	
18	Spring Seat	1	272	2798	
19	Body and Plunger Assy.	1	273	3096	
20	Socket Head Screw (8-32 x 1-1/2)	2	272	2796	
21	Gasket	1		*	
21	Single Injector Manifold	1	12658		
	Two Injector Manifold	1	11962		
22	Three Injector Manifold	1	11963		
22	Four Injector Manifold	. 1	11964		
	Five Injector Manifold	1	11965		
	Six Injector Manifold	1	246965		
23	Gasket	1		ż	
24	Adapter Bolt	1	273	3097	
25	Adapter	1	273	3098	

^{*} Included in 272970 Repair Kit



MANIFOLD INJECTORS


SINGLE UNIT INJECTOR

SPECTRUM ADJUSTMENT SLEEVES

Output		Ratio from	Ratio from	Sleeve	
in3	(cc)	Minimum Output	Maximum Output	Color	
0.015	(0.25)	1	0.2	N/A	
0.03	(0.50)	2	0.4	red	
0.045	(0.75)	3	0.6	silver	
0.06	(1.00)	4	0.8	gold	
0.075	(1.25)	5	1.0	green	
	in3 0.015 0.03 0.045 0.06 0.075	in3 (cc) 0.015 (0.25) 0.03 (0.50) 0.045 (0.75) 0.06 (1.00) 0.075 (1.25)	in3 (cc) Minimum Output 0.015 (0.25) 1 0.03 (0.50) 2 0.045 (0.75) 3 0.06 (1.00) 4	in3 (cc) Minimum Output Maximum Output 0.015 (0.25) 1 0.2 0.03 (0.50) 2 0.4 0.045 (0.75) 3 0.6 0.06 (1.00) 4 0.8 0.075 (1.25) 5 1.0	

NOTE: Remove and discard Lock Nut (Item 4) before installing Spectrum Adjustment Sleeve onto Adjusting Screw (Item 3).





SL-V Injector Operation

Stage 1

The injector starts in its normal or rest position. Incoming lubricant is directed through the slide valve to both sides of the piston. The pressure of the incoming lubricant acting on both sides of the piston causes the piston to move downward against the shoulder and fills the measuring chamber. The indicator stem is fully retracted away from the stop of the adjusting screw.

Stage 2


Further increase in pressure causes the slide valve to move against the force of the springs. As the slide valve moves, it closes passage 1 and opens passage 2 to the outlet port. The pressure of the incoming lubricant is now acting only upon the bottom of the piston. The incoming lubricant displaces the piston which forces the lubricant in the measuring chamber to be dispensed through passage 2, through the slide valve and through the outlet port to the lube point.


Stage 3


The piston will dispense lubricant until the indicator stem hits the stop of the adjusting screw. The volume of lubricant dispensed can be adjusted by limiting the travel of the piston. The piston and slide valve remain in this position until the lubricant pressure in the supply line is vented.

Stage 4

As the pressure in the supply line vents to 1000 psig [69 bar], the slide valve moves downward and closes passage 2 and opens passage 1. The lubricant pressure in the supply line is now acting upon both sides of the piston causing it to move downward. As the piston moves downward, a volume of lubricant flows from the underside of the piston, past the slide valve, through passage 1 and to the upper side of the piston. Since the volume on top of the piston is greater than the volume under the piston, an additional volume of lubricant flows from the supply line to the upper side of the piston. This volume of lubricant leaving the supply line causes the pressure to drop very quickly. The piston may or may not fully return to the shoulder, depending upon the volume of lubricant in the supply line. The injector is now ready for the next cycle.









Model No. 85770-1, -2, -3, -4, -5, -6 85771, 85772 85780-1, -2, -3, -4, -5, -6 85781, 85782 SL-V INJECTOR

Lincoln Industrial Standard Warranty

LIMITED WARRANTY

Lincoln warrants the equipment manufactured and supplied by Lincoln to be free from defects in material and workmanship for a period of one (1) year following the date of purchase, excluding therefrom any special, extended, or limited warranty published by Lincoln. If equipment is determined to be defective during this warranty period, it will be repaired or replaced, within Lincoln's sole discretion, without charge.

This warranty is conditioned upon the determination of a Lincoln authorized representative that the equipment is defective. To obtain repair or replacement, you must ship the equipment, transportation charges prepaid, with proof of purchase to a Lincoln Authorized Warranty and Service Center within the warranty period.

This warranty is extended to the original retail purchaser only. This warranty does not apply to equipment damaged from accident, overload, abuse, misuse, negligence, faulty installation or abrasive or corrosive material, equipment that has been altered, or equipment repaired by anyone not authorized by Lincoln. This warranty applies only to equipment installed, operated and maintained in strict accordance with the written specifications and recommendations provided by Lincoln or its authorized field personnel.

THIS WARRANTY IS EXCLUSIVE AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE WARRANTY OF MERCHANTIBILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

In no event shall Lincoln be liable for incidental or consequential damages. Lincoln's liability for any claim for loss or damages arising out of the sale, resale or use of any Lincoln equipment shall in no event exceed the purchase price. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, therefore the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights. You may also have other rights that vary by jurisdiction.

Customers not located in the Western Hemisphere or East Asia: Please contact Lincoln GmbH & Co. KG, Walldorf, Germany, for your warranty rights.

Lincoln Industrial Special Limited Warranty

SPECIAL LIMITED 2 YEAR WARRANTY

SL-V Series, Single Injectors-85772, 85782, and Replacement Injectors-85771, 85781
Lincoln warrants the SL-V Injector series to be free from defects in material and workmanship for two (2) years following the date of purchase. If an injector model (single or replacement) is determined to be defective by Lincoln, in its sole discretion, during this warranty period, it will be repaired or replaced, at Lincoln's discretion, without charge.

Lincoln Industrial Contact Information

To find Lincoln Industrial's Nearest Service Center Call one of the following numbers, you may also use our wbsite

Customer Service - 314-679-4200 Website - www.lincolnindustrial.com Model No. 85770-1, -2, -3, -4, -5, -6 85771, 85772 85780-1, -2, -3, -4, -5, -6 85781, 85782 SL-V INJECTOR



Declaration by the manufacturer as defined by machinery directive 89/392/EEC Annex IIB

Herewith we declare that the supplied model of

SL-V

is intended to be incorporated into machinery covered by this directive and must not be put into service until the machinery into which it is to be incorporated has been declared in conformity with the provisions of the directive.

Applied harmonized standards in particular:

EN292 T1/T2 prEN 809

Paul Conley, Chief Engineer



TEXACO STARPLEX®

CUSTOMER BENEFITS

Texaco Starplex greases deliver value through:

- Good water resistance Strong resistance to wash out of bearings.
- Good rust and corrosion protection, even in wet conditions.
- · Extreme pressure protection
- Protection against shock loading, thus extending bearing life.
- Outstanding film strength and adhesive properties.
- Good low temperature pumpability Better handling in the container and grease dispensing equipment.

FFATURES

Texaco Starplex greases are water resistant, extreme pressure, heavy duty chassis, wheel bearing and general purpose lubricating greases.

They are manufactured using highly refined, select high viscosity index base oils, and a lithium complex soap.

Texaco Starplex greases are available in two grades:

- NLGI 1 for better pumpability at low ambient temperatures
- NLGI 2 for use in normal ambient temperatures

FUNCTIONS

Texaco Starplex greases are formulated to:

- Protect bearings and other metal surfaces from corrosion when exposed to wet conditions.
- Resist water. These greases strongly resist being washed out of bearings.
- Retain their consistency under adverse service conditions
- Provide outstanding film strength and adhesive properties. As a result, Texaco Starplex greases are particularly effective in providing low wear in shock load service.
- Operate effectively over a wide temperature range.

APPLICATIONS

Texaco Starplex greases are recommended for:

- general use in the lubrication of trucks, tractors, and passenger cars. This includes ball joints, universal joints, and all other chassis points, wheel bearings, water pumps, and fifth wheels.
- boat trailer wheel bearings
- high temperature disc brake bearing applications

Texaco Starplex greases are approved for the NLGI Certification Mark GC-LB.

TYPICAL TEST DATA


NLGI Grade	1	2
CPS Number	221927	221935
MSDS Number	8807	8807
Operating Temperature, °C(°F) Minimum ¹ Maximum ²	-40(-40) 177(350)	-40(-40) 177(350)
Penetration, at 25°C(77°F) Unworked Worked	310 325	267 280
Dropping Point, °C(°F)	270(518)	270(518)
Four-Ball Weld Point, kg Wear Scar Diameter, mm	315 0.4	315 0.4
Timken OK Load, lb	40	40
Thickener, % Type	9 Lithium Complex	12 Lithium Complex
Viscosity, Kinematic* cSt at 40°C cSt at 100°C	188 19.4	188 19.4
Viscosity, Saybolt* SUS at 100°F SUS at 210°F	987 92	987 92
Viscosity Index*	104	104
Flash Point, °C(°F)*	198(388)	198(388)
Pour Point, °C(°F)*	-12(+10)	-12(+10)
Texture	Smooth, Stringy	Smooth, Strigy
Color	Red	Red


Typical test data are average values only. Minor variations which do not affect product performance are to be expected in normal manufacturing.

Minimum operating temperature is the lowest temperature at which a grease, already in place, could be expected to provide lubrication. Most greases cannot be pumped at these minimum temperatures.

Maximum operating temperature is the highest temperature at which the grease could be used with frequent (daily) relubrication.

^{*} Determined on mineral oil extracted by vacuum filtration.







HOR LONGITUDINAL LOADS ARE CALCULATED AS BEING MAX 10% OF


THE VERTICAL DL & LL. SHEARBAR AND SKIRT FRICTION LOADS ARE

TRANSFERRED DIRECTLY TO FEEDER FRAME (SHEARBAR BRACE FRAME BY OTHERS)





SECTION A-A




INDUSTRIAL EQUIPMENT MANUFACTURING LTD. SURREY, B.C. CERTIFIED CORRECT

FOR MEGATECH PROJECT CUSTOMER

THEIR INTERESTS

PER G.J.Williamson DATE SPET 13/12
P.eng


<u>NOTES:</u>
I. PAN HEIGHT IS BASED ON EXPECTED STEEL DIMENSIONS AND MAY VARY +/- 3 mm - CONFIRMED PRIOR TO SHIPMENT.



RIGHT SIDEVIEW

#8009I 24VDC 8L RESERVOIR W INTERNAL PRESS. TRANSDUCER

| #8009I 24VDC 8L RESERVOIR W INTERNAL PRESS. TRANSDUCER
| XI 2 TORQUE ARM ASSEMBLY WITH FLOOR MOUNTING BRACKET
| YI | I | 10" x 8" x 6" NEMA 4X JUNCTION BOX
| A6~G6 22 REMOVABLE ANGLE FRAME EXPANDED METAL GUARDS
| I | ITEM OF INSTALLATION & MAINTENANCE MANUAL



MK. QTY.

DESCRIPTION

330 DIA. @ SPKTS. 300 @ BRGS. AND 300 @ REDUCER

2 FAG #SDD23064K.M300TA P. BLOCKS, TACONITE SEALS AND

FAG SAFD 22528.415 PILLOW BLOCKS, TACONITE SEALS

IEM WELDED STL. SCREW TAKE-UP x 254 mm ADJUSTMENT

2 | D8N SALT TRACK CHAIN 215.9mm P. x (74+75) LINKS/CHAIN C/W

2134 WIDE x 215.9 PIT. 38mm THICK, C/W LIFTING EYE AT CENTER

PLANETARY REDUCER WITH HOLLOW SHAFT AND SHRINK DISC

WELD'D STL. MACHINED SWING-BASE MOTOR/REDUCER MOUNT

TEFC FOR INVERTER DUTY, ADVANTAGE PLUS IEEE 841
SEVERE DUTY NEMA 444T FRAME WITH FOOT MOUNT

(THE ABOVE INFO IS PROVIDED FOR REFERENCE ONLY &

PCI 2 R+W SERVOMAX TORQUE LIMITER ES2/1500BF, DI 85.73H7, D2 50H7 90

ROTECH 4B ZERO SPEED SWITCH (SUPPLIED BY MEGATECH)

C/W TENSION SPRING, TURNBUCKLE, THIMBLES, & CLAMPS

REINFORCED WELDED STEEL FEEDER FRAME, C/W MOUNTING

ABOVE MECHANICAL ITEMS TO BE SHOP ASSEMBLED

I HYDRAULIC HANDPUMP POWER UNIT C/W MOUNTING BRKT

HYDRAULIC ASSIST TAKE-UP C/W 2 HYDRAULIC CYLINDERS &

LINCOLN AUTO LUBE SYSTEM C/W INJECTORS & EL PUMP P653S

TOTAL WEIGHT OF DUAL DRIVES & TORQUE ARMS (WITHOUT EL. MOTOR): 9,420 kg.

CI 2 D8N x 21 TOOTH SPROCKET-3 SEGMENTS BOLTED TO HUB,

I OPEN AND FIXED, I CLOSED AND FREE

C/W HYDRAULIC TAKEUP ASSIST ITEM VI

JI | 149 | DUAL IMPACT SKID CAST MANGANESE STEEL APRON PAN

KI | 1192 | 22 DIA. (7/8") x 89 (3 1/2") LG HIGH-TENSILE TRACK BOLTS

NI 22 FABRICATED STL. DOORS/BRACKETS FOR RETURN ROLLER

MOUNT WITH SOLID SHAFT INPUT AND FOOT MOUNT

THE MOTORS WILL BE SUPPLIED BY OTHERS)

CROUSE HINDS' SINGLE END PULLCORD SWITCH

TI 2 GALV. VINYL COVERED WIRE ROPE PULL CORD ASSY.

2-AFU0333-05 RIGHT AND 2-AFU0333-50 LEFT

AND ANCHOR BOLT HOLES, BRG. SHIM PLATES,

|| SET || 13mm THK || INSTALLATION SHIM PACKAGE (BY OTHERS)

PI | IL/IR | SEW EURODRIVE PHF082MC3RLSF06 RIGHT ANGLE

Pbl | IL/IR | 93.2 kW (125 HP) EL. MOTOR 1760 RPM, 575V/3/60,

DISENGAGEMENT TORQUE: 1250 N.m

2 SPLIT MASTER LINKS / CHAIN

C/W TRACK NUTS & HFW

MI | 22 | IEM RETURN ROLLER S638B

TO FRAME

| SET | ITEM OF SHOP & FILED BOLTS

LI 68 D8R CARRYING TRACK ROLLER #2-1986 (SF)

FI | 2 | HARDENED RIM TRACTION WHEEL- 3 SEGMENTS PER WHEEL

KS FN-2 FIT, SPROCKETS P.D.: 732mm

336 mm DIA. 4340 HTSR x 3868mm LG HEADSHAFT NECKED TO

OIL RELEASE ADAPTOR, I OPEN AND FIXED, I OPEN AND FREE

| 177.8 mm DIA CIO45 TAIL SHAFT, NECKED TO 125.4 mm DIA.@ BRGS | 560

<u>"AOI" ONE | 2134 mm WIDE INCLINED APRON FEEDER D&N</u>

WEIGHT ko

680

910

200

8,073

30,750

256

7,050

1,108

998

6,450

10

25

16,000

1,000

50

1,000


WEIGHT OF FEEDER LESS DRIVE: 67,451 kg.

TOTAL WEIGHT PER FEEDER WITHOUT EL. MOTOR: 76,871 kg.

DETAIL B
SCALE: 1:4


SE	E DWG NO	D: V977	-0 -0	FOR 1	FI FVAT	TON V	ΊFΜ .	AND	TOP	VIF

				2 COF	PECIFICATIONS: SP6 COMMERCIAL BLAST FOLLOWED BY: NTS CARBOLINE 890 EPOXY 3.0 MILS DFT PER COAT	CODE	INDUSTRIAL FORT KEL	SCALE: LS 1:25 U.N.O.
				1	COLOR GREY DS: POWDER COATED SAFETY YELLOW		MANUFACTURING LTD. SURREY, B ISO 9001:2000 Certified	DRAWN BY: OZH
				D	APR 24/12 UPDATED INFO OF TORQUE ARM AND BRACKET AS BULIT	OZH	GENERAL ARRANGEMENT OF	CHKD. BY GJW
6	SEPT 13/12	CORRECTED THE BORE SIZES OF R+W TORQUE LIMITER	OZH	C	APR 19/12 UPDATED LOADS OF ANCHOR BOLTS	OZH	2134 mm WIDE APRON FEEDER D8N	DATE:
F	JUN 18/12	UPDATED ANCHOR BOLT'S LOADS FOR COLUMN A & B	OZH	В	MAR 02/12 UPDATED AS CLIENT'S COMMENTS AND ISSUED CERTIFIED	OZH	EQPT #: SHT 2 OF	2 JAN 12/12
E	JUN <i>0</i> 5/12	UPDATED INFO OF JUNCTION BOX AND WEIGHTS	OZH	A	JAN 12/12 ISSUED FOR APPROVAL	OZH	FOR: THEOATECH ENGINEERING LTD.	RAWING No.: REV.
REV.	DATE	DESCRIPTION	CHKD.	REV.	DATE DESCRIPTION	CHKD.	V	/977-01-02 <i>/</i> 6\




FIELD TO INSTALL ASSEMBLIES


MK.	QTY.	DESCRIPTION	
'A502R'	ONE	EMERGENCY PULL-CORD SWITCH ASSY RH	
<u>'A502L'</u>	<u>ONE</u>	EMERGENCY PULL-CORD SWITCH ASSY LH	
b/R	2	CROUSE-HINDS SINGLE END SWTICH AFU0333-05 RIGHT	
b/L	2	CROUSE-HINDS SINGLE END SWTICH AFU0333-50 LEFT	
C	2	3/8" x 6" GALV'D TURNBUCKLE HOOK AND EYE	
d	4	3/16" GALV'D OR SS THIMBLE	
f	8	3/16" W.R. CABLE CLAMPS	
g	2	1/8" DIA. 7 x 19 - GALV'D WIRE ROPE, 3/16" DIA. PVC	
		YELLOW JACKET x 60'-0 LG.	
m	8	3/8" x 4" LG. EYEBOLT W 2HN & 2FW	
f _l	8	HEX CAP SCREW, GR-5, 3/8 UNC x 1/2"Lg. W HN & LW	



I-REQ'D - EMERGENCY PULL-CORD, R.H. - MK.'A502R' AS SHOWN <u>I-REQ'D - EMERGENCY PULL-CORD, L.H. - MK.'A502L'</u>

				FOUIPMENT PORT KELLS	
				MANUFACTURING LTD. SURREY, B.C. ISO 9001:2000 Certified	OZH
				PULLCORD SWITCH ASSY	CHKD. BY
					DATE:
				EQPT #	APR 09/12
Α	APR 09/12	ISSUED FOR FABRICATION	<i>OZH</i>	FOR: MEGATECH ENGINEERING LTD.	
REV.	DATE	DESCRIPTION	CHKD.	V97	7-502 /





MK.	QTY.	DESCRIPTION
	<u>ONE</u>	HYDRAULIC TAKE-UP ASSIST SYSTEM
		PARTS FOR ONE
I	I	HAND PUMP, TANKLESS, 3000 psi, 0.6 cu. in.,
		BRAND HYDRAULICS HP6IDATL
		(PAINT AS PER NOTES)
2	2	BALL VALVE, 2-WAY, 3/8"NPT, c/w HANDLE
		HYDAC KHB-IONPT-I-I-4-IIX
3	1	PRESSURE GAUGE, 2 1/2" SERIES, STEM MOUNT,
		0-3000 psi, I/4"NPT, F0STER 9317644
4	I	FLUID-LEVEL INDICATOR, 5", c/w THERMOMETER
		HYDAC FSA-127-1.1-T-12
5	1	FILLER-BREATHER, 3/4"NPT, IOum,
		HYDAC BFP3GIOWI.O
6	1	5 GALLON RESERVOIR
7		3/8" HOSE ASSYS C/W JIC SWIVEL FEMALE ENDS
8		Φ2 1/2" × 10" STROKE HYS 25MAL10-10, Φ1 1/2" ROD
		HY-SPEC MAL CYLINDER
9		#ASP - 4BV BREATHER PLUG, I/2" NPT

SEE DWG: V977-505 FOR Q'ty OF ITEM '7', '8' & '9"


NOTES: I. PRE-SET HYDRAULIC PUMP RELIEF VALVE
TO 2,260 PSI FOR MAX FORCE OF II,100 lbs/CYLINDER
2. ITEM 7 HOSE ASSYS - LENGTH TO SUIT.

ONE - HYDRAULIC TAKE-UP ASSIST

_					┙╻
] <u> </u>
] ' `
	Α	MAR 14/12	ISSUED FOR FABRICATION	OZH	FOR:
	REV.	DATE	DESCRIPTION	CHKD.	

INDUSTRIAL PORT KELL	5	SCALE:	
EQUIPMENT MANUFACTURING LTD. ISO 9001:2000 Certified		DRAWN BY:	
HYDRAULIC TAKE-UP ASSIST DIAGRAM		CHKD. BY GJW	
FOR APRON FEEDER		DATE: mar 14/12	
TOR:	DRAWIN	IG No.:	REV.
	V97	17-507	A

MK.	QTY.	DESCRIPTION	MK.	QTY.	DESCRIPTION
af		ADAPTER I/2" NPT (M) x I/4" NPT (F) #2081-8-45	<u>'A5I3'</u>	<u>ONE</u>	CENTROMATIC LUBRICATING SYSTEMS FOR APRON FEEDER
ag	20	90° ADAPTER 1/8" NPT(M) x 3/8" JIC (M) #2024-2-65	а	1	MODEL #80091 P653S LINCOLN 24VDC EL PUMP C/W
ah	1	ADAPTER I/2" NPT(M) x I/4" NPT (M)			8L RESERVIOR, INTERNAL PRESSURE TRANSDUCER \$
ak	7	Φ1/4"-28NF MALE x 1/8" NPT(F) ADAPTER			PROGRAMMABLE CONTROL
am	2	3/8" NPT HEX PLUG	Ь	1	SL-I INJECTORS (DOUBLE) #85770-2
an	2	90° ADAPTER 1/4" NPT(M) x 3/8" JIC (M) #2024-4-65	C	3	SL-I INJECTORS (TRIPLE) #85770-3
			d	1	PRESSURE GAUGE NOSHOK # 25.901-5000 PS1/350 kPA
			aa	2	ADAPTER 1/2" JIC (M) x 3/8" NPT(M)
hl~hl3	1 Set	3/8" HOSE C/W 3/8" JIC (F) FITTINGS BOTH ENDS (LENGTH TO SUIT)	ab	1	CROSS 1/2" NPT (FFFF) #2080-8-85
h14~h15	1 Set	1/2" HOSE C/W 1/2" JIC (F) FITTINGS BOTH ENDS (LENGTH TO SUIT)	ac	2	ADAPTER 1/2" JIC (M) x 1/2" NPT(M) #2021-8-85
			ad	4	90° ADAPTER 3/8" NPT(M) x 3/8" JIC (M) #2024-6-65



*OZ*H

CHKD.

APR 23/12

DATE

ISSUED FOR FABRICATION

DESCRIPTION

FOR 2134mm WIDE APRON FEEDERS D8N

FOR: MEGATECH ENGINEERING LTD.

DATE:

DRAWING No.:

V977-513

APR 23/12

REV.

LENGTH TO SUIT

GENERAL 3/8" HOSE ASSY - TYPICAL

No.	DWG	MK	QTY	DIAM	LG	DESCRIPTION	HN	TN	JN	LN	LW	FW	BW	HW				LOCATION		
1	V977-01	k1	1192	7/8	3 1/2	H. T. S. TRACK BOLTS		1192						1192	D8N 1	PANS	TO CHAINS(*NO HW REQ'I	O FOR MASTER LIN	IKS)
2	V977-02	x02	2	1	6	HEX HD BOLT GR5	2				2				T-up (CYLIN	DERS MTG			
3	V977-02	b1	2	3/8	1 1/2	HEX HD BOLT GR5	2				2				LUBE	E PUM	P MOUNTING	G		
4	V977-02	b2	7	3/8	2	HEX HD BOLT GR5	7				7				GRE/	ASE IN	JECTOR MO	UNTING		
5	V977-03	b1	4	5/8	1 1/2	HEX HD BOLT GR5	4				4				BOTT	OM F	RAME, ITEM	'h03' BOLTING	ĵ	
6	V977-03	b2	8	1 1/2	10 1/2	HEX HD BOLT GR5	8				8			8	PILLO	OW BL	OCKS MTG			
7	V977-04	b1	136	3/4	5 1/2	HEX HD BOLT GR5	136				136				CARI	RY RO	LLER MTG			
8	V977-04	b2	136	3/4	3 1/2	HEX HD BOLT GR5	136				136				CARE	RY RO	LLER MTG			
9	V977-04	b3	136	3/4	2 1/4	HEX HD BOLT GR5	136				136				CARE	RY RO	LLER BRACE	KETS MTG		
10	V977-05	b1	54	7/8	7	HEX HD BOLT GR8	54							54	SPRO	CKET	SEGMENTS	TO HUB		
11	V977-07	b1	88	3/4	2	HEX HD BOLT GR5					88				DOO	R MTC	ì			
12	V977-08	b1	8	1	5 1/2	HEX HD BOLT GR5	8				8			8	PILLO	OW BL	OCK TO TAI	KE UP		
13	V977-08	b2	8	1	3 1/2	HEX HD BOLT GR5				8				8	TAKE	E-UP T	O FRAME			
14	V977-08	b3	12	3/4	4	HEX HD BOLT GR5	12				12			12	GUID	E BAI	R MTG			
15	V977-10	b1	48	1 1/2	7 1/2	HEX HD BOLT GR5	48				48				TORG	QUE A	RM ASSEMB	LY		
16	V977-10	b2	12	1/4	1/2	Hex Socket FL HD Cap Screw	12				12				TORG	QUE A	RM ASSEMB	LY		
17	V977-11	b1	4	3/8	1	HEX HD BOLT GR5	4				4				HYDI	RAUL	C ASSIST PO	WER UNIT M	ΓG	
18	V977-11	b2	4	1/4	2 1/2	HEX HD BOLT GR5	4				4				HYDI	RAUL	C ASSIST PC	WER UNIT M	ΓG	
19	V977-11	b3	8	1/4	1/2	HEX HD BOLT GR5					8				HYDI	RAUL	C ASSIST PC	WER UNIT M	ΓG	
20	V977-12	b1	16	1 1/4	3 1/2	HEX HD BOLT GR5	16				16				SHIPI	PING S	SUPPORT TO	FEEDER		
21	V977-501	b1	18	1	6	HEX HD BOLT GR5	18				18							MENTS TO HU		
22	V977-506	b1	4	1/2	1 1/2	HEX HD BOLT GR5	4				4							ST POWER UN	IIT TO MTG BRACKI	ETS
23	V977-518	d518	4	1 1/4	5	SQ HD SET Screw			4						PILLO	OW BI	OCKS			
					<u> </u>			<u> </u>												
					<u> </u>			<u> </u>												
		N	OTN	DIAM	1.0	DESCRIPTION	TTN	TEN.		Y N1	Y XX/	TOXX/	DXX	****	No.	OTN	DYAM	1.0	PECCHIPTION	1
31	ımmary	No.	QIY	DIAM	LG	DESCRIPTION	HN	TN		LN	LW	r w	ВW	HW	No.	QIY	DIAM	LG	DESCRIPTION	
				$\vdash \vdash \vdash$		ļ														
				i i																
																NOT	ES:			
																NOT		8 BOLTS TO B	E ZN PLATED.	
																1. Al	LL GR5 & GR	8 BOLTS TO B	E ZN PLATED. S U.N.O.	
																1. Al	LL GR5 & GR LL DIMENSIO	ONS IN INCHE		
																1. Al 2. Al 3. LN	LL GR5 & GR LL DIMENSION ARE NYLO	ONS IN INCHE: N INSERT HEX	S U.N.O. K LOCKNUT &	
																1. Al 2. Al 3. LN	LL GR5 & GR LL DIMENSION ARE NYLO	ONS IN INCHE: N INSERT HEX	S U.N.O.	
																1. Al 2. Al 3. LN	LL GR5 & GR LL DIMENSION ARE NYLO	ONS IN INCHE: N INSERT HEX	S U.N.O. K LOCKNUT &	
																1. Al 2. Al 3. LN	LL GR5 & GR LL DIMENSION ARE NYLO	ONS IN INCHE: N INSERT HEX	S U.N.O. K LOCKNUT &	
																1. Al 2. Al 3. LN	LL GR5 & GR LL DIMENSION ARE NYLO	ONS IN INCHE: N INSERT HEX	S U.N.O. K LOCKNUT &	
																1. Al 2. Al 3. LN	LL GR5 & GR LL DIMENSION ARE NYLO	ONS IN INCHE: N INSERT HEX	S U.N.O. K LOCKNUT &	
																1. Al 2. Al 3. LN	LL GR5 & GR LL DIMENSION ARE NYLO	ONS IN INCHE: N INSERT HEX	S U.N.O. K LOCKNUT &	
																1. Al 2. Al 3. LN	LL GR5 & GR LL DIMENSION ARE NYLO	ONS IN INCHE: N INSERT HEX	S U.N.O. K LOCKNUT &	
																1. Al 2. Al 3. LN	LL GR5 & GR LL DIMENSION ARE NYLO	ONS IN INCHE: N INSERT HEX	S U.N.O. K LOCKNUT &	
																1. Al 2. Al 3. LN TN	LL GR5 & GR LL DIMENSIC N ARE NYLO N IS TRACK N	ONS IN INCHES N INSERT HEX NUT AND JN IS	S U.N.O. K LOCKNUT &	
																1. Al 2. Al 3. Lh Th	LL GR5 & GR LL DIMENSIC N ARE NYLO N IS TRACK N	ONS IN INCHES N INSERT HEX NUT AND JN IS	S U.N.O. K LOCKNUT & S HEX JAM NUT	
																1. Al 2. Al 3. LN TN	LL GR5 & GR LL DIMENSIC NARE NYLO N IS TRACK N STRIAL EQU 9433 96th Ave	ONS IN INCHES N INSERT HEX NUT AND JN IS	S U.N.O. K LOCKNUT & S HEX JAM NUT UFACTURING LTD. CANADA V4N 4C4	
																1. Al 2. Al 3. Lh Th INDU 109-19	LL GR5 & GR LL DIMENSIC NARE NYLO N IS TRACK N STRIAL EQU 9433 96th Ave	DNS IN INCHES N INSERT HEX NUT AND JN IS IPMENT MAN PORT OF THE STREET HER PROPERTY	S U.N.O. K LOCKNUT & S HEX JAM NUT UFACTURING LTD. CANADA V4N 4C4	
																1. Al 2. Al 3. Lt Tr INDU 109-19 FOR:	LL GR5 & GR LL DIMENSIO N ARE NYLO N IS TRACK N STRIAL EQU P433 96th Ave MEGATECH MEGATECH	DNS IN INCHES N INSERT HEX NUT AND JN IS IPMENT MAN PORT OF THE STREET HER PROPERTY	S U.N.O. K LOCKNUT & S HEX JAM NUT UFACTURING LTD. CANADA V4N 4C4 G LTD.	

No.	DWG	MK	QTY	DIAM	LG	DESCRIPTION	HN	TN	LN	LW	FW	BW	HW				LOCATION		
1	V977-02	fl	20	5/8	2	HEX HD BOLT GR5	20			20				PC SU	JPPOR	RTS TO FRAN	ИE		
2	V977-02	f2	4	1/2	1 1/2	HEX HD BOLT GR5	4			4				LUBE	E PUM	P MTG BRAG	CKET TO MAIN	N FRAME	
3	V977-02	f3	4	5/8	2	HEX HD BOLT GR5	4			4				HPU I	MTG E	BRACKET TO	MAIN FRAM	Е	
4	V977-502	fl	8	3/8	1 1/2	HEX HD BOLT GR5	8			8				PULL	CORD	SWITCH TO	MTG BRACK	ETS	
5																			
6																			
																		1	1
Si	ımmary	No.	QTY	DIAM	LG	DESCRIPTION	HN	TN	LN	LW	FW	BW	HW	No.	QTY	DIAM	LG	DESCRIPTION	
		2																	
		3																	
		4																	
															NOT	ES:			
																	TS TO BE ZN P		
<u> </u>															2. AI	LL DIMENSIO	ONS IN INCHE	S U.N.O.	
<u> </u>														 	n	ampri = = -	· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·	
<u> </u>																		UFACTURING LTD).
-																CONDUME		CANADA V4N 4C4	
-																CONDUMEX		FIELD BOLT I	LIST
																	DATE:	Dwg No.:	REV
															СНКГ		APR 26/12	V977-521	Â

MEGATE	CH PRO	JECT	IEM WO NO). V977	SHIPPIN	IG LIST		SEPT 13/12
2134 Wid	e D8N A	pron Feeder	GA DWG	V977-01	V977-52	2	Rev B	
Item NO.	Q'ty	Description	Mark No	Weight		mensions		
		qty components		in kg	length	height	width	Ship date
1	1	Feeder Assembly	V977-01	66,228	16.60	1.65	3.90	
		1 Bottom Frame	'a03'	5,928				
		1 Top Frame	'a04'	8,425				
		2 21-tooth Sprockets	'A05'	708				
		2 Traction Wheels	'a502'	579				
		11L/11R Return roller assy	'A07L/R'	1,928				
		2 T-up assembly	'a08R/L'	254				
		1 Head shaft assy & FAG SDD23064K	'a09'	3,333				
		1 Tail shaft assy& FAG SAFD22528.415	'b09'	1,607				
		68 D8N Carry rollers	'L1'	6,020				
		D8N Chain 8.5" P.x 149 Links including	'H1'	7,325				
		2 Split Master links/chain						
		149 2134mm Wide Apron pans D8N	'J1'	29,800				
		2 2 1/2x10 HYS 25Mal10-10 Hydr Cylinder	'm505'	20	(TO TIE	UP BEFC	RE SHIP	PING)
		1 Misc and bolts	A520	300				
2	12	Side guard panel - Type A	'A06'	305	1.62	0.22	1.00	
3	2	Side guard panel - Type B	'B06'	55	1.75	0.22	1.00	
4	2	Side guard panel - Type C	'C06'	57	1.88	0.22	1.00	
5	1R/1L	Side guard panel - Type D	'D06'	58	1.55	0.24	1.00	
6	2	Side guard panel - Type E	'E06'	50	1.52	0.22	1.00	
7	1R/1L	Tail guard panel - Type G	'G06L/R'	54	1.61	0.20	1.00	
8	1R/1L	SEW PHF082MC3RLSF06 REDUCER W SWING	'P1, Pa1,					
		Base, Guards and TA	'X1'	9,330	2.75	1.20	1.70	
9	2	R+W Torque Limiter ES1/1500BF, D1: 85.73H7,						
		D2: 50H7	'Pc01'	90				
10	2	Pullcord sw 1-AFU0333-05 Right	'b502R'	3				
11	2	Pullcord sw 1-AFU0333-50 Left	'b502L'	3				
12	2	C4 x 5.4 x 3'-2 1/4" LG	'f02'	16	1.00	0.10	0.04	
13	2	C4 x 5.4 x 2'-1 15/16" LG	'g02'	12	0.66	0.10	0.04	
14	6	L2 1/2 x 2 1/2 x 1/4" x 2'-11 3/4" LG	'h02'	33	0.91	0.07	0.06	
15	1	5 Gal. Hydraulic Power-unit & mtg brckts	'A11,A506'	100	0.61	0.53	0.34	
16	1	#80091 P653s EL Pump c/w Bkt	'A513'	90				

MEGATECH PROJECT						IEM WO NO. V977		SHIPPING LIST		SEPT 13/12
2134 Wide	D8N A	pron Feed	der		GA DWG	V977-01	V977-522		Rev B	
Item NO.	Q'ty			Description	Mark No	Weight	Dimensions, m			
		qty	compon	ents		in kg	length	height	width	Ship date
17	1	NEMA 4X JUNCTION BOX			'Y1'	50				
18	1	FIELD BO	DLTS		'A521'	10				
				Total Weight/Feeder I	67,214	kg				
				То	76,544	kg				