



KNIGHT GLOBAL

Servo Hoist Operation Manual



THIS MANUAL CONTAINS IMPORTANT INFORMATION REGARDING INSTALLATION, SAFETY, MAINTENANCE, AND OPERATION OF THE KNIGHT GLOBAL SERVO HOIST AND SHOULD BE AVAILABLE TO ALL PERSONNEL RESPONSIBLE FOR USING THE HOIST.

REV: 002-202009

This manual provides important information for all personnel involved in the installation, operation and maintenance of the Knight Global Servo Hoist. All personnel must read this document before operating the equipment.

Every effort has been made to provide complete and accurate product information in this manual. However, due to product improvements and changes, discrepancies and omissions may be present. Visit our website at www.knight-ind.com for the updated information on all our products.

It is the responsibility of the end user to exercise common sense and judgment when performing the tasks described in this manual. If any procedure seems inaccurate, incomplete or unsafe please put the equipment in a safe condition and contact Knight Global service department for assistance. Knight service department's phone number is: (248) 375-7962.

Throughout this manual there are steps and procedures that if not performed correctly can result in personal injury or equipment damage. The following signal words are used to identify the level of potential hazard.

	WARNING Indicates a hazard which will cause severe injury, death or substantial equipment damage.
	CAUTION Indicates a hazard which can or will cause injury or equipment damage.
	NOTE Notifies personnel of installation, operation or maintenance information which is important but not hazard related.

1. SAFETY	1
A. General Safety Precautions	2
B. Safety Devices	3
Motor Holding Brake	3
Overload Capacity Protection	3
Run-Stop Push Button	3
Safety Drop Stop (SDS) Chain	3
2. INSTALLATION	5
A. Introduction	6
B. Initial Setup	7
Step 1: Unpacking	7
Step 2: System Assembly	7
Step 2a) Servo Hoist Trolley Installation:	8
Step 2b) Safety Cable Installation:	9
Step 2c) 19-pin Coil Cable Installation:	10
Step 2d) 4mm and 5mm Chain Installation:	11
Step 3: Power Supply to Servo Hoist	12
Step 4: Releasing the Run-Stop button	12
Step 5: Control Handle Set-up	13
Step 5a) Inline Handle setup:	13
Step 5b) Fixture Handle setup:	13
Step 5c) Discrete Up / Down Handle setup:	14
Step 5d) Digital Wireless Remote Up / Down Controller with Run-Stop:	14
Step 6: Test Hoist Movement	15
Step 7: Back-Up Software	15
Step 8: Software Adjustments (If necessary)	15
3. OPERATION	17
A. Principle of Operation	17
B. Model Number	17
Servo Hoist Control Configurations	18
C. Servo Hoist Functionality Modes	19
Run-Stop	19
Shut Down	19
Start Up	19
No Mode	19
Lift Mode	19
Travel Limits	21
Fault Mode	21
4. MAINTENANCE	23
A. CHAIN INSPECTION	23
4.1 Inspection Overview	23
4.2 Use of Chain Safely in Any Application	24
4.3 Determining the Frequency of Chain Inspections	25
4.3.1 Service Rating Load Criteria	25
4.3.2 Service Class (Duty Cycle)	25
4.4 Type of Inspections	26
4.4.1 Frequent Inspection (Visual)	26
4.4.1.1 What to Look for During a Frequent Inspection	26
4.4.2 Periodic Inspection (Documented)	27
4.4.2.1 Recommendations for Periodic Inspections	27
4.4.2.2 Recommended Record Keeping for Periodic Inspections	29
4.4.3 Chain Lubrication:	30
4.4.4 Load Chain Replacement:	30
4.4.5 Double Roller Chain:	31
4.4.5.1 Roller Chain Gauge Replacement Measurement	31
4.4.5.2 Lubricating the Servo Arm Roller Chain	32

4.5 Servo Hoists Inspections	33
4.5.1 Recommendations for Frequent Inspections for Servo Hoists (Visual)	33
4.5.2 Periodic Inspection (Documented)	34
4.6 Load and Safety Drop Stop Chain Replacement (Normal Maintenance)	36
4.6.1 Resetting the Encoder Offset	41
4.7 Broken Chain Replacement	42
4.7.1 Resetting the Encoder Offset	47
5. SOFTWARE	49
A. Getting Started	50
B. Connecting to a Servo Hoist	51
C. Backing up the Knight Servo Hoist Software	54
D. Load a New Drive with Existing Software	58
E. Check or Change Setup Values	62
F. Encoder Offset Setup Procedure	64
G. Operating Test Mode	65
H. Accessing the Servo Hoist's Fault Log	66
6. PARAMETER DESCRIPTIONS	67
A. iSTS Status Array	67
B. fSTS Status Array	67
C. F8L1 Parameter Array	71
D. User Retained Variables Parameter Array	76
E. F8L2 Parameter Array	82
F. F8L3 Parameter Array	89
7. TROUBLESHOOTING	91
A. Troubleshooting Screens	91
B. System Activity screens including Faults, Warnings and Error Codes	101
C. Troubleshooting Inputs and Outputs	108
D. Troubleshooting Chart	109
8. SPARE PARTS LIST	110
9. DECOMMISSIONING OF A SERVO HOIST	110
10. KNIGHT'S PERFORMANCE WARRANTY	111
11. APPENDIX A: USB LOCATION IN SERVO HOIST MANUAL	112
12. APPENDIX B: 250LB AND 500LB SERVO INFORMATION	113
13. APPENDIX C: 350LB, 750LB AND 1000LB SERVO INFORMATION	118

1. SAFETY

Knight Global cannot be aware of or provide for all the procedures by which the Servo Hoist operations or repairs may be conducted and the hazards which may result from each method. If operation or maintenance not specifically recommended by Knight Global is conducted, it must be ensured that product or personnel safety is not endangered by these actions. If not sure of an operation or maintenance procedure or step, personnel should place the Servo Hoist in a safe condition and contact a supervisor and/or Knight Global's service department for technical support. Modifications to upgrade, re-rate or otherwise alter this equipment shall be authorized only by the original equipment manufacturer.

If a below-the-hook lifting device or sling is used with the Servo Hoist, refer to ANSI/ASME B30.9 "Safety Standard for Slings", or ANSI/ASME B30.20 "Safety Standard for Below-the-Hook Lifting Devices".

Electrical equipment described in this manual are designed and built in compliance with ANSI/NFPA 70, "National Electrical Code". It is the responsibility of the system designer, system manufacturer, crane or rail manufacturer, installer, and user to ensure that the installation and associated wiring of the Servo Hoist and components are in compliance with ANSI/NFPA 70, and all applicable Federal, State and Local Codes.

Hazardous voltages are present in the Servo Hoist and components. Only properly trained and competent personnel should perform inspections or repairs on the Servo Hoist or accessories. Prior to performing any maintenance (mechanical or electrical) on the Servo Hoist, de-energize (disconnect) the main switch supplying power to the Servo Hoist. Lock out the power supply following standard plant procedures.

Ensure that the installation, inspection, testing, maintenance and operation are in compliance with ANSI/ASME B30.16 "Safety Standard for Overhead Hoists", OSHA Regulations, ANSI/NFPA 70, National Electric Code, and applicable ANSI/ASME standards. This is the responsibility of the owner/operator.

All personnel that will install, operate, inspect, test or maintain the hoist should read this manual and be familiar with all applicable portions of the referenced standards.

If clarification of any information in this manual or additional information is required, contact Knight Global. Do not install, operate, inspect, test or maintain the hoist unless all information is understood.

A. General Safety Precautions

- Do not operate the Servo Hoist before reading this technical manual.
- Allow only personnel trained in safety and operation of this Servo Hoist to operate the Servo Hoist.
- If the Servo Hoist is locked out or a "DO NOT OPERATE" sign is on the Servo Hoist or controls, do not operate the Servo Hoist until the lock or sign is removed by designated personnel.
- Do not use the Servo Hoist if hook's safety latch has been sprung or broken.
- If the Servo Hoist utilizes a hook, ensure the hook's safety latch is engaged before operating the hoist.



- Before each shift or prior to use, inspect the Servo Hoist in accordance with the procedures defined in the Maintenance section of this manual.
- Never place your hand or fingers inside the throat area of a hook.
- Never operate a Servo Hoist with twisted, kinked or damaged chain.
- Only operate a Servo Hoist when the chain is centered over the hook. Do not "side pull" or "yard" the chain.
- Do not force the hook into place by hammering.
- Ensure the load is properly seated in the saddle of the hook.
- Never run the chain over a sharp edge.
- Pay attention to the load at all times when operating the Servo Hoist.
- Ensure no personnel are in the path of the load.
- Do not lift the load over personnel.
- Never use a Servo Hoist for lifting or lowering people.
- Do not allow anyone to stand on a suspended load.
- Do not swing a suspended load.
- Never leave a suspended load unattended.
- Never cut or weld a suspended load.
- Do not operate a Servo Hoist if the chain is jumping, jamming, overloading or binding.
- Do not operate a Servo Hoist if it is generating excessive noise.
- Avoid collisions or bumping of the Servo Hoist.
- Do not operate Servo Hoist when damaged or malfunctioning.
- Do not remove load or handling device until tension is released from the chain.
- Discontinue operation of Servo Hoist after multiple unresolved faults. A system fault would be signified by the Red light on the Run-Stop button continuously flashing or the Run-Stop button having to be repeatedly reset.

B. Safety Devices

Motor Holding Brake

A motor holding braking system engages and holds the vertical axis in place in the event of a power outage or when the Run-Stop button is pressed.

Overload Capacity Protection

Protects the equipment and prevents the operator from lifting or moving more weight than the system is rated for. If the load weight exceeds the programmed capacity, the hoist will not lift any further until the excess load is removed. Downward motion is permitted when overloaded to allow the user to safely set the weight back down on a stable surface.

Run-Stop Push Button

If an operator needs to shut down the system immediately, the operator pushes the Run-Stop button. The system will not function until it is reset. To reset the system from the Run-Stop condition, the operator turns the button clockwise to release it from the depressed position. All virtual limits and programs remain intact.

Safety Drop Stop (SDS) Chain

All Standard units have a Safety Drop Stop (SDS) chain included. The SDS Chain moves up and down the vertical axis with the load chain. It provides load stabilization in the event of a catastrophic load chain failure. This unique feature has a US Patent NO. 10,099,904 awarded as of 2018.

2. INSTALLATION

Prior to installation, visually inspect the Servo Hoist for signs of damage or missing parts.

	CAUTION
	Prior to installation, the chain must be lubed using a SAE 50 to 90 EP oil. Follow the procedure detailed in section 4.4.3 “Chain Lubrication” of this manual. Knight Global recommends the use of Demag Chain Grease. The part number of the Demag Chain grease tube is 665 009 44.

	CAUTION
	Prior to placing this unit into service, the owners and user are advised to examine specific local and/or other regulations, including ANSI and OSHA regulations that may apply to the use of this product.

	WARNING
	A falling load can cause injury or death. Before installing this hoist read the “Safety” section of this manual.

Follow all procedures in this section for installation and set-up of the Servo Hoist.

Retain all product information supplied with the Servo Hoist for future reference.

Ensure that the supporting structure is able to support the weight of the system and load. The structure should be able to support 300 percent of the combined weight of the Servo Hoist and load. Do not use a supporting structure that tilts the Servo Hoist to one side or the other.

For safe and proper installation into a rail system, refer to the installation manual provided by the rail system manufacturer.

When installation is complete and prior to placing the Servo Hoist into operation, inspect the Servo Hoist following the instructions in section 4.4.2.1 “Recommendations for Periodic Inspections” of the “Maintenance” portion of this manual.

A. Introduction

Prior to installing and operating the Knight Servo Hoist, all operators using this device should be familiar with the main components of the lifting system. (Refer to Figure 2-1)

Servo Hoist: The Servo Hoist assembly is a powered lifting device. The upper drive assembly contains the servo motor with holding brake, gearbox, servo drive, power contactor, 24 VDC Power Supply, regen board, chain bucket, chain guide assembly, and AC Plug.

Coiled Cable Assembly: In most cases, a 19-pin coil cable carries signals from the control handle to the Servo Hoist. Some examples are: Analog load cell voltages, digital inputs and outputs including direction commands, Lift Mode, Float Mode, and Run-Stop signals. In some cases, a 19-pin strait cable carries some or all of these signals to the Servo Hoist.

Control Handle: The main interface between the operator and the lifting device. The handle can be an inline handle, a fixture handle, or a discrete up / down handle.




Figure 2-1

B. Initial Setup

Step 1: Unpacking

- 1) Unpack the Servo Hoist. Lift the hoist carefully out of packaging.
- 2) Keep the accompanying documents with the hoist or near the site of operation.

Step 2: System Assembly

Knight Servo Hoists are typically delivered pre-assembled; if not, read the following sections.

- 2a) Servo Hoist Trolley Installation
- 2b) Safety Cable Installation
- 2c) 19-pin Coil Cable Installation
- 2d) 4mm and 5mm Chain Installation

Step 2a) Servo Hoist Trolley Installation:

Prior to installation visually inspect the trolley for signs of damage or missing parts.

- 1) Slide the trolley or adapter plate into the trolley mounting plate on top of the Servo Hoist.
(Refer to Figure 2-2)

	CAUTION Ensure that there is a (2) two-point connection when using the universal adapter plate to hang the hoist from a structure. (Refer to Figure 2-3)
---	---

- 2) Insert the (2) two ½-13x1¾" (grade 8 or better) socket head cap screws (SHCS) and (2) two washers.

	NOTE The trolley should be mounted offset of the load distribution.
---	--

- 3) Secure the (2) two SHCS with (2) two ½-13 reverse lock nuts. As each bolt is tightened, the reverse lock nut will get drawn into its slot and get trapped there.
- 4) Install the safety cable through the servo trolley or adapter and the trolley mounting plate.
(Refer to Step 2b "Safety Cable Installation")
- 5) Roll hoist into rail system.




Figure 2-2




Figure 2-3

Step 2b) Safety Cable Installation:

- 1) Slide thimbles together. (Refer to Figure 2-2)
- 2) Slide (2) two Crosby cable clamps onto the cable.
- 3) Loop the end of cable around thimble and run the end through the Crosby clamps.
The cable saddle (forged part) rests on the "live" (longer) end of the cable.
The U-bolt rests on the "dead" (shorter) end of the cable. (Refer to Figure 2-3)
- 4) Tighten each nut on a single clamp, alternating sides. Repeat this procedure on the other clamp.
Each nut should be tightened to a minimum of 15 ft-lbs.
- 5) Follow the steps below for trolley or adapter plate.
- 6) Insert cable through the center hole on the trolley bracket which is attached to the hoist and place (2) two Crosby clamps on the other end of the cable. (Refer to Figure 2-4)
- 7) Secure the (2) two Crosby clamps snug to the thimble, repeating step 3.
- 8) Install the cable so that the Servo Hoist has a drop of not more than 1 in. [2.54 cm].
- 9) Trim excess cable and tape ends of cable to prevent fraying. (Refer to Figure 2-4)





Figure 2-2



Step 2c) 19-pin Coil Cable Installation:

- 1) Ensure power is removed from hoist.
- 2) Slide the 19-pin coil cable upward over the chain and into the clamping assembly.
- 3) Secure the (4) four M6 nuts onto the bolts that pass through the clamping assembly from the bottom of the Servo Hoist. (Refer to Figure 2-6)
- 4) Connect the 19-pin connector to the bottom of the Servo Hoist. (Refer to Figure 2-7)
- 5) Seat both chains into the control handle's chain nest. Secure both of the chain's retaining bolts through the provided holes in the chain nest. (Refer to Step 2d "4mm and 5mm Chain Installation")
- 6) Loosen the (2) two M4 screws holding the 19-pin receptacle and slide it out of the control handle's housing. (Refer to Figure 2-8)
- 7) Connect the 19-pin connector to the receptacle, slide it back into the control handle's housing and secure the (2) two M4 screws. (Refer to Figure 2-9)
- 8) Secure the (2) two M6 bolts for each of the handle coil cable clamping rings located on top of the control handle. (Refer to Figure 2-9)




Figure 2-6




Figure 2-7




Figure 2-8




Figure 2-9

Step 2d) 4mm and 5mm Chain Installation:

	CAUTION
	DO NOT CUT CHAIN TO SHORTEN IT! The chain will be reeled into the hoist in Section 2, Step 5 “Control Handle Set-up”.

- 1) Thread both chains through the coil cable.
- 2) Place the load chain into the top portion of the chain nest and insert the bolt provided thru chain nest in front of load chain's last link. A M4 allen wrench is required if the servo's capacity is 250 or 500lbs. Otherwise both M4 and M5 allen wrenches will be required. (Refer to Figure 2-10)
- 3) Ensure that both chains are parallel with no twists from the gear box down to the chain nest.
- 4) Install the last link of the Safety Drop Stop (SDS) chain into the lower portion of the chain nest in front of the load chain. Ensure that the SDS chain is kept parallel to the load chain.
- 5) Install the bolt provided into the bottom bolt hole in the chain nest and through the last link in the SDS chain. (Refer to Figure 2-13)
- 6) Ensure that the large O-ring is fitted into the groove of the chain nest and the small O-ring is just above the chain nest but below the safety chain ID tag. (Refer to Figure 2-14)
- 7) Figure 2-15 shows the completed installation of both chains into the chain nest.




Figure 2-10




Figure 2-11




Figure 2-12




Figure 2-13

Step 3: Power Supply to Servo Hoist

Prior to installation visually inspect the Servo Hoist for signs of damage or missing parts.

Power Requirements: Call a Knight Representative to obtain the correct power requirements for your system.
Standard: 240 VAC Single Phase 50/60 Hertz.

Refer to system specific documentation for any special power requirements.

- 1) The Servo Hoist power is connected by a twist lock plug (Refer to Figure 2-16: Standard) or fed by a hard-wired circuit, provided by end user (Refer to Figure 2-17: CE Compliant).
- 2) After power has been applied and the servo has finished its boot-up sequence, the red light on the Run-Stop button will illuminate.




Figure 2-16: Standard



Figure 2-17: CE Compliant

Step 4: Releasing the Run-Stop button

The Run-Stop button is engaged for shipping purposes.

- 1) Turn Run-Stop button a quarter of a turn clockwise to release the Run-Stop and wait for red light to turn off. (Refer to Figure 2-18)
- 2) Please, refer to the Run-Stop mode functionality in section 3.C. "Servo Hoist Functionality Modes" of this manual for more information.



Figure 2-18

Step 5: Control Handle Set-up

There are (4) four control handle configurations. This section discusses the correct setup of each of these.

- 5a) Inline Handle setup
- 5b) Fixture Handle setup
- 5c) Discrete Up / Down Handle setup
- 5d) Digital Wireless Remote Up / Down Controller with Run-Stop

Step 5a) Inline Handle setup:

- 1) Hold the inline handle and trigger with one hand, and hold the chain away from the inline handle with other hand. (Refer to Figure 2-19)
- 2) Apply upward pressure on inline handle until the green light flashes.
- 3) Once green light starts flashing, release the inline handle and the GREEN light will illuminate.
- 4) Grasp the inline handle and apply upward pressure until the chain starts feeding into the hoist. Continue this until the inline handle is hanging vertically from the hoist at a comfortable height.



Figure 2-19

Step 5b) Fixture Handle setup:

- 1) Set-up the fixture handle into the orientation in which it will be used in the application. Refer to the layout drawings for the application to determine this. (Refer to Figure 2-20)
- 2) Apply upward pressure on fixture handle until the green light on the Operator Control Interface (OCI) flashes. (Refer to Figure 2-21)
- 3) Once green light starts flashing, release the fixture handle and the GREEN light will illuminate.
- 4) Grasp the fixture handle and apply upward pressure until the chain starts feeding into the hoist. Continue this until the fixture is hanging from the hoist at a comfortable height.



Figure 2-20



Figure 2-21

Step 5c) Discrete Up / Down Handle setup:

- 1) Press the Up lever until the green light on the Operator Control Interface (OCI) starts to flash. (Refer to Figure 2-22)
- 2) Once the green light starts flashing, release the Up lever and the GREEN light will illuminate.
- 3) Press the Up lever again until the chain starts feeding into the hoist. Continue this until the fixture is hanging from the hoist at an acceptable height.

**Step 5d) Digital Wireless Remote Up / Down Controller with Run-Stop:**

- 1) Press the Up button until the green light on the Operator Control Interface (OCI) starts to flash. (Refer to Figure 2-23)
- 2) Once the green light starts to flash on the OCI, release the Up button until the green light illuminates.
- 3) Press the Up button again until the chain starts to feed into the hoist. Continue holding the Up button until the fixture is hanging from the hoist at an acceptable height.



	NOTE
	A continuously flashing GREEN light indicates a safe start activation fault. The system is sensing commanded motion during the Power-Up sequence. <u>Remedy</u> Analog Handle: Release the handle and verify that the GREEN light illuminates solid. If the GREEN light still flashes after the handle is released, refer to section 7. "Troubleshooting". Up/Down Pendant: Release both buttons and verify that the GREEN light illuminates solid. If the GREEN light still flashes after the button is released, refer to section 7. "Troubleshooting".

Step 6: Test Hoist Movement

Test the Servo Hoist movement by applying upward and downward pressure on the inline or fixture handle. If the system uses a discrete Up / Down handle, press the Up and Down levers to move the fixture up and down.

Step 7: Back-Up Software

Knight Servo Hoists are pre-programmed prior to delivery. It is a good practice to back-up this software before initial operation. Refer to the section 5. 'Software' portion of this manual for instructions to connect to the Servo Hoist and to back-up the software.

Step 8: Software Adjustments (If necessary)

After making a back-up of the software in step 7, it may be necessary to adjust certain parameters in the software to ensure that the servo performs correctly for a specific application. Refer to the following first-time adjustments in section 5. 'Software'.

- Verify the hoist's maximum weight. This is also known as the Up Stop weight of the hoist.
- Verify the hoist's minimum weight. This is also known as the Down Stop or pay out weight of the hoist.
- Verify the hoist's fixture weight.
- Verify that the analog handle is balanced.
- Verify that the encoder offset is correct.

3. OPERATION

A. Principle of Operation

The Servo Hoist system receives a command to move up or down along the “Z” axis from any input force applied to the handles or by pressing the Up or Down levers.


B. Model Number

The Servo Hoist model number designates the Servo Hoist type and its specifications. (Refer to Figure 3-1) The first set of letters indicate the type of Servo Hoist. Please refer to Table 3-1 for the Servo Hoist Type prefix letters. The numbers following the Servo Hoist Type prefix letters reference the system's rated capacity. Next, we have an “S” to designate our Safety Drop Stop feature. The next (3) three numbers indicates the voltage and then the following number indicates the phase of the system. The last (3) three digits are an inhouse control servo code.

The hoist's model number and serial number can be found on the Knight identification label located on the Servo Hoist.

Letters	Servo Hoist Type *
KSH	Single Chain
KSHTC	Twin Chain
KSHTCDM	Twin Chain Dual Motor
KSHFA	Floor Mounted Articulating Arm
KSHCA	Overhead Carriage Articulating Arm
KSHEA	Extension Arm
KSHVA	Vertical Arm
KSHVAA	Vertical Articulating Arm
KSHXZ	Servo Hoist and Tractors with X and Z Movement
KSHXYZ	Servo Hoist and Tractors with X, Y, and Z Movement

Table 3-1



* For all models and specifications, refer to the website: <https://www.knightglobal.com/servo.html>.

** All Knight Servo Hoists include a Safety Drop Stop chain that travels with the load chain to support the fixture in the event of a catastrophic load chain failure.

Servo Hoist Control Configurations




Figure 3- 2

NUMBER	DESCRIPTION
1	KNIGHT SERVO HOIST (xxxx = CAPACITY in LBS.)
2	KNIGHT 19-PIN COIL CABLE (xx = FT.)
3	KNIGHT 19-PIN STRAIGHT CABLE (xx = FT.)
4	KNIGHT LOAD MONITORING MODULE WITH OPERATOR CONTROL INTERFACE (OCI)
5	KNIGHT ANALOG INLINE HANDLE
6	KNIGHT LOAD MONITORING MODULE (LMM)
7	KNIGHT DUAL SPEED HANDLE PENDENT
8	KNIGHT FIXTURE HANDLE WITH INTERNAL LOAD CELL
9	KNIGHT OPERATOR CONTROL INTERFACE (OCI)
10	KNIGHT DUAL SPEED HANDLE WITH OPERATOR CONTROL INTERFACE (OCI)

C. Servo Hoist Functionality Modes

Run-Stop

Step 1. Press the RUN-STOP button, located on the Operator Control Interface (OCI) module.

- Drive power is removed from the system and the holding brake is set.
- The Run-Stop button will flash red.

Recovery:

Step 1. Reset the RUN-STOP button by twisting it a quarter of a turn clockwise.

Shut Down

Step 1. Press the RUN-STOP button, located on the Operator Control Interface (OCI).

Step 2. Follow the warning labels on the Servo Hoist and disconnect the power supplied to the unit.

Start Up

Step 1. Connect the power supply to the unit.

Step 2. Reset the RUN-STOP button by twisting it a quarter of a turn clockwise.

- The hoist will power up and the OCI's RED and GREEN indications will briefly flash when the system is ready to function.
- The unit will then default to No Mode: the OCI's GREEN, BLUE, and RED indicators will turn off.

No Mode

When the Servo Hoist powers up or if it is inactive for a continuous time period, the unit will shift to this energy saving mode. The factory default time period is 15 minutes. The holding brake will engage and power will be removed from the motor while No Mode is active. When the unit is in No Mode, the OCI's GREEN, BLUE, and RED indicators will be off.

Lift Mode

Press the GREEN (Lift) button to place the Servo Hoist into Lift Mode.

- The GREEN (Lift) indicator will illuminate.

	NOTE
	A continuously flashing GREEN light indicates a safe start activation fault. The system is sensing commanded motion during the Power-Up sequence. Remedy Analog Handle: Release the handle and verify that the GREEN light illuminates solid. If the GREEN light still flashes after the handle is released, refer to section 7. "Troubleshooting". Up/Down Pendant: Release both buttons and verify that the GREEN light illuminates solid. If the GREEN light still flashes after the button is released, refer to section 7. "Troubleshooting".

Systems with In-line or Fixture Handle Style Lift Controls:

- Step 1. Apply force to the handle in the desired direction of travel (upward or downward).
The travel speed of the fixture is proportional to the force applied to the handle.

Systems with Discrete Up / Down Style Lift Controls:

- Step 1. Press the Up or Down button to move the hoist in the desired direction.



NOTE

If the hoist is in No Mode and a lift command is given to the system, the hoist will automatically go into Lift Mode.

Float Mode

- Step 1. Press the BLUE (Float) button to place the Servo Hoist into Float Mode.
When the BLUE button is pressed, a snapshot is taken of the load that is attached to the end of the hoist (i.e. the system records the weight suspended from the fixture).
The BLUE (Float) indicator will illuminate.
- Step 2. Apply pressure to the top of the part to move it down or lift up on the part to move it up.
Do not use the lift controls to move the part as this will place the hoist back into Lift Mode.



WARNING

An operator should never be able to release a load while in Float mode. The operator must switch to Lift mode in order to release a load.



NOTE

If the Knight controls team programmed the hoist, it will never release or unclamp a part while it is in Float mode. The hoist will have to be switched to Lift mode for a part to be released or unclamped.

To change from Float Mode to Lift Mode, follow any of the steps below:

- Operate the lift controls. The hoist will automatically change to Lift Mode and then it will move the fixture or handle up or down.
- Press the GREEN (Lift) push button and the unit will change into Lift Mode.
- Allow the Float Mode Timeout timer to expire. This timer is set at the factory to 5 minutes of non-use. To change this timer, refer to section 6. 'Variable Descriptions' in the Software section.



NOTE

The part must be picked up while the hoist is in Lift Mode and then the operator may place the Servo Hoist into Float Mode.



NOTE

Do not rest your hand on the part when pressing the Float push button. This can cause a bias or an incorrect zero value measurement to be processed and may cause unintended movement.



NOTE

Use of the Lift Mode controls will prevent the unit from remaining in or changing to Float Mode.

Travel Limits



NOTE

During operation (Lift or Float Mode) the hoist will ramp down in speed as the travel limits are approached.



NOTE

The absolute upper and lower travel limits are factory set to the physical limits of the Servo Hoist. Contact a Knight Global Representative for information regarding changes to these absolute limits.

Fault Mode

The Red light will flash.

Step 1. Press the RUN-STOP button, located on the Operator Control Interface (OCI).

- Drive power is removed from the system and the holding brake is set.
- The RUN-STOP button will flash red.

Recovery:

Step 1. Correct the situation that caused the fault.

Refer to section 7.B. "System Activity screens including Faults, Warnings and Error Codes" for a list of common faults.

Step 2. Follow the Start Up procedure to restore power to the unit.

4. MAINTENANCE

A. CHAIN INSPECTION

4.1 Inspection Overview

The inspection procedures and recommendations in this manual are based on ANSI/ASME B30.16 "Overhead Underhung and Stationary Hoists" and ISO7592-1983 "Calibrated Round Steel Link Lifting Chains -- Guidelines to proper use and maintenance." The following definitions and recommendations are from both specifications and pertain to the recommended inspection procedures in this manual.

Qualified Person: A person who, by possession of a recognized degree in an applicable field, or certificate of professional standing, or who by extensive knowledge, training and experience, has successfully demonstrated the ability to solve or resolve problems relating to the subject matter at work.

Designated Person: A person selected or assigned by the employer or the employer's representative as being competent to perform specific duties.

Abnormal Operating Conditions: Environmental conditions that are unfavorable, harmful, or detrimental to the operation of a hoist, such as excessively high or low ambient temperatures, exposure to weather, corrosive fumes, dust laden or moisture laden atmospheres, and hazardous locations.

4.2 Use of Chain Safely in Any Application

Balance: Know the Load - determine the weight, center of gravity, angle and lift.	
Overload: Never Overload the Chain - check the working load limit on the identification tag.	
Knots, Twists and Kinks - Ensure chain is not twisted, knotted or kinked before lifting load. Chains should not be shortened with knots, bolts or other make-shift devices.	
Sharp Edges - Protect chain with padding when lifting sharp edged loads.	
Abrupt Movement - Lift and lower loads smoothly. Do not jerk.	
Extreme Temperatures - Do not expose alloy chain to temperatures of 400°F or higher or -40°F or lower.	

4.3 Determining the Frequency of Chain Inspections

Knight recommends utilizing load criteria and duty cycle data when determining the frequency of inspections. Inspection frequency should be identified by a qualified person and is based on factors such as the severity of the environment the hoist is being used in, percentage of capacity lifts, cycle time and shock loading. Each Servo Hoist should be rated individually and inspections performed in accordance with that rating.

Proper maintenance depends on an evaluation of the severity of usage to which the hoist and the chains are subjected to in the specific application.

The overall determination of how often the hoist and chains should be inspected is a combination of its Service Rating Load Criteria (4.3.1) and its Service Class or Duty Cycle (4.3.2).

4.3.1 Service Rating Load Criteria

Light Service: Hoist and chains normally subjected to light loads and very rarely to maximum loads.

Moderate Service: Hoist and chains normally subjected to moderate loads but fairly frequently to maximum loads.

Heavy Service: Hoist and chains normally subjected to loads of heavy magnitude and frequently to maximum loads.

Very Heavy Service: Hoist and chains regularly subjected to maximum loads.

4.3.2 Service Class (Duty Cycle)

Service Class is determined by the total number of cycles the system has performed. (Table 4-1)

- Service Class 0: 0 to 20,000 loaded cycles.
- Service Class 1: 20,001 to 100,000 loaded cycles.
- Service Class 2: 100,001 to 500,000 loaded cycles.
- Service Class 3: 500,001 to 2,000,000 loaded cycles.
- Service Class 4: over 2,000,000 loaded cycles.

Cycles Per Day	Desired Life (Years)				
	1	5	10	20	30
5	0	0	0	1	1
10	0	0	1	1	2
25	0	1	1	2	2
50	0	1	2	2	3
100	1	2	2	3	3
200	1	2	3	3	4
300	2	3	3	4	4
750	2	3	4	4	4
1,000	2	3	4	4	4

Table 4-1: Service Class

Example: If the system is performing 100 cycles per day, it will progress through Service Classes during its use:

1 year	26,000 cycles	Service Class 1
5 years	130,000 cycles	Service Class 2
10 years	260,000 cycles	Service Class 2
20 years	520,000 cycles	Service Class 3
30 years	780,000 cycles	Service Class 3

4.4 Type of Inspections

The inspection procedure is divided into two general classifications based upon the intervals at which the inspections should be performed for the hoist and chains during regular use. The general classifications are herein designated as "frequent" and "periodic" with respective intervals between inspections as defined below.

In addition, visual observations shall be conducted during regular service for any damage or evidence of malfunction which might occur between regular inspections.

4.4.1 Frequent Inspection (Visual)

This is a visual examination of the hoist and its chains by the operator or other designated personnel, without requiring records to be made. This inspection should be carried out at the following intervals:

A. Light Service	or	Service Class 0 / 1	– Every Month
B. Moderate Service	or	Service Class 2	– Every Two Weeks
C. Heavy Service	or	Service Class 3	– Every Week
D. Very Heavy Service	or	Service Class 4	– Every Day

Additionally, the operator should check the system continually during operation to ensure that no malfunctions are occurring (such as abnormal noises or binding of the chain).

4.4.1.1 What to Look for During a Frequent Inspection

Operator should examine the chain throughout its working length to detect any evidence of wear, distortion or external damage. Equipment should be operated under a load as near as possible to the usual operating load, in both directions and observe the functioning of the chain. The chain should feed smoothly into and out of the servo. Additionally, the operator should check the system continually during operation to ensure that no malfunctions are occurring.

- Check for visual signs or abnormal noises (grinding etc.) which would indicate a potential problem.
- Ensure controls function properly and return to neutral when released.
- Ensure the load chain feeds through the hoist correctly.
- Ensure that the chain doesn't bind, is excessively noisy or "clicks" as it leaves the bottom of the servo.

If any of these abnormal conditions are evident, the Servo Hoist should be taken out of service and a detailed inspection and corrective actions should be taken by qualified maintenance personnel.

4.4.2 Periodic Inspection (Documented)

This is a thorough examination of the hoist and its chains conducted by a qualified person, making records of external conditions to provide a basis for the hoist's continuing evaluation. This Inspection should be carried out at the following intervals:

- A. Light Service or Service Class 0/1 – **Yearly**
(equipment remains in place).
- B. Moderate Service or Service Class 2 – **Every Six Months**
(equipment remains in place unless external conditions indicate that disassembly should be done to permit detailed inspection).
- C. Heavy Service or Service Class 3 – **Every Three Months**
(equipment remains in place unless external conditions indicate the disassembly should be done to permit detailed inspection).
- D. Very Heavy Service or Service Class 4 – **Every Six Weeks**
(equipment remains in place unless external conditions indicate that disassembly should be done to permit detailed inspection).

4.4.2.1 Recommendations for Periodic Inspections

Perform the inspection detailed under section 4.4.1.1 "Ideas Regarding What to Look for During a Frequent Inspection" of this manual.

Next, the chains should be cleaned for inspection, using any cleaning method that will not cause damage. Adequate lighting should be provided for the person inspecting the chain. The chain should be examined link by link for cracks, gouges, nicks, distortion, corrosion, deposits of foreign material, and for interlink wear. To inspect for wear at the interlink contact points, slacken the chain and rotate adjacent links to expose the inner ends of the link. If wear is observed or if elongation is suspected, measure the chain using the supplied chain gauge shipped with the servo hoist.

A. Chain Link Thickness

If chain is worn to less than the minimum allowable thickness (T), remove the chain from service. (Refer to Figure 4-1)



Minimum Allowable Chain Link Thickness at Any Point

Nominal Chain Size		Minimum Thickness "T"	
Inches	mm	Inches	mm
.157	4.0	.137	3.48
.196	5.0	.171	4.35

Figure 4-1

B. Chain Gauge Replacement Measurement for 4mm and 5mm Load Chains

1. Determine which type of chain is being inspected, either 4mm or 5mm, by placing a single link into the chain gauge where the arrows are located. (Refer to Figure 4-2)
2. Raise the hoist to the full up position and mark the chain.
3. Lower the hoist to the full down position.
4. Select 13 links starting with the link that was marked in step 2.
5. The 13-selected links should fit loosely onto gauge prongs as shown below. If links number 1 and 13 do not fit onto prongs or have to be forced into selection, replace the load chain. This length has stretched 2% or more and should be removed from service and replaced with new chain.
6. Perform this inspection in multiple sections of the chain working up to the sprocket.




Figure 4-2

C. If Chain Gauge is Not Available

- Select an unworn, un-stretched length of the load chain.
- Suspend the chain vertically under tension. Use a caliper type gauge to measure the accumulated pitch of between 5 and 13 links.
- Measure the same number of links throughout the used chain and calculate the percentage increase in length.
- The chain should be replaced if the gauge length measured over any 5, 7, 9, 11, or 13 links as appropriate exceeds that of the unused chain by 2%.

D. Rejection Criteria

The chain should be rejected and replaced if any of the following conditions are observed: (Refer to Figure 4-3)

- Cracked or worn links
- Severe nicks or gouges
- Twisted or bent links
- Severe corrosion
- Deposits which cannot be removed
- Increase in gauge length which exceeds the manufacturer's recommendations. In the absence of manufacturer's recommendations, the chain should be replaced if the gauge length measured over any 5, 7, 9, 11, or 13 links as appropriate exceeds that of the unused chain by 2%.




Figure 4-3

4.4.2.2 Recommended Record Keeping for Periodic Inspections

Adequate records as a part of periodic inspection are essential for the proper use of calibrated chains. The chain record should include a complete description and identification of the new chain, the date and results of each inspection, the date and results of each test and the date and description of any maintenance.

The record is a continuous history of the chain and shows that it has been regularly inspected and maintained in good operating condition.

When the chain is removed from service, a new record should be prepared for the replacement chain.

4.4.3 Chain Lubrication:

Keep chain well lubricated. Never operate a hoist when the load chain does not flow freely and smoothly into and out of the gear box assembly or when it makes noises indicative of binding or other malfunctions. Replace the chain if it is visibly damaged in any way.

Clean, lubricate, and inspect the load chain based on the frequent inspection criteria described in section 4.4.1. In a corrosive environment, lubricate more frequently than normal. Failure to maintain a clean and well lubricated load chain will result in rapid load chain wear that can lead to chain failure which can cause severe injury, death or substantial property damage.

If required, clean the chain with acid free solvent to remove rust or abrasive dust buildup before the chain is lubricated.

Lubricate each link of the chain with a light coat of SAE 50 to 90 EP oil or equivalent machine/gear oil. Ensure that oil is applied to the bearing surfaces of the load chain links. Wipe off excess oil from the load chain surfaces. Substitute a dry lubricant for use in dusty environments. Knight recommends Demag Chain Grease: P/N 665 009 44. (Refer to Figure 4-4: Chain Lubrication)

Lubricate hook and safety latch pivot points with same lubricant used on the load chain.

Lubricate chain without load on chain. This will allow lube to penetrate between links.

	WARNING Failure to maintain clean and lubricated load chain will void the manufacturer's warranty.
---	--



Figure 4-4: Chain Lubrication

4.4.4 Load Chain Replacement:

Care should be taken to re-install the chain without any twists down the entire chain's length between the gear box and its anchored end in the chain nest. Proper orientation of the entering link should be established since a twist cannot be corrected except by removing and re-installing the chain.

Refer to 4.6 "Load and Safety Drop Stop Chain Replacement (Normal Maintenance)" for further instructions on how to replace load chain.

4.4.5 Double Roller Chain:



Over time the chain elongates as it wears leading to a significant increase in actual pitch and potential chain failure. When the normal pitch length has been extended by 2-3%, the service life of the chain is significantly reduced and the ultimate breaking strength is considerably lower. At 2% elongation a qualified service technician must set a safe time limit for replacement. At 3% the chain must be replaced immediately.

Knight Global provides a Roller Chain Gauge with each roller chain hoist.

The roller chain should be checked at intervals depending on the service and load conditions. (Refer to section 4.3)

4.4.5.1 Roller Chain Gauge Replacement Measurement

Roller Chains should be cleaned for inspection, using any cleaning method that will not cause damage.

1. Close gauge to confirm calibration: Check the calibration by closing the slide fully.	
2. Read the 'Percentage Wear' window: When the gauge is fully closed, if the black arrow moves into the '+' or '-' zones, the gauge will not give an accurate measurement and should not be used. Similarly, if the 'V' jaws are damaged the instrument may also not perform accurately.	
3. Identify the pitch: Align the red arrows within the center of the pins on ONE of the OUTER link plates. Depending on ease of access, one pair of arrows will be more suitable than the others. The normal pitch will appear in the 'Pitch' window. The number of pins (n) that the chain is to be measured over will appear in the 'Measure over pins' window.	
4. Select the Correct side of the gauge: Select the correct scale according to pitch size. Once the pitch is determined, the number of pins to measure is displayed. Knight's Roller Chain uses the "A Scale" side. NOTE: "A Scale" side = 3/8", 1/2", 5/8", 3/4", 1", 1 1/4", 1 1/2", 2 1/2", and 3". "B Scale" side = 1 3/4" x 2"	

Continued on next page

5. Measure the Chain:

The chain should be cleaned and measured in its location while placed under approximately 1% of the minimum breaking load. If a set of check weights is not available, it is sufficient for the chain to be tensioned by the weight of the carriage and lift assist.


Identify the section of the chain that regularly runs over the pulley as this part of the chain is most susceptible to wear. Measurements must then be made in at least 3 separate locations on this section.

Place the 'V' jaw of the chain gauge over the first pin of one of the selected sections and then extend the slide until the other 'V' jaw reaches the final pin. The final pin will be the one that appeared in the 'Measure over pins' window as previously determined in step 3.



6. Read off the Percentage:

Check the 'Percentage Wear' windows. A percentage will appear in 0.25% (¼%) increments. If the chain has elongated by 2% or more, the warning window will be filled with red and necessary action must be taken.



4.4.5.2 Lubricating the Servo Arm Roller Chain

After changing the roller chain, before a test load is lifted and before the hoist is put into operation as well as during normal operation when no load is attached, the chain link contact areas must be lubricated with Demag gear grease, part no. 665 009 44.

The chain link contact areas must be re-lubricated appropriately – after being cleaned – at intervals depending on the service and load conditions.

Knight recommends the roller chain be lubricated periodically in accordance with section 4.4.3 Chain Lubrication.

Cut off the tip of the grease tube and inject grease into the chain's links by compressing the tube while you run the chain to its end positions to ensure complete and even lubrication of the chain.

B. PREVENTATIVE MAINTENANCE FOR KNIGHT SERVO HOIST

4.5 Servo Hoists Inspections

4.5.1 Recommendations for Frequent Inspections for Servo Hoists (Visual)

This is a visual examination by the operator or other designated personnel, without requiring records to be made. Inspection should be carried out at the following intervals recommended in section 4.4.1 'Frequent Inspection (Visual)'.

Additionally, the operator should check the system continually during operation to ensure that no malfunctions are occurring.

4.5.1.1 Servo Hoist:

- Visually inspect the Servo Hoist and ensure that it is in good general working order. Repair or replace any broken or missing parts.
- Cycle the Servo Hoist and listen for any abnormal noises (grinding, etc.). If any abnormal noises are evident, an inspection of the Servo Hoist must be performed.
- Inspect how the chain feeds through the Servo Hoist. If any binding is evident, clean and lubricate the chain (Refer to section 4.4.2 'Periodic Inspection (Documented)'). If the problem persists replace the chain.
- Cycle the Run-Stop button and ensure it functions correctly.

4.5.1.2 Load Shackle:

- Check the shackle for signs of wear.
- Ensure the load shackle is not cracked, nicked or gouged. Replace the shackle as necessary.
- Confirm all cotter pins and / or keepers are in place.

If any of these abnormal conditions are evident, the Servo Hoist should be taken out of service and a detailed inspection and corrective actions should be taken by qualified maintenance personnel.

4.5.2 Periodic Inspection (Documented)

Perform the items listed in the section 4.4.1.1. 'What to Look for During a Frequent Inspection' in addition to the items listed below. All findings from this inspection should be recorded.

4.5.2.1 Supporting Structure:

- Check for distortion, wear and continued ability to support the load. Refer to manufacturers' instructions for overhead rail systems.

4.5.2.2 Rail Trolley (if applicable):

- Ensure wheels and side rollers run smoothly and are not excessively worn. Replace the wheels and side rollers as necessary.
- Visually check the nylon at the bearing and along the face of the wheel for cracks.

4.5.2.3 Fasteners:

- Check all fasteners and ensure they are not loose, missing or damaged.

4.5.2.4 Load Hook (if applicable):

- Inspect for cracks, wear or damage.
- Inspect hook throat for spreading and proper safety latch engagement.
- Measure hook throat at wear points: greater than ten percent wear in any throat zone requires replacement. Refer to manufacturer's instructions for wear zone information.
- Inspect the hook eye or chain nest and sleeve for correct functionality. Also, each should rotate without binding and should not be damaged.

4.5.2.5 Valves, Timers, and Switches:

- Check during an operation cycle to ensure the sequence is operating at optimum efficiency. Repair or replace if needed.

4.5.2.6 Wiring:

- Check for broken, loose, missing, and worn wires. Check all electrical cables for signs of age, wear, or damage, and make sure all connections are tight and secure. Repair or replace if needed.


4.5.2.7 Electrical Enclosures, Disconnect Boxes, and Circuit Breakers:

- Check for obvious signs of damage and repair or replace if needed.
- Verify disconnect is operational. Check for loose, bent, or broken components. Repair or replace if needed.
- Inspect for loose or broken terminals. Check for the presence of contaminants like dirt, dust, grease, or rust. Repair or replace if needed.

If any of these abnormal conditions are evident, the Servo Hoist should be taken out of service and a detailed inspection and corrective actions should be taken by qualified maintenance personnel.

4.5.2.8 Labels and Tags:


- Ensure that all labels are intact and legible. Replace as necessary. (Refer to Figure 4-5)



If any of the labels or warning tags listed above are missing, contact Knight Global at 248-377-4950 to order replacements.

4.6 Load and Safety Drop Stop Chain Replacement (Normal Maintenance)

The materials required for the chain replacement are shown in Figure 4-6:



- Step 1. Raise the inline handle or Load Monitoring Module to its full up position.
- Step 2. Measure the distance from the top of the inline handle or load cell assembly to the bottom of the servo hoist. (Refer to Figure 4-7)
- Step 3. Record this measurement because it will be used in section 5.F. 'Encoder Offset Setup Procedure'.



<u>Date of Replacement</u>	<u>Measurement</u>
_____	_____ in.
_____	_____ in.
_____	_____ in.
_____	_____ in.
_____	_____ in.

- Step 4. Move the inline handle or load cell assembly down to a comfortable working height.
- Step 5. Remove ALL of the load that is attached to the hoist under the inline handle or load cell assembly. This includes the part and the system's fixture.

Step 6. Push the RUN-STOP button. The RED light will illuminate and the power will be disconnected from the Servo Hoist.

	WARNING
	Wait for the capacitors to discharge. It will typically take about (5) five minutes for the capacitors to fully discharge.

Step 7. Remove both chains from the chain nest. The bottom bolt releases the Safety Drop Stop (SDS) chain and the top bolt releases the Load chain.

For a 250 or 500lbs system, a 4mm allen wrench will be required. For any other capacity system, both 4mm and 5mm allen wrenches will be required. (Refer to Figure 4-8)




Figure 4-8

Step 8. Remove the bottom bolt and the SDS chain first and then remove the top bolt and load chain. Ensure that the inline handle or load cell assembly is supported before the load chain is disengaged from the chain nest.

Step 9. Remove the side covers from Servo Hoist. (Refer to Figure 4-9)

- a. Remove the (2) two M6 screws on the bottom of each of the covers.
- b. Lift cover upwards off the pins.




Figure 4-9

- Step 10. While supporting the chain buckets, remove the (1) one M5 retainer bolt that secures both chain buckets inside of the Servo Hoist. (Refer to Figure 4-10)




Figure 4-10

- Step 11. Remove both chain buckets through the bottom of the Servo Hoist.
 Step 12. Remove both chains from their individual chain buckets.
 Step 13. Remove both of the end-stop assemblies from the each of the old load and Safety Drop Stop (SDS) chains.
 Step 14. Connect both of the old chains together with the both of new chains by using both of the yellow chain interface links. (Refer to Figure 4-11)




Figure 4-11

- Step 15. To enable the chain pay-out sequence, using the Operator Control Interface (OCI), twist the Run-Stop button clockwise to enable the hoist.
 Within 3 seconds, press the Run-Stop button, press and release the Green Lift button and then the Blue Float button, twist the Run-Stop button clockwise and release. This will start the pay-out mode after three to ten seconds.
 If the direction is incorrect, press the Run-Stop button to stop the pay-out mode and repeat the above sequence to pay-out the chain in the opposite direction.
- Step 16. Stop the pay-out mode by pressing the Run-Stop button when the yellow interface chain links have moved through the gear box and are at an acceptable height to reattach the inline handle or load cell assembly.
- Step 17. Lubricate both the load and the Safety Drop Stop (SDS) chains per section 4.4.3 'Chain Lubrication'.

- Step 18. Reinstall both chains into each of their correct chain buckets.
- Step 19. Reinstall the chain buckets back into the servo hoist.
- Step 20. Reinstall the servo hoist side covers.
- Step 21. The SDS chain needs to be cut to the correct length so it has slack in it when the load chain is properly connected.
- Step 22. Ensure that both chains are parallel with no twists from the gear box down to their respective ends.
- Step 23. Count down seven links from the end of the load chain. Cut the seventh link so the SDS chain is six links longer than the load chain. (Refer to Figure 4-12)




Figure 4-12


- Step 24. Install the safety chain identification sleeve on the SDS chain and then heat shrink it to the SDS chain on the eighth link up from the bottom of the SDS chain. (Refer to Figure 4-13)



Figure 4-13

- Step 25. Reinstall the new small O-ring around both the load and SDS chains.
- Step 26. Reinstall both chains back through the center of the coil cable.

Step 27. Ensure that both chains are parallel to each other and have NO twists in them when they are installed into the chain nest. (Refer to Figure 4-14)



Step 28. First, the last link of the load chain is installed into the top slot of the chain nest. The chain must be kept parallel with no twists. The bolt is installed in front of the last link of the load chain and into the chain nest. (Refer to Figure 4-15)



Figure 4-15

Step 29. Next, the last link of the SDS chain is installed into the bottom slot of the chain nest. The chain must be kept parallel with no twists. The bolt is installed through the last link of the SDS and into the chain nest. (Refer to Figure 4-16)




Figure 4-16

Step 30. Reinstall the large O-ring into the groove located on the chain nest.
(Refer to Figure 4-15)

Step 31. Move the small O-ring down so it is just above the top of the chain nest.

Step 32. The servo hoist may now be repowered and tested.


4.6.1 Resetting the Encoder Offset

Please refer to section 5.F. 'Encoder Offset Setup Procedure' for the steps to reset the encoder offset for this system.

	WARNING
	Do NOT raise the servo handle above the recorded measurement obtained in Step 3 of section 4.6 'Load and Safety Drop Stop Chain Replacement (Normal Maintenance)' or damage may be done to the servo.

4.7 Broken Chain Replacement

The materials required for the chain replacement are shown in Figure 4-18:



- Step 1. Raise the inline handle or Load Monitoring Module to its full up position.
- Step 2. Measure the distance from the top of the inline handle or load cell assembly to the bottom of the servo hoist. (Refer to Figure 4-19)
- Step 3. Record this measurement because it will be used in section 5.F. 'Encoder Offset Setup Procedure'.



<u>Date of Replacement</u>	<u>Measurement</u>
_____	_____ in.
_____	_____ in.
_____	_____ in.
_____	_____ in.
_____	_____ in.

- Step 4. Move the inline handle or load cell assembly down to a comfortable working height.
- Step 5. Remove ALL of the load that is attached to the hoist under the inline handle or load cell assembly. This includes the part and the system's fixture.

Step 6. Push the RUN-STOP button. The RED light will illuminate and the power will be disconnected from the Servo Hoist.

	WARNING
	Wait for the capacitors to discharge. It will typically take about (5) five minutes for the capacitors to fully discharge

Step 7. Remove both chains from the chain nest. The bottom bolt releases the Safety Drop Stop (SDS) chain and the top bolt releases the Load chain.

For a 250 or 500lbs system, a 4mm allen wrench will be required. For any other capacity system, both 4mm and 5mm allen wrenches will be required. (Refer to Figure 4-20)




Figure 4-20

Step 8. Remove the bottom bolt and the SDS chain first and then remove the top bolt and load chain. Ensure that the inline handle or load cell assembly is supported before the load chain is disengaged from the chain nest.

Step 9. Remove the side covers from Servo Hoist. (Refer to Figure 4-21)

- a. Remove the (2) two M6 screws on the bottom of each of the covers.
- b. Lift cover upwards off the pins.






Figure 4-21

- Step 10. While supporting the chain buckets, remove the (1) one M5 retainer bolt that secures both chain buckets inside of the Servo Hoist. (Refer to Figure 4-22)



- Step 11. Remove the chain buckets through the bottom of the Servo Hoist.
 Step 12. Remove both chains from the individual chain buckets.
 Step 13. Remove both of the end-stop assemblies from the each of the old load and Safety Drop Stop (SDS) chains.
 Step 14. Connect the old SDS chain to the new SDS chain using one of the yellow interface links. (Refer to Figure 4-23)



- Step 15. To enable the chain pay-out sequence, using the Operator Control Interface (OCI), twist the Run-Stop button clockwise to enable the hoist. Within 3 seconds, press the Run-Stop button, press and release the Green Lift button and then the Blue Float button, twist the Run-Stop button clockwise and release. This will start the pay-out mode after three to ten seconds. If the direction is incorrect, press the Run-Stop button to stop the pay-out mode and repeat the above sequence to pay-out the chain in the opposite direction.
 Step 16. When the yellow chain interface link reaches the gear box, stop the pay-out mode by pressing the Run-Stop button.

Step 17. Using the chain installation tool, locate the load chain pocket opening on the bottom of the gear box. (Refer to Figure 4-24)



Figure 4-24

Step 18. Using the chain installation tool, feed it completely through the gear box.

Step 19. Connect the new load chain to the chain installation tool.

Step 20. Pull the chain installation tool until the load chain just enters the gear box chain pocket opening.

Step 21. Ensure that the new load chain is aligned correctly so that it will enter the gear box properly.

Step 22. Ensure that there is tension on the chain replacement tool so that it is pulled into the gear box when the payout mode is started.

Step 23. Restart the pay-out mode by following the procedure listed in Step 15 above.

Step 24. This will feed the new load chain and SDS chain through the gear box.

Step 25. When the new load chain is long enough to attach to the chain nest, press the Run-Stop button to stop the pay-out mode.

Step 26. Lubricate both the load and the Safety Drop Stop (SDS) chains per section 4.4.3 'Chain Lubrication'.

Step 27. Reinstall both chains into each of their correct chain buckets.

Step 28. Reinstall the chain buckets back into the servo hoist.

Step 29. Reinstall the servo hoist side covers.

Step 30. The SDS chain needs to be cut to the correct length so it has slack in it when the load chain is properly connected.

Step 31. Ensure that both chains are parallel with no twists from the gear box down to their respective ends.

- Step 32. Count down seven links from the end of the load chain. Cut the seventh link so the SDS chain is six links longer than the load chain. (Refer to Figure 4-25)




Figure 4-25

- Step 33. Install the safety chain identification sleeve on the SDS chain and then heat shrink it to the SDS chain on the eighth link up from the bottom of the SDS chain. (Refer to Figure 4-26)



Figure 4-26

- Step 34. Reinstall the new small O-ring around both the load and SDS chains.
 Step 35. Reinstall both chains back through the center of the coil cable.
 Step 36. Ensure that both chains are parallel to each other and have NO twists in them when they are installed into the chain nest. (Refer to Figure 4-27)




Figure 4-27

- Step 37. First, the last link of the load chain is installed into the top slot of the chain nest. The chain must be kept parallel with no twists. The bolt is installed in front of the last link of the load chain and into the chain nest. (Refer to Figure 4-28)



Figure 4-28

- Step 38. Next, the last link of the SDS chain is installed into the bottom slot of the chain nest. The chain must be kept parallel with no twists. The bolt is installed through the last link of the SDS and into the chain nest. (Refer to Figure 4-29)




Figure 4-29

- Step 39. Reinstall the large O-ring into the groove located on the chain nest.
(Refer to Figure 4-28)
- Step 40. Move the small O-ring down so it is just above the top of the chain nest.
- Step 41. The servo hoist may now be repowered and tested.

4.7.1 Resetting the Encoder Offset

Please refer to section 5.F. 'Encoder Offset Setup Procedure' for the steps to reset the encoder offset for this system.

	WARNING
	Do NOT raise the servo handle above the recorded measurement obtained in Step 3 of 4.7 'Broken Chain Replacement' or damage may be done to the servo.

5. SOFTWARE

There are several subjects related to the Servo Hoist's software that will be reviewed here:

- 5.A.) Getting Started
- 5.B.) Connecting to a Servo Hoist
- 5.C.) Backing up the Knight Servo Hoist Software
- 5.D.) Load a New Drive with Existing Software
- 5.E.) Check or Change Setup Values
- 5.F.) Encoder Offset Setup Procedure
- 5.G.) Operating Test Mode
- 5.H.) Accessing the Servo Hoist's Fault Log

In the next few sections of the manual a shorthand is used to point to a particular screen in the Knight Servo Studio (KSS) program. The shorthand that explains how to find each screen or parameter in the KSS is explained below:

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Status \ System Status Bits

This means that the Knight Servo Studio's 'User Level' dropdown located on the top menu must be set to the 'Advanced' option. Next, in the 'Workspace' panel on the left-hand side of the screen, the '+' sign next to the Knight Work Order number needs to be pressed. This will expand the selection tree. Mouse down and press the '+' sign next to the 'Status' option and double-click on the 'System Status Bits' screen. This will open that screen and any specific parameters can be inspected.

KSS Home screen location: Quick View panel \ Row 6 (Lower right-hand portion of the screen)

This means that on the Knight Servo Studio's home screen there is a panel located in the lower right-hand portion of the screen labeled 'Quick View'. The parameter in question is located on 'Row 6' of that panel.

If the Servo Hoist is being set up for the first-time, here is a list of functions to initially verify.

The functions can be accessed from the 'Quick Setup' screen located here:

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Quick Setup

- 1) The hoist's maximum allowed weight: This can be verified by following the instructions in section 5.E. 'Check or Change Setup Values' on 'Row #6'.
- 2) The hoist's set down weight: This can be verified by following the instructions in section 5.E. 'Check or Change Setup Values' on 'Row #7'.
- 3) The hoist's fixture weight is correct: This can be verified by following the instructions in section 5.E. 'Check or Change Setup Values' on 'Row #4'.
- 4) The analog handle is balanced: This can be verified by following the instructions in section 5.E. 'Check or Change Setup Values' on 'Row #9'.
- 5) The encoder offset procedure: This can be verified by following the instructions in section 5.F. 'Encoder Offset Setup Procedure'.

A. Getting Started

Listed below are the hardware and software items needed to connect to a Knight Servo Hoist:
(Refer to Figure 5-1)

- Laptop running Microsoft Windows 7 or above. (Customer Supplied)
- Ethernet Cable with (1) RJ45 connector and (1) M12 4-pin connector.
- The Knight Servo Studio software package.

Note: The Knight Servo Studio software and an Ethernet Cable can be ordered from Knight: P/N EBA1395.



Figure 5-1

B. Connecting to a Servo Hoist

The Knight Servo Studio Servo software is used to configure and troubleshoot the Knight Servo Hoist. The following steps are required to initiate a connection between a computer running the Knight Servo Studio software and the Knight Servo Hoist:

Knight Servo Studio Software Package Setup:

- Step 1. Setup the Ethernet communication settings for your laptop.
- Using a Microsoft Windows based PC open the **Network and Sharing Center**.
 - Right click on **Local Area Connections**. Select **Properties**. (Refer to Figure 5-2)




Figure 5-2

- Select **Internet Protocol Version 4 (TCP/IPv4)**. Select **Properties**.
- Select **Use the following IP address:**
 In most cases the laptop's IP Address should be: 196.168.2.250
 Type the correct IP address and Subnet mask into the spaces provided and press the 'OK' button. (Refer to Figure 5-3)




Figure 5-3

- Step 2. Insert the USB card that was supplied with Servo Hoist into the laptop.
Double-click on the “ksh_sm_user.exe” icon to launch the Knight Servo Studio installation software. (Refer to Figure 5-4)




Figure 5-4

- Step 3. Double click on the blue Knight Servo Studio software icon located on the desktop and allow the Knight Servo Studio software to load. (Refer to Figure 5-5)




Figure 5-5

- Step 4. When the software loads, choose the ‘Open Project from Device’ option.
Input the correct IP Address into the Network Configuration box.
The IP Address for the hoist will be located next to the M12 ENET receptacle located on the Load Monitoring Module or the Inline Handle, but in most cases is: 192.168.2.101
(Refer to Figure 5-5)

- Step 5. Move the mouse to the right side of the screen and select the 'Connect' button. If the communications are operating correctly the red 'Disconnected' box will turn to a green 'Connected' box. (Refer to Figure 5-6)

If the Knight Servo Studio software does not connect to the hoist, recheck all of the connections and ensure that the hoist has its 240VAC power connected.




Figure 5-6

C. Backing up the Knight Servo Hoist Software

The section will explain how to save a backup copy of the 'Knight Servo Studio' (a .KSP file) and the 'Knight SD3 Program Editor' (a .PRJ file).

Save a copy of the Knight Servo Studio's .KSP file:

- Step 1. Mouse up to the top menu bar located on the left-hand side of the screen and select 'File'. Highlight the 'Save To File' option and select it. (Refer to Figure 5-7)



Figure 5-7

- Step 2. Select the folder where to save the backup copy of the file. Ensure the Knight Work Order number is included in the filename. (Refer to Figure 5-8)

Knight suggests that a 'Controls' folder be created as well as subdirectories for each servo. The hoist's Work Order number should be used as the name for these new subdirectories. i.e. \Controls\123748.




Figure 5-8


- Step 3. Send a copy of the newly saved file to Knight's Servo Team at servos@knightglobal.com.

Save a copy of the Knight SD3 Program Editor's .PRJ file:

- Step 1. Open the 'Knight SD3 Program Editor' by clicking on the appropriate Knight Icon. (Refer to Figure 5-9)

**Figure 5-9**

- Step 2. After the program loads, mouse to the top menu, select the 'Project' Tab, then mouse down and select 'Upload...'. (Refer to Figure 5-10)

**Figure 5-10**

- Step 3. Input the IP Address into the selection box that appears. In most cases the IP Address will be: 192.168.2.101 (Refer to Figure 5-11)




Figure 5-11

- Step 4. The program will examine the servo drive and display the programs that are held within it. Highlight the latest one and press the 'Open' button. (Refer to Figure 5-12)




Figure 5-12

- Step 5. After the program data is downloaded to the laptop, the program will display this new information inside the 'Knight SD3 Program Editor' on the 'Drive Info' Tab. (Refer to Figure 5-13)




Figure 5-13

- Step 6. The 'Other Code' Tab can be selected to review application specific code. (Refer to Figure 5-14)




Figure 5-14

D. Load a New Drive with Existing Software

This section of the manual explains how to copy the Knight drive files from an old drive to a new drive.


Step 1. Lower the hoist's support fixture and part so that no load is suspended from the hoist.

	WARNING There can be NO load suspended from the hoist prior to replacing a drive.
---	--

Step 2. Press the Run-Stop button.

Step 3. Remove the 240VAC power from the system.

Step 4. In order to remove the old Drive from the Enclosure, remove the two #3 Phillips screws and then the cover from the top of the hoist's enclosure. (Refer to Figure 5-15)



Step 5. Remove all of the connectors attached to the servo drive:

- X20: 24-pin connector.
- X18: Encoder cable.
- X21: D-sub connector.
- X14: Ethernet connector.
- X25: 24-pin connector.

Step 6. Remove the (2) two 10mm nuts that secure the servo to the bottom plate using a metric deep well socket wrench. The (2) two button head bolts that the nuts thread onto are 6mm and if they back out use a 4mm Allen wrench to secure them.

- Step 7. Remove the I/O Modules from both of the old and new drives. This is accomplished by loosening the thumbscrews (use a #1 Philips if necessary) and then carefully lifting the I/O Module up off the top of the servo. (Refer to Figures 5-16)
- Step 8. The SD card is now accessible and can be seen in the old drive. (Refer to Figures 5-17)




Figure 5-16




Figure 5-17

- Step 9. Place your finger on the circuit board in front of the SD card. When the SD card is released it will spring back with enough force to move several inches. See Note below. (Refer to Figure 5-18)
- Step 10. Eject the SD card by pressing it in with your other index finger and then allowing it to spring back. (Refer to Figure 5-19)




Figure 5-18



Figure 5-19



NOTE

When released, the SD card may spring out of the slot quickly. If there is nothing in front of the SD card, it may be ejected with enough force to move several inches and possibly drop down inside the servo. After the SD Card is released, if it doesn't move forward far enough to be removed from the slot, you may need to move your finger off of the card more quickly.

- Step 11. Label the SD card and keep it safe and accessible for replacement.
- Step 12. Prepare the new Sieb and Meyer servo drive obtained from Knight Global for installation.
- Step 13. Install the SD card into the new drive. This will guarantee that all of the parameters that depict the functionality of the system will be maintained.
- Step 14. Re-install the I/O module into the new drive. Do not apply an excessive amount of force. The I/O module should easily slide into place if it is lined up correctly. Tighten the thumbscrews fully by hand, before using a #1 Philips screwdriver; Ensure the screws don't strip when tightening.
- Step 15. Re-secure the new drive to the bottom plate of the hoist's enclosure and reattach all of the cable connectors:
- X20: 24-pin connector.
 - X18: Encoder cable.
 - X21: D-sub connector.
 - X14: Ethernet connector.
 - X25: 24-pin connector.
- Step 16. Reinstall the cover on top of the hoist's enclosure. (Refer to Figure 5-15)
- Step 17. Re-connect the 240VAC power to the drive.
- Step 18. The Run-Stop red light and the green light will flash on and off briefly when the Servo Hoist has reinitialized. This will take 1-2 minutes after the unit has been powered up.
- Step 19. Connect to the Servo Hoist by following the 5.B. "Connecting to a Servo Hoist" procedure.
- Step 20. Check for any Drive Faults. A fault will be designated by an illuminated red box next to the fault's description on the Active Fault screen. See Chapter 7.B. for details. (Refer to Figure 5-20)




Figure 5-20

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Status \ Active Faults

- Step 21. Check for any Drive Warnings. A warning will be designated by an illuminated yellow box next to the warning's description on the Active Warnings screen. See Chapter 7.B. for details. (Refer to Figure 5-21)




Figure 5-21

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Status \ Active Warnings

- Step 22. If the I/O devices connected to the I/O module are not working, verify that the green terminal block is correctly seated into the Remote I/O Module and that the module is installed properly into the servo drive.
- Step 23. If the unit doesn't work properly, follow the troubleshooting screens located inside the Knight Servo Studio under the Troubleshooting branch of Workspace directory tree. (Refer to Figure 5-22)

Refer to Chapter 7 for a complete description of each screen listed on the directory tree below.




Figure 5-22

E. Check or Change Setup Values

The Knight Servo Studio Servo software can be used to setup the Knight servo drive. Follow these steps to configure the servo drive after a laptop has been connected to the system.
Refer to section 5.B. "Connecting to a Servo Hoist".

- Step 1. Mouse up to the top menu bar located on the left-hand side of the screen and select 'User Level'. Highlight the 'Advanced' option and select it.
- Step 2. Just below the top menu bar is a window named 'Workspace'. There will be a '+' sign next to the Job Number of the Knight servo you are doing maintenance on. Press this '+' button and a selection tree will appear.
- Step 3. Mouse down the selection tree to 'Setup'. Press the '+' sign next to the 'Setup' selection. Double-click on the 'Quick Setup' option.
- Step 4. This will display a screen labeled 'Quick Setup (Job Number: Setup)'.

Quick Setup screen: (Refer to Figure 5-23)

- Row #1) Float Load Cell setup: The 'Re-Zero Float LC' button should only be pressed if there is nothing hanging from the bottom of the Load Monitoring Module (LMM). This button is usually only pressed when the LMM has been replaced.
- Row #2) Encoder Offset set-up: Inputting a number into the 'Home Position' box and pressing the 'Set Encoder Offset' button will equate the 'Current Position' of the hoist to that number. The hoist is usually moved to its top position, a zero is entered into the 'Home Position' display, and the 'Set Encoder Offset' button is pressed equating this top position to zero inches.
- Row #3) Upper / Lower limits: This Row displays the absolute Upper and Lower Limits of the Servo Hoist.
- Row #4) Fixture Weight setup: If the weight of the fixture changes, ensure that the fixture is hanging free without a part or any extra weight hanging from it and press the 'Set Fixture weight' button to change the 'Fixture Weight (lb)' to the current 'Total Weight (lb)' displayed.
- Row #5) Maximum rated capacity of the servo: This value should not be changed.
- Row #6) Maximum allowed weight: This is the total amount of weight that the servo will lift. If this value is exceeded the servo will stop moving upward. I.e. an Up Stop Fault will be generated and processed.
- Row #7) Minimum weight: This is the amount of weight that the servo will set down on a surface. This can be set to ensure that only a specific amount of weight is set down on a pallet or surface. Also, it ensures that the servo will not pay-out additional chain when the part is set down.
- Row #8) Handle selection: This value should not be changed.
- Row #9) Lift Load Cell setup: If the hoist has an analog handle this function is active. The 'Re-Zero Lift LC' button can be pressed to equate the 'Lift LC Bias' to the 'Lift LC Voltage'. This function may also be used to stop the fixture from 'drifting' up or down. Ensure there is no external force affecting the handle and press the 'Re-Zero Lift LC' button.
- Row #10) Commit Row: If ANY of the Rows above are changed, the 'Commit' button will turn yellow and must be pressed for that change to be processed by the servo.

NOTE: If any values are changed, Ensure that the Servo Hoist program is backed up to the PC.
See Chapter 5.C. 'Backing up the Knight Servo Hoist Software' for details.

Quick Setup (QALabServo: Se... X)

Float LC Voltage	Float LC Bias	Re-Zero Float LC
-8.35616	-8.356616	
Current Position (in)	Home Position (in)	Set Encoder Offset
18.86	0	
Reverse/Upper Limit (in)	Forward/Lower Limit (in)	
0	50	
Total Weight (lb)	Fixture Weight (lb)	Set Fixture Weight
483.9231	350	
Max Rated Capacity	250lb 350lb 500lb 750lb 1000lb	
750		
Max Allowed Weight	250lb 350lb 500lb 750lb 1000lb	
350		
Minimum Weight	-10lb -20lb -30lb	
-10		
Lift Filter Bandwidth	Inline Handle	Fixture Handle Use Trigger Offset
6		
Lift LC Voltage	Lift LC Bias	Re-Zero Lift LC
-2.93389	-2.952855	
Commit	Revert	Fault Reset

Figure 5-23

F. Encoder Offset Setup Procedure

The Knight Servo Studio Servo software can be used setup Encoder Offset position of the servo. Refer to section 5.B. "Connecting to a Servo Hoist".

- Step 1. Follow the steps in the previous section to display the 'Quick Setup' screen.
KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Quick Setup \ Row 2.
- Step 2. Move the fixture or inline handle to the overall top position.
This should be the maximum top point that the servo will have to travel up to but should be low enough not to cause damage to the 19-pin coil cable.

	CAUTION The 19-pin coil cable should not be compressed when the hoist is in the full up or zero position. There should be addition room below the servo so a two-inch (2") spacer could be inserted between the coils of the 19-pin coil cable when the hoist is in the full up position.
---	---

- Step 3. Set the 'Home Position (in)' input box to a value of zero (0).
- Step 4. Press the 'Set Encoder Offset' button. The 'Commit' button located on the bottom left-hand side of the panel will turn yellow.
- Step 5. Press the 'Commit' button. This will equate the current position of the hoist to its upper most or zero location.

G. Operating Test Mode

The 'Test Mode' can be initiated from the Knight Servo Software.

- Step 1. Mouse to the 'Workspace' panel and select the '+' next to the Knight Work Order Number.
- Step 2. Next, mouse to and select the '+' next to 'Motion' and then double-click on 'Test Mode'.
- Step 3. This will display a screen labeled 'Test Mode (Job Number: Motion)'.

Test Mode screen: (Refer to Figure 5-24)

- Row #1) Upper and Lower limit setup: The hoist's movement in the reverse direction will stop at the upper limit and its forward movement will stop at the lower limit.
Note: When the 'Start' button is pressed, the servo will move to the upper limit and then continue the test cycle.
- Row #2) The 'Velocity (ips)' value should be set between 3 to 10.
The 'Accel (ips²)' value should be set between 2 to 10.
The 'Decel (ips²)' value should be set between 2 to 10.
- Row #3) The 'Delay (ms)' value should equal the time it takes for the servo to move from the upper limit to the lower limit during the cycle. If using the settings on the screen below, the delay should be set to 6000ms or a six second delay.
The 'Max Moves' box displays the total number of cycles that the servo will perform in test mode.
- Row #4) The 'Move Count' box will display the current number of cycles the hoist has performed.
Press the 'Reset Counter' button if the current number of cycles needs to be reset to zero.
- Row #5) Press the 'Start' button once to start the test cycle. The button will turn green and the test will start within a few seconds.
Press the 'Start' button again to stop the test cycle. The button will turn grey and the hoist's movement will immediately stop.




Figure 5-24

H. Accessing the Servo Hoist's Fault Log

The servo drive's Fault Log is accessible from its web page.

- Step 1. Open your web browser and enter on the hoist's IP Address in the address bar.
This will be 192.168.2.101 in most cases.
- Step 2. The web page will be similar to what is shown in Figure 5-24.




Figure 5-24

- Step 3. Select the 'Fault Logs' button to see a list of all of the faults recorded by the servo. Each fault will have a 'Fault ID', a 'Description', the time the fault occurred and the duration the fault lasted. (Refer to Figure 5-25)

The screenshot shows the 'Fault Log' section of the Knight Servo Hoist web interface. It includes a header with 'Firmware Fault Log' and 'User Program Fault Log'. Below the header is a table of fault logs. The table has four columns: 'Fault ID', 'Description', 'Set Time', and 'Duration (seconds)'. The table contains 14 rows of data, including faults like 'Run/Stop Pressed' and 'Lift LC Not Connected'.

Fault ID	Description	Set Time	Duration (seconds)
101	Run/Stop Pressed	Feb 8 17:37:46 2018	72
101	Run/Stop Pressed	Feb 8 17:37:42 2018	28
101	Run/Stop Pressed	Feb 8 17:37:40 2018	17
101	Run/Stop Pressed	Feb 8 17:37:32 2018	1
101	Run/Stop Pressed	Feb 7 17:38:06 2018	1728
101	Run/Stop Pressed	Feb 7 17:37:56 2018	1
101	Run/Stop Pressed	Feb 7 17:37:37 2018	8
1285	Lift LC Not Connected	Feb 7 13:55:55 2018	4
107	Float LC Not Connected	Feb 7 13:55:55 2018	6
101	Run/Stop Pressed	Feb 7 13:55:33 2018	5
1285	Lift LC Not Connected	Feb 7 13:55:28 2018	10

Figure 5-25

6. PARAMETER DESCRIPTIONS

There are several parameter status arrays described in this section:

- 6.A.) iSTS Status Array
- 6.B.) fSTS Status Array
- 6.C.) F8L1 Parameter Array
- 6.D.) User Retained Variables Parameter Array
- 6.E.) F8L2 Parameter Array
- 6.F.) F8L3 Parameter Array

A. iSTS Status Array

This complete array is reserved for internal use.

B. fSTS Status Array

This Global Array is used as a status file to review the current state of the Servo Hoist.

These parameters are listed in the fSTS array and can be displayed at:

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Parameters \ fSTS \ Row xx.

Many of these parameters have equivalent displays located on various Knight Servo Studio (KSS) screens.

The location of these screens is listed at the end of each parameter's description.

See section 5. 'Software' for an explanation of the shorthand used.

fSTS:00 – Run-Stop

Variable Units: Boolean (0=Off, 1=On)

Description: This parameter displays a '1' if the Run-Stop button is in the run position and the 19-pin coil cable is connected to the Servo Hoist. It will be a '0' if the Run-Stop button is in the opened condition or if the 19-pin coil cable is disconnected.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Status \ System Status Bits

fSTS:01 – Lowest Set Fault Number

Variable Units: Fault #

Description: This parameter displays the current drive fault if one exists. If the number is between 1 and 310 then a drive fault has occurred and will be displayed on the Knight Servo Studio Active Fault screen.

A complete list of faults is listed in this manual in section 7 under the heading 'Error Codes'.

KSS Home screen location: Quick View panel \ Row 1 (Lower right-hand portion of the screen).

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Status \ Active Faults

fSTS:02 and fSTS:03 – Spare

fSTS:04 – Current Mode (0=none, 1=Lift, 2=Float, 3=Position, 4=Payout)

Variable Units: Choice (0 = No Mode/Sleep, 1=Lift Mode, 2=Float Mode, 3=Test Mode)

Description: This parameter displays the current operating mode of the hoist.

fSTS:05 – Current Motion Time (s)

Variable Units: Seconds

Description: This parameter displays the time it took to complete the last cycle.

fSTS:06 through fSTS:09 – Spare

fSTS:10 – Float Load Cell Raw Voltage

Variable Units: Volts

Description: This parameter displays the analog voltage from the float load cell.

fSTS:11 – Float Load Cell Filtered Voltage

Variable Units: Volts

Description: This parameter displays an intermediate calculation of the force exerted on the float load cell.

fSTS:12 – Float Load Cell Bias Voltage

Variable Units: Volts

Description: This parameter displays an intermediate calculation of the force exerted on the float load cell.

fSTS:13 – Float Load Cell Raw Weight Reading (lb)

Variable Units: Pounds

Description: This parameter displays an intermediate calculation of the force exerted on the float load cell.

fSTS:14 – Zeroed and Filtered Weight Reading (lb)

Variable Units: Pounds

Description: This parameter displays an intermediate calculation of the force exerted on the float load cell.

fSTS:15 – Total Filtered and Compensated Weight (lb)

Variable Units: Pounds

Description: This parameter displays an intermediate calculation of the force exerted on the float load cell.

fSTS:16 – Floating Weight (lb)

Variable Units: Pounds

Description: This parameter displays the weight used by the hoist while it is in Float Mode.

fSTS:17 – Steady Part Weight (lb)

Variable Units: Pounds

Description: This parameter displays the weight of the part hanging from the fixture or inline handle.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Quick Setup \ Row 4.

KSS Home screen location: Quick View panel \ Row 6 (Lower right-hand portion of the screen).

fSTS:18 – Float Load Cell Weight - Fixture Weight (lb)

Variable Units: Pounds

Description: This parameter displays an intermediate calculation of the force exerted on the float load cell.

fSTS:19 – Float Load Cell Scaled Value (lb)

Variable Units: Pounds

Description: This parameter displays an intermediate calculation of the force exerted on the float load cell.

fSTS:20 – Lift Load Cell Raw Voltage

Variable Units: Volts

Description: Analog voltage from the lift load cell.

fSTS:21 – Lift Load Cell Filtered Voltage

Variable Units: Volts

Description: This parameter displays an intermediate calculation of the force exerted on the lift load cell.

fSTS:22 – Lift Load Cell Bias Voltage

Variable Units: Volts

Description: This parameter displays an intermediate calculation of the force exerted on the lift load cell.

fSTS:23 – Lift Load Cell Raw Weight Reading (lb)

Variable Units: Pounds

Description: This parameter displays an intermediate calculation of the force exerted on the lift load cell.

fSTS:24 – Lift Load Cell Adjusted Weight (lb)

Variable Units: Pounds

Description: This parameter displays an intermediate calculation of the force exerted on the lift load cell.

fSTS:25 – Lift Load Cell Weight (lb)

Variable Units: Pounds

Description: This parameter displays an intermediate calculation of the force exerted on the lift load cell.

fSTS:26 – Lift Load Cell Weight, Filtered (lb)

Variable Units: Pounds

Description: This parameter displays an intermediate calculation of the force exerted on the lift load cell.

fSTS:27 – Lift Weight - Adjusted, Zeroed, Filtered (lb)

Variable Units: Pounds

Description: This parameter displays the force applied to the fixture or inline handle.

fSTS:28 – Spare

fSTS:29 – Motor Encoder Raw Position (in)

Variable Units: Inches

Description: This parameter displays the encoder information directly from the motor.

fSTS:30 – Motor Encoder Real World Position (in)

Variable Units: Inches

Description: This parameter displays the normalized encoder information.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Quick Setup \ Row 2.

KSS Home screen location: Quick View panel \ Row 5 (Lower right-hand portion of the screen).

fSTS:31 – Command Velocity (ips)

Variable Units: Inches per second

Description: This parameter displays an intermediate calculation of the force exerted on the lift load cell.

fSTS:32 – Feedback Velocity (ips)

Variable Units: Inches per second

Description: This parameter displays an intermediate calculation of the force exerted on the lift load cell.

fSTS:33 – 2nd Float Load Cell Raw Voltage

Variable Units: Volts

Description: This parameter displays information relating to a second float load cell.

fSTS:34 – 2nd Float Load Cell Filtered Voltage

Variable Units: Volts

Description: This parameter displays information relating to a second float load cell.

fSTS:35 – 2nd Float Load Cell Bias Voltage

Variable Units: Volts

Description: This parameter displays information relating to a second float load cell.

fSTS:36 – Feedback Acceleration (ips^2)

Variable Units: Inches per second²

Description: This parameter displays the feedback acceleration of the hoist.

fSTS:37 and fSTS:38 – Spare

fSTS:39 – Lift Mode Max Speed (ips)

Variable Units: Inches per second

Description: This parameter sets the maximum speed of the hoist when in Lift Mode.

fSTS:40 – Float Mode Max Speed (ips)

Variable Units: Inches per second

Description: This parameter sets the maximum speed of the hoist when in Float Mode.

fSTS:41 – Max Motor Speed (ips)

Variable Units: Inches per second

Description: This parameter sets the maximum speed the hoist can move.

fSTS:42 – Max Command Speed (ips)

Variable Units: Inches per second

Description: This parameter sets the maximum command speed the hoist will accept.

fSTS:43 – Command Current

Variable Units: Amps

Description: This parameter displays the instantaneous command current of the hoist.

fSTS:44 and fSTS:45 – Spare**fSTS:46 – Total Distance (in)**

Variable Units: Inches

Description: This parameter displays the overall distance the servo has traveled since delivery.

fSTS:47 – Lift Mode Distance (in)

Variable Units: Inches

Description: This parameter displays the total distance the servo has traveled while in Lift Mode.

fSTS:48 – Float Mode Distance (in)

Variable Units: Inches

Description: This parameter displays the total distance the servo has traveled while in Float Mode.

fSTS:49 – Position Mode Distance (in)

Variable Units: Inches

Description: This parameter displays the total distance the servo has traveled while in position mode.

fSTS:50 through fSTS:127 are reserved for User Program code located in the Knight SD3 Program Editor's .PRJ file under the 'Other Code' Tab.

C. F8L1 Parameter Array

This array stores the parameters that are most frequently adjusted by the end user. This list contains parameters used to fine tune the hoist's performance. It also contains configuration parameters that must be adjusted after maintenance to the servo, motor or gearbox or after modification of the fixture or lift handle.

These parameters are listed in the F8L1 array and can be displayed at:

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Parameters \ F8L1 \ Row xx.

Many of these parameters have equivalent displays located on various Knight Servo Studio (KSS) screens.

The location of these screens is listed at the end of each parameter's description.

See section 5. 'Software' for an explanation of the shorthand used.

F8L1:00 – Initial Settings

Variable Units: Various

Description: *Reserved for internal use only.*

F8L1:01 – Calibration Weight

Variable Units: Pounds

Description: *Reserved for internal use only.*

F8L1:02 – Voltage Difference

Variable Units: Volts

Description: *Reserved for internal use only.*

F8L1:03 and F8L1:04 – Spare

F8L1:05 – Reverse/Upper Limit (in)

Variable Units: Inches

Description: This parameter sets the upper travel limit for the hoist. This value should be set to a number greater than or equal to zero. The home position or absolute physical top limit of the hoist's movement is set to zero inches.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Quick Setup \ Row 3.

F8L1:06 – Forward/Lower Limit (in)

Variable Units: Inches

Description: This parameter sets the lower travel limit for the hoist. This value should be set to the physical lowest limit of the hoist.

NOTE: All measurements increase in value as the fixture moves downward towards the ground.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Quick Setup \ Row 3.

F8L1:07 – Spare

F8L1:08 – Handle Weight (lb)

Variable Units: Pounds

Description: This parameter is not currently used for software calculations.

F8L1:09 – Fixture Weight (lb)

Variable Units: Pounds

Description: This parameter is used to show the static weight of all equipment hanging below the hoist's Load Monitoring Module (LMM). This equipment includes the hook, shackle and fixture.

This parameter must be adjusted if the fixture is modified or replaced.

See section 5.D. 'Check or Change Setup Values' to modify this parameter.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Quick Setup \ Row 4.

F8L1:10 – Spare

F8L1:11 – Encoder Offset (in)

Variable Units: Inches

Description: This parameter sets the offset that the hoist uses to compute its home position. It offsets the absolute encoder's zero position so the hoist's zero position becomes the position at the physical upper limit of its travel. A setting of zero indicates a non-absolute incremental motor and is only for compatibility with legacy systems. This parameter must be adjusted when the motor, gearbox or chain are replaced.

See section 5.D. 'Check or Change Setup Values' to modify this parameter.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Quick Setup \ Row 2.

F8L1:12 – Decel Rate at Limits (ips^2)Variable Units: Inches per second²

Description: This parameter sets the rate of deceleration when the hoist reaches its top and bottom limits. These limits are typically F8L1:5 'Reverse/Upper Limit (in)' and F8L1:6 'Forward/Lower Limit (in)'.

The greater the number the quicker the hoist slows down when it approaches a limit.

F8L1:13 through F8L1:20 – Spare**F8L1:21 – Max Weight (lb)**

Variable Units: Pounds

Description: This parameter sets the maximum load that the Servo Hoist will lift. This includes the weight of the fixture and the part.

NOTE: F8L2:21 'Max Weight Override (lb)' also restricts the maximum load that the hoist will lift.

F8L1:21 must be set to a value less than or equal to the value of F8L2:21.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Quick Setup \ Row 6.

F8L1:22 – Min Weight (lb)

Variable Units: Pounds

Description: This parameter limits the load that the Servo Hoist will set down on a surface. In other words, once the weight supported by the hoist measures below this value, the Servo Hoist will not set down any more weight and hence will not pay out any more chain.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Quick Setup \ Row 7.

F8L1:23 – Lift Mode Timeout (minutes)

Variable Units: Minutes

Description: This parameter sets the length of time that the hoist will stay in Lift Mode unattended. When idle for longer than this specified time, the hoist will disable itself and revert to No Mode. If this variable is set to zero, the hoist will not switch from Lift Mode to No Mode.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Lift Mode \ Row 1.

F8L1:24 – Lift Mode Speed Limit (ips)

Variable Units: Inches per second

Description: This parameter sets the maximum lift velocity for the Servo Hoist while in Lift Mode.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Lift Mode \ Row 1.

F8L1:25 through F8L1:28 – Spare**F8L1:29 – Lift Handle Force Sense (Float) (lb)**

Variable Units: Pounds

Description: Before the hoist switches from Float Mode to Lift Mode, this amount of force is required to be registered on a fixture or inline handle. This parameter only applies to systems that do not have a trigger that enables Lift Mode.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Lift Mode \ Row 2.

F8L1:30 – Lift Handle Force Sense (not Float) (lb)

Variable Units: Pounds

Description: Before the hoist switches from No Mode to Lift Mode, this amount of force is required to be registered on a fixture or inline handle. This parameter only applies to systems that do not have a trigger that enables Lift Mode.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Lift Mode \ Row 2.

F8L1:31 – Lift Handle Force Deadband (lb)

Variable Units: Pounds

Description: This parameter sets the amount of input force that is required to be registered on a fixture or inline handle to start motion.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Lift Mode \ Row 3.

F8L1:32 through F8L1:35 – Spare

F8L1:36 – Digital Lift Fast Speed (ips)

Variable Units: Inches per second

Description: This parameter sets the maximum velocity for a hoist with discrete up/down controls. This parameter is used by the software when a digital lever is fully depressed.

Note: Applies to systems with up/down pendants or wireless transmitters only.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Lift Mode \ Row 4.

F8L1:37 – Digital Lift Normal Speed (ips)

Variable Units: Inches per second

Description: This parameter sets the minimum velocity for a hoist with discrete up/down controls. This parameter is used by the software when a digital lever is only depressed half way.

Note: Applies to systems with up/down pendants or wireless transmitters only.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Lift Mode \ Row 4.

F8L1:38 – Digital Lift Accel (ips²)

Variable Units: Inches per second²

Description: This parameter sets the acceleration for hoists with discrete up/down controls.

Note: Applies to systems with up/down pendants or wireless transmitters only.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Lift Mode \ Row 5.

F8L1:39 – Digital Lift Decel (ips²)

Variable Units: Inches per second²

Description: This parameter sets the deceleration for hoists with discrete up/down controls.

Note: Applies to systems with up/down pendants or wireless transmitters only.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Lift Mode \ Row 5.

F8L1:40 – Spare

F8L1:41 – Float Mode Top Limit (in)

Variable Units: Inches

Description: This parameter sets the upper travel limit for the hoist when it is in Float Mode. This is used to restrict the Float Mode travel to a position greater than the overall upper limit set in

F8L1:5 'Reverse/Upper Limit (in)'.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Float Mode \ Row 2.

F8L1:42 – Float Mode Bottom Limit (in)

Variable Units: Inches

Description: This parameter sets the lower travel limit for the hoist when it is in Float Mode. This is used to restrict the Float Mode travel to a position less than the overall lower limit set in

F8L1:6 'Forward/Lower Limit (in)'.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Float Mode \ Row 2.

F8L1:43 – Float Mode Timeout (minutes)

Variable Units: Minutes

Description: This parameter sets the length of time that the hoist will stay in Float Mode unattended. When idle for longer than this specified time the hoist will disable and revert to No Mode. If this variable is set to zero, the hoist will not switch from Float Mode to No Mode.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Float Mode \ Row 1.

F8L1:44 – Float Mode Speed Limit (ips)

Variable Units: Inches per second

Description: This parameter sets the maximum velocity of the Servo Hoist when it is in Float Mode.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Float Mode \ Row 1.

F8L1:45 – Float Force Deadband (lb)

Variable Units: Pounds

Description: This parameter sets the minimum amount of force that is required to be exerted on the fixture or part hanging from the bottom of the Load Monitoring Module to start motion while the hoist is in Float Mode.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Float Mode \ Row 3.

F8L1:46 through F8L1:77 – Spare**F8L1:78 – Slow Zone Mode (0 = off, 1 = down, 2 = up, 3 = both)**

Variable Units: Choice (0=off, 1=down, 2=up, 3=up and down)

Description: This parameter configures the hoist's automatic slow zone. This parameter works with the variables F8L1:79 to F8L1:84 to configure the automatic slow zone.

0 = Slow Zone feature is disabled.

1 = Program will automatically decrease the speed of the hoist only when moving down.

2 = Program will automatically decrease the speed of the hoist only when moving up.

3 = Program will automatically decrease the speed of the hoist when moving up or down.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Slow Zone \ Row 1.

NOTE: If using this function, all parameters (F8L1:79 to F8L1:84) must be non-zero for the Slow Zone to function correctly.

F8L1:79 – Slow Zone Part Loaded Weight (lb)

Variable Units: Pounds

Description: This parameter sets the number of pounds that the hoist needs to register in order to indicate that a part is loaded on the fixture.

This parameter is only processed if the Slow Zone is turned on. i.e. F8L1:78 'Slow Zone Mode' is not zero.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Slow Zone \ Row 2.

F8L1:80 – Slow Zone Part Loaded Position (in)

Variable Units: Inches

Description: This parameter sets the height that the hoist will start to run at a reduced speed when a part is loaded.

This parameter is only processed if the Slow Zone is turned on. i.e. F8L1:78 'Slow Zone Mode' is not zero.

NOTE: The current position of the hoist is visible in fSTS: 30 "Real World Position" or on the

KSS Home screen location: Quick View panel \ Row 5 (Lower right-hand portion of the screen).

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Slow Zone \ Row 2.

F8L1:81 – Slow Zone Part Loaded Speed (ips)

Variable Units: Inches per second

Description: This parameter sets the reduced speed that the hoist runs at when a part is loaded and it is below the F8L1:80 'Slow Zone Part Loaded Position' parameter.

This parameter is only processed if the Slow Zone is turned on. i.e. F8L1:78 'Slow Zone Mode' is not zero.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Slow Zone \ Row 2.

F8L1:82 – Slow Zone Part Unloaded Position (in)

Variable Units: Inches

Description: This parameter sets the height that the hoist will start to run at a reduced speed when a part is not loaded. This is only valid if the Slow Zone is turned on. i.e. F8L1:78 'Slow Zone Mode' is not zero.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Slow Zone \ Row 3.

F8L1:83 – Slow Zone Part Unloaded Speed (ips)

Variable Units: Inches per second

Description: This parameter sets the reduced speed that the hoist runs at when a part is not loaded and it is below the F8L1:82 'Slow Zone Part Unloaded Position' parameter.

This parameter is only processed if the Slow Zone is turned on. i.e. F8L1:78 'Slow Zone Mode' is not zero.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Slow Zone \ Row 3.

F8L1:84 – Slow Zone Max Decel (ips^2)

Variable Units: Inches per second²

Description: This parameter sets the deceleration constant when the hoist approaches the slow zone and transitions from the normal speed to the reduced speed.

This parameter is only processed if the Slow Zone is turned on. i.e. F8L1:78 'Slow Zone Mode' is not zero.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Slow Zone \ Row 4.

F8L1:85 – Slow Zone Invert

Variable Units: Boolean (0=Off, 1=On)

Description: The slow zone usually is only initiated when the hoist is Below the slow zone heights. This parameter changes the functionality of the slow zone so that it initiates when the hoist is Above the stated heights.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Setup \ Slow Zone \ Row 1.

F8L1:86 through F8L1:255 – Spare

D. User Retained Variables Parameter Array

This array displays all of the user retained variables for the hoist.

These parameters are listed in the User Retained Variables array and can be displayed at:

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ User Program \ UserRetainVars \ Row xx

UserRetainVars:00 – Test Mode Upper Position

Variable Units: Inches

Description: This parameter sets the upper travel limit for the hoist while it is in Test Mode. This value should be set to a number greater than or equal to zero and should not be less than F8L1:05 'Reverse/Upper Limit (in)'.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Motion \ Test Mode \ Row 1

UserRetainVars:01 – Test Mode Lower Position

Variable Units: Inches

Description: This parameter sets the lower travel limit for the hoist while it is in Test Mode. This value should be set to a number greater than the UserRetainVars:00 'Test Mode Upper Position' parameter.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Motion \ Test Mode \ Row 1

UserRetainVars:02 – Test Mode Target Velocity

Variable Units: Inches per second

Description: This parameter sets the speed of the hoist while it is in Test Mode.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Motion \ Test Mode \ Row 2

UserRetainVars:03 – Test Mode Target Acceleration

Variable Units: Inches per second²

Description: This parameter sets the acceleration of the hoist while it is in Test Mode.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Motion \ Test Mode \ Row 2

UserRetainVars:04 – Test Mode Target Deceleration

Variable Units: Inches per second²

Description: This parameter sets the deceleration of the hoist while it is in Test Mode.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Motion \ Test Mode \ Row 2

UserRetainVars:05 – Test Mode Delay Between Moves

Variable Units: Milliseconds

Description: This parameter sets the time delay between upward and downward cycles of the hoist while it is in Test Mode. The hoist will move up, delay at its upper position, move down and then delay at its lower position.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Motion \ Test Mode \ Row 3

UserRetainVars:06 – Test Mode Target Move Count

Variable Units: Count

Description: This parameter sets number of movements the hoist will perform while it is in Test Mode. This count will be increased for every move up and move down the hoist completes. i.e. A complete up and down cycle of the hoist will count as TWO movements.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Motion \ Test Mode \ Row 3

UserRetainVars:07 – Test Mode Start Test Cycle

Variable Units: Boolean (0=Off, 1=On)

Description: This parameter starts the Test Mode if it is a One and stops Test Mode if it is a Zero.

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Motion \ Test Mode \ Row 5

UserRetainVars:08 – Test Mode Current Movement Count

Variable Units: Count

Description: This parameter sets displays the current movement count of the hoist while it is in Test Mode.
KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Motion \ Test Mode \ Row 4

UserRetainVars:09 through UserRetainVars:11 – Spare**UserRetainVars:12 – Part Loaded Weight (lb)**

Variable Units: Pounds

Description: This is a weight in pounds that triggers the part loaded bit On. If the current weight hanging from the fixture is greater than this parameter, then the part loaded bit is On. If the current weight hanging from the fixture is less than this parameter, then the part loaded bit is Off.

UserRetainVars:13 – Clear to Rotate Position (in)

Variable Units: Inches

Description: This parameter sets a height that the hoist must be above to allow the Rotate function to execute.

UserRetainVars:14 – Fixture Down Force (lb)

Variable Units: Pounds

Description: This parameter controls the amount of weight that the hoist has to set down before permitting the clamp open motion to execute. This Ensures that the operator places at least a portion of the part's weight down on a surface before allowing the part clamp to open.

UserRetainVars:15 – Tilt Window Upper Position, Loaded (in)

Variable Units: Inches

Description: This parameter sets the upper limit of the window that allows the Tilt function to execute while the hoist is loaded. i.e. The Part Weight (fSTS:17 'Steady Part Weight') is greater than the value in UserRetainVar:12 'Part Loaded Weight (lb)'.

UserRetainVars:16 – Tilt Window Lower Position, Loaded (in)

Variable Units: Inches

Description: This parameter sets the lower limit of the window that allows the Tilt function to execute while the hoist is loaded. i.e. The Part Weight (fSTS:17 'Steady Part Weight') is greater than the value in UserRetainVar:12 'Part Loaded Weight (lb)'.

UserRetainVars:17 – Tilt Window Upper Position, Unloaded (in)

Variable Units: Inches

Description: This parameter sets the upper limit of the window that allows the Tilt function to execute while the hoist is unloaded. i.e. The Part Weight (fSTS:17 'Steady Part Weight') is less than the value in UserRetainVar:12 'Part Loaded Weight (lb)'.

UserRetainVars:18 – Tilt Window Lower Position, Unloaded (in)

Variable Units: Inches

Description: This parameter sets the lower limit of the window that allows the Tilt function to execute while the hoist is unloaded. i.e. The Part Weight (fSTS:17 'Steady Part Weight') is less than the value in UserRetainVar:12 'Part Loaded Weight (lb)'.

UserRetainVars:19 and UserRetainVars:20 – Spare**UserRetainVars:21 – Fixture Disconnected Maximum Lift Weight (lb)**

Variable Units: Pounds

Description: This parameter sets the maximum weight that the hoist is allowed to lift when the fixture is not connected to the Load Monitoring Module (LMM).

UserRetainVars:22 – Parameter Set 1 Target Velocity (ips)

Variable Units: Inches per second

Description: This Parameter Set 1 variable must be enabled. If enabled, it sets the velocity during an automatic move function.

UserRetainVars:23 – Parameter Set 1 Target Acceleration (ips^2)

Variable Units: Inches per second²

Description: This Parameter Set 1 variable must be enabled. If enabled, it sets the acceleration during an automatic move function.

UserRetainVars:24 – Parameter Set 1 Target Deceleration (ips^2)

Variable Units: Inches per second²

Description: This Parameter Set 1 variable must be enabled. If enabled, it sets the deceleration during an automatic move function.

UserRetainVars:25 – Parameter Set 1 Target Position (in)

Variable Units: Inches

Description: This Parameter Set 1 variable must be enabled. If enabled, it sets the destination for an automatic move function.

UserRetainVars:26 – Parameter Set 1 Float Weight (lb)

Variable Units: Pounds

Description: This Parameter Set 1 variable must be enabled. If enabled, it sets the weight used by Float Mode instead of using the normal instantaneous weight obtained when Float Mode is initiated.

UserRetainVars:27 – Parameter Set 1 Forward/Lower Limit (in)

Variable Units: Inches

Description: This Parameter Set 1 variable must be enabled. If enabled, it sets the lower travel limit for the hoist.

UserRetainVars:28 – Parameter Set 1 Reverse/Upper Limit (in)

Variable Units: Inches

Description: This Parameter Set 1 variable must be enabled. If enabled, it sets the upper travel limit for the hoist.

UserRetainVars:29 – Parameter Set 1 Minimum Part Weight (lb)

Variable Units: Pounds

Description: This Parameter Set 1 variable must be enabled. If enabled, it limits the load that the Servo Hoist will set down on a surface.

UserRetainVars:30 – Parameter Set 1 Maximum Total Weight (lb)

Variable Units: Pounds

Description: This Parameter Set 1 variable must be enabled. If enabled, it sets the maximum load that the Servo Hoist will lift.

UserRetainVars:31 – Parameter Set 1 Maximum Torque (Nm)

Variable Units: Newton meters

Description: This Parameter Set 1 variable must be enabled. If enabled, it sets the maximum motor feedback torque allowed.

UserRetainVars:32 – Parameter Set 1 Maximum Motor Current (A)

Variable Units: Amps

Description: This Parameter Set 1 variable must be enabled. If enabled, it sets the maximum current sent to the motor.

UserRetainVars:33 – Parameter Set 1 Maximum Velocity (ips)

Variable Units: Inches per second

Description: This Parameter Set 1 variable must be enabled. If enabled, it sets the maximum speed that the Servo Hoist may travel.

UserRetainVars:34 – Parameter Set 1 Fixture Weight (lb)

Variable Units: Pounds

Description: This Parameter Set 1 variable must be enabled. If enabled, it shows the static weight of all equipment hanging below the hoist's Load Monitoring Module (LMM).

UserRetainVars:35 – Parameter Set 1 Invert Slow Zone

Variable Units: Boolean (0=Off, 1=On)

Description: The Parameter Set 1 slow zone usually is only initiated when the hoist is Below the Parameter Set 1 slow zone heights. This parameter changes the functionality of the Parameter Set 1 slow zone so that it initiates when the hoist is Above the stated Parameter Set 1 heights.

This parameter is only processed if the Parameter Set 1 Slow Zone is turned on:

i.e. UserRetainVar:36 'Parameter Set 1 Slow Zone Mode' is not zero.

UserRetainVars:36 – Parameter Set 1 Slow Zone Mode

Variable Units: Choice (0=off, 1=down, 2=up, 3=up and down)

Description: This Parameter Set 1 variable must be enabled. If enabled, the hoist's automatic slow zone will be active.

This parameter works with the User Retained Variables 37 - 42 to configure the Parameter Set 1 slow zone.

0 = Parameter Set 1 Slow Zone feature is disabled.

1 = Program will automatically decrease the speed of the hoist only when moving down.

2 = Program will automatically decrease the speed of the hoist only when moving up.

3 = Program will automatically decrease the speed of the hoist when moving up or down.

NOTE: If using this function, all parameters (37 to 42) must be non-zero for the Slow Zone to function correctly.

UserRetainVars:37 – Parameter Set 1 Slow Zone Part Loaded Sense Weight (lb)

Variable Units: Pounds

Description: This parameter sets the number of pounds that the hoist needs to register in order to indicate that a part is loaded on the fixture.

This parameter is only processed if the Parameter Set 1 Slow Zone is turned on:

i.e. UserRetainVar:36 'Parameter Set 1 Slow Zone Mode' is not zero.

UserRetainVars:38 – Parameter Set 1 Slow Zone Part Loaded Max Speed (ips)

Variable Units: Inches per second

Description: This parameter sets the reduced speed that the hoist moves at when a part is loaded and it is below the UserRetainVar:39 'Parameter Set 1 Slow Zone Part Loaded Position (in)' parameter.

This parameter is only processed if the Parameter Set 1 Slow Zone is turned on:

i.e. UserRetainVar:36 'Parameter Set 1 Slow Zone Mode' is not zero.

UserRetainVars:39 – Parameter Set 1 Slow Zone Part Loaded Position (in)

Variable Units: Inches

Description: This parameter sets the height that the hoist will start to move at a reduced speed when a part is loaded.

This parameter is only processed if the Parameter Set 1 Slow Zone is turned on:

i.e. UserRetainVar:36 'Parameter Set 1 Slow Zone Mode' is not zero.

NOTE: The current position of the hoist is visible in fSTS: 30 "Real World Position" or on the KSS Home screen location: Quick View panel \ Row 5 (Lower right-hand portion of the screen).

UserRetainVars:40 – Parameter Set 1 Slow Zone Part Unloaded Max Speed (ips)

Variable Units: Inches per second

Description: This parameter sets the reduced speed that the hoist moves at when a part is unloaded and it is below the UserRetainVar:41 'Parameter Set 1 Slow Zone Part Unloaded Position (in)' parameter.

This parameter is only processed if the Parameter Set 1 Slow Zone is turned on:

i.e. UserRetainVar:36 'Parameter Set 1 Slow Zone Mode' is not zero.

UserRetainVars:41 – Parameter Set 1 Slow Zone Part Unloaded Position (in)

Variable Units: Inches

Description: This parameter sets the height that the hoist will start to move at a reduced speed when a part is unloaded.

This parameter is only processed if the Parameter Set 1 Slow Zone is turned on:

i.e. UserRetainVar:36 'Parameter Set 1 Slow Zone Mode' is not zero.

UserRetainVars:42 – Parameter Set 1 Slow Zone Entry Decel Rate

Variable Units: Inches per second²

Description: This parameter sets the deceleration rate of the hoist as it transitions from its normal speed to its slow zone speed.

This parameter is only processed if the Parameter Set 1 Slow Zone is turned on:

i.e. UserRetainVar:36 'Parameter Set 1 Slow Zone Mode' is not zero.

UserRetainVars:43 through UserRetainVars:63 – Parameter Set 2

Variable Units: See above

Description: These parameters are described in the Parameter Set 1 section: UserRetainVars:22 to 42.

UserRetainVars:64 through UserRetainVars:84 – Parameter Set 3

Variable Units: See above

Description: These parameters are described in the Parameter Set 1 section: UserRetainVars:22 to 42.

UserRetainVars:85 through UserRetainVars:105 – Parameter Set 4

Variable Units: See above

Description: These parameters are described in the Parameter Set 1 section: UserRetainVars:22 to 42.

UserRetainVars:106 through UserRetainVars:126 – Parameter Set 5

Variable Units: See above

Description: These parameters are described in the Parameter Set 1 section: UserRetainVars:22 to 42.

UserRetainVars:127 through UserRetainVars:147 – Parameter Set 6

Variable Units: See above

Description: These parameters are described in the Parameter Set 1 section: UserRetainVars:22 to 42.

UserRetainVars:148 through UserRetainVars:168 – Parameter Set 7

Variable Units: See above

Description: These parameters are described in the Parameter Set 1 section: UserRetainVars:22 to 42.

UserRetainVars:169 through UserRetainVars:189 – Parameter Set 8

Variable Units: See above

Description: These parameters are described in the Parameter Set 1 section: UserRetainVars:22 to 42.

UserRetainVars:190 through UserRetainVars:210 – Parameter Set 9

Variable Units: See above

Description: These parameters are described in the Parameter Set 1 section: UserRetainVars:22 to 42.

UserRetainVars:211 through UserRetainVars:231 – Parameter Set 10

Variable Units: See above

Description: These parameters are described in the Parameter Set 1 section: UserRetainVars:22 to 42.

UserRetainVars:232 through UserRetainVars:252 – Parameter Set 11

Variable Units: See above

Description: These parameters are described in the Parameter Set 1 section: UserRetainVars:22 to 42.

UserRetainVars:253 through UserRetainVars:273 – Parameter Set 12

Variable Units: See above

Description: These parameters are described in the Parameter Set 1 section: UserRetainVars:22 to 42.

UserRetainVars:274 through UserRetainVars:294 – Parameter Set 13

Variable Units: See above

Description: These parameters are described in the Parameter Set 1 section: UserRetainVars:22 to 42.

UserRetainVars:295 through UserRetainVars:315 – Parameter Set 14

Variable Units: See above

Description: These parameters are described in the Parameter Set 1 section: UserRetainVars:22 to 42.

UserRetainVars:316 through UserRetainVars:336 – Parameter Set 15

Variable Units: See above

Description: These parameters are described in the Parameter Set 1 section: UserRetainVars:22 to 42.

E. F8L2 Parameter Array

This array stores advanced parameters that affect the performance of the hoist. These parameters should only be adjusted with the aid of a Knight Representative.

These parameters are listed in the F8L2 array and can be displayed at:

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Parameters \ F8L2 \ Row xx.

Many of these parameters have equivalent displays located on various Knight Servo Studio (KSS) screens.

The location of these screens is listed at the end of each parameter's description.

See section 5. 'Software' for an explanation of the shorthand used.

	WARNING
	<u>ALL</u> variables in the F8L2 parameter list should <u>NOT</u> be manipulated without the aid of a Knight representative.

F8L2:00 – Spare

F8L2:01 – Inline Handle Trigger Bias (V)

Variable Units: Volts

Description: *Reserved for internal use only.*

F8L2:02 – Spare

F8L2:03 – Reverse Encoder Direction

Variable Units: Boolean (0=Off, 1=On)

Description: This parameter sets the forward direction of the encoder. This is a physical property and should not be modified.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Setup \ Motor and Gearbox \ Row 1½.

F8L2:04 – Spare

F8L2:05 – Gear Ratio

Variable Units: Integer

Description: This parameter states the gear ratio of the gear reducer. This is a physical property and should not be modified.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Setup \ Motor and Gearbox \ Row 4.

F8L2:06 – Max Motor Speed (RPM)

Variable Units: RPM

Description: This parameter states the maximum revolutions per minute of the servo motor. This is a physical property and should not be modified.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Setup \ Motor and Gearbox \ Row 1.

F8L2:07 – Lift Load Cell Gain (lb/V)

Variable Units: Pounds per Volt

Description: This parameter states the gain of the lift load cell. This is a physical property and should not be modified.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Tuning \ Analog Calibration \ Row 3.

F8L2:08 – Float Load Cell Gain (lb/V)

Variable Units: Pounds per Volt

Description: This parameter states the gain of the float load cell. This is a physical property and should not be modified.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Tuning \ Analog Calibration \ Row 2.

F8L2:09 – Lift Load Cell Bias (V)

Variable Units: Volts

Description: This parameter states the value of the lift load cell's analog input when there is no external force exerted on the handle. This is a physical property and should not be modified unless the fixture or inline handle is replaced.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Tuning \ Analog Calibration \ Row 3.

F8L2:10 – Float Load Cell Bias (V)

Variable Units: Volts

Description: This parameter states the value of the float load cell's analog input when there is no external weight hanging from the Load Monitoring Module (LMM). This is a physical property and should not be modified unless the LMM is replaced.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Tuning \ Analog Calibration \ Row 2.

F8L2:11 – Reverse Motor Direction

Variable Units: Boolean (0=Off, 1=On)

Description: This parameter sets the direction of the servo motor. This is a physical property of the servo motor and should not be modified.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Setup \ Motor and Gearbox \ Row 1.

F8L2:12 – Spare**F8L2:13 – Max Velocity Following Error (ips)**

Variable Units: Inches per second

Description: This parameter sets the maximum acceptable amount of following error allowable by the hoist. This is used by the controller for detecting a velocity following error which generates a fault number of 104.

F8L2:14 – Chain Pitch (mm)

Variable Units: Millimeters

Description: This parameter states the pitch or length of each chain link. This is a physical property and should not be modified.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Setup \ Motor and Gearbox \ Row 2.

F8L2:15 – Chain Links per Revolution

Variable Units: Number of Chain Links Per Rev

Description: This parameter states the size of the drive sprocket. This is a physical property and should not be modified.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Setup \ Motor and Gearbox \ Row 3.

F8L2:16 – Fault Decel Rate (ips²)

Variable Units: Inches per second²

Description: This parameter sets the deceleration rate of the hoist when a fault occurs. The minimum setting for this is 50in/s².

F8L2:17 – Lift Mode Allow Down Full Speed

Variable Units: Boolean (0=Off, 1=On)

Description: Setting this parameter to a 1 (or On) allows the hoist to travel at its maximum speed when lowering its load in Lift Mode. This speed is dynamically limited by the load weight when moving upwards in Lift Mode. Setting this to a 0 (or Off) dynamically limits the speed when lifting and lowering in Lift Mode.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Setup \ Lift Mode \ Row 4.

F8L2:18 – Hard Stop Home Position (in)

Variable Units: Inches

Description: This parameter displays the “real world” position after accepting a value by pressing the ‘Set Encoder Offset’ button on the ‘Quick Setup’ screen.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Setup \ Quick Setup \ Row 2.

F8L2:19 – Spare**F8L2:20 – Lift Mode Enable**

Variable Units: Boolean (0=Off, 1=On)

Description: This parameter is used to enable or disable Lift Mode.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Setup \ Lift Mode \ Row 1.

F8L2:21 – Max Weight Override (lb)

Variable Units: Pounds

Description: This sets the maximum load that the Servo Hoist will lift. This includes the weight of the fixture and the part.

NOTE: Parameter F8L1:21 ‘Max Weight (lb.)’ also restricts the maximum load. F8L1:21 must be set to a value less than or equal to the value of F8L2:21.

F8L2:22 – Up Stop Resume Bandwidth (lb)

Variable Units: Pounds

Description: *Reserved for internal use only.*

F8L2:23 – Down Stop Resume Bandwidth (lb)

Variable Units: Pounds

Description: *Reserved for internal use only.*

F8L2:24 – Up/Down Stop Resume Time (ms)

Variable Units: Milliseconds

Description: *Reserved for internal use only.*

F8L2:25 – Lift Mode Max Speed Scale Factor

Variable Units: Factor

Description: This factor is multiplied by F8L1:24 ‘Lift Mode Speed Limit (ips)’ to obtain the maximum lift speed of the hoist. This value is normally a one. Any value above one will increase the hoist’s maximum speed and any value below one will reduce the hoist’s maximum speed.

F8L2:26 – Spare**F8L2:27 – Impulse Limiting Enable**

Variable Units: Boolean (0=Off, 1=On)

Description: This parameter is used to enable the hoist’s impulse limiting code. When this code is enabled, the hoist will sense an instantaneous increase in weight registered by the float load cell and slow the hoist to reduce the impact on the system. Instead of suddenly moving the load upwards, the hoist senses the impulse and automatically slows down to a controlled speed.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Tuning \ Impulse Limiting \ Row 1.

F8L2:28 – Impulse Limiting Max Speed (ips)

Variable Units: Inches per second

Description: This parameter sets the speed that the hoist will slow to when impulse limiting is enabled and a sudden movement is detected.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Tuning \ Impulse Limiting \ Row 2.

F8L2:29 – Impulse Limiting Max Speed Time (ms)

Variable Units: Seconds

Description: This parameter sets the duration that the slow speed will be active when impulse limiting is enabled and a sudden movement is detected.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Tuning \ Impulse Limiting \ Row 2.

F8L2:30 – Lift Analog Handle Enable

Variable Units: Boolean (0=Off, 1=On)

Description: This parameter is used to enable an analog handle. This parameter is enabled for systems that have an inline or fixture handle.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Setup \ Lift Mode \ Row 2.

F8L2:31 – Lift Filter Bandwidth

Variable Units: Frequency

Description: This parameter controls how quickly the hoist responds to force changes on the lift load cell. The larger the number the faster the hoist reacts to changes in force applied to the analog handle.

F8L2:32 – Lift Analog Decel on Trigger Release (ips²)

Variable Units: Inches per second²

Description: *Reserved for internal use only.*

F8L2:33 – Lift Proportional Accel (ips²)

Variable Units: Inches per second²

Description: *Reserved for internal use only.*

F8L2:34 – Lift Proportional Decel (ips²)

Variable Units: Inches per second²

Description: *Reserved for internal use only.*

F8L2:35 – Lift Command Force Limit (lb)

Variable Units: Pounds

Description: This parameter sets the maximum lift command that can be given to the hoist via an analog handle without generating a fault. For example, if this parameter is set to 100lbs and a force of more than 100lbs is applied to the handle while the hoist is in Lift Mode then the software will generate a fault.

F8L2:36 – Lift Cancel Gain

Variable Units: Real Number

Description: This parameter controls how much of the force registered on the lift load cell is subtracted from the force seen on the float load cell when using a fixture handle.

F8L2:37 – Spare**F8L2:38 – Lift Digital PB Enable**

Variable Units: Boolean (0=Off, 1=On)

Description: This parameter is used to enable a digital handle. This parameter is enabled for systems that have a single-speed or two-speed pushbutton control handle or a wireless transmitter pendant.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Setup \ Lift Mode \ Row 3.

F8L2:39 – Spare**F8L2:40 – Float Mode Enable**

Variable Units: Boolean (0=Off, 1=On)

Description: This parameter is used to enable or disable Float Mode.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Setup \ Float Mode \ Row 1.

F8L2:41 through F8L2:44 – Spare

F8L2:45 – Float Mode Max Speed Scale Factor

Variable Units: Factor

Description: This factor is multiplied by F8L1:44 'Float Mode Speed Limit (ips)' to obtain the maximum speed of the hoist while it is in Float Mode. This value is normally a one. Any value above one will increase the hoist's maximum speed and any value below one will reduce the hoist's maximum speed.

F8L2:46 through F8L2:50 – Spare**F8L2:51 – "In Position" Velocity Window**

Variable Units: Inches

Description: *Reserved for internal use only.*

F8L2:52 – Spare**F8L2:53 – Float Proportional Accel (ips²)**

Variable Units: Inches per second²

Description: *Reserved for internal use only.*

F8L2:54 – Float Proportional Decel (ips²)

Variable Units: Inches per second²

Description: *Reserved for internal use only.*

F8L2:55 – Float Command Force Limit (lb)

Variable Units: Pounds

Description: This parameter sets the maximum float command that can be given to the hoist without generating a fault. For example, if this parameter is set to 100lbs and a force of more than 100lbs is applied to the fixture or part while the hoist is in Float Mode then the software will generate a fault.

F8L2:56 through F8L2:59 – Spare**F8L2:60 – Float Proportional Gain**

Variable Units: Real Number

Description: This parameter sets the target velocity per unit of force exerted on the float load cell while the hoist is in Float Mode.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Setup \ Float Mode \ Row 4.

F8L2:61 – Float Filter Scale Factor

Variable Units: Real Number

Description: This parameter sets how quickly the force applied to the load suspended from the Load Monitoring Module changes the float command velocity.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Setup \ Float Mode \ Row 4.

F8L2:62 – Spare**F8L2:63 – Float Force Filter Trim Scale Factor**

Variable Units: Real Number

Description: This parameter allows the hoist to respond quicker to a float motion input command. The higher the value, the easier it is to begin movement of the hoist while it is in Float Mode.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Setup \ Float Mode \ Row 5.

F8L2:64 – Max Speed for Jerk Limiting (ips)

Variable Units: Inches per second

Description: This parameter controls the maximum velocity the hoist can be travelling at and still reset the "Hit Ground" bit while it is in Float Mode.

F8L2:65 – Disable Gear Unlock Code

Variable Units: Real Number

Description: When this parameter is enabled, it limits the initial maximum velocity of Float Mode. When the hoist slows below the speed listed in F8L3[68] 'Gear Unlock Feedback Velocity (ips)', then the software will prevent any increase in speed over F8L3[67] 'Gear Unlock Command Velocity (ips)' for the amount of time in F8L3[69] 'Gear Unlock Time (ms)'. After this delay, the hoist is allowed to ramp up towards its commanded velocity.

F8L2:66 – Spare**F8L2:67 – Enable Accelerometer**

Variable Units: *Reserved for internal use only.*

Description: *Reserved for internal use only.*

F8L2:68 – Accelerometer Gain (G/V)

Variable Units: *Reserved for internal use only.*

Description: *Reserved for internal use only.*

F8L2:69 and F8L2:70 – Spare**F8L2:71 – Enable Stress Relief Logic**

Variable Units: *Reserved for internal use only.*

Description: *Reserved for internal use only.*

F8L2:72 – Spare**F8L2:73 – Polynomial Weight Correction Factor 6**

Variable Units: *Reserved for internal use only.*

Description: *Reserved for internal use only.*

F8L2:74 – Polynomial Weight Correction Factor 5

Variable Units: *Reserved for internal use only.*

Description: *Reserved for internal use only.*

F8L2:75 – Polynomial Weight Correction Factor 4

Variable Units: *Reserved for internal use only.*

Description: *Reserved for internal use only.*

F8L2:76 – Polynomial Weight Correction Factor 3

Variable Units: *Reserved for internal use only.*

Description: *Reserved for internal use only.*

F8L2:77 – Polynomial Weight Correction Factor 2

Variable Units: *Reserved for internal use only.*

Description: *Reserved for internal use only.*

F8L2:78 – Polynomial Weight Correction Factor 1

Variable Units: *Reserved for internal use only.*

Description: *Reserved for internal use only.*

F8L2:79 – Polynomial Weight Correction Factor 0

Variable Units: *Reserved for internal use only.*

Description: *Reserved for internal use only.*

F8L2:80 – Touch Filter Bandwidth

Variable Units: Real Number

Description: This parameter controls how quickly the system triggers a Down Stop or Up Stop in response to exceeding the minimum or maximum weight. The larger the number the more quickly the hoist responds.

F8L2:81 – Steady Weight Filter Constant

Variable Units: Real Number

Description: This parameter controls how quickly the "Steady Part Weight" value changes in response to changes in float load cell force. The larger the number the more quickly the hoist responds.

F8L2:82 – Spare**F8L2:83 – Active Damping Filter Constant (LF)**

Variable Units: Real Number

Description: This parameter is used in conjunction with F8L2:86 'Active Damping Gain (LF)' to prevent low frequency oscillations occurring at the control handle.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Tuning \ Active Dampening Filters \ Row 1.

F8L2:84 – Spare**F8L2:85 – Active Damping Filter Constant (HF)**

Variable Units: Real Number

Description: This parameter is used in conjunction with F8L2:87 'Active Damping Gain (HF)' to prevent high frequency oscillations occurring at the control handle.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Tuning \ Active Dampening Filters \ Row 2.

F8L2:86 – Active Damping Gain (LF)

Variable Units: Real Number

Description: This parameter is used in conjunction with F8L2:83 'Active Damping Filter Constant (LF)' to prevent low frequency oscillations occurring at the control handle.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Tuning \ Active Dampening Filters \ Row 1.

F8L2:87 – Active Damping Gain (HF)

Variable Units: Real Number

Description: This parameter is used in conjunction with F8L2:85 'Active Damping Filter Constant (HF)' to prevent high frequency oscillations occurring at the control handle.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Tuning \ Active Dampening Filters \ Row 2.

F8L2:88 and F8L2:89 – Spare**F8L2:90 – Active Damping Min Gain (Lift)**

Variable Units: Real Number

Description: This parameter sets the lowest point the velocity-based ramp-down multiplier can reach. This is only valid for Lift Mode.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Tuning \ Active Dampening Filters \ Row 3.

F8L2:91 – Active Damping Min Gain (Float)

Variable Units: Real Number

Description: This parameter sets the lowest point the velocity-based ramp-down multiplier can reach. This is only valid for Float Mode.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Tuning \ Active Dampening Filters \ Row 3.

F8L2:92 – Active Damping Always On

Variable Units: Boolean (0=Off, 1=On)

Description: This parameter controls whether or not the low frequency Active Damping velocity is ramped down based on velocity. If the value is a one (or On), the hoist will only control the ramp function while it is moving down towards the ground. If the value is a zero (or Off), it will control the velocity in both directions.

F8L2:93 – Active Damping Ramp Down Start Position (in)

Variable Units: Inches

Description: This parameter sets the point at which the active damping velocity starts to ramp down based on position.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Tuning \ Active Dampening Filters \ Row 4.

F8L2:94 – Active Damping Ramp Down Min Gain Position (in)

Variable Units: Inches

Description: This parameter sets the point at which the position-based ramp reaches its minimum multiplier value.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Tuning \ Active Dampening Filters \ Row 4.

F8L2:95 – Active Damping Ramp Down Min Gain

Variable Units: Real Number

Description: This parameter sets the lowest point the position-based ramp-down multiplier can reach.

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Tuning \ Active Dampening Filters \ Row 4.

F8L2:96 – Enable LF AD Notch Filter

Variable Units: *Reserved for internal use only.*

Description: *Reserved for internal use only.*

F8L2:97 – Enable HF AD Notch Filter

Variable Units: *Reserved for internal use only.*

Description: *Reserved for internal use only.*

F8L2:98 – 2nd Float LC Gain (lb/V)

Variable Units: *Reserved for internal use only.*

Description: *Reserved for internal use only.*

F8L2:99 – 2nd Float LC Bias (V)

Variable Units: *Reserved for internal use only.*

Description: *Reserved for internal use only.*

F8L2:100 through F8L2:255 – Spare

	WARNING
	<u>ALL</u> variables in the F8L2 parameter list should NOT be manipulated without the aid of a Knight representative.

F. F8L3 Parameter Array

This entire array is reserved for internal use.

7. TROUBLESHOOTING

There are several troubleshooting screens described in this section:

- 7.A.) Troubleshooting Screens
- 7.B.) System Activity screens including Faults, Warnings and Error Codes
- 7.C.) Troubleshooting Inputs and Outputs
- 7.D.) Troubleshooting Chart

A. Troubleshooting Screens

There are several Troubleshooting screens covered in this section. Each of these screens is listed below and can be accessed inside the Knight Servo Studio (KSS) software from:

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Troubleshooting \ ...

- 7a) Motion Not Allowed screen
- 7b) Can't Enter Lift Mode screen
- 7c) Can't Enter Float Mode screen
- 7d) Can't Move Up/Reverse screen
- 7e) Can't Move Down/Forward screen
- 7f) Flashing Red Light screen
- 7g) Flashing Green Light screen
- 7h) Not Booting/Displays All Show 0 screen
- 7i) Drive Won't Enable screen
- 7j) Not Moving Correctly screen
- 7k) Velocity Following Error/Overspeed screen

See section 5. 'Software' for an explanation of the shorthand used.

7a) Motion Not Allowed screen

This screen lists the steps to trace down the reason why the hoist's motion is not allowed.

In section (I), if the indicator box is green then the hoist's motion is allowed, but if the indicator box is red then the hoist's motion is restricted.

If the hoist's motion is restricted, follow the steps listed on the screen below. (Refer to Figure 7-1)




Figure 7-1

7b) Can't Enter Lift Mode screen

This screen lists the steps to trace down the reason why the hoist will not enter Lift Mode.

In section (I), if the indicator box is green then the function is on, but if the indicator box is red then the function is off.

In section (II), if the indicator box is green then the function is on, but if the indicator box is grey then the function is off.

In section (III), if the indicator box is green then the function is on, but if the indicator box is red then the function is off.

If the hoist will not enter Lift Mode, ensure all of the conditions listed on the screen below are met.
(Refer to Figure 7-2)




Figure 7-2

7c) Can't Enter Float Mode screen

This screen lists the steps to trace down the reason why the hoist will not enter Float Mode.

In section (I), if the indicator box is green then the function is on, but if the indicator box is red then the function is off.

In section (II), if the indicator box is green then the function is on, but if the indicator box is grey then the function is off.

In section (III), if the indicator box is green then the function is on, but if the indicator box is red then the function is off.

If the hoist will not enter Float Mode, ensure all of the conditions listed on the screen below are met.
(Refer to Figure 7-3)




Figure 7-3

7d) Can't Move Up/Reverse screen

This screen lists the steps to trace down the reason why the hoist won't move upwards towards the bottom of the servo.

In section (I), if the indicator box is green then the function is on, but if the indicator box is grey then the function is off.

In section (II), the current measured weight is shown as well as the maximum weight the hoist will lift.

In section (III), the current position is shown as well as the upper limit of the hoist.

In section (IV), both of the load cell voltages are shown in real time.

NOTE: If the hoist only has a digital up/down control handle, the 'Lift LC Voltage' will be zero.

In section (V), if the indicator box is red then the hoist's Up Stop is active, but if it is grey the hoist's Up Stop is off. If the Up Stop is active then the software is preventing the hoist from moving up.

If the hoist won't move up, ensure all of the conditions listed on the screen below are met.
(Refer to Figure 7-4)




Figure 7-4

7e) Can't Move Down/Forward screen

This screen lists the steps to trace down the reason why the hoist won't move down towards the facilities' floor.

In section (I), if the indicator box is green then the function is on, but if the indicator box is grey then the function is off.

In section (II), the current measured weight is shown as well as the total weight that the hoist will set down on a surface.

In section (III), the current position is shown as well as the lower limit of the hoist.

In section (IV), both of the load cell voltages are shown in real time.

NOTE: If the hoist only has a digital up/down control handle, the 'Lift LC Voltage' will be zero.

In section (V), if the indicator box is red then the hoist's Down Stop is active, but if it is grey the hoist's Down Stop is off. If the Down Stop is active then the software is preventing the hoist from moving down.

If the hoist won't move down ensure all of the conditions listed on the screen below are met.

(Refer to Figure 7-5)

The screenshot shows a software interface titled "Can't Move Down/Forward (... X)". It contains several sections with status indicators and numerical data. Five red arrows labeled I through V point to the following sections:

- I** points to the "Must be in lift or float mode." section, which includes two checkboxes: "In Lift Mode" (green) and "In Float Mode" (grey).
- II** points to the "Part weight must be above minimum value." section, which includes two input fields: "Part Weight (lb)" with the value 479.5886 and "Minimum Part Weight (lb)" with the value -10.
- III** points to the "Current position must be above lower limit (Negative=up, Positive=down)." section, which includes two input fields: "Current Position" with the value 39.93143 and "Lower Limit" with the value 50.
- IV** points to the "Load cells must react to applied force if installed. Verify values change when force is applied." section, which includes two input fields: "Lift LC Voltage" with the value -2.925415 and "Float LC Voltage" with the value 4.515991.
- V** points to the "User Program Commanded Down Stop - Check user program logic and variables." section, which includes a checkbox labeled "User Program Down Stop" (grey).

Figure 7-5

7f) Flashing Red Light screen


This screen lists the steps to trace down the reason why the hoist's red fault light is flashing.

In section (I), if the indicator box is red then either a Fault or Warning is Active.

If the hoist's red light is flashing, check the 'Code' display to find out which Fault or Warning is Active.

The 'Code' display is located in the left-middle portion of the screen below, and this error code can also be seen at:

KSS Home screen location: Quick View panel \ Row 6 (Lower right-hand portion of the screen).
(Refer to Figure 7-6)



7g) Flashing Green Light screen

This screen lists the steps to trace down the reason why the hoist's green light is flashing. This green light is customarily referred to as the 'Lift Mode light' because it is normally illuminated during Lift Mode.

In section (I), if the indicator box is green then the function is on, but if the indicator box is grey then the function is off.

In section (II), if the indicator box is green then the function is on, but if the indicator box is grey then the function is off. This screen lists information generated by both a digital and an analog handle.

In section (III), if the green light is flashing, then usually one of two situations are occurring:

- 1) The analog handle is being activated with an excessive amount of force influencing the handle.
- 2) The hoist has application specific code communicating an event to the operator.

If the hoist's green light is flashing, follow the steps listed on the screen below. (Refer to Figure 7-7)





Figure 7-7

7h) Not Booting/Displays All Show 0 screen


This screen lists the steps to trace down the reason why the hoist's Knight Servo Studio is displaying all Zeros on its displays.

If the KSS displays are all showing Zeros, follow the steps listed on the screen below. (Refer to Figure 7-8)

**7i) Drive Won't Enable screen**

This screen lists the steps to trace down the reason why the hoist won't enable.


If the hoist won't enable, follow the steps listed on the screen below. (Refer to Figure 7-9)



7j) Not Moving Correctly screen

This screen lists the steps to trace down the reason why the hoist won't move up and down smoothly.

If the hoist won't move up and down easily, follow the steps listed on the screen below. (Refer to Figure 7-10)


**7k) Velocity Following Error/Overspeed screen**

This screen lists the steps to trace down the reason why the hoist is experiencing multiple Velocity Following errors. The Velocity Follow error will generate a 104 Fault in the software.

This fault will be listed on the:

KSS Home screen location: Quick View panel \ Row 1 (Lower right-hand portion of the screen).

If the hoist is experiencing an excessive number of Velocity Following errors, follow the steps listed on the screen below. (Refer to Figure 7-11)



B. System Activity screens including Faults, Warnings and Error Codes

There are several System Activity screens covered in this section. Each of these screens is listed below and can be accessed inside the Knight Servo Studio (KSS) software from:

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Status \


- 7l) System Status Bits screen
- 7m) Active Faults screen
- 7n) Active Warnings screen
- 7o) Knight Error Codes - These error codes are displayed in the Knight Servo Studio.
- 7p) Sieb & Meyer Error Codes - These codes are flashed on the servo's 7-segment display.

7l) System Status Bits screen

This screen shows many aspects of the hoist's systems in real time.

In section (I), if the indicator box is green then that particular hoist's function is on, but if the indicator box is grey then that particular hoist's function is off.

This screen gives an overview of the hoist's readiness. (Refer to Figure 7-12)



7m) Active Faults screen

This screen shows all faults that may be active on the hoist.

In section (I), if the indicator box is red then that fault is active, but if the indicator box is grey then that fault is off.

This screen graphically shows if a fault is active. If a fault is active it will correspond to a particular fault code.

This fault code can be easily viewed at:

KSS Home screen location: Quick View panel \ Row 1 (Lower right-hand portion of the screen).

(Refer to Figure 7-13)



Figure 7-13

7n) Active Warnings screen

This screen shows all warnings that may be active on the hoist.

In section (I), if the indicator box is yellow then that warning is active, but if the indicator box is grey then that warning is off.

This screen graphically shows if a warning is active. If a warning is active it will correspond to a particular warning code. This warning code can be easily viewed at:

KSS Home screen location: Quick View panel \ Row 1 (Lower right-hand portion of the screen).

(Refer to Figure 7-14)




Figure 7-14

7o) Knight Error Codes

These are the error codes that can be generated by the Knight firmware and displayed in the Knight Servo Studio.

Error Code	Description
100	Hardware Fault
101	Run-Stop button pressed
102	Bad Parameters
103	Bad Position Command
104	Velocity Following Error
105	Position Following Error
106	Axis Enable Failure
107	Float Load Cell Not Connected
109	Excessive Lift Force Fault
111	Overspeed Fault
140	User Program Fault
150	Heartbeat Lost Fault
152	Illegal Encoder State
153	Forward Overtravel
154	Reverse Overtravel
250	Position Out Of Range
252	Onboard I/O Fault
253	Addon I/O Fault
254	Payout Mode Active
255	Fatal Error
256	Output Stage Overcurrent Fault
257	Motor Overcurrent Fault
258	Output Overtemperature Fault
259	CPU Overtemperature Fault
260	Output Overtemperature U Fault
261	Output Overtemperature V Fault
262	Output Overtemperature W Fault
263	Output Stage Failure Fault
264	Output Stage Supply Fault
265	Output Stage Overload Fault
266	Output Stage Overload U Fault
267	Output Stage Overload V Fault
268	Output Stage Overload W Fault

Error Code	Description
269	Motor Temperature Fault
270	Feedback Fault
271	Chopper IIT Fault
272	Power IIT Fault
273	Power Lost Fault
274	Rintern IIT Fault
275	Rextern IIT Fault
276	Power Overload Fault
277	Power Undervoltage Fault
278	Power Overvoltage Fault
279	Chopper Overload Fault
280	Power Overcurrent Fault
281	Enable Lost Fault
282	LL EStop Fault
283	LL Error Fault
284	Onboard I/O #4 Fault
285	Onboard I/O #5 Fault
286	Onboard I/O #6 Fault
287	Onboard I/O #7 Fault
288	Onboard I/O #8 Fault
289	Onboard I/O #9 Fault
290	Onboard I/O #10 Fault
291	Onboard I/O #11 Fault
292	Onboard I/O #12 Fault
293	Onboard I/O #13 Fault
294	Onboard I/O #14 Fault
295	Onboard I/O #15 Fault
296	Addon I/O #36 Fault
297	Addon I/O #37 Fault
298	Addon I/O #38 Fault
299	Addon I/O #39 Fault
300	Addon I/O #40 Fault
301	Addon I/O #41 Fault
302	Addon I/O #42 Fault
303	Addon I/O #43 Fault
304	Addon I/O #44 Fault
305	Addon I/O #45 Fault
306	Addon I/O #46 Fault
307	Addon I/O #47 Fault

7p) Sieb & Meyer Error Codes

The 7-segment display located on the front of the Sieb & Meyer SD3 servo drive displays internal error codes programmed by the manufacturer. These error codes are flashed on the display one digit at a time and are preceded by an “E”. For instance, the error “Supply Voltage Too Low” equates to Error Code 0132. The 7-segment display would flash an “E”, then a “0”, then a “1”, then a “3”, then a “2.”. This code will repeat until the error is remedied.

The Knight fault codes displayed in Knight Servo Studio are the primary troubleshooting resource, but the Sieb & Meyer error codes are provided here for reference.

Error Code	Description
0002	Log File
0003	File Not Found
0004	Create XML File
0005	Real Time FIFO
0006	Install ISR
0007	Task Let
0008	ISR Install
0009	Shared Memory Not Found
0010	Undefined State
0011	Wrong Parameter Value
0012	Object Not Found
0013	Wrong Object Size
0014	Parameter File Not Found
0015	Type Plate File Not Found
0016	EEPROM Time Out
0017	EEPROM Check Sum
0018	No Valid Interrupt ID
0019	No Valid Serial Number
0020	Wrong Hardware ID Code
0021	Task Create
0022	Wrong Command
0023	Compensation File Not Found
0024	Command Canceled
0025	Machine Stop
0026	No PCIe Device
0027	FPGA Done Time Out
0028	FPGA Initialization Time Out
0029	Wrong File Format
0030	Mapping
0031	No Shared Memory Block
0032	No Plugin Found
0033	Shared Memory Block Not Found
0034	Shared Memory Block Size
0035	No Response
0036	Buffer Full
0037	Wrong Curve Count
0038	FPGA Wrong Version
0039	Wrong Product Name
0040	Wrong Product ID
0041	Wrong Product Version
0042	Wrong Product ID In Parameter File
0043	Create Object Dictionary File
0044	Create Device Configuration File
0045	Create Parameter Files

Error Code	Description
0046	Hardware File
0047	System Clock Not Set
0073	Quit Reboot
0074	Quit Create Object Dictionary
0075	Quit Create Default Parameter
0076	Quit Program
0077	Quit Restart
0078	Quit IP
0079	Parameter Not Found
0080	Script Execution Fault
0081	Hardware Not Available
0082	FPGA Package File Not Found
0112	IIT Power
0113	IIT Chopper Resistor
0114	Input Lost
0115	Undervoltage
0116	Overvoltage
0117	Chopper Overload
0118	DC-DC Converter Fault
0119	DC-DC Overload
0120	PFC Fault
0121	Preload Time
0122	Power Overload
0123	Preload
0124	Power Off
0125	DCO Voltage
0126	DC1 Voltage
0127	DC2 Voltage
0128	Safety
0129	Chopper Resistor Too Low
0130	Chopper Power Too High
0131	Chopper Resistor Power Too High
0132	Supply Voltage Too Low
0133	Chopper Voltage Too Low
0134	Unknown Supply Type
0135	Supply Voltage Too High
0136	IIT Chopper Resistor 90
0137	Restart Application
0138	Incompatible FPGA File
0139	FPGA File Does Not Exist
0140	Power User Fault
0141	Power Busy

Error Code	Description
0142	IIT Chopper Resistor Internal
0143	IIT Chopper Resistor External
0144	IIT Chopper
0145	Chopper Voltage Level
0146	Power Ok
0147	Module Chopper Temperature
0148	Module Rectifier Temperature
0160	Not Calibrated
0161	Profile
0162	Actual Position Not Destination Position
0163	SG Command Busy
0164	Not Operation Enabled
0165	Illegal Cal Method
0166	Illegal Drive Number
0167	Wrong Drive Type
0168	Not Ready To Switch On
0169	Wrong Start Condition
0170	Drive Parameter Fault
0171	Velocity Out Of Limits
0172	Simulated Error
0173	Change On The Fly
0174	Not In Gantry Mode
0175	Wrong Master
0176	Emergency Stop
0177	Limit Switch P
0178	Limit Switch N
0179	Position Out Of Limits
0180	Parameter Out Of Limits
0181	Motor Temperature
0182	Heat Sink Temperature
0183	Drive Overload
0184	Drive Overvoltage
0185	Drive Undervoltage
0186	Power Stage Off
0187	Gantry Positions Not Equal
0188	Not In Hold Mode
0189	Power Stage On
0190	Acceleration Out Of Limits
0191	Jerk Out Of Limits
0192	Bad Switching
0193	Overload U
0194	Overload V
0195	Overload W
0196	Overload
0197	No Valid Parameter
0198	Output Stage Off
0199	IIT Motor
0200	IIT Output Stage
0201	Module U Temperature
0202	Module V Temperature
0203	Module W Temperature

Error Code	Description
0204	Water Temperature
0205	Ambient Temperature
0206	Feedback
0207	Over Speed
0208	Output Stage Enabled
0209	Limit Switch Input Not Enabled
0210	Brake Output Not Enabled
0211	Function Disabled
0256	NR No Tool
0257	NR Time Out
0258	NR Angle Too Low
0259	NR Angle Too High
0260	NR Torque Out Of Range
0261	NR Friction Torque Too Low
0262	NR Friction Torque Too High
0263	NR Angle Max
0264	NR Current Too Low
0265	NR Current Too High
0266	NR Time Max
0267	NR Illegal Variant
0268	NR Illegal Section
0269	NR Unknown Tool
0270	NR No Transducer
0271	NR No Scanner
0272	NR Start Lost
0273	NR No Valid Section Type
0320	Network Invalid Telegram ID
0321	Network Zero Data
0322	Network CRC
0323	Network Synchronization
0324	Network Configuration
0325	Network NMT
0326	Network Addressing
0327	Network Node Guarding
0328	Network EEPROM
0329	Network Heartbeat
0337	Network Invalid AL Control
0338	Network Unknown AL Control error
0339	Network Boot Not Supported
0340	Network No Valid Firmware
0342	Network Invalid Mbx Configuration
0345	Network No Valid Outputs
0346	Network Sync Error
0347	Network SM Watchdog
0349	Network Invalid SM Out Configuration

Error Code	Description
0351	Network Invalid SM In Configuration
0361	Network Free Run Needs 3 Buffer Mode
0365	Network Fatal Sync Error
0368	Network Invalid Sync Configuration
0374	Network Sync Zero Cycle Time
0377	Network EE Error
0496	OEM
0559	OEM End
0640	TI Base
0641	TI Wrong State
0642	TI Command Not Supported
0643	TI Break Command
0644	TI Wrong Address
0645	TI Config Com Port
0646	TI Device Not Supported
0647	TI No Connection
0650	TI UART Config COM Port
0651	TI UART RX Buffer 0 Overflow
0652	TI UART RX Buffer 1 Overflow
0653	TI UART TX Buffer 0 Overflow
0654	TI UART TX Buffer 1 Overflow
0655	TI UART CRC Error
0656	TI UART Telegram Counter
0660	TI IIC Timeout
0661	TI IIC Wrong Mode
0662	TI IIC Write Data
0663	TI IIC ACK
0664	TI IIC NACK
0665	TI IIC STOP
0666	TI IIC PSR
0667	TI IIC Device
0668	TI IIC res28
0669	TI IIC res29
0670	TI ZMDI IIC
0671	TI ZMDI Measurement
0672	TI ZMDI CRC Error
0673	TI ZMDI Command Not Supported

C: Troubleshooting Inputs and Outputs

This screen can be used to inspect the hoist's Inputs and Outputs. This screen can be accessed inside the Knight Servo Studio (KSS) software from:

KSS Workspace tree location (User Level= Advanced): Knight Work Order # \ Motion \ I/O Control

7q) I/O Control screen

7q) I/O Control screen

This screen shows each of the onboard inputs and outputs.

In section (I), if the indicator box in the 3rd column is green then that I/O point is on, but if that indicator box is grey then it is off.

This screen graphically shows if an Input or Output is On, Forced On, or Forced Off.

In order to Force an I/O point On, mouse to and press the button in the 1st column (labeled 'ON') next to that point. A yellow box in the 1st column indicates that I/O point is Forced On.

NOTE: If the point being Forced On is an Output and that specific Output does not turn on within 25ms, then this will be reflected on the 'I/O Fault' screen. This screen is located at:

KSS Workspace tree location (User Level= Advanced): Knight WO# \ Status \ I/O Fault

In order to Force an I/O point Off, mouse to and press the button in the 2nd column (labeled 'OFF') next to that point. A yellow box in the 2nd column indicates that I/O point is Forced Off.

NOTE: All Forced On or Forced Off I/O points are RESET every time the Run-Stop button is cycled. (Refer to Figure 7-18)




Figure 7-18

D: Troubleshooting Chart

The Servo Hoist operation may be affected by various factors. If your hoist is not performing as well as expected, follow the table below to diagnose the problem. If unable to resolve the issue, contact the Knight Service Department at 248-375-7962 or via e-mail at service@knightglobal.com.

Problem	Cause	Solution
Hoist does not lift or lower	Power loss	Check circuit breaker, switches, and connections of all power lines. Check Run-Stop button, reset if necessary.
	Incorrect voltage	Check supply voltage and frequency of power supply to ensure it is correct for the Servo Hoist.
	Electrical fault	Secure power to the hoist; check all wiring and connections on the Servo Hoist.
	Hoist capacity exceeded	Reduce the weight of the load to within the rated or programmed capacity of the Servo Hoist.
Servo Hoist lifts but does not lower	"Lower Travel Limit" set incorrectly	Check parameter F8L1:06 "Forward / Lower Limit (in)".
	Damaged pendent cord	Check each conductor in the pendent cable for continuity. Replace damaged cable as required.
Servo Hoist lowers but will not lift	"Upper Travel Limit" set incorrectly	Check parameter F8L1:05 "Reverse / Upper Limit (in)".
	Damaged pendent cord	Check each conductor in the pendent cable for continuity. Replace damaged cable as required.
	Hoist capacity exceeded	Reduce the weight of the load to within the rated or programmed capacity of the Servo Hoist.
	Low voltage in power supply	Determine the cause of low voltage and restore voltage back to within +/-10% of required voltage supply.
Servo Hoist does not lift at proper speed	Hoist capacity exceeded	Reduce the weight of the load to within the rated or programmed capacity of the Servo Hoist.
	Low voltage in power supply	Determine the cause of low voltage and restore voltage back to within +/-10% of required voltage supply.
Servo Hoist operates intermittently	Open / Short circuit	Check circuit for loose connections or broken conductors. Repair or replace as necessary.
	Damaged pendent cord	Check each conductor in the pendent cable for continuity. Replace damaged cable as required.
	Damaged handle	Check each conductor in the pendent cable for continuity. Replace damaged conductors as required. Check connections and replace if necessary.
Continuously flashing Green light using an Up/Down Pendent	Damaged pendent cord or switch	Check each conductor in the pendent cable for continuity. Check switch for correct functionality. Replace damaged part as required.

8. SPARE PARTS LIST

Because Knight is continuously improving and updating its products, all product drawings and spare parts lists for this Servo Hoist are provided as supporting documentation accompanying this manual and delivered with the system.

9. DECOMMISSIONING OF A SERVO HOIST

Knight Servo Hoists contain various materials which, at the end of the service life, must be disposed of or recycled (where appropriate), in accordance with statutory regulations.

Decommissioning:

	WARNING Knight Servo Hoists must be decommissioned by qualified personnel.
---	--

- Ensure there is not a load on the hoist.
- Remove power from hoist.
- Remove hoist from rail or support structure.
- If desired, Knight Global will properly dispose of the hoist. Contact a Knight Global representative to obtain a Return Material Authorization form.

10. KNIGHT'S PERFORMANCE WARRANTY

Knight warrants that its products and parts shall meet all applicable specifications, performance requirements, and be free from defects in material and workmanship for one year, (Servo Systems for (2) two years, Pneumatic Lift Tables for (5) five years), from the date of invoice, unless otherwise noted.

Knight warrants the Servo Hoist, Arms, and Tractors to be free from defects in material or workmanship for a period of two years or 6000 hours use from the date of shipment.

On design and build jobs, the customer is the owner of the equipment once they authorize shipment. The purchased equipment cannot be returned for reimbursement or credit.

Exclusions

This warranty shall not cover the failure or defective operation caused by inadequate training provided by customer regarding the operation and/ or maintenance of the tool, misuse, negligence, misadjustment, or any alteration not approved by Knight Global. Knight's obligation is limited to the replacement or repair of Knight's products at a location designated by Knight Global. Buyer is responsible for all associated internal removal and reinstallation costs as well as freight charges to and from Knight Global. Knight's maximum liability shall not in any case exceed the contract price for the products claimed to be defective.

Any field modification made to Knight Products or Systems without the written authorization by Knight Global shall void Knight's warranty obligation.

Any purchased components not manufactured by Knight Global and their specific individual warranties are not covered. Paint defects, scratches and marring from shipping are also excluded on all Knight Global products and products not manufactured by Knight Global.

Knight Distributors/ Agents are not authorized to circumvent or change any of these terms and/ or conditions of this warranty unless prior approval is received in writing by Knight Global Management. Verbal statements made by Knight Distributors/ Agents do not constitute warranties.

Disclaimer

OTHER THAN AS SET FORTH HEREIN, NO OTHER EXPRESSED WARRANTIES, AND NO IMPLIED WARRANTIES, ORAL AND WRITTEN, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE MADE BY KNIGHT GLOBAL WITH RESPECT TO ITS PRODUCTS AND ALL SUCH WARRANTIES ARE HEREBY SPECIFICALLY DISCLAIMED.

KNIGHT GLOBAL SHALL NOT BE LIABLE UNDER ANY CIRCUMSTANCES FOR ANY INCIDENTAL, SPECIAL AND/OR CONSEQUENTIAL DAMAGES WHATSOEVER, WHETHER OR NOT FORESEEABLE, INCLUDING BUT NOT LIMITED TO DAMAGES FOR LOST PROFITS AND ALL SUCH INCIDENTAL, SPECIAL AND/OR CONSEQUENTIAL DAMAGES ARE HEREBY ALSO SPECIFICALLY DISCLAIMED. KNIGHT GLOBAL WILL NOT BE LIABLE FOR ANY LOSS, INJURY OR DAMAGE TO PERSONS OR PROPERTY, NOR FOR DAMAGES OF ANY KIND RESULTING FROM FAILURE OR DEFECTIVE OPERATION OF ANY MATERIALS OR EQUIPMENT FURNISHED HEREUNDER.

11. APPENDIX A: USB LOCATION IN SERVO HOIST MANUAL

Location of Electronic Knight Servo Hoist Technical Manual and Documentation

In an effort to reduce waste of natural resources, Knight has migrated to a complete set of controls documentation in electronic format that is located on a USB drive. This USB drive is created for each Knight Servo System order and is placed in the inside of the front cover of the Knight Servo Technical Manual binder which ships with each job. Please refer to Figure 1 and Figure 2 below.

Knight Servo System Technical Manual and USB Drive



Figure 1



Figure 2

The typical folder layout structure of the Knight Servo System information on the USB drive is shown in Figure 3.




Figure 3

12. APPENDIX B: 250lb and 500lb SERVO INFORMATION

Knight includes a Recommended Spare Parts list and a set of electrical drawings with each system. Below is an example of a Recommended Spare Parts list (Figure 1) and standard system layouts (Figures 2 – 5) for a 250lb or a 500lb servo system.

250lb and 500lb STANDARD SERVO KNIGHT SERVO HOIST RECOMMENDED SPARE PARTS

PART NUMBER	DESCRIPTION	MANUFACTURER
KCA1040-xx.001	19P COIL CABLE, xxFT	KNIGHT GLOBAL
KCA1057-xx.001	POWER CABLE, 3C, 12AWG, SOOW, xxFT	KNIGHT GLOBAL
KSAA1003.001	CHAIN WEAR GAUGE	KNIGHT GLOBAL
A165ELS24D02	ILLUMINATED PB, RED, MUSHROOM, 24VDC	OMRON
A165LTGM24D2	ILLUMINATED PB, GREEN, 24VDC	OMRON
A165LTAM24D2	ILLUMINATED PB, BLUE, 24VDC	OMRON
KCA1037.001	SIEB & MEYER 3.8 KVA SERVO DRIVE	KNIGHT GLOBAL
KSHA1005.001	KOLLMORGEN SERVO MOTOR	KNIGHT GLOBAL
KCA1035-1M.001	MOTOR POWER / BRAKE CABLE, M23, 1M	KNIGHT GLOBAL
KCA1036-1M.001	MOTOR ENCODER FEEDBACK CABLE, M23, 1M	KNIGHT GLOBAL
MDP60-24A-1C	POWER SUPPLY, 24VDC, 2.5A	MICRON
440R-GL2S2T	SAFETY RELAY	ALLEN BRADLEY
2966171	SLICE RELAY, 24VDC, SPDT	PHOENIX
KSHD1017.001	GRAPHITE STICK	KNIGHT GLOBAL
KDSA1010.001	SDS CHAIN REPLACEMENT KIT, 4mm, 18FT	KNIGHT GLOBAL

250lb Servo Reducer Assembly

KDSA1000.001	REDUCER ASSEMBLY, 250 LB, 18' CHAIN	KNIGHT GLOBAL
--------------	-------------------------------------	---------------

500lb Servo Reducer Assembly

KDSA1002.001	REDUCER ASSEMBLY, 500 LB, 18' CHAIN	KNIGHT GLOBAL
--------------	-------------------------------------	---------------

Figure 1




Figure 2




Figure 3




Figure 4

69	4	M8	LOCK WASHER	COMMERCIAL
68	4	M8	WASHER	COMMERCIAL
67	4	M8 x 30mm LG.	SHCS	COMMERCIAL
66	18	M8	HEX KEPS NUT	COMMERCIAL
65	2	M8	NYLOK NUT	COMMERCIAL
64	4	M8	WASHER	COMMERCIAL
63	4	M8 x 50mm LG.	BHCS	COMMERCIAL
62	1	M8 x 25mm LG.	BHCS	COMMERCIAL
61	4	M8 x 20mm LG.	BHCS	COMMERCIAL
60	2	M8 x 18mm LG.	BHCS	COMMERCIAL
59	2	M8 x 14mm LG.	BHCS	COMMERCIAL
58	3	M8 x 12mm LG.	BHCS	COMMERCIAL
57	10	M4	NYLOK NUT	COMMERCIAL
56	8	M4 NOM.	FLAT WASHER	COMMERCIAL
55	8	M4 x 18mm LG.	BHCS	COMMERCIAL
54	2	M4 x 12mm LG.	BHCS	COMMERCIAL
53	4	M4 x 10mm LG.	BHCS	COMMERCIAL
52	16	#12 x 1/2 LG.	PAN HEAD PHILLIPS	COMMERCIAL
51	4	#4-40 x 3/8 LG.	SHCS	COMMERCIAL
50	4	94808A153	CLIP-ON NUT, 10-24	MCMMASTER-CARR
49	2	3960T4	SNAP HOOK	MCMMASTER-CARR
48	1	90312A371	LANYARD, 38"	MCMMASTER-CARR
47	-	-	-	-
46	-	-	-	-
45	1	2988171	SLICE RELAY, 24VDC, SPDT	PHOENIX
44	1	440R-GL2S2T	SAFETY RELAY	ALLEN BRADLEY
43	2	240-2079-ND	FERRITE SLEEVE	STEWART
42	1	490-8814-ND	CAPACITOR, 0.1uF	LITTEL FUSE
41	1	MDP80-24A-1C	POWER SUPPLY, 24VDC, 2.5A	MICRON
40	1	1.5KE47CA	TVS DIODE, 1.5KW	LITTEL FUSE
39	1	KCA1036-1M.001	MOTOR ENCODER FEEDBACK CABLE, M23, 1M	KNIGHT GLOBAL
38	1	KCA1035-1M.001	MOTOR POWER / BRAKE CABLE, M23, 1M	KNIGHT GLOBAL
37	1	KSHA1005.001	KOLLMORGEN SERVO MOTOR	KNIGHT GLOBAL
36	1	2097-R2	SHUNT RESISTOR	ALLEN BRADLEY
35	1	KCA1034-STANDARD.001	SWISSBIT 16GB MICRO SD CARD	KNIGHT GLOBAL
34	1	KCA1037.001	SIEB & MEYER 3.8 KVA SERVO DRIVE	KNIGHT GLOBAL
33	4	3030174	JUMPER, 3 POLE	PHOENIX
32	6	0800886	TERMINAL ANCHOR	PHOENIX
31	2	3030488	END BARRIER	PHOENIX
30	15	3209549	TERMINAL	PHOENIX
29	1	3208977	LARGE END BARRIER	PHOENIX
28	2	3211771	LARGE TERMINAL	PHOENIX
27	1	0514500000-3 25	MOUNTING RAIL, DIN	WEIDMULLER
26	1	0514500000-6 5	MOUNTING RAIL, DIN	WEIDMULLER
25	1	KDSD1060.001	GROUND BAR ~ ALTER	KNIGHT GLOBAL
24	1	HL4579C	RECEPTACLE, 3P, 15A, 250V	HUBBELL
23	1	HL4570C	PLUG, 3P, 15A, 250V	HUBBELL
22	1	221203-8	POWER CABLE, 12/3 OLFLEX TRAY II, BLACK, 6 FT	LAPP
21	2	SPN-8	CABLE CLAMP, 1/2"	RICHCO
20	1	BL-75	LOCK NUT, 3/4"	APPLETON
19	1	STG-75	SEAL RING, 3/4"	APPLETON
18	1	CG-5075S	CORDGRIP, 3/4"	APPLETON
17	4	85985K18	5/8" ID LOCKING RIGID PLASTIC PLUG	MCMMASTER-CARR
16	4	FKFD 4.4-2	4 PIN RECEPTACLE, MICRO	TURCK
15	1	KCA1016.001	19 PIN WIRE HARNESS	ORRI
14	1	KDSD1053.001	TAP BACKER PLATE	KNIGHT GLOBAL
13	1	KDSD1044.001	SINGLE 19 PIN MOUNTING PLATE	KNIGHT GLOBAL
12	1	KDSD1043.001	RETAINER PLATE	KNIGHT GLOBAL
11	1	KDSD1010.002	COMPONENT MOUNTING BRACKET	KNIGHT GLOBAL
10	1	KDSD1046.002	CABLE CLAMP	KNIGHT GLOBAL
9	1	KDSD1008.002	SAFETY DROP STOP CHAIN GUIDE	KNIGHT GLOBAL
8	1	KDSA1000.001	REDUCER ASSEMBLY, 250 LB, 18" CHAIN	KNIGHT GLOBAL
7	1	KDSD1007.002	INNER SUPPORT PLATE, SMALL HOIST	KNIGHT GLOBAL
6	1	KDSD1006.001	ACCESS COVER, SMALL HOIST	KNIGHT GLOBAL
5	1	KDSD1002.003	BACK PLATE, SMALL HOIST	KNIGHT GLOBAL
4	2	KDSD1003.001	SIDE COVER, SMALL HOIST	KNIGHT GLOBAL
3	1	KDSD1005.002	TOP COVER, SMALL HOIST	KNIGHT GLOBAL
2	1	KDSD1000.001	FRONT PLATE, SMALL HOIST	KNIGHT GLOBAL
1	1	KDSD1004.003	BOTTOM COVER, SMALL HOIST	KNIGHT GLOBAL
DET	QTY	PART NUMBER	DESCRIPTION	MANUFACTURER

Figure 5

13. APPENDIX C: 350lb, 750lb and 1000lb SERVO INFORMATION

Knight includes a Recommended Spare Parts list and a set of electrical drawings with each system. Below is an example of a Recommended Spare Parts list (Figure 1) and standard system layouts (Figures 2 – 5) for a 350lb, 750lb or a 1000lb servo system.

350lb, 750lb and 1000lb STANDARD SERVO KNIGHT SERVO HOIST RECOMMENDED SPARE PARTS

PART NUMBER	DESCRIPTION	MANUFACTURER
KCA1040-xx.001	19P COIL CABLE, xxFT	KNIGHT GLOBAL
KCA1057-xx.001	POWER CABLE, 3C, 12AWG, SOOW, xxFT	KNIGHT GLOBAL
KSAA1003.001	CHAIN WEAR GAUGE	KNIGHT GLOBAL
A165ELS24D02	ILLUMINATED PB, RED, MUSHROOM, 24VDC	OMRON
A165LTGM24D2	ILLUMINATED PB, GREEN, 24VDC	OMRON
A165LTAM24D2	ILLUMINATED PB, BLUE, 24VDC	OMRON
KCA1037.001	SIEB & MEYER 3.8 KVA SERVO DRIVE	KNIGHT GLOBAL
KSHA1006.001	KOLLMORGEN SERVO MOTOR	KNIGHT GLOBAL
KCA1035-1M.001	MOTOR POWER / BRAKE CABLE, M23, 1M	KNIGHT GLOBAL
KCA1036-1M.001	MOTOR ENCODER FEEDBACK CABLE, M23, 1M	KNIGHT GLOBAL
MDP60-24A-1C	POWER SUPPLY, 24VDC, 2.5A	MICRON
440R-GL2S2T	SAFETY RELAY	ALLEN BRADLEY
2966171	SLICE RELAY, 24VDC, SPDT	PHOENIX
KSHD1017.001	GRAPHITE STICK	KNIGHT GLOBAL
KDSA1011.001	SDS CHAIN REPLACEMENT KIT, 5mm, 12FT	KNIGHT GLOBAL

350lb Servo Reducer Assembly

KDSA1001.001	REDUCER ASSEMBLY, 350 LB, 12' CHAIN	KNIGHT GLOBAL
--------------	-------------------------------------	---------------

750lb Servo Reducer Assembly

KDSA1003.001	REDUCER ASSEMBLY, 750 LB, 12' CHAIN	KNIGHT GLOBAL
--------------	-------------------------------------	---------------

1000lb Servo Reducer Assembly

KDSA1004.001	REDUCER ASSEMBLY, 1000 LB, 12' CHAIN	KNIGHT GLOBAL
--------------	--------------------------------------	---------------

Figure 1




Figure 2




Figure 3




Figure 4

69	4	M8	LOCK WASHER	COMMERCIAL
68	4	M8	WASHER	COMMERCIAL
67	4	M8 x 30mm LG.	SHCS	COMMERCIAL
66	18	M8	HEX KEPS NUT	COMMERCIAL
65	2	M8	NYLOK NUT	COMMERCIAL
64	4	M8	WASHER	COMMERCIAL
63	4	M8 x 50mm LG.	BHCS	COMMERCIAL
62	1	M8 x 25mm LG.	BHCS	COMMERCIAL
61	4	M8 x 20mm LG.	BHCS	COMMERCIAL
60	2	M8 x 16mm LG.	BHCS	COMMERCIAL
59	2	M8 x 14mm LG.	BHCS	COMMERCIAL
58	3	M8 x 12mm LG.	BHCS	COMMERCIAL
57	10	M4	NYLOK NUT	COMMERCIAL
56	8	M4 NOM.	FLAT WASHER	COMMERCIAL
55	8	M4 x 16mm LG.	BHCS	COMMERCIAL
54	2	M4 x 12mm LG.	BHCS	COMMERCIAL
53	4	M4 x 10mm LG.	BHCS	COMMERCIAL
52	20	#12 x 1/2 LG.	PAN HEAD PHILLIPS	COMMERCIAL
51	4	#4-40 x 3/8 LG.	SHCS	COMMERCIAL
50	4	94808A153	CLIP-ON NUT, 10-24	MCMMASTER-CARR
49	2	3960T4	SNAP HOOK	MCMMASTER-CARR
48	1	90312A371	LANYARD, 36"	MCMMASTER-CARR
47	-	-	-	-
46	-	-	-	-
45	1	2966171	SLICE RELAY, 24VDC, SPDT	PHOENIX
44	1	440R-GL2S2T	SAFETY RELAY	ALLEN BRADLEY
43	2	240-2079-ND	FERRITE SLEEVE	STEWART
42	1	490-8814-ND	CAPACITOR, 0.1uF	LITTELFUSE
41	1	MDP00-24A-1C	POWER SUPPLY, 24VDC, 2.5A	MICRON
40	1	1.5KE47CA	TVS DIODE, 1.5KW	LITTELFUSE
39	1	KCA1036-1M.001	MOTOR ENCODER FEEDBACK CABLE, M23, 1M	KNIGHT GLOBAL
38	1	KCA1035-1M.001	MOTOR POWER / BRAKE CABLE, M23, 1M	KNIGHT GLOBAL
37	1	KSHA1006.001	KOLLMORGEN SERVO MOTOR	KNIGHT GLOBAL
36	1	2097-R2	SHUNT RESISTOR	ALLEN BRADLEY
35	1	KCA1034-STANDARD.001	SWISSBIT 16GB MICRO SD CARD	KNIGHT GLOBAL
34	1	KCA1037.001	SIEB & MEYER 3.8 KVA SERVO DRIVE	KNIGHT GLOBAL
33	4	3030174	JUMPER, 3 POLE	PHOENIX
32	6	0800886	TERMINAL ANCHOR	PHOENIX
31	2	3030488	END BARRIER	PHOENIX
30	15	3209549	TERMINAL	PHOENIX
29	1	3208977	LARGE END BARRIER	PHOENIX
28	2	3211771	LARGE TERMINAL	PHOENIX
27	1	0514500000-3.25	MOUNTING RAIL, DIN	WEIDMULLER
26	1	0514500000-6.5	MOUNTING RAIL, DIN	WEIDMULLER
25	1	KDSD1060.001	GROUND BAR ~ ALTER	KNIGHT GLOBAL
24	1	HLB2323	RECEPTACLE, 3P, 20A, 250V	HUBBELL
23	1	HLB2321	PLUG, 3P, 20A, 250V	HUBBELL
22	1	221203-6	POWER CABLE, 12/3 OLFLEX TRAY II, BLACK, 6 FT	LAPP
21	2	SPN-8	CABLE CLAMP, 1/2"	RICHO
20	1	BL-75	LOCK NUT, 3/4"	APPLETON
19	1	STG-75	SEAL RING, 3/4"	APPLETON
18	1	CG-5075S	CORDGRIP, 3/4"	APPLETON
17	4	85985K18	5/8" ID LOCKING RIGID PLASTIC PLUG	MCMMASTER-CARR
16	4	FKFD 44-2	4 PIN RECEPTACLE, MICRO	TURCK
15	1	KCA1016.001	19 PIN WIRE HARNESS	ORRI
14	1	KDSD1053.001	TAP BACKER PLATE	KNIGHT GLOBAL
13	1	KDSD1044.001	SINGLE 19 PIN MOUNTING PLATE	KNIGHT GLOBAL
12	1	KDSD1043.001	RETAINER PLATE	KNIGHT GLOBAL
11	1	KDSD1010.002	COMPONENT MOUNTING BRACKET	KNIGHT GLOBAL
10	1	KDSD1046.002	CABLE CLAMP	KNIGHT GLOBAL
9	1	KDSD1008.002	SAFETY DROP STOP CHAIN GUIDE	KNIGHT GLOBAL
8	1	KDSA1004.001	REDUCER ASSEMBLY, 1000LB, 12' CHAIN	KNIGHT GLOBAL
7	1	KDSD1037.002	INNER SUPPORT PLATE, LARGE HOIST	KNIGHT GLOBAL
6	1	KDSD1057.001	ACCESS COVER, LARGE HOIST	KNIGHT GLOBAL
5	1	KDSD1040.003	BACK PLATE, LARGE HOIST	KNIGHT GLOBAL
4	2	KDSD1042.001	SIDE COVER, LARGE HOIST	KNIGHT GLOBAL
3	1	KDSD1038.001	TOP COVER, LARGE HOIST	KNIGHT GLOBAL
2	1	KDSD1041.001	FRONT PLATE, LARGE HOIST	KNIGHT GLOBAL
1	1	KDSD1039.002	BOTTOM COVER, LARGE HOIST	KNIGHT GLOBAL
DET	QTY	PART NUMBER	DESCRIPTION	MANUFACTURER

Figure 5



KNIGHT

GLOBAL

KNIGHT GLOBAL
2705 Commerce Parkway
Auburn Hills, MI 48326
Phone 248-377-4950 | Fax 248-377-2135

For additional copies of the literature contact: salesorders@knightglobal.com
For technical questions contact: servos@knightglobal.com
For service-related requests contact: service@knightglobal.com

www.knightglobal.com